Signal	targets for STW1 in Interface Mode SINAMIC	CS (p2038 = 0)					<1>	PROFIdrive Refer to	sampling time
Signal	Meaning	. ,	Interconnection parameters	[Function diagram] internal control word	[Function signal		Inverted	T CO CO	5[1020.7]
STW1.0	ON (pulses can be enabled)  0 = OFF1 (braking with ramp-function generator, then pulse cancellation)	es can be enabled) braking with ramp-function generator, then pulse cancellation and ready-to-power-up)		[2501.3]	[2610]		-		
STW1.1	No OFF2 (enable is possible) - OFF2 (immediate pulse cancellation and power-on inhibit)		p0844[0] = r2090.1	[2501.3]	[2610]		-		
STW1.2	1 = No OFF3 (enable possible) 0 = OFF3 (braking with the OFF3 ramp p1135, then pulse cancellation a	e cancellation and power-on inhibit)		[2501.3]	[2610]		-		
STW1.3	1 = Enable operation (pulses can be enabled) 0 = Inhibit operation (cancel pulses)  1 = Operating condition (the ramp-function generator can be enabled) 0 = inhibit ramp-function generator (set the ramp-function generator output to zero)  1 = Enable the ramp-function generator 0 = stop the ramp-function generator (freeze the ramp-function generator output)		p0852[0] = r2090.3	[2501.3] [2610] [2501.3] [3060] [3070] [3080]		10]	-		
STW1.4			p1140[0] = r2090.4			-			
STW1.5			p1141[0] = r2090.5	[2501.3]	[3060] [3070]		-		
STW1.6	1 = Enable setpoint 0 = inhibit setpoint (set the ramp-function generator input to zero)	or input to zero)		[2501.3]	[3060] [30	[3060] [3070] [3080]			
STW1.7	= Acknowledge faults		p2103[0] = r2090.7	[2546.1]	[8060]		-		
STW1.8	Reserved  Reserved  1 = Control via PLC <2>		-	-		-	-		
STW1.9					-		-		
STW1.10			p0854[0] = r2090.10	[2501.3]	[25	01]	-		
STW1.11	1 = Dir of rot reversal <3>		p1113[0] = r2090.11	[2505.3]	[3040]				
STW1.12	Reserved		-	-	-		-		
STW1.13	1 = Motorized potentiometer, setpoint, raise <3>		p1035[0] = r2090.13	[2505.3]	5.3] [3020]		-		
STW1.14	1 = Motorized potentiometer, setpoint, lower <3>		p1036[0] = r2090.14	[2505.3]	[3020]		-		
STW1.15			-	-			-		
	grams 1, 2, 3, 4, 5, 6, 7, 110, 352. be set in the first PZD word of the telegram received from PROFIBUS in o	order to ensure that the driv	ve accepts the process	data. <3> Only for "ex	cpanded setp	oint channe	el" and "exte	nded ramp-funct	ion generat
1	2 3	4	5	6	6		7		8
: SERVO, VECTOR				fp_2442_01_	2442_01_eng.vsd Functio		tion diagram		- 2442
OFIdrive - STW1 control word interconnection (p2038 = 0)				14.07.06 V0	14.07.06 V02.05.00 SINAMI			AMICS S	