

10-4D

GEI-9321G

FILE

INSTRUCTIONS

FILE COPY

AIR CIRCUIT BREAKER

TYPES

AE-1-25, AEF-1, and AE-1-25Y1

Formerly Types AE-1B, AEF-1B, and AE-1BY1

RAU

King Plant 2
Switchgear

GENERAL  ELECTRIC
SCHENECTADY, N.Y.

୧୫

	<u>Page</u>
FIG. 1 Manually Operated Live Front Breaker.....	1
FIG. 2 Electrically Operated Dead Front Breaker.....	1
FIG. 3 Manually Operated, Enclosed Breaker.....	1
FIG. 4 Removing Breaker from Enclosed Case.....	1
FIG. 5 Mounting Terminals and Solderless Connectors in Enclosed Case.....	1
FIG. 6 Instructions for Removal from Temporary Base.....	3
FIG. 7 Left Side View of Pole Unit.....	5
FIG. 8 Contact Assembly.....	7
FIG. 9 Manually Operated Mechanism.....	9
FIG. 10A Operating Positions of Operating Mechanism.....	10
10B " " " " " ".....	11
10C " " " " " ".....	12
FIG. 11 Adjustment Eccentrics for Trip Arm and Latch.....	12
FIG. 12 Electrically Operated Mechanism.....	13
FIG. 13 Manual Closing of Electrically Operated Breaker.....	14
FIG. 14 Closing Relay.....	14
FIG. 15 Rotary Type Auxiliary Switch.....	15
FIG. 16 Operating Switch.....	16
FIG. 17 Cut-off Device.....	18
FIG. 18 Dual Magnetic Overcurrent Trip Device(Oil-Film Type).....	18
FIG. 19 Approximate Time-Current Characteristics of Dual Magnetic Overcurrent Trip Device(Oil-Film Type).....	19
FIG. 20 Thermal Magnetic Overcurrent Trip Device(External View).....	20
FIG. 21 Approximate Time-Current Characteristics of Thermal Magnetic Overcurrent Trip Device.....	21
FIG. 22 Thermal Magnetic Overcurrent Trip Device.....	22
FIG. 23 Magnetic Instantaneous Overcurrent Trip Device.....	23
FIG. 24 Instantaneous Short Circuit Trip Device.....	23
FIG. 25A Instantaneous Undervoltage Trip Device.....	26
25B Time Delay Undervoltage Trip Device.....	26
FIG. 26 Reverse Current Trip Device, Rotor Type.....	28
FIG. 27 Diagrammatic Magnetic Circuits of Reversed Current Trip Device(Hinged Armature Type).....	29
FIG. 28 Reverse Current Trip Device(Hinged Armature Type).....	30
FIG. 29 Shunt Trip Device.....	31
FIG. 30 Bell Alarm Device.....	32
FIG. 31 Safety Interlock for Enclosed Breakers.....	33
FIG. 32 Disconnects for Enclosed Breakers.....	33
FIG. 33 Manual Operating Handle Assembly for Switchboard Front Plates.....	34
FIG. 34 Electrically Operated Type AEF-1 Field Switch (Live Front).....	35
FIG. 35 Field Discharge Switch.....	36
FIG. 36 Current and Duty Cycle Limits of Type AE-1-25 Y1 Breaker.....	37
FIG. 37 Schematic Wiring Diagram, Momentary Contact Control Switch.....	38
FIG. 38 Schematic Wiring Diagram, Maintained Contact Control Switch.....	38
FIG. 39 Typical Wiring Diagram, Momentary Contact Control Switch.....	38
FIG. 40 Typical Wiring Diagram, Maintained Contact Control Switch.....	38

CONTENTS

GENERAL INFORMATION

Application.....	
Ratings.....	
Operating Characteristics.....	

SHIPPING-UNPACKING-STORAGE

Transportation Damages.....	
Unpacking.....	
Storage.....	

INSTALLATION

Location.....	
Breaker Connections.....	
Dead Front Breakers.....	
Enclosed Breakers.....	
Temporary Breaker Mounting.....	

OPERATION AND MAINTENANCE

Operation.....	
Maintenance.....	

DESCRIPTION OF COMPONENTS AND ATTACHMENTS

Contact Assembly.....	
Arc Quenchers and Barriers.....	
Manual Operating Mechanism.....	
Solenoid Operating Mechanism.....	
Closing Relay.....	
Rotary Type Auxiliary Switch.....	
Operating Switch.....	
Cut-off Device.....	
Dual Magnetic Overcurrent Trip Device(Oil-film Type).....	
Thermal Magnetic Overcurrent Trip Device.....	
Magnetic Instantaneous Overcurrent Trip Device.....	
Instantaneous Short-Circuit Trip Device.....	
Instantaneous Undervoltage Trip Device.....	
Time Delay Undervoltage Trip Device.....	
Reverse Current Trip Device, Rotor Type.....	
Reverse Current Trip Device, Hinged Armature Type.....	
Shunt Trip Device.....	
Bell Alarm Device.....	
Safety Interlock for Enclosed Breakers.....	
Disconnects for Enclosed Breakers.....	
Manual Operating Handle Assembly for Switchboard Front Plates.....	

TYPE AEF-I FIELD SWITCH

Field Discharge Switch.....	
-----------------------------	--

TYPE AE-I-25YI AIR CIRCUIT BREAKER.....

WIRING DIAGRAMS.....	
----------------------	--

SPARE PARTS.....	
------------------	--




FIG. 1
MANUALLY OPERATED LIVE FRONT BREAKER.




FIG. 2
ELECTRICALLY OPERATED DEAD FRONT BREAKER.






FIG. 3
MANUALLY OPERATED, ENCLOSED BREAKER.



Th
ill d
from
net i
r m
e de
which
hase
rrred

pe
ich

g to
ad u
refu

PLIQ

R
ere
used
ctrl
cuit
ustr
ine;
lpper
p de
othe

For
ie br
3600

NGS

Cur

Volt

Int

22

.TING

Type
R 11
lly
thre
sork
uenc
ontar
led
cor

the
peral

AIR CIRCUIT BREAKERS

TYPES AE-1-25, AEF-1, AE-1-25Y1

These instructions do not purport to cover all details or variations in equipment nor to provide for every possible contingency to be met in connection with installation, operation or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the General Electric Company.

GENERAL INFORMATION

These breakers were formerly designated Type AE-1B, Type AEF-1B and Type AE-1-BY1 to which these instructions generally apply.

Before unpacking, installing or attempting to operate these air circuit breakers, read this instruction book thoroughly and carefully.

APPLICATION

The type AE-1-25 air circuit breakers covered by this instruction book are generally used for the protection and control of electrical apparatus, main feeders and branch circuits, including equipment in buildings, industries and power stations, and merchant marine application. The breakers may be equipped with a wide choice of operating and trip devices and accessories for overcurrent and other functions.

Further discussion and application of these breakers will be found in publication GET-3600.

RATINGS

- Current Ratings:-
Up to and including 600 amperes.
Voltage Ratings:-
Up to and including 600 volts A-c.
Up to and including 250 volts D-c.
Interrupting Ratings:-
25,000 amperes.

OPERATING CHARACTERISTICS

Type AE-1-25 breakers can be furnished either live front or dead front, and either manually or electrically operated with one, two, three or four poles and with various accessories. All breakers are provided with arc quenchers to extinguish the arc after the contacts open and box type barriers are provided for dead front and enclosed breakers to confine the arc.

The breaker is closed by a toggle mechanism operated either manually, or electrically

by a solenoid, against a heavy spring between the operating mechanism and the operating shaft, upon which the movable contacts are mounted, and against springs behind the contacts. These springs supply the power to open the breaker when a latch is released manually or by tripping devices. The breaker is trip free which assures that the contacts cannot be closed as long as the latch is in the tripped position.

Current enters the breaker by the upper stud, passes through the stationary contacts, the movable contacts, the flexible connection, through the series coil and out the lower stud. When the breaker opens, the main contacts separate first which shunts the current to the arcing contacts to prevent burning of the main silver contacts as described under "Contact Assembly". When these open the current is again shunted to arc runners in series with a blowout coil which magnetically blows the arc upwards among the cooling pins and arc barriers, as described under "Arc Quenchers and Barriers", to quickly open the circuit.

SHIPPING-UNPACKING-STORAGE

TRANSPORTATION DAMAGE


Immediately upon receipt of the breakers, an examination should be made for any damage or loss sustained during transportation. If injury, rough handling, or loss is evident a damage claim should be filed at once with the transportation company and the nearest General Electric Sales Office should be promptly notified.

UNPACKING

The breakers should be unpacked as soon as possible after being received as difficulty may be experienced in making claim for damage, not evident upon receipt, if delayed. Care should be used in unpacking in order to avoid damaging any of the breaker parts. Be sure that no loose parts are missing or left in the packing material. Blow out any dirt or particles of packing material that may be accumulated on the breaker parts.

STORAGE

If the breakers are not to be mounted in their permanent locations at once, they should be stored in a clean dry place and preferably in a vertical position. They should be supported to prevent bending of studs, or damage to breaker parts. It is best not to cover the breakers with any packing material or other material that is apt to absorb moisture which may cause corrosion of breaker parts. A covering of paper will prevent dust from settling on the breaker parts and should be used if the breakers are to be stored for any considerable length of time.



"I" (SEE FIG. 10) REMOVE COMPRESSION SPRING (PT. 25) BY PRESSING SPRING GUIDE (PT. 24) TO REAR AND REMOVE IT FROM CAM (PT. 22) AND CRANK (PT. 27). REMOVE PIN FROM CRANK.

"J" (SEE FIG. 10) REMOVE OPERATING MECHANISM AS A UNIT BY REMOVING SCREWS FROM REAR OF BASE.

NOTE:— OTHER DEVICES SHOULD BE REMOVED AS UNITS WITHOUT DISTURBING ADJUSTMENTS OR CALIBRATIONS.

INSTALL THE ABOVE PARTS AND DEVICES ON PERMANENT BASE IN THE REVERSE ORDER.

FIG. 6
REMOVAL OF BREAKER FROM TEMPORARY BASE

INSTALLATION

LOCATION

The AE-1-25 breaker should be installed in a clean, dry place where it is readily accessible for convenient operation, inspection and maintenance. When mounted on a live front switchboard it should preferably be located at the top of the panel. Space of at least 8" should be allowed above arc quenchers if no barriers are provided.

Most breakers are shipped on permanent bases, or panel sections, with or without enclosures, and the mounting consists of simply bolting the bases to the supporting framework or structure.

Silver contacts, described under "Contact Assembly" should be checked as follows before the breaker is put in operation:-

1. Wipe off any dust which may have collected on the contact surfaces with a clean cloth.
2. Clean the contacts with a good grade of silver polish or very fine sandpaper to remove any dark surface film so that the contacts are clean and bright. If silver polish is used, be careful to remove all polish from the contacts or insulated parts, after cleaning. If sandpaper is used, care must be exercised to maintain line contact.
3. Take contact impressions as described under "Contact Assembly" to determine if proper line contact is being maintained. If necessary, improve the contacts as described under "Maintenance".

BREAKER CONNECTIONS

Before connecting current-carrying bus bars or cables or secondary control wiring, every precaution must be taken to be sure that all leads to be connected to the breaker are de-energized.

The connections to the breaker studs should be clean, flat and free from burrs to assure full contact area and firmly clamped or bolted in place to prevent excessive heating. In enclosed breakers the cables should be clean and of ample size to assure full contact surface when attached by the swivelled clamping screw in the solderless connectors. The connecting bus bars or cables should have adequate current-carrying capacity, otherwise, heat will be conducted from them to the breaker which could not be expected to carry normal current without exceeding the specified temperature rise. Connecting cables or bus bars should be supported so that the breaker studs will not be subjected to unnecessary strains.

DEAD FRONT BREAKERS

Breakers equipped with dead front barriers, Fig. 2, can be installed on framework or elsewhere without removing the barriers.

ENCLOSED BREAKERS

The enclosed breakers, Fig. 3, can easily be installed by first removing the cover and the two top mounting bolts in the breaker base, Fig. 4. Tilt the breaker unit forward to disengage disconnects and for removal. Next, mount the box in the desired location and secure the cables in the solderless connectors in the box, (Fig. 5). Finally, return the removable breaker unit to the box, and replace the two upper mounting bolts and the cover to complete the installation.

WHILE INSTALLING, OR BEFORE REMOVING THE BREAKER, IT IS IMPORTANT THAT IT SHOULD BE IN THE OPEN POSITION.

TEMPORARY BREAKER MOUNTING

It is always preferable to have an air circuit breaker shipped on a permanent base or panel section. Remounting of a breaker by persons not entirely familiar with its detailed construction may result in misalignment or improper adjustment with resultant unsatisfactory operation. Temporary bases will not be supplied when reverse current trip devices are involved.

For those cases where it is found necessary to transfer a breaker from a temporary base to a permanent base or panel, first make sure that the permanent base or panel is properly drilled in accordance with an approved drilling plan furnished by the General Electric Company for the particular breaker. In transferring the breaker, it should not be dismantled any more than is necessary to affect the transfer. Sub-assemblies, such as overcurrent devices, the operating mechanism, etc. should be transferred as units. This will help maintain adjustments and will minimize the possibility of incorrect assembly. A recommended sequence of procedure for transferring an AE-1-25 air circuit breaker is given in Fig. 6. It is suggested that this procedure be followed in the order in which the operations are alphabetically arranged. Reinstall parts and devices on the permanent breaker base in the reverse order. It is important that the main shaft and crank (Pt. 27, Fig. 10) should move freely in bearings and clear of cam (Pt. 22, Fig. 10) before spring (Pt. 25, Fig. 10) is installed. After the transfer has been completed and the operating mechanism, main and trip shafts are working freely, the alignment of the contacts and operation of all parts should be checked as described under "Operation" and "Contact Assembly".




FIG. 7

OPERATION AND MAINTENANCE

OPERATION

After the breaker has been installed, slowly operate it manually several times (as described below) and observe whether the contacts line up properly and make sure that all parts move freely in a proper manner without binding or excessive friction. See that the breaker latches securely and trips freely. If the breaker is equipped with an under-voltage device the breaker cannot be latched unless normal potential is applied to its coil, or the plunger is forced into the coil.

Manually operated AE-1-25 breakers, covered in these instructions, are closed by first turning the operating handle in the counter-clockwise direction from the normal position of "handle down" to a position of "handle up" to reset the operating mechanism latch, and then turning the handle in a clockwise direction to position of "handle down" to close the breaker (as described under "Operating Mechanism"). DO NOT ATTEMPT TO OPEN THE BREAKER BY COUNTER-CLOCKWISE ROTATION OF THE OPERATING HANDLE. The breaker is opened by pushing on the trip button to release the trip latch. The handle remains in the "down" position after tripping.

Electrically operated AE-1-25 breakers, covered in these instructions, may be closed manually by inserting a maintenance closing handle between the armature and the left side frame and under the pin which connects the armature to the operating mechanism, (as described under "Solenoid Operating Mechanism"). The breaker is likewise opened by pushing on the trip button to release the trip latch, and not by the maintenance closing handle.

The electrically operated breaker is automatically reset by the falling of the armature when the breaker is tripped, but not if the maintenance closing handle is in place. Therefore, if the breaker has been closed by the maintenance closing handle, be sure to remove it before attempting to trip the breaker.

After checking the operation manually, as above, an electrically-operated breaker should be operated electrically at rated voltage a few times to make sure that all control circuits are properly connected and the closing solenoid, closing relay and other control attachments are functioning properly. Bear in mind that the solenoid is rated for intermittent service. Reasonable care should be exercised when testing to avoid overheating of the solenoid by repeated operations.

MAINTENANCE

Periodic inspection of the breaker is recommended at least once a year, or more

exist. An inspection of the contacts and arc quenchers should always be made after it is known that the breaker has opened a severe short circuit. If the breaker remains open or closed for a long period of time, it is recommended that arrangements be made to open and close it several times in succession, clean and lubricate, where necessary, to keep the contacts and moving parts in good working condition.

Before inspecting or repairing, make sure that the breaker and accessories are disconnected from all electric power, both primary and control voltages.

If overheating, not caused by overcurrent, is observed, look for loose connections, or damaged contacts or flexible connections.


Periodic maintenance of contacts should include the following:

1. Wipe off dust and clean the contacts as described under "Installation".
2. Take contact impressions, as described under "Contact Assembly", and improve the contacts if necessary. Remove high or rough spots with a fine clean file or very fine sandpaper. Do not use emery or crocus cloth. Small pittings need not be removed if 75% of line contact can be obtained.

In general, the breaker mechanism requires very little lubrication which should be applied sparingly. Any excess amount of oil on the breaker parts is apt to collect dust and dirt and is to be avoided. A general recommendation for lubrication of an air circuit breaker mechanism is to occasionally use a few drops of a good grade of light machine oil at bearing points and wipe off any excess with a clean cloth. Latch surfaces should be kept smooth and clean with crocus cloth. They should be lightly greased and the excess removed with a clean cloth.

If the breaker is equipped with a type of oil-film time delay trip devices make sure that, when the breaker is installed, the oil pots of these devices are thoroughly cleaned and filled with oil to the proper level as marked on the pots. It is important that these oil pots be kept clean and properly filled with fresh oil to the proper level at regular inspection periods at least every six months, and more frequently if service is severe. A small can of oil for use in these pots is furnished with each breaker. Additional oil, per General Electric Company specifications DGB7A1, can be obtained from the factory. When cleaning the oil pots, use kerosene or naphtha only, and wipe dry with a clean cloth. Other cleaning fluids may act as a solvent of the material of which the pot is made.

At all times it is important not to



1. SCREW R.H. $\frac{1}{8}$ "-18 WITH LOCKWASHER
2. CORE OF BLOWOUT COIL
3. INSULATION
4. BLOWOUT COIL
5. SCREW R.H. $\frac{1}{8}$ "-32 WITH WASHER AND LOCKWASHER
6. UPPER STUD AND SILVER CONTACT
7. SCREW R.H. $\frac{1}{8}$ "-20 WITH LOCKWASHER AND NUT
8. BRACKET
9. SCREW HEX. HD. $\frac{1}{4}$ "-20 WITH LOCKWASHER
10. SPRING GUIDE

11. PIN IN CONTACT SUPPORT
12. COMPRESSION SPRING
13. CONTACT SUPPORT
14. MAIN SHAFT
15. CLAMP
16. SCREW HEX. HD. $\frac{1}{4}$ "-20 X $\frac{3}{8}$ " WITH LOCKWASHER
17. TERMINAL OF SERIES COIL OR LOWER STUD
18. SCREW R.H. $\frac{1}{8}$ "-20 WITH WASHER, LOCKWASHER AND NUT
19. MAIN FLEXIBLE CONNECTION
20. FLEXIBLE CONNECTION

21. SCREW HEX. HD. $\frac{1}{8}$ "-18 X $\frac{3}{8}$ " WITH WASHER AND LOCKWASHER
22. PIN IN CONTACT SUPPORT AND CUTTER PINS
23. ADJUSTING SCREW R.H. $\frac{1}{8}$ "-18 X $1\frac{1}{2}$ " WITH WASHER, LOCKWASHER AND NUT
24. MOVABLE CONTACT AND SILVER CONTACT
25. SCREW R.H. $\frac{1}{8}$ "-40 X $\frac{1}{2}$ " WITH LOCKWASHER
26. SCREW R.H. $\frac{1}{8}$ "-40 X $\frac{1}{2}$ " WITH LOCKWASHER
27. MOVABLE ARCING CONTACT
28. STATIONARY ARCING CONTACT
29. INSULATION
30. STATIONARY ARC RUNNER, WELDED TO PC6

FIG. 8
CONTACT ASSEMBLY

of different degrees of conductivity to short circuit insulation strips or barriers between surfaces of different potential on breaker parts or attachments. Even oil on such insulation surfaces may accumulate dirt to allow leakage of current.

Further discussion of maintenance inspection and trouble-shooting will be found in "How to Maintain Air Circuit Breakers", GET-1165.

DESCRIPTION OF COMPONENTS AND ATTACHMENTS

Although, under this heading, the adjustable features of the air circuit breaker and its attachments are given, it should be understood that the breaker has already been adjusted, tested and inspected at the factory in accordance with the information given herein. However, it is possible that unusual rough handling, transportation, and operating conditions may have resulted in some loosening or disturbance of the equipment to warrant re-checking and, in some cases, readjustment may be necessary.

CONTACT ASSEMBLY

Current is carried through the breaker by solid copper studs, stationary and movable contacts, and flexible connections, as shown in detail in Fig. 8, (see also Fig. 7). The stationary contact assembly consists of an upper stud (Pt. 6) with a brazed silver contact, blowout coil (Pt. 4) and stationary arc runner (Pt. 30), riveted and silver soldered together as one unit and attached to the mounting base by bracket (Pt. 8) and screws (Pts. 1 and 5). A sheet of insulation (Pt. 29) separates the blowout coil and the arcing horn. The main silver contact strip is silver soldered to the front of the upper stud. The removable stationary arcing contact (Pt. 28) with silver alloy contacts is attached to arc runner by screws (Pt. 25).

The movable contact assembly consists of a movable contact (Pt. 24) pivoted to a contact support (Pt. 13) by pin (Pt. 22) and the contact support is rigidly attached to the square main shaft (Pt. 14) by clamp (Pt. 15). The square shaft is covered throughout its length with heavy insulating material and extends through the movable contact assembly of each pole and is connected to the operating mechanism by crank (Pt. 27 Fig. 10). A main silver contact strip is silver soldered to the movable contact. The removable arcing contact (Pt. 27), with silver alloy inserts, is attached to it by screws (Pt. 26). The flexible connection (Pt. 19) is attached to the movable contact by screws (Pt. 21 and 23) and to the upper end of the series coil, or lower stud, by screw (Pt. 18). Compression spring, (Pt. 12), mounted over guide (Pt. 10) and backed up by pin (Pt. 11) in the contact support, causes the movable contact to revolve about pin (Pt. 22) in the contact support to maintain pressure between the main contacts, when the breaker is closed.

In closing, the arcing contacts close before the main contacts close, and, as the contact support (Pt. 13) is drawn further to the rear, the movable contact (Pt. 24) revolves over the main contacts as a fulcrum to draw the arcing contacts apart. Screw (Pt. 23) must be adjusted to cause a gap of .020" to .040" between the arcing contacts when the breaker is latched closed.

Compression spring (Pt. 12) should be set to require a pull of 19 to 24 pounds, applied at the movable arcing contact, to open the main contacts. The arcing contacts should be separated by 3/4" to 1" when the breaker is open. When the arcing contacts just touch, the main contacts should be between 1/16 to 3/16" apart.

— As the breaker opens, the arcing contacts close again and remain closed until after the main contacts open. Thus, when the main contacts open the breaker current is shunted to the arcing contacts to prevent burning of the silver contacts. When the movable arcing contact (Pt. 27) passes under the front arc runner (Pt. 26 Fig. 7) of the arc quencher, the breaker current is again shunted over flexible connection (Pt. 20) to the arc runner, and the arc is transferred to the front and rear arc runners and among the pins of the arc quencher. A magnetic field is set up by the shunted current through the blowout coil (Pt. 4) which quickly opens the circuit as described under "Arc Quenchers".

The breaker is equipped with fine silver high pressure line type main contacts, silver soldered to the upper stud (Pt. 6) and the movable contact (Pt. 24). The surfaces of these contacts have been coated with wax at the factory to prevent the formation of surface film. The wax will not interfere with operation as it will volatilize at normal operating temperatures of the breaker.

To maintain line contact in the AE-1-25 breaker the silver inserts on the movable contact are machined flat but those on the upper studs are slightly curved. It is important for proper breaker operation that adequate line contact be maintained which can be checked as follows:-- Hold between the contacts a piece of thin carbon paper with tissue paper on the carbon side. Close and open the breaker and examine the impression on the paper. Good contact is indicated if a well-defined impression shows for 75% or more of the length of the contact. Good contact is also indicated if a .002" feeler gauge cannot be inserted between the contacts for more than 25% of the length of the contact. Should poor contact be found, it will be necessary to improve the contacts as described under "Maintenance". The curved surface should be maintained on the stationary contact so that the line contact will not be too broad.

ARC QUENCHERS AND BARRIERS


An arc quencher is provided for each pole of AE-1-25 breakers to quickly extinguish the arc after the contacts open. Each arc quencher, Fig. 7, consists of a large number of small solid pins (Pts. 32 and 33) supported between molded compound side plates (Pt. 23) which are placed vertically on both sides of each set of contacts. The pins are copper except those in the two lower rows which are of a metal that has a higher melting point than copper. Baffles (Pt. 31) of molded compound are placed between the side plates above and in front of the pins. An arc runner (Pt. 26) is mounted on an insulation block (Pt. 30) between the side plates and in front of the pins. To this runner is connected a flexible shunt connection (Pt. 22) after the arc quencher is in place. Pole piece plates (Pt. 35) are placed on the outside of the side plates and act with the blowout coil with a slotted steel core (Pt. 6) of the stationary contact to provide a magnetic path to blow the arc upwards on the arc runners and among the pins and baffles when the breaker current is shunted from the contacts as described under "Contact Assembly". The steel core, enclosed in insulation, is inserted in the coil when the arc quencher is installed. As the arc travels up the arc runners and through the pins and baffles it is lengthened and cooled which quickly opens the circuit. Each arc quencher is attached to the mounting base by a screw (Pt. 2) which passes through


a mounting support (Pt. 1) in the upper part of the arc quencher and which engages a locking plate (Pt. 3) mounted on the rear of the mounting base.

For dead front and enclosed AE-1-25 breakers a box type barrier of molded compound is provided to fit over the top, sides and front of all arc quenchers to confine the arcs. Barriers are provided to isolate each pole unit. The front is attached by nuts and can be removed for inspection of arc quenchers. The barrier rests on a horizontal strip above the arc quenchers and is attached to the circuit breaker base by two long bolts with front nuts shown in Fig. 2.


MANUAL OPERATING MECHANISM

The manually operated mechanism of the AE-1-25 breaker is operated by revolving a pistol grip handle (Pt. 23) located at the front of the mechanism, as shown in Fig. 10. The normal position of the handle is "down" and in order to close the manually operated breaker, it must be turned counter-clockwise approximately 180° to the "reset" position which resets the latch (Pt. 12), and then must be turned clockwise to the "down" position, to close the breaker. The mechanism is tripped by pushing on a trip button in the bottom front part of the side frame of the mechanism, or by any tripping device which revolves the trip shaft (Pt. 18) in a counter-clockwise direction (looking from





(VIEW FROM LEFT SIDE)



(VIEW FROM RIGHT SIDE)

FIG. 10A

TRIPPED POSITION

left) to release the latch (Pt. 12). When tripped manually or by any tripping device, the handle remains in the "down" position. Therefore, to reclose the breaker, the handle must first be turned counter-clockwise to the "reset" position and then clockwise to the "down" position as described above.

The operating mechanism, Fig. 10, of the manually operated breaker consists of a group of toggles, links, levers and a latch attached to the frame by fixed pins (Pt. 9, 10, 13 and 21). The insulation covered main shaft (Pt. 29) the trip shaft (Pt. 18) and the handle shaft also have fixed bearings in the frame. All parts move otherwise on floating pins. The mechanism operates a cam assembly (Pt. 22) to close the breaker and places springs (Pt. 25) of the mechanism and springs (Pt. 12, Fig. 8) of the movable contact assembly under compression. Tripping, by any means, releases the latch (Pt. 12) to allow these springs to extend which supplies the power to open the breaker and hold the contacts apart after tripping.

A torsion spring (Pt. 11) around pin (Pt. 10) applies force to the latch (Pt. 12) in the clockwise direction to reset the latch. The spring (Pt. 14) jointly holds prop (Pt. 15) in the vertical position and trip arm (Pt. 20) in the normal position.

In a cycle of manual operation, the mechanism parts take three positions as follows:-

TRIPPED POSITION - In the tripped position Fig. 10A, the latch (Pt. 12) of the toggle mechanism is in the vertical position and is free of the latch plate (Pt. 17) which is attached to the trip shaft (Pt. 18). The

handle is down. Other parts assume positions as shown.

RESET POSITION - When the manual handle (Pt. 23) is turned counter-clockwise to the "reset" position with handle up, Fig. 10B, the eccentric (Pt. 1) on the handle shaft lowers link (Pt. 2), block (Pt. 4) and a pair of closing links (Pt. 6), collapsing toggle links (Pt. 8A and 8B) causing the latch (Pt. 12) to revolve about its fixed pin (Pt. 10) in frame and engage the latch plate (Pt. 17).

CLOSED POSITION - When the manual handle (Pt. 23) is turned clockwise from the "reset" position to the "closed" or "down" position Fig. 10-C, the closing links are raised to the vertical position, extending toggle links (Pt. 8A and 8B) which forces the cam (Pt. 22) forward, because the pin in the rear end of toggle link (Pt. 8D) is held fixed by latch (Pt. 12) which is engaged on latch plate (Pt. 17). The cam raises the operating crank (Pt. 27) which turns the main shaft (Pt. 29) to the closed position to close the contacts. At the same time a torsion spring around pin (Pt. 13) draws prop (Pt. 15) under closing links (Pt. 6) to prevent opening of the breaker by counterclockwise rotation of the manual handle.

The type AE-1-25 breaker is trip free because the toggle links (Pt. 8A and 8B) cannot be extended to move the cam (Pt. 22) forward as long as the trip shaft (Pt. 18) is held in the tripped position by any device. This prevents the latch (Pt. 12) from being held by the latch plate (Pt. 17) as shown in Fig. 10B, and even if an attempt is made to close the breaker, the latch simply returns to the tripped position of Fig. 10A, without moving the cam (Pt. 22) forward.




FIG. 10B
RESET POSITION

- | | | |
|--------------------------|---------------------------|-----------------------------------------|
| 1. ECCENTRIC SHAFT | 11. TORSION SPRING | 21. PIN IN FRAME |
| 2. LINK | 12. LATCH | 22. CAM |
| 3. GUIDE WELDED TO BLOCK | 13. PIN IN FRAME | 23. MANUAL CLOSING HANDLE |
| 4. BLOCK | 14. SPRING | 24. GUIDE |
| 5. PIN | 15. PROP | 25. OUTER AND INNER COMPRESSION SPRINGS |
| 6. CLOSING LINKS | 16. STOP SURFACE FOR PROP | 26. CAM STOP |
| 7. RIVETED OVER PIN | 17. LATCH PLATE | 27. OPERATING CRANK |
| 8. TOGGLE LINKS A,B,C,D | 18. TRIP SHAFT | 28. BRACKET |
| 9. PIN IN FRAME | 19. FRAME | 29. MAIN SHAFT |
| 10. PIN IN FRAME | 20. TRIP ARM | |

POSITIONS OF OPERATING MECHANISM (A,B,C)

Adjustments are made by cams as shown in Fig. 11. To adjust the engagement between latch (Pt. 2) and latch plate (Pt. 5), slowly move the trip arm (Pt. 7) by hand, with the breaker closed, and measure the travel "A", of the front end of the arm from the point of rest to the point of trip, which should be between $1/8"$ and $3/16"$. Adjustment can be made by loosening the screw (Pt. 9) and turning the eccentric stop (Pt. 8), on the left side of the operating mechanism frame, which bears against the buffer spring (Pt. 10) attached to the left end of the trip shaft (Pt. 6). After adjusting the eccentric be sure to tighten the screw.


The latch clearance adjustment is obtained by turning eccentric cam (Pt. 4) by screw-driver after loosening nut (Pt. 3). Although the cam is on the inside of the operating mechanism frame, a threaded shank with a screw-driver slot extends through the frame. A clearance "B" of approximately $1/64"$ should be allowed between the latch (Pt. 2) and the cam when the latch rests against the latch plate (Pt. 5). If the clearance is too great, the latch receives

too great shock, particularly from the closing of the solenoid, and if the clearance is too small, the latch will not reset. To tighten the lock nut securely after adjustment.


In replacing the latch plate (Pt. 5) it is important that the point of contact of the latch plate should be on the upper side shown in the insert of Fig. 11, and the lower side.

SOLENOID OPERATED MECHANISM

The electrically operated mechanism of the type AE-1-25 breaker is the same as the manual operation except that the parts of Fig. 10, manual handle (Pt. 1), eccentric shaft (Pt. 1), link (Pt. 2), block (Pt. 3) and block (Pt. 4) are replaced by a solenoid of Fig. 13 and a closing link of Fig. 14. In solenoid operation the latch is automatic, in that the closing of the armature (Pt. 4, Fig. 13) causes the lapse of toggle links (Pts. 10A and 10), which duplicates the resetting of the manually operated mechanism described in Fig. 10B.




(VIEW FROM LEFT SIDE)



(VIEW FROM RIGHT SIDE)

FIG. 10C
CLOSED POSITION
(OF OPERATING MECHANISM)



- | | |
|------------------------------------------------|----------------------------------------------------------|
| 1. PIN IN FRAME | 6. TRIP SHAFT |
| 2. LATCH | 7. TRIP ARM |
| 3. NUT $\frac{1}{4}$ - 20 WITH LOCKWASHER | 8. ECCENTRIC |
| 4. ECCENTRIC WITH $\frac{1}{4}$ THREADED SHANK | 9. SCREW HEX. HD. 10-32 X $\frac{7}{16}$ WITH LOCKWASHER |
| 5. LATCH PLATE | 10. BUFFER SPRING |

FIG. 11
ADJUSTMENT ECCENTRICS
FOR TRIP ARM AND LATCH

Manual closing of the solenoid operated breaker is shown in Fig. 13 by inserting a maintenance closing handle (Pt. 7) through the front of the mechanism under pin (Pt. 5) between the armature (Pt. 4) and the left side frame (Pt. 2) and resting it on pin (Pt. 6) as a fulcrum. Pushdown on the handle and be sure that the armature is lifted until the breaker is latched closed.

The breaker is likewise tripped by pushing on the trip button to release the trip latch, and not by the maintenance closing handle. In closing the breaker with the maintenance closing handle, it is important to remove it before tripping, as the breaker will have to be reset if the handle is still under the armature.

CLOSING RELAY

An electrically operated AE-1-25 breaker is equipped with a closing relay, Fig. 14, which operates to control the solenoid closing coil current so that the closing switch contacts will not be called upon to break the main closing coil current. This relay is attached to the mounting panel directly below the operating mechanism. No adjustments are required except to keep the contacts clean.

The coil (Pt. 2) is mounted in the magnet (Pt. 1), which is screwed to a separate mounting base (Pt. 11). The coil is held in place

by two brass guides (Pt. 3) between armature (Pt. 4) is free to move. ends of the guides are clamped over the armature and against the coil to keep it in place, and the upper ends are fastened to the magnet by self-tapping screws (Pt. 1). The coil is energized by the closing operating switch, Fig. 16, or a remote relay contacts or other devices, the armature is drawn up into the coil. It carries a movable contact strip (Pt. 7) which bridges the stationary contact blocks to energize the breaker closing coil control power source and close the breaker. As soon as the coil is de-energized, the armature falls by its own weight and the breaker closing circuit at the movable contact strip.

ROTARY TYPE AUXILIARY SWITCH

The rotary type auxiliary switch, Fig. 15, is the SB-1 type and is used on manually operated breakers when auxiliary functions are required. It is placed on the mounting panel above the operating mechanism and connected by crank and link (Pt. 9) to the operating crank (Pt. 27, Fig. 10) of the breaker main switch. The number of stages and the arrangement of the auxiliary contact switches are determined by the functions desired and the character of the circuits to be controlled such as indicator lamps, control circuits, bell alarm circuits, locking of breakers, etc.




FIG. 12
ELECTRICALLY OPERATED MECHANISM.


in a plane at right angles to the shaft. A stationary contact support (Pt. 4) carries the stationary contacts of all stages and is attached to the front frame and the rear barrier by two round head screws. Two bolts pass through the molded barriers and through the front end frame (Pt. 7). When the shaft is rotated the cam of each stage opens or closes both movable contacts simultaneously. In the auxiliary switch for the AE-1-25 breaker the two stationary contacts are insulated from each other in order that both switches of each stage may be connected in series for one circuit with two breaks as in Stage 1, or may be used for two separate circuits with one break in each circuit, as in Stage 2, as shown in wiring diagrams, Fig. 39 and 40. The cam bushing fits over the square shaft (Pt. 10) and has 24 external teeth and the cam (Pt. 7) with 24 corresponding internal teeth fits over the bushing to allow steps of 15° placement with reference to its setting on the shaft. The proper placement of the cam on the bushing and the bushing on the shaft is important for proper operation of the breaker. There is an index mark on the bushing and reference marks on the cam for this purpose.

The contacts of any stage may be changed from "a" to "b", or any intermediate position required, by a change in breaker operation by changing the position of the cam with reference to the shaft. If a change of 90° is required, the cam and bushing should be re-

moved together and replaced on the square shaft in the proper position. If the change is 15° or a multiple of 15° the cam will have to be relocated on the bushing. Each reference mark on the cam represents 15° of angular placement.

To make the change in the field, first remove interfering wiring and the stationary contact support (Pt. 4) with all the stationary contacts (Pt. 3) by removing two round head screws. Then remove the two tie bolts which hold the molded barriers (Pt. 1) to the front end frame (Pt. 7). Now remove the rear molded barrier with the two movable contacts of the rear stage, which will leave the cam and bushing of the rear stage exposed. Continue removing molded barriers, cams and bushings until the cam to be changed is exposed. In removing cams and bushings be particularly careful to make an accurate sketch showing the relation of reference marks on the cams, the index mark on the bushing and the position of the bushing on the shaft, and keep the parts of each stage together. The cam can then be changed to its new position and the auxiliary switch can be reassembled.

At regular inspection periods of the breaker, the auxiliary switch should be examined for burned contacts, and broken shunts on contact fingers. If contacts are slightly pitted or coated with oxide, scrape them gently with a sharp knife or dress with a



1. CONTACT BRACKETS AND BINDING SCREWS
2. SCREW R.H. #4-40 X $1\frac{1}{4}$ " WITH WASHERS
3. GUIDE
4. MOVEABLE CONTACT STRIP
5. INSULATION
6. SPRING
7. WASHER
8. MOLDED BASE
9. SPRING
10. OPERATING ROD
11. SCREW R.H. #8-36 X $\frac{3}{4}$ " WITH NUT & LOCKWASHER
12. MOUNTING BRACKET
13. SCREW R.H. #10-32 X $\frac{3}{8}$ " WITH LOCKWASHER

FIG. 16
OPERATING SWITCH

fine file. If the moving contact is burned or has a broken shunt, the entire contact finger assembly should be replaced. If a stationary contact is burned or damaged the complete stationary contact support and contacts should be replaced.

OPERATING SWITCH

The operating switch, Fig. 16, which energizes the closing relay, Fig. 14, of the solenoid operated breaker, is mounted on the front of the solenoid magnet. It requires no attention other than keeping the contacts clean.

The switch consists of a molded base which supports an operating rod (Pt. 10) on which rides a movable bridging contact strip (Pt. 4) and also contact brackets (Pt. 1) which carry the stationary contacts and binding screws. A compression spring (Pt. 9) normally holds rod and contact strip in the open position. Contact spring (Pt. 6) exerts pressure of the contact strip against the stationary contacts when in the closed position.

CUT-OFF DEVICE

The purpose of the cut-off devices, Fig. 17, for the AE-1-25 breaker is to de-energize the breaker closing coil (Pt. 3, Fig. 13) as soon as its armature has been lifted sufficiently to latch the breaker closed, to prevent damage to the closing coil should the operating switch, Fig. 16, be held in the closed position too long. This device is necessary when maintained contact control switches are used, as shown in Wiring Diagrams, Fig. 38 and 40.

The device consists of a two circuit switch and a holding coil mounted vertically on flanges of bracket (Pt. 2) which is attached to the left side frame (Pt. 3) of the operating mechanism. The switch is operated by a flat spring (Pt. 5) which is pivoted on pin (Pt. 4) mounted in this bracket. This spring is lifted by pin (Pt. 6) which replaces pin (Pt. 5, Fig. 13) through the armature of the breaker closing solenoid. When the closing solenoid is energized the pin is lifted and the flat spring bears against washer and cotter pin (Pt. 12) in pin (Pt. 13) of armature (Pt. 8). This pin bears against operating rod (Pt. 15) of the switch and opens the normally closed contacts which de-energizes the closing relay Fig. 14, and therefore, opens the closing solenoid circuit. At the same time the normally open contacts are closed which closes the circuit of holding coil (Pt. 11) to seal the contact in this position as long as the operating switch Fig. 16 is held in the closed position. This sealing-in also prevents pumping should the breaker fail to be latched. It is important that this device should not open too soon in the closing stroke of the

energize the closing coil before the breaker is latched closed. See also Wiring Diagram Fig. 40.


The contact brackets (Pt. 17), with stationary contacts and binding screws, are mounted on a molded base (Pt. 22). The operating rod (Pt. 15) passes through the lower part of the base, and a guide (Pt. 20), attached to the upper end of the operating rod by screw (Pt. 21), passes through the upper part of the molded base. The movable contact strips (Pt. 18) move over the square section of the guide and are separated by contact spring (Pt. 19) which also maintains adequate pressure against the contacts. Spring (Pt. 16) normally holds the operating rod in the lowered position which will close the normally closed contacts in order that the closing solenoid shall be energized as soon as the closing switch is closed.

DUAL MAGNETIC OVERCURRENT TRIP DEVICE (oil Film Type)

This device, Fig. 18, automatically trips the breaker under two distinct conditions: overload; first, with inverse time delay for overcurrents in excess of calibration setting and less than ten times rated current; a second, with instantaneous tripping for interrupting overloads exceeding ten times rated current.

To accomplish inverse time tripping a current in the series coil (Pt. 9) sets up a magnetic circuit which tends to pick up armature (Pt. 1) pivoted on pin (Pt. 13) in frame (Pt. 12) and operate trip finger (Pt. 2) and turn the trip shaft counter-clockwise (looking from the left). The armature (Pt. 1) is restrained by a calibration spring (Pt. 3) held under tension between the armature assembly and the calibration index (Pt. 23) and also by a thin oil film between upper disc (Pt. 17), which is pivoted to the armature assembly, and the lower disc (Pt. 1) attached to the bottom of oil cup (Pt. 1) which holds the oil in which both discs are immersed. For currents below the calibration setting, the calibration spring prevents the armature from picking up and force is exerted to separate the discs in oil pot. For currents in excess of the calibration setting the magnetic pull on the armature exceeds the pull on the calibration spring (Pt. 21) and the excess force tends to pull the two flat disc surfaces (Pt. 16, 17) apart by rupturing the oil film between them. Once this oil film is ruptured, the armature picks up and trips the breaker. The time required to rupture the oil film varies inversely with the force applied and hence inversely with the current through the breaker. Thus, if the overcurrent falls below the calibration setting before the oil film is ruptured the breaker will not trip.

For instantaneous tripping for currents in excess of ten times the breaker rated



- | | |
|-------------------------------------------------------------------------|-------------------------------------------------------------------|
| 1. SCREW R.H. $\frac{1}{8}$ -36 X $\frac{1}{2}$ WITH NUT AND LOCKWASHER | 13. PIN IN ARMATURE |
| 2. FLANGED BRACKET | 14. SCREW $\frac{1}{8}$ -32 WITH LOCKNUT |
| 3. FRAME OF OPERATING MECHANISM | 15. OPERATING ROD |
| 4. PIN AND COTTER PIN | 16. SPRING |
| 5. PLAT SPRING | 17. CONTACT BRACKETS WITH SHIMMING SCREW |
| 6. PIN (REPLACING PIN PT 5 FIG. 10) | 18. MOVEABLE CONTACT STRIPS |
| 7. SCREWS R.H. $\frac{1}{8}$ -36 X $\frac{1}{2}$ WITH LOCKWASHERS | 19. CONTACT SPRINGS |
| 8. ARMATURE | 20. GUIDE |
| 9. BRASS GUIDE | 21. SCREW R.H. $\frac{1}{4}$ -40 X $\frac{1}{2}$ WITH LOCKWASHERS |
| 10. MAGNET | 22. MOLDED BASE OF SWITCH |
| 11. COIL | |
| 12. WASHER AND COTTER PIN | |

FIG. 17
CUT-OFF DEVICE
BREAKER IN OPEN POSITION




FIG. 18
DUAL MAGNETIC OVERCURRENT TRIP DEVICE.
(OIL FILM TYPE)

- | | |
|--------------------------------------------------|-----------------------------------------------------------------------|
| 1. ARMATURE ASSEMBLY | 15. LOWER DISC |
| 2. SCREW R.H. $\frac{1}{8}$ -20, NUT AND WASHERS | 17. UPPER DISC |
| 3. SCREW HEX. HD. $\frac{1}{8}$ -20, AND WASHERS | 18. SHIM |
| 4. MAGNET | 19. SPRING |
| 5. LOWER STUD (WELDED TO COIL) | 20. INSTANTANEOUS TRIP SPRING |
| 6. SCREW R.H. $\frac{1}{8}$ -20 NUT AND WASHER | 21. CALIBRATION SPRING |
| 7. LOWER STUD BRACKET | 22. CALIBRATION ADJUSTING KNOB |
| 8. SCREW R.H. $\frac{1}{8}$ -20 AND WASHERS | 23. CALIBRATION INDEX & SCREW |
| 9. SERIES OVERCURRENT COIL WITH UPPER TERMINAL | 24. ADJUSTING STOP |
| 10. INSULATING TUBE | 25. SCREWS HEX. HD. $\frac{1}{8}$ -20 X $\frac{1}{2}$ NUT AND WASHERS |
| 11. INSULATING WASHERS | 26. SCREWS R.H. $\frac{1}{8}$ -36 X $\frac{1}{2}$ AND WASHER |
| 12. FRAME | 27. CALIBRATION PLATE |
| 13. PIN & COTTERS | 28. TRIP FINGER |
| 14. PIVOTED COVER & SUPPORT | |
| 15. OIL POT | |

the armature is further restrained by a pair of heavier instantaneous trip springs (Pt. 20), one on each side of the device, attached at the lower front end to the fixed frame (Pt. 12) and at the upper rear end to the cover and support (Pt. 14). This cover is pivoted on pin (Pt. 13) and supports the oil pots. Thus, if overcurrent demands immediate tripping, the heavier pull on the upper disc lifts the complete oil pot assembly, as the springs yield, without waiting for the rupture of the oil film, allowing the armature to pick up and trip the breaker immediately.

Calibration settings for 100, 125, 150, 175, and 200 per cent of breaker normal current rating are marked in amperes on the calibration plate (Pt. 27). For general feeder applications, the calibration setting should not be less than 125 per cent of actual load being carried by the breaker.

An adjustment is provided for varying the amount of time delay obtained. This is accomplished by turning the oil pot (Pt. 15) to different marked time delay settings, which increases or decreases the area of disc surfaces separated by oil film. The disc surfaces have part of their contact area cut away in the form of a wide band parallel to the diameter of the disc surfaces. The smaller the contact area between discs, the shorter will be the time delay obtained.

The armature air gap is adjusted at the factory by an adjustable stop (Pt. 24) which is pivoted to the frame (Pt. 12) by screw (Pt. 25) in the rear end and adjusted by a similar screw through a slot in the front end. This stop registers with the pivoted cover and support (Pt. 14) which carries the oil pot. By raising or lowering the oil pot, the armature air gap is changed because shank (Pt. 18) is pivoted to both the armature assembly and to the upper disc (Pt. 17). The air gap should not be changed unless means are available for the recalibration of the complete device.

To check the adjustment of this device for positive tripping, pick up the armature manually; the breaker should trip with approximately $1/32$ " gap between the magnet and the armature. To obtain this adjustment, bend the trip finger (Pt. 28) attached to the trip shaft so that the armature will engage the trip finger sooner or later as required.

It is important that the facing surfaces of the discs be clean and smooth, otherwise the calibration will be affected. If these surfaces are damaged or affected in any way they should be relapped or made smooth by rubbing them over crocus cloth backed up by a smooth, flat surface. It is of utmost importance that the oil in the cup be kept clean and at the proper level. See "Maintenance"




FIG. 19
APPROXIMATE TIME-CURRENT CHART
OF DUAL MAGNETIC OVERCURRENT

If a new series coil is required any considerable repair is necessary recommended that a complete factory calibrated dual magnetic overcurrent device be supplied.

A typical time-current trip curve for this device is shown in Fig. 19. The curve is approximate and consideration in time delay may be expected upon the cleanliness of the oil film, the time allowed for




FIG. 20
THERMAL MAGNETIC OVERCURRENT TRIP DEVICE.
(EXTERNAL VIEW)

THERMAL MAGNETIC OVERCURRENT TRIP DEVICE

This device, Fig. 22, also automatically trips the breaker under two distinct conditions of overcurrent, first, with inverse time delay when the current exceeds the value of calibration setting and is less than 12 to 15 times the breaker rating, the inverse time tripping being obtained by the time required to heat and flex a bimetallic strip; and second, instantaneously when the breaker current exceeds 12 to 15 times the normal breaker current.

This device operates on alternating current only, and is principally used for motor protection. The unit is enclosed in a molded frame as shown in Fig. 20.

Current in the series coil (Pt. 5) sets up a magnetic circuit which tends to pick up the armature (Pt. 19) as described below, and operate the trip finger (Pt. 30) on trip shaft. The armature is attached to the lower member of the magnet (Pt. 6) by a spring hinge (Pt. 14) and is restrained by a yoke (Pt. 20) which is pivoted to the center of the armature by pin (Pt. 25) between two flat buffer springs (Pt. 22). The yoke is restrained at the bottom by a latch plate (Pt. 15) and also at the top by two heavy compression short circuit springs (Pt. 1) supported between pin (Pt. 28) in the yoke and the rear frame. Current in the series coil induces current in the short-circuited

ring (Pt. 7), mounted around the lower magnet member, generating heat which is conducted to the bimetallic strip (Pt. 13). This strip is riveted at its rear end to the thermal trip arm (Pt. 9) and held at the front end between the calibrating cam (Pt. 18) and the compression spring (Pt. 16). The thermal trip arm (Pt. 9) is pivoted to the frame on pin (Pt. 8). When sufficient heat has been developed to cause the bimetallic strip (Pt. 13) to bend, with the convex surface downward, the thermal trip arm will tend to revolve about pin (Pt. 8) in a clockwise direction (looking from left) and bear against an adjusting screw (Pt. 12), set in the latch support (Pt. 10), also pivoted on pin (Pt. 8), to cause the latch plate (Pt. 15) to disengage the yoke (Pt. 20) at the lower end. This will allow the armature to be picked up and trip the breaker as the lower end of the yoke moves to the rear over the latch plate (Pt. 15) while the upper end of the yoke is held fixed by the heavy springs (Pt. 1). A torsion spring (Pt. 11) is mounted over pin (Pt. 8) to hold the thermal trip arm (Pt. 9) and latch support (Pt. 10) together against the adjusting screw (Pt. 12). Thus, if the overcurrent falls below the calibration setting before the bimetallic strip is sufficiently bent, the breaker will not be tripped.

Should the overcurrent exceed 12 to 15 times the breaker rating, the heavier pull on the armature (Pt. 19) will cause the upper




FIG. 21
APPROXIMATE TIME-CURRENT CHARACTERISTIC
OF THERMAL MAGNETIC OVERCURRENT TRIP DEVICE
(STARTING COLD IN 24° AMBIENT)

end of yoke (Pt. 20) to compress the heavy short circuit springs (Pt. 1), while the lower end of the yoke is held fixed against latch plate (Pt. 15). As these heavy springs yield the armature will pick up and trip the breaker immediately without waiting for release of latch plate (Pt. 15) by the heating of the bimetallic strip as described above.

The lock nut on spring guide (Pt. 2) controls the compression of the short circuit spring (Pt. 1) and is adjusted at the factory to provide instantaneous tripping when the current exceeds approximately 12 to 13 times normal breaker current.

The adjustable stop screw (Pt. 23) is secured to the armature (Pt. 19) and provides a stop against the front molded frame to control the clearance of 1/16" to 3/32" between the latch surface on the yoke (Pt. 20) and the latch plate (Pt. 15) to insure positive reset. The reset spring (Pt. 26) between adjusting screw (Pt. 27) and the lower end of yoke (Pt. 20), provides the proper tension to the yoke to insure positive resetting after a tripping operation by drawing the lower end of the yoke forward to engage the latch plate (Pt. 15).

strip (Pt. 13) must bend before releasing latch plate (Pt. 15) to trip the breaker.

The calibration adjustment knob (Pt. 1) can be turned to revolve the cam (Pt. 18) indications as marked on the nameplate change the calibration range from 80 to 120 per cent of breaker rating. Revolving the cam raises or lowers the front end of the bimetallic strip against spring (Pt. 16).

To check the adjustment of this device for positive tripping, pick up the armature manually and the breaker should trip with approximately 1/32" gap between the armature and the magnet. To obtain this adjustment bend the trip finger (Pt. 30) attached to the trip shaft so that the trip arm (Pt. 29) engages this finger sooner or later as required.

There are available other special accessories that can be attached to the tension of the thermal trip arm (Pt. 9) to perform special functions when the bimetallic strip (Pt. 13) flexes. These are specifications and information concerning them should be obtained from the nearest sales office of the company.

Typical time-current tripping curves




FIG. 22

THERMAL MAGNETIC OVERCURRENT TRIP DEVICE

- 1. SHORT CIRCUIT SPRING
- 2. SPRING GUIDE AND LOCK NUT
- 3. TUBULAR SPRING GUIDE AND COTTER
- 4. MOLDED FRAME
- 5. SERIES COIL
- 6. MAGNET
- 7. INDUCTION RING
- 8. PIN
- 9. THERMAL TRIP ARM
- 10. LATCH SUPPORT
- 11. TORSION SPRING
- 12. ADJUSTING SCREW

- 13. BIMETALLIC STRIP
- 14. SPRING HINGE
- 15. LATCH PLATE
- 16. SPRING FOR THERMAL TRIP ARM
- 17. CALIBRATING KNOB
- 18. CALIBRATING CAM, SPRING, AND COTTER
- 19. ARMATURE
- 20. YOKE
- 21. ADJUSTING SCREW AND SPRING
- 22. FLAT BUFFER SPRING
- 23. ARMATURE ADJUSTING SCREW AND NUT

- 24. LEATHER BUFFER
- 25. YOKE AND ARMATURE PIN
- 26. RESET SPRING FOR YOKE
- 27. ADJUSTING SCREW
- 28. PIN
- 29. TRIP ARM
- 30. TRIP FINGER

the
17)
) to
to
120
this
the
5).

vice
ture
with
ture
ent,
to
29)
re-

ac-
ex-
to
llic
cial
be
of

ry
h
t
cont





FIG. 23

MAGNETIC INSTANTANEOUS OVERCURRENT TRIP DEVICE

- | | |
|-----------------------|-------------------------------------------------------|
| 1. ARMATURE ASSEMBLY | 9. STOP PLATE, RIVETED TO |
| 2. MAGNET | ARMATURE ASSEMBLY |
| 3. LOWER STUD | 10. CALIBRATION SPRING |
| 4. SERIES COIL | 11. CALIBRATION ADJUSTING KNOB |
| 5. FRAME | 12. CALIBRATION INDEX |
| 6. PIN AND COTTER PIN | 13. SCREW R.H. #10-32 X $\frac{1}{2}$ AND LOCKWASHERS |
| 7. STOP AND HEX NUT | 14. CALIBRATION PLATE |
| 8. SUPPORT FOR STOP | 15. TRIP FINGER |



- | | |
|-----------------------------------------------------|----------------------------|
| 1. LOWER STUD | 8. ARMATURE |
| 2. BRASS PLATE | 9. NUTS $\frac{1}{4}$ -20 |
| 3. SCREWS, F.H. 10-32 X 1 | 10. BRASS ROD, BRAZED TO 2 |
| 4. MAGNET | 11. TRIP ARM |
| 5. SCREWS, R.H. 10-32 X $\frac{1}{16}$ & LOCKWASHER | 12. BRASS TUBE |
| 6. BRASS GUIDES | 13. COMPRESSION SPRING |
| 7. GUIDE ROD, WELDED TO 8 | 14. BRASS CUP |

MAGNETIC INSTANTANEOUS OVERCURRENT TRIP DEVICE

This device, Fig. 23, is magnetically operated to trip the breaker instantaneously by the current through the breaker when this current exceeds the calibration setting. Standard calibration settings for 100, 125, 150, 175 and 200 per cent of breaker normal current rating are marked on the calibration plate. For general applications, the calibration setting used should not be less than 125 per cent of normal load.

This device is similar to the dual magnetic overcurrent trip device without the time delay assembly and support and the heavy instantaneous trip springs. As shown in Fig. 23, the armature has a stop plate or weight (Pt. 9) riveted to it and is pivoted on pin (Pt. 6) in the frame (Pt. 5). It is restrained by the calibration spring (Pt. 10) only. The armature air gap is adjusted by raising or lowering the stop (Pt. 7) in support (Pt. 8) which is attached to the frame (Pt. 5) by screws (Pt. 13).

INSTANTANEOUS SHORT-CIRCUIT TRIP DEVICE

According to NEMA standards, all air circuit breakers shall be inherently automatic for overcurrent tripping. Hence, if the type AE-1-25 breaker is not to be equipped with time delay or instantaneous overcurrent trip device, it will be furnished with an instantaneous short-circuit trip device. For the type AE-1-25 breaker this device is set to operate at 9000 amperes and no provision is made for field adjustment.

The instantaneous short-circuit trip device, Fig. 24, is mounted on the upright portion of the lower stud on the front of the mounting base. It consists of a U-shaped magnet (Pt. 4) attached to the stud (Pt. 1) by flat head screws (Pt. 3) through a brass plate (Pt. 2) to which is brazed a brass rod (Pt. 10). This rod supports the armature assembly (Pt. 8) which includes a guide rod (Pt. 7), the trip arm (Pt. 11) and the brass guide tube (Pt. 12) which slides over the rod (Pt. 10). A compression spring (Pt. 13) slides over the rod (Pt. 10) and fits into a brass cup against the brass plate (Pt. 2) to force the armature (Pt. 8) against the lock nuts (Pt. 9) on the rod. Brass guides (Pt. 6) are attached to the magnet by screws (Pt. 5). Current in the lower stud sets up a magnetic field which picks up the armature to trip the breaker when trip arm (Pt. 11) engages a trip finger on the trip shaft.

INSTANTANEOUS UNDERVOLTAGE TRIP DEVICE

The function of this device is to trip the breaker when the voltage drops below a predetermined value. As long as a voltage of this value or greater, is impressed on the coil, the armature is held down into the coil and the device has no effect upon closing or tripping of the breaker in any way, but when the voltage drops to approximately

50% of normal, or lower, the magnet is weakened and a strong spring draws the armature out of the coil and causes the breaker to trip. The breaker cannot be reclosed until the necessary voltage returns.

The device, Fig. 25A, is mounted on the front of the mounting base under the breaker shaft and the trip shaft and to the right of the breaker poles. An insulation barrier (Pt. 17) is placed between the mounting strap (Pt. 19) of the device and the mounting base (Pt. 18) and also covers the entire right side of the device. The coil (Pt. 22) is mounted in magnet (Pt. 23) over two brass guides (Pt. 24) between which the armature (Pt. 25) is free to move. The upper ends of the guides are clamped over the magnet and holds the coil in place and the lower ends are fastened to the magnet by screws (Pt. 16). A trip lever (Pt. 9) is pivoted on pin (Pt. 10) in frame (Pt. 13) and is restrained by tension spring (Pt. 12) attached by adjusting screw (Pt. 14) to the same frame which extends forward and is riveted to the sides of the magnet. A trip adjusting screw (Pt. 4) in the trip lever (Pt. 9) bears against the trip arm (Pt. 6) which is attached to the trip shaft (Pt. 5).

Fig. 25A shows the breaker in the open position, with or without potential applied to the coil (Pt. 22). The reset arm (Pt. 1) is in the lowered position against buffer spring (Pt. 2) and the armature (Pt. 25) is forced down into the coil. However, when the breaker is in the closed position, with potential applied to the coil, the reset arm is lifted clear of the buffer spring by the main shaft (Pt. 30) as it revolves clockwise (looking from right) to close the breaker contacts. The breaker cannot be kept closed unless potential is applied to the coil. When the voltage falls, or drops below the predetermined value, the coil is de-energized. This allows spring (Pt. 12) to draw the front end of trip lever (Pt. 9) down and the trip adjusting screw (Pt. 4) bears against the rear end of trip arm (Pt. 6) which causes the trip shaft (Pt. 5) to revolve clockwise to trip the breaker. At the same time the rear end of trip lever (Pt. 9) lifts the armature out of the coil and exerts a hammer blow against the reset adjusting screw (Pt. 29), which is set in the reset link (Pt. 7), causing the latter, together with springs (Pts. 2 and 3) to revolve clockwise about pin (Pt. 28) in the support (Pt. 27). A stop link (Pt. 11) is attached by pin (Pt. 8) to the reset link (Pt. 7) and is hooked under the trip lever (Pt. 9) to prevent the reset link from springing upward to the vertical position and remaining there. The rear end of the trip lever (Pt. 9) is stopped by pin (Pt. 28).

When voltage is applied to the de-energized coil, the pull of the magnet is not strong enough to draw the armature down into it against the force of spring (Pt. 12) so that a means of resetting must be provided.

When the breaker is open, whether the coil is energized or not, the reset arm (Pt. 1) is against buffer spring (Pt. 2) and the armature is pressed down into the coil, as shown in Fig. 25A, and is therefore in the reset position. When the breaker opens it is automatically reset as follows:- Just as soon as the main shaft (Pt. 30) revolves counter-clockwise to open the breaker contacts, the reset arm (Pt. 1) is forced downwards against buffer spring (Pt. 2) which cause adjusting screw (Pt. 29) to force the armature firmly against the bottom member of magnet (Pt. 23), in the case of alternating current applications, or against set screw (Pt. 15) in direct current application. Then, if potential is applied to the coil, the armature will be held within the coil.

For direct current application, the brass stop screw and locknut (Pt. 15) through the lower member of the magnet are necessary to slightly separate the armature from the magnet to prevent sticking due to residual magnetism and allow tripping.

Adjustments consist first, in direct current application, in setting the stop screw (Pt. 15) so that the bottom of the armature (Pt. 25) is just separated from the magnet (Pt. 23).

Make the following adjustments for both alternating and direct current applications.

With the breaker in the open position and the reset arm (Pt. 1) in the open position, as shown in Fig. 25A, the reset adjusting screw (Pt. 29) should be set to allow between $1/32"$ to $1/8"$ between the buffer spring (Pt. 2) and flat spring (Pt. 3) when the reset arm presses against the buffer spring. Then tighten lock nut.

With the breaker in the closed position and the coil de-energized, turn the trip adjusting screw (Pt. 4) in the trip lever (Pt. 9) until the breaker trips, and then continue to turn the screw between $1/2$ and $3/4$ of a turn more and then tighten the locknut.

The spring (Pt. 12) should be adjusted by adjusting screw (Pt. 14) to prevent drop-out of armature (Pt. 25) when the breaker is closed and the coil is energized by voltages above 50% of normal, but to positively trip at 50% of normal or less.

TIME DELAY UNDERVOLTAGE TRIP DEVICE

This device, Fig. 25B, is constructed and operates in a similar manner as in the instantaneous undervoltage trip device with the addition of the oil film time delay attachment and the omission of the reset stop link (Pt. 11). The time delay attachment consists of a disc (Pt. 37) immersed in oil in a dash pot (Pt. 36) which is attached to a cover (Pt. 35) which, in turn, is riveted to its own frame (Pt. 34) and fastened by

7) by plunger assembly (Pt. 33) to delay the tripping of the breaker until the oil film between the lapped surfaces of the disc at the bottom of the dash pot, ruptures. Thus if normal voltage is restored before the oil film ruptures, the breaker will not open.

First adjust, in direct current application, the clearance of the bottom of armature (Pt. 25) from the magnet by stop screw (Pt. 15) as described in instantaneous undervoltage trip device adjustment above.

Make the following adjustments for both alternating and direct current applications: Then with the breaker in the closed position and the coil (Pt. 22) de-energized, push the armature (Pt. 25) down into the coil to lower the reset link (Pt. 7) and disc (Pt. 37). Now screw the dash pot cup on the cover (Pt. 35) until the reset link (Pt. 7) begins to lift and then turn it another half turn which should make the cup tight against its seat. If not seated by about half a turn, then turn the adjusting screw (Pt. 29) and repeat until this condition is obtained.

Now, when the breaker is opened and the reset arm (Pt. 1) is down, the disc should be pressed firmly against the bottom of the dash pot by the buffer spring (Pt. 2) which should now be about $1/32"$ to $1/8"$ from the flat spring (Pt. 3). If not, the buffer spring will have to be bent to secure the clearance.

The adjustment of trip adjustment screw (Pt. 4) and the spring (Pt. 12) will be the same as in the instantaneous undervoltage trip devices, described above.

REVERSE CURRENT TRIP DEVICE (ROTOR TYPE)

A direct acting reverse current trip device of the rotor type, Fig. 26, is available for the AE-1-25 breaker for direct current application which will trip the breaker when the reversed current exceeds the calibration setting. The device is constructed similar to a bipolar motor with a stationary pole assembly in which is mounted a series coil carrying the breaker current, and rotating armature on which is wound a potential coil. The magnetic field set up by the current in the potential coil together with the field set-up by the load current through the series coil in the normal direction produces a torque which tends to rotate the armature in a direction to prevent tripping. However, when the current in the series coil is reversed, the torque is reversed to cause the reverse rotation which trips the breaker.

As shown in Fig. 26, the motor element is mounted horizontally on the rear of mounting base by studs (Pt. 34). The armature shaft (Pt. 14) extends through to front to operate the tripping equipment. The series coil (Pt. 5) is mounted vertically on the motor element with horizontal




FIG. 25 A

INSTANTANEOUS UNDERVOLTAGE TRIP DEVICE
WITH BREAKER IN OPEN POSITION




FIG. 25 B

TIME DELAY UNDERVOLTAGE TRIP DEVICE
WITH BREAKER IN OPEN POSITION

1. RESETTNG ARM
2. BUFFER SPRING
3. FLAT SPRING
4. TRIP ADJUSTING SCREW R.H.
#10-32 X 1/2" AND NUTS
5. BREAKER TRIP SHAFT
6. COMPOSITION TRIP ARM
7. RESET LINK
8. PIN AND COTTER PINS
9. TRIP LEVER
10. PIN AND COTTER PINS
11. STOP LNK
12. SPRING

13. FRAME
14. SPRING ADJUSTING SCREW R.H.
#10-32 X 1 1/2" AND NUTS
15. STOP SCREW R.H. #10-32 X 1 1/2"
WITH HEX NUT (DIRECT CURRENT ONLY)
16. SCREW R.H. SELF TAPPING #4 X 1/2"
17. BARRIER
18. MOUNTING BASE
19. MOUNTING STRAP
20. SCREW R.H. SELF-TAPPING #8 X 1 1/2" LONG AND LOCKWASHER
21. SCREW R.H. #10-32 X 1 1/2" WITH LOCKWASHER
22. COIL
23. MAGNET

24. BRASS GUIDES
25. ARMATURE
26. PIN AND COTTER PINS
27. SUPPORT FOR PT. 7
28. PIN AND COTTER PIN
29. RESET ADJUSTING SCREW HEX. HD.
#10-32 X 1 1/2" WITH NUT
30. MAIN SHAFT
31. SCREW R.H. #10-32 X 1 1/2" WITH LOCKWASHER
32. GROOV PIN TYPE I, 1/8" DIA. X 1 1/2"
33. PLUNGER ASSEMBLY
34. FRAME
35. COVER
36. OIL DASH POT
37. DISC

41) by screws (Pt. 3) and to the pole shoes (Pt. 43) by screws (Pt. 1). The upper part of the coil extends to the rear as a connection bar (Pt. 39) for external load connection which is supported by bar support (Pt. 40) held in place by screws (Pts. 3 and 4). The lower part of the coil is connected to the lower stud (Pt. 7) by connection bar (Pt. 8) and screw (Pt. 6).

The armature shaft (Pt. 14) is supported in bronze bearing castings (Pts. 33 and 38) which are fastened to the pole shoes by screws (Pt. 37) at the rear and by studs (Pt. 34) with nuts (Pt. 31) in spacer (Pt. 32) with nut housings at the front. An escutcheon plate (Pt. 30) is mounted on the front of the mounting base by nuts (Pt. 31) on studs (Pt. 34) and to it are riveted two posts for calibration plate (Pt. 18) and two posts for stop screws (Pts. 12 and 22). A trip crank (Pt. 13) is clamped firmly by screw (Pt. 15) and set screw (Pt. 16) to the extended armature shaft (Pt. 14) and supports the trip arm assembly (Pt. 25) on pin (Pt. 26). A trip lever (Pt. 24) is screwed to the trip shaft (Pt. 23) and is free to move over the upper end of the rod between properly spaced jam nuts to permit sufficient travel when the breaker is tripped by other devices.

When current passes through the series coil in the normal direction, the armature will tend to revolve clockwise (looking from the front) to force the trip crank (Pt. 13) against stop screw (Pt. 22). The calibration spring (Pt. 20) also normally, holds the trip crank against this stop screw. But when current passes through the series coil in the reverse direction, the armature will tend to rotate counter-clockwise away from this stop screw, and when the current exceeds the calibration setting, it will rotate sufficient to lower the trip rod (Pt. 25) and trip the breaker. The stop screw (Pt. 12) limits the counter-clockwise travel. The calibration plate (Pt. 18) is mounted on posts on the escutcheon plate. The calibration screw (Pt. 17) passes through these posts (Pt. 29) and carries a threaded calibration index (Pt. 19) attached to the calibration spring. By turning the hexagonal head of the calibration screw against the compression spring (Pt. 21), the reverse current trip setting can be changed.

The trip crank is clamped to the armature shaft so that the potential coil (Pt. 44) will be located approximately in the vertical position with a somewhat larger air gap on the trip side when the crank is against the stop screw (Pt. 22), which should extend approximately $1/16"$ to $3/32"$ beyond the post. When rated voltage is applied to the potential coil with no current passing through the breaker and the calibration spring is connected, there should be no movement of the armature in the tripping direction. However, if a movement is detected, back off slightly on the stop screw (Pt. 22) to increase the

After this adjustment has been completed, the stop screw (Pt. 12) can be set to limit the travel of the armature so that the trip crank (Pt. 13) will be stopped slightly past the horizontal. Now adjust the nuts at the top of trip rod (Pt. 25) so that the breaker will trip with $1/32"$ overtravel of the trip lever measured at the trip lever. Slight variations of these adjustments may be necessary to improve the operation of the device.

The adjustment of stop screw (Pt. 22) and the tripping crank (Pt. 13) will affect the calibration of the reverse current device so their setting should not be changed unless facilities for checking calibration are available.


Because the potential must not drop below 80% of normal, the potential coil should be connected to a reliable constant potential source, preferably to a station battery bus, if possible.

REVERSE CURRENT TRIP DEVICE (HINGED ARMATURE)


A direct acting reverse current trip device of the magnet and hinged armature type is available for AE-1-25 breakers for direct current applications. It will operate to trip the breaker when the reverse current exceeds the calibration setting. The principle of operation is shown diagrammatically in Fig. 27, and in detail in Fig. 28A and B.

The device consists of a composite magnet with a series coil on the middle core, which carries the breaker current, and a potential coil on the bottom core. An air gap in the upper leg of the magnet is bridged by an armature which is attracted to the magnet and held by the flux from the potential coil alone, or more firmly when reinforced by the flux due to the current of the breaker through the series coil in the normal direction. But, when the current passes through the breaker in the reverse direction, the two fluxes are on longer cumulative and the flux across the air gap is weakened sufficiently to allow a spring to pull the armature away and trip the breaker.


The series coil (Pt. 4) is in the same location as the standard overcurrent coil, between the lower stud and the connection to the movable contact on the front of the breaker base. It is mounted on the middle core of the composite magnet (Pts. 2 and 6) while the potential coil (Pt. 9) is mounted on the bottom core. The magnet is provided with two thin non-magnetic spacers to provide two small magnetic gaps so placed to cause the greater part of both fluxes to flow through the upper leg of the magnet. The armature assembly (Pt. 11) is pivoted on pin (Pt. 10) which passes through the supporting frame (Pt. 12). The pivoted armature (Pt. 22) is held against the magnet to close the air gap when the potential coil is energized, and



FRONT VIEW (MOTOR ELEMENT NOT DETAIL)



RIGHT SIDE VIEW (COIL NOT DETAIL)



SECTION 'A-A'

1. SCREWS NO. 10-32 X 1/2" AND LOCKWASHER
2. SUPPORT
3. SCREWS NO. 10-32 X 1/2" AND LOCKWASHER
4. SCREWS NO. 10-32 X 1/2" WITH LOCKWASHER AND
5. NUTS AND INSULATION WASHERS AND RIVETS
6. SCREWS NO. 10-32 X 1/2" WITH WASHER, LOCKWASHER & NUT
7. LOWER STUD
8. LOWER CONNECTION BAR, WELDED TO P.C.S.
9. ANGLE SUPPORT FOR LOWER STUD SEE PT. 9, P. 16
10. SCREWS NO. 10-32 X 1/2" WITH WASHER & LOCKWASHER SEE P. 16, P. 16
11. COLLAR WASHER
12. STOP SCREW WITH LOCKWASHER AND NUT
13. TRIP SHAFT
14. ARMATURE SHAFT
15. SCREW NO. 10-32 X 1/2" AND LOCKWASHER
16. SET SCREW CUP POINT NO. 10-32 X 1/2"
17. CALIBRATION SCREW NO. 10-32 X 1/2" WITH WASHER AND COTTER PIN
18. CALIBRATION PLATE
19. CALIBRATION WHEEL
20. CALIBRATION SPRING
21. COIL SCREW WITH LOCKWASHER AND NUT
22. TRIP SHAFT
23. TRIP SHAFT
24. TRIP LEVER
25. TRIP ROD ASSEMBLY
26. PM WASHER AND COTTER PIN
27. SPACER
28. SCREWS NO. 10-32 X 1/2" AND LOCKWASHER
29. POST
30. THROTTLE PLATE
31. NUT, NO. 10-32 X 1/2" AND LOCKWASHER
32. SCREW NO. 10-32 X 1/2" WITH WASHER, LOCKWASHER & NUT
33. FRONT MACHINE BEARING
34. STUD
35. SPACER WITH NUT HOUSING
36. THROTTLE WASHER AND INSULATION WASHER
37. SCREWS NO. 10-32 X 1/2" AND LOCKWASHER
38. BEARING
39. REAR BRIDGE BEARING
40. UPPER CONNECTION BAR WELDED TO P.C.S.
41. CONNECTION BAR SUPPORT
42. COIL
43. INSULATION TUBE
44. POLE SHOE
45. POTENTIOMETER
46. ARMATURE
47. SCREW NO. 10-32 X 1/2" WITH WASHER & LOCKWASHER

FIG. 26
REVERSE CURRENT TRIP DEVICE (ROTOR TYPE)

is held more firmly when the magnetic flux is increased by the breaker current in the normal direction.

When the current in the series coil reverses the magnetic pull on the pivoted armature (Pt. 22) in armature assembly (Pt. 11) decreases, and when the reverse current exceeds the calibration setting, the pull is not enough to overcome the pull of the spring (Pt. 15) which moves the armature away from the magnet. When the armature assembly is pulled away it strikes the trigger (Pt. 18) attached to the trip shaft (Pt. 19) which is supported in bearing plate (Pt. 20) attached to the frame by two screws (Pt. 21). This causes the trip shaft to revolve counter-clockwise, (looking from left), to trip the breaker.

The magnetic pull produced by the potential coil alone will not draw the pivoted armature (Pt. 22) to close the air gap against the pull of the spring (Pt. 15) after the break has tripped due to reversed current, making it necessary to reset the armature as follows:- As soon as the breaker opens the main shaft (Pt. 23) and reset crank (Pt. 25) revolve clockwise (looking from left) and draw insulation link (Pt. 26) and link (Pt. 27) to the left. This link (Pt. 27) and reset lever (Pt. 30) are pivoted on the same pin (Pt. 28) and held together by torsion spring (Pt. 29) against lugs on each, so that when the reset lever (Pt. 30) is moved to the left it pushes the pivoted armature (Pt. 22) against the magnet (Pt. 2) where it is held by the magnetic pull of the potential coil (Pt. 9). The potential coil must be connected to the circuit so that it will be continuously energized in order to hold the armature against the magnet when the breaker is tripped by other means than reversed current, otherwise the armature assembly will


hold the trip shaft in the tripped position and the breaker will not close.

When the breaker is closed and the main shaft (Pt. 23) revolves counter-clockwise the reset linkage drives the reset lever (Pt. 30) away from the armature assembly (Pt. 11) so that it will not retard the armature when released by reverse current.

Because the potential must not drop below 80% of normal, the potential coil should be connected to a reliable constant potential source, preferable to a station battery bus if possible.

When all the poles of a breaker require series coils for overcurrent trips, it is necessary to place the reverse current trip device, of this type, "off pole" in the location of an additional pole to the right of the regular poles. In this case, the series coil is placed in series with the coil of an adjoining pole by placing a connection between the lower studs back of the mounting base. An upper stud is supplied for connection to the source, or the load, as desired. Extensions are provided for the main shaft and trip shaft to make provision for the resetting linkage and tripping. In such installations the current in the series coil is in the opposite direction from standard practice in which case it will be important that the potential coil should also be reversed.

For correct operation, the armature and magnet face must be kept clean. The armature should be firmly seated against the top leg and the vertical leg of the magnet. If adjustments are made to the reverse current device, the calibration should be checked after the adjustments are made.



ti
main
ise,
ever
(Pt.
ture

be-
ould
tial
bus,

quire
is
trip
lo-
t of
ries
f an
bar
ting
nec-
red.
shaft
re-
in-
coil
dard
tant
re-

ture
leg
ad-
rent
cked





FIG. 28 A
TRIPPED POSITION

(WITH LEFT COVER AND RESET MECHANISM REMOVED)



WIRING DIAGRAM
(BACK VIEW)




FIG. 28 B
POTENTIAL COIL ENERGIZED AND
BREAKER IN CLOSED POSITION

REVERSE CURRENT TRIP DEVICE (HINGED TYPE)

- | | | |
|--------------------------------------------------------------|----------------------------------------------------------------------------|------------------------------------------------------------------------------|
| 1. TERMINAL OF SERIES COIL | 11. ARMATURE ASSEMBLY | 22. PIVOTED ARMATURE |
| 2. LAMINATED SECTION OF MAGNET | 12. FRAMES | 23. MAIN SHAFT |
| 3. INSULATION | 13. STOP PIN | 24. SCREWS R.H. $\frac{1}{4}$ " - 20X $\frac{1}{2}$ " WITH |
| 4. SERIES COIL | 14. CALIBRATION PLATE | 25. RESET CRANK LOCKWASHER |
| 5. LOWER STUD | 15. CALIBRATION SPRING | 26. INSULATION LINK |
| 6. SOLID SECTION OF MAGNET | 16. CALIBRATION KNOB | 27. LINK |
| 7. SCREW HEX. NO. $\frac{1}{4}$ " - 20X $\frac{1}{2}$ " WITH | 17. CALIBRATION INDEX AND SCREW | 28. PIN AND COTTER FOR LINK |
| 8. INSULATION | 18. TRIGGER | 29. TORSION SPRING |
| 9. POTENTIAL COIL | 19. TRIP SHAFT | 30. RESET LEVER |
| 10. PIN AND COTTER FOR ARMATURE | 20. BEARING PLATE | 31. CRANK AND CLAMP |
| | 21. SCREWS R.H. $\frac{1}{4}$ " - 32X $\frac{1}{2}$ " WITH LOCK-
WASHER | 32. SCREWS HEX. NO. $\frac{1}{4}$ " - 20X $\frac{1}{2}$ "
WITH LOCKWASHER |




FIG. 29
SHUNT TRIP DEVICE

SHUNT TRIP DEVICE

A shunt trip device, Fig. 29, is available for AE-1-25 breakers which will trip the breaker when its coil is energized by closing a switch, or relay contacts, at some remote point. The coil is designed for intermittent service only, hence it should be so connected that the opening of the breaker, by any means, will open the shunt trip device circuit. The usual means is to place an "a" contact of an auxiliary switch in the shunt trip circuits, as shown in the wiring diagrams.

The device in the AE-1-25 breaker is mounted between the lower front part of the side plates that enclose the operating mechanism. It consists of a solenoid with a coil and armature in a vertical position, and, when energized, the armature is lifted into the coil which causes a pin in the upper end to engage the trip arm (Pt. 3) and trip the breaker. When de-energized, the armature falls by its own weight to the normal position.



The coil (Pt. 4) is mounted over a brass guide tube (Pt. 5) within which the armature (Pt. 7) is free to move. The fall of the armature is limited by the travel of a cotter pin (Pt. 10) in the armature pin against brass and cork washers in the top of magnet (Pt. 9). The guide tube (Pt. 5) is held in place by washer (Pt. 6) which is attached by screws

BELL ALARM DEVICE

This device, Fig. 30, together with HGA relay, and a push button switch, similar to the operating switch, Fig. 16, and in same position, is designed to provide a means of silencing the bell alarm after the breaker is automatically tripped and to prevent a bell alarm from ringing when the breaker manually tripped. It consists of a horizontally operated manual trip rod and button and an additional rod operated simultaneously and to the left of the main trip rod assembly. This latter rod operates the push button switch. Fig. 30 shows a plan view of the device and a wiring diagram of connection.

When the breaker is tripped automatically, a "b" contact of the auxiliary switch closed to ring the bell alarm through normally closed contacts of an HGA relay. Then when the hand trip button is operated the normally open contacts of the push button switch are closed to close a circuit to energize the relay. This opens the normally closed contacts of the relay to open the bell circuit and seals in the relay, thus silencing the bell.

When the breaker is tripped manually the trip button, the push button switch will be operated to energize the relay coil which will de-energize the bell alarm circuit, before the main trip rod will trip the breaker as described below, and prevent the operation of the bell alarm.



- | | |
|-------------------------------------------------------------------|----------------------------------|
| 1. TRIP ARM (SEE FIG. 10) | 7. BRACKET |
| 2. BREAKER TRIP SHAFT (SEE FIG. 10) | 8. YOKE WITH BOSS AND GROOV PINS |
| 3. LEFT FRAME OF OPERATING MECHANISM | 9. ROD |
| 4. SCREWS R.H. #10-32 X $\frac{3}{16}$ " WITH LOCKWASHERS | 10. BUTTON AND LOCKWASHER |
| 5. PUSH BUTTON SWITCH (SEE FIG. 16) | 11. SPRING |
| 6. ADJUSTING SCREW HEX. HD. #10-32 X $\frac{1}{8}$ " WITH LOCKNUT | 12. TRIP ROD ASSEMBLY |

FIG. 30
BELL ALARM DEVICE
(PLAN VIEW)


The device consists of a bracket (Pt. 7) attached to the left side of the operating mechanism frame (Pt. 3) by screws (Pt. 4). The main trip rod assembly (Pt. 12) with a trip button (Pt. 10) passes through this bracket and engages the breaker trip arm (Pt. 1). Spring (Pt. 11) normally keeps it disengaged. Another rod (Pt. 9) passes through this bracket parallel to rod (Pt. 12) and is operated by a yoke (Pt. 8) so that both rods operate simultaneously in the same direction when button (Pt. 10) is pressed. An adjusting screw (Pt. 6), in the rear of the rod (Pt. 9), provides the adjustment that the push button switch will be operated before the breaker trip arm is engaged. Thus the button can be operated by the operator at will to silence the bell alarm after the breaker is tripped automatically, or to manually trip the breaker without ringing the bell alarm.

SAFETY INTERLOCK FOR ENCLOSED BREAKERS

The purpose of this interlock (Fig. 31) is to make provision that the breaker will be tripped whenever the door of an enclosing case is opened.


The trip rod (Pt. 5) operates horizontally in a molded trip rod guide (Pt. 7) and extends through to the front of a molded handle (Pt. 9), mounted on the front of the enclosing case door (Pt. 12). The guide has lugs on the right and left sides which allow it to slide horizontally through slots in the molded support (Pt. 15). The support is attached to bracket (Pt. 2), which is attached to the operating mechanism side frames (Pt. 1).

The molded handle (Pt. 9) is inserted through the door (Pt. 12) and is attached to it by screws (Pt. 10) through the nameplate (Pt. 11). Spring (Pt. 8), backed up by contracted turns in the rear of the handle, exerts pressure to seal the steel washer (Pt. 14) and felt washer (Pt. 13) against the inside of the door. The rear end of the handle is internally threaded, and is screwed over the threaded front end of the trip rod guide (Pt. 7) when the door is closed, and, in so doing, draws the trip rod guide forward to the position as shown in Fig. 31. Compression spring (Pt. 6), backed up against the bracket (Pt. 2), forces the trip rod forward through




- | | | | |
|---------------------------------------------------------------|--------------------------|----------------------------------------------------------------------------|--------------------------------------------------------------------------|
| 1. OPERATING MECHANISM FRAME | 5. TRIP ROD | 10. SCREWS R.H. $\frac{1}{4}$ X $\frac{1}{2}$ SELF TAPPING WITH LOCKWASHER | 14. STEEL WASHER |
| 2. BRACKET | 6. COMPRESSION SPRING | 11. NAME PLATE | 15. MOLDED SUPPORT |
| 3. SCREWS R.H. $\frac{1}{4}$ X $\frac{1}{2}$ WITH LOCKWASHERS | 7. MOLDED TRIP ROD GUIDE | 12. ENCLOSED CASE DOOR | 16. COMPRESSION SPRING |
| 4. TRIP LEVER | 8. COMPRESSION SPRING | 13. FELT WASHER | 17. SCREWS R.H. $\frac{1}{4}$ X $\frac{1}{2}$ WITH WASHER AND LOCKWASHER |
| | 9. MOLDED HANDLE | | |

FIG. 31
INTERLOCK FOR ENCLOSED CASES



- | |
|----------------------------------------------------------------------|
| 1. SCREWS HEX. HD. $\frac{1}{4}$ - 20 WITH NUTS |
| 2. SPRINGS |
| 3. CONTACT FINGER |
| 4. STATIONARY STUD TERMINAL |
| 5. SCREW HEX. HD. $\frac{1}{8}$ - 18 X $\frac{1}{4}$ WITH LOCKWASHER |
| 6. SWIVELLED CABLE CLAMP |
| 7. WASHERS AND SHIMS |
| 8. RETAINING RING |
| 9. BREAKER LOWER STUD |
| 10. BREAKER UPPER STUD |
| 11. BREAKER BASE |
| 12. ENCLOSED CASE BASE |



1. COUPLING
2. SHAFT
3. SET SCREW 10-32 X 1/4 ALLEN HD. CUP PT.
4. SHAFT AND BRAZED PLATE
5. CLAMPING RING
6. STEEL DOOR
7. STEEL WASHER

8. SCREWS R.H. #2-36 X 1/2 WITH LOCKWASHERS
9. NAME PLATE
10. WASHER
11. MOLDED HANDLE
12. KNOB AND LOCKWASHER
13. SHIM
14. WASHER

FIG.33

MANUAL OPERATING HANDLE ASSEMBLY SWITCHBOARD FRONT PLATE

The guide (Pt. 7) and clear of the breaker trip lever (Pt. 4) when the door is closed. In this position the trip rod (Pt. 5) can be operated through the molded handle against compression spring (Pt. 6) to trip the breaker.

The design is such that the door cannot be opened until the handle is unscrewed from the trip rod guide (Pt. 7). When the handle is unscrewed, the compression spring (Pt. 16), backed up against the inside front end of the support (Pt. 15), forces the trip rod guide and trip rod to the rear to engage the breaker trip lever (Pt. 4) and trip the breaker whenever the door is opened.

DISCONNECTS FOR ENCLOSED BREAKERS

When type AE-1-25 breakers are to be installed in enclosed cases, spring maintained contact fingers are provided for both upper and lower studs. These have silver contact surfaces and automatically fit over stationary studs, with silver contact surfaces, mounted in the enclosed housing. Before the door of an enclosed case opens, Fig. 31, and before the breaker is removed from the enclosed case, the breaker is automatically opened, so that these contact fingers will not be called upon to open the breaker current, nor can the breaker be installed in the enclosure in the closed position.

Fig. 32 shows the contact fingers (Pt. 1) attached to the breaker studs by screws.

(Pt. 1), springs (Pt. 2) and retaining rings (Pt. 8). The stationary stud terminals (Pt. 4) are mounted on a base (Pt. 12) in the enclosed case. Power cables are connected to stationary stud terminals with swivelled cable clamps (Pt. 6).

MANUAL OPERATING HANDLE ASSEMBLY FOR SWITCHBOARD FRONT PLATES

On certain installations a disconnecting handle (Pt. 11) is provided and attached to the door to engage the shaft of the operating mechanism as shown in Fig. 33.

A clamping ring (Pt. 5) is attached to the steel door (Pt. 6) by three screws (Pt. 8) which pass through the nameplate (Pt. 9) and steel washer (Pt. 7). The shaft and plate (Pt. 4) are brazed together and pass through the door from the rear. Handle (Pt. 11), washer (Pt. 14) shim (Pt. 13) and washer (Pt. 10) are attached to the front of the shaft by knob (Pt. 12). When the door closes the rear end of the shaft (Pt. 4) engages coupling (Pt. 1) which is attached to shaft (Pt. 2) of the operating mechanism by set screw (Pt. 3).

To prevent undue friction in the movement of the handle it is recommended that a lubricant should be applied to the engaging surfaces between shaft and plate (Pt. 4) and the clamping ring (Pt. 5). Lubricate #130-A, G.E. Spec. D50H10 should be used.




FIG. 34
ELECTRICALLY OPERATED TYPE AEF-1 FIELD SWITCH (LIVE FRONT).

TYPE AEF-1 FIELD SWITCH

The type AEF-1 field switch, Fig. 34, is used for the control of generator or motor shunt field circuits. It consists of a regular two pole type AE-1-25 air circuit breaker, manually or electrically operated, automatic or non-automatic, as described herein, but equipped with a field discharge switch placed between the two main poles of the field switch. The contacts of the discharge switch are closed and opened by a self-contained mechanism connected to the main shaft of the field switch. The discharge switch is operated and constructed, as described below, to connect a discharge resistor across the shunt field terminals when the field switch opens the field circuit. The connection of this resistor prevents a high induced voltage across the field terminals caused by the rapid collapse of flux in the magnetic circuit of the shunt field.


This field switch is not used with synchronous condensers or synchronous motors which start on alternating current as induction motors at full or reduced voltage.

FIELD DISCHARGE SWITCH

The field discharge switch, Fig. 35 of the AEF-1 field switch consists of an upper stud (Pt. 7) with a silver alloy contact, a lower stud (Pt. 11) both mounted through the bases of both the field switch and the

pivoted on pin (Pt. 27) in the frame and an operating mechanism. The contact is connected to the lower stud by a connection (Pt. 12) and has a silver contact at the top which registers similar contact on the upper stud. The shaft (Pt. 18) is connected to the lever by crank (Pt. 20), link (Pt. 14), catch (Pt. 28) and spring (Pt. 26) as described below so that when shaft revolves clockwise (looking left) to open the field circuit, the contacts of the discharge switch will positively close before the contacts of the field switch. The closing of these contacts connects the discharge resistor directly across the terminals of the shunt field to discharge induced high voltage in the field, in the accompanying connection diagram 35 shows the discharge switch in the closed position.

When the main shaft revolves clockwise to close the main contact field switch, the spring rod (Pt. 32) is pulled forward through pin (Pt. 32) contact lever against the pressure spring (Pt. 30), but before locknuts (Pt. 33) engage the pin, the catch (Pt. 28) engages rivet (Pt. 29) also contact lever, and draws the contact lever forward to open the contacts far apart as the lower end of catch (Pt. 28) moves over the kick-off screw (Pt. 22) as the catch disengages the rivet.



1. BARRIER FOR ARC CHUTE
2. POLE PIECE OF ARC CHUTE
3. SUPPORT FOR ARC CHUTE
4. RIVETED PIN
5. SCREW R.H. SELF TAPPING *6 x 1"
6. BASE
7. UPPER STUD AND CONTACT
8. MAGNET
9. RIVETED PIN
10. SCREW R.H. SELF TAPPING *8 x $\frac{3}{8}$ " FOR PT. 35
11. LOWER STUD
12. FLEXIBLE CONNECTION (INCLUDED IN PT. 34)

13. SCREW R.H. #10-32 X $\frac{5}{8}$ " WITH LOCKWASHER AND NUT
14. CRANK
15. PIN AND SPACER
16. TENSION SPRING
17. LINK
18. MAIN SHAFT
19. SCREW HEX. HD. $\frac{1}{4}$ " - 20 X $\frac{5}{8}$ " WITH LOCKWASHER
20. CRANK AND CLAMP
21. PIN, COTTER PIN AND SPACER
22. SCREW R.H. #10-32 X $\frac{5}{8}$ " WITH LOCKWASHER AND NUT
23. FRAME
24. RIVET AND WASHERS

- 25. RIVET
- 26. SPRING ROD
- 27. PIN, COTTER PIN AND SPACER
- 28. CATCH
- 29. RIVET
- 30. COMPRESSION SPRING
- 31. WASHER
- 32. PIN
- 33. LOCKNUTS AND LOCKWASHER
- 34. CONTACT LEVER
- 35. BARRIER FOR LIVE FRONT SWITCHES

FIG. 35
FIELD DISCHARGE SWITCH
WITH FIELD SWITCH IN OPEN POSITION

to the rear allows compression spring (Pt. 30) to force the contact lever in the closing direction but the contacts do not close because pin (Pt. 32) is stopped by the locknuts to keep the contacts apart 1/8 of an inch.

Then when the field switch opens and the main shaft revolves clockwise, the spring rod and locknuts move to the rear to close the discharge switch contacts.

An arc chute encloses the contacts with a barrier (Pt. 1) and pole pieces (Pt. 2) on each side and supported to the field switch base by support (Pt. 3), rivets (Pt. 4) and self-tapping screw (Pt. 5). A magnet (Pt. 8) is supported between the barriers below the upper stud (Pt. 7) by rivet (Pt. 9). In live front field switches barriers (Pt. 35) are attached to the discharge switch base (Pt. 6) by self-tapping screws (Pt. 10).

The first adjustment consists of adjusting the kickoff screw (Pt. 22) so that the catch (Pt. 28) disengages rivet (Pt. 29) just before the field switch is fully closed.



The second adjustment consists of adjusting the locknuts (Pt. 33) on spring rod (Pt. 26) until the contacts of the discharge switch are 1/8 of an inch apart when the field switch is fully closed.

TYPE AE-1-25YI AIR CIRCUIT BI

This breaker is designed for the protection of resistance welding machines; it can trip at higher current than provided with the regular instantaneous trip device as shown in Fig. 35. The breaker differs from the regular AE-1-25 breaker only in the provision of a special trip shaft to allow large travel of the instantaneous over trip device for current settings above 1500 amperes.

Standard calibration ranges are 1500 amperes, 1400 to 4000 amperes to 5000 amperes. Within reasonable other ranges can be provided where the test calibration settings will not be approximately 2-1/2 times the lowest calibration setting.

As the duty imposed on the AE breaker is intermittent and quite variable depending upon various types of welds to be done, the breaker is not given a continuous current rating. It is designed to carry "during-weld amperes" or "during-weld KVA" at welding periods not to exceed the corresponding "duty-cycle" as tabulated in Fig. 36.



Duty Cycle	During-weld AMP Rms	During-weld KVA		
		220 Volts	440 Volts	550 Volts
0.03	4040	890	1780	2225
0.04	3500	770	1540	1925
0.05	3130	689	1378	1722
0.06	2860	629	1258	1574
0.07	2640	580	1161	1453
0.08	2740	544	1087	1360
0.09	2330	513	1025	1282
0.10	2215	487	974	1219
0.20	1566	345	689	861
0.30	1278	281	562	703
0.40	1107	244	487	609
0.50	990	218	436	545

WIRING DIAGRAMS

Figs. 37 and 38 show schematic wiring diagrams for electrically operated AE-1-25 breakers with momentary and maintained contact control switches respectively. Fig. 39 and 40 show typical wiring diagrams with the

momentary and maintained contact control switches respectively.

The standard arrangement for direct current circuits is to have voltage coils connected solidly to the negative bus or line where possible.

OUT-OFF DEVICE FN.17 IS MECHANICALLY PICKED UP BY CLOSING MECHANISM OF BREAKER

2'-AUX. SW. OPEN WHEN BREAKER IS OPEN.
3'-AUX. SW. CLOSED WHEN BREAKER IS OPEN.

1- CONTACT OPEN WHEN DEVICE IS IN THE DE-ENERGIZED OR NON-OPERATED POSITION.
4- CONTACT CLOSED WHEN DEVICE IS IN THE DE-ENERGIZED OR NON-OPERATED POSITION.

TERMINAL BOARDS FOR CONTROL WIRING ARE PROVIDED WITH STANDARD BREAKERS. CONNECT CONTROL POWER TO TERMINAL POINTS 1 AND 2. IF D.C. POWER IS USED MAKE 1 POSITIVE AND 2 NEGATIVE. FOR REMOTE OPERATION CONNECT THE CLOSING SWITCH BETWEEN TERMINAL POINTS 1 AND 3 AND THE TRIPPING SWITCH BETWEEN TERMINAL POINTS 1 AND 4.




FIG. 37

SCHEMATIC WIRING
FOR ELECTRICALLY OPERATED AE-1-25 BREAKER
WITH MOMENTARY CONTACT CONTROL SWITCH




FIG. 38

SCHEMATIC WIRING
FOR ELECTRICALLY OPERATED AE-1-25 BREAKER
WITH MAINTAINED CONTACT CONTROL SWITCH




FIG. 39

TYPICAL WIRING DIAGRAM
FOR ELECTRICALLY OPERATED AE-1-25 BREAKER
WITH MOMENTARY CONTACT CONTROL SWITCH




FIG. 40.

TYPICAL WIRING DIAGRAM
FOR ELECTRICALLY OPERATED AE-1-25 BREAKER
WITH MAINTAINED CONTACT CONTROL SWITCH

SPARE PARTS

Item	Pt.	Fig.	Item	Pt.	Fig.
CONTACT STUDS, POLE UNIT ASSEMBLY					
1 Upper Stud, Blowout Coil and Arc Runner Assembly.....	4,6,30	8	27 Screw RH 1/4"-20 with Washer, Lockwasher and Nut.....	18	8
Upper Stud, Blowout Coil and Arc Runner Assembly.....	7	7	Screw RH 1/4"-20 with Washer, Lockwasher and Nut.....	14	7
2 Series Coil, Lower Stud Assembly.....	See Overcurrent Devices		Screw RH 1/4"-20 with Washer, Lockwasher and Nut.....	2	8
3 Insulation.....	29	8	28 Screws Hex. Hd. 1/4"-20 with Washer and Lockwasher.....	15	7
4 Core.....	2	8	Screws Hex. Hd. 1/4"-20 with Washer and Lockwasher.....	3	18
"	6	7	29 Screws RH 1/4-20 with Lock washers.....	17	7
5 Insulation.....	3	8	Screws RH 1/4-20 with Lock washers.....	6	18
6 Stationary Arcing Contact...	28	8	Screws RH 1/4-20 with Lock washers.....	10	26
7 Screws RH 5/16-18 with lockwasher.....	1	8	30 Trip Shaft.....	20	7
Screws RH 5/16-18 with lockwasher.....	5	7	"	18	10
8 Screws RH #10-32 with Washer and Lockwasher.....	5	8	"	5	25
Screws RH #10-32 with Washer and Lockwasher.....	8	7	"	19	28
9 Screws RH #6-40 x 1/2" with Lockwashers.....	25	8	"	2	29
10 Bracket.....	8	8	"	2	30
"	11	7	ARC QUENCHER		
"	7	18	31 Side Plates.....	23	7
"	9	26	32 Support for Arc Quencher...	1	7
11 Screws RH 1/4-20 with Lockwasher and Nut.....	7	8	33 Screw RH 5/8"-18 with Lockwasher.....	2	7
Screws RH 1/4-20 with Lockwasher and Nut.....	9	7	34 Locking Plate and Self-Tapping Screws.....	3	7
Screws RH 1/4-20 with Lockwasher and Nut.....	6	18	35 Screws RH #10-32 x 2-1/2 with Lockwashers and Nuts..	4	7
12 Screws Hex. Hd. 1/4"-20 with Lockwasher.....	17	7	36 Pole Piece Plates.....	35	7
Screws Hex. Hd. 1/4"-20 with Lockwasher.....	18	8	37 Screws RH. #10-32 x 2-3/4 with Lockwasher and Nuts...	28	7
Screws Hex. Hd. 1/4"-20 with Lockwasher.....	8	18	38 Front Arc Runners.....	26	7
13 Movable contact and Silver Contact.....	24	8	39 Insulation Blocks.....	30	7
14 Movable Arcing Contact.....	27	8	40 Screws RH #10-32 x 1/4" with Lockwasher and Washer.....	25	7
15 Screw RH #6-40 x 3/8" with Lockwasher.....	26	8	41 Screws RH #10-32 x 1/2.....	29	7
16 Adjusting Screw RH 5/16" - 18 x 1-1/4 with washer, Lockwasher and Nut.....	23	8	42 Screws R.H. #10-32 x 1/2 with Lockwashers and Nuts..	27	7
17 Screw Hex. Hd. 5/16"-18 x 7/8" with Lockwasher and Washer.....	21	8	43 Baffles.....	31	7
18 Pin and Cotter Pins.....	22	8	44 Screws R.H. #10-32 x 2-5/8" with Lockwashers and Nuts..	34	7
19 Contact Support.....	13	8	45 Pins, Copper.....	33	7
"	12	7	46 Pins, High Melting Point...	32	7
20 Clamp.....	15	8	OPERATING MECHANISM		
21 Screw, Hex. Hd. #4-20 x 5/8" with Lockwasher.....	16	8	47 Manual Closing Handle.....	23	1
22 Compression Spring.....	12	8	48 Eccentric Shaft.....	1	1
23 Spring Guide.....	10	8	49 Link.....	2	1
24 Pin.....	11	8	50 Block and Guide Pin.....	3,4	1
25 Main Shaft.....	14	8	51 Pin.....	5	1
"	13	7	52 Closing Links.....	6	1
"	29	10	53 Toggle Links, A,B,C,D.....	8	1
"	30	25	54 Pin in Frame.....	9	1
"	18	34	55 Pin in Frame.....	10	1
26 Flexible Connection.....	19,20	8	56 Torsion Spring.....	11	1
			57 Latch.....	12	1
			58 Pin in Frame.....	13	1

Item	Pt.	Fig.	Item	Pt.	Fig.
60 Spring.....	14	10	102 Cover.....	5	15
61 Prop.....	15	10	103 Cam and Toothed Bushing.....	6	15
61 Latch Plate.....	17	10	104 End Frame.....	7	15
62 Frame.....	19	10	105 Crank, Pin and Cotter Pin....	8	15
".....	2	13	106 Link.....	9	15
".....	3	17	107 Shaft.....	10	15
".....	3	30			
63 Trip Arm.....	20	10	OPERATING SWITCH		
".....	3	29	108 Mounting Bracket.....	12	16
".....	1	30	109 Screw R.H. #8-36 x 3/4 with		
".....	4	31	Nut and Lockwasher.....	11	16
64 Pin in Frame.....	21	10	110 Molded Base.....	8	16
65 Cam.....	22	10	111 Contact Brackets and Bind-		
66 Outer and Inner Springs.....	25	10	ing Screws.....	1	16
67 Spring Guide.....	24	10	112 Screw R.H. #10-32 x 3/4 with		
68 Cam Stop Pin.....	26	10	Lockwasher.....	13	16
69 Operating Cam.....	27	10	113 Operating Rod.....	10	16
70 Bracket.....	28	10	114 Spring.....	9	16
			115 Washer.....	7	16
ADJUSTMENT ECCENTRICS FOR TRIP ARM AND LATCH			116 Contact Spring.....	6	16
71 Eccentric with 1/4"-20			117 Insulation.....	5	16
Threaded Shank.....	4	11	118 Movable Contact Strip.....	4	16
72 Nut 1/4"-20.....	3	11	119 Guide.....	3	16
73 Eccentric.....	8	11	120 Screw R.H. #4-40 x 1-1/4		
74 Screw, Hex. Hd. #10-32 x			with Washers.....	2	16
7/16" with Lockwasher.....	9	11			
75 Buffer Spring.....	10	11	CUT-OFF DEVICE		
			121 Flanged Bracket.....	2	17
SOLENOID OPERATING MECHANISM			122 Pin and Cotter Pin in		
76 Magnet.....	1	13	Bracket.....	4	17
77 Coil.....	3	13	123 Flat Spring.....	5	17
Armature.....	4	13	124 Pin in Armature.....	6	17
Pin in Armature.....	5	13	125 Screws R.H. #8-36 x 3/8"		
".....	6	17	with Lockwashers.....	7	17
80 Pin in Frame.....	6	13	126 Magnet.....	10	17
81 Maintenance Closing Handle...	7	13	127 Coil.....	11	17
			128 Armature.....	8	17
CLOSING RELAY			129 Brass Guides.....	9	17
82 Magnet.....	1	14	130 Pin in Armature.....	13	17
83 Coil.....	2	14	131 Washer and Cotter Pin.....	12	17
84 Brass Guide.....	3	14	132 Screw and Locknut.....	14	17
85 Armature.....	4	14	133 Operating Rod.....	15	17
86 Stationary Contacts.....	5	14	134 Spring.....	16	17
87 Binding Screws and Lock-			135 Contact Brackets and Bind-		
washers.....	6	14	ing Screws.....	17	17
88 Movable Contact Assembly.....	7	14	136 Movable Contact Strips.....	18	17
89 Pin and Cotter Pin.....	8	14	137 Contact Spring.....	19	117
90 Insulation Angle.....	9	14	138 Guide.....	20	17
91 Screw, R.H. Self-Tapping			139 Screw, R.H. #4-40 x 1-1/4		
#8 x 3/8 with Lockwasher.....	10	14	with Washers.....	21	17
92 Relay Base.....	11	14	140 Screw R.H. #8-36 x 3/4		
93 Screw F.H. #10-32 x 3/4".....	12	14	with Lockwasher and Nut.....	1	17
94 Screw FH #8-36 x 1/2.....	13	14	141 Molded Base.....	22	17
95 Screw RH #10-32 with Lock-			142 Screw R.H. #8-36 x 3/4" with		
washer and Nut.....	15	14	Lockwasher and Nut.....	1	17
96 Screw R.H. Self-Tapping #6			MAGNETIC OVERCURRENT TRIP DEVICE (OIL-FILM		
x 3/16".....	16	14	TYPE)		
97 Screw R.H. Self-Tapping #4			143 Series Coil, Lower Stud and		
x 1/4".....	17	14	Terminal.....	5,9	18
			Series Coil, Lower Stud and		
ROTARY TYPE AUXILIARY SWITCH			Terminal.....	3,4	23
98 Molded Barriers.....	1	15	Series Coil, Lower Stud and		
Movable Contact Assembly.....	2	15	Terminal.....	4,5	28
Stationary Contact Assembly..	3	15	144 Magnet.....	4	18
Stationary Contact Support...	4	15	".....	2	23

[illegible]

Item	Pt.	Fig.	Item	Pt.	Fig.
REVERSE CURRENT TRIP DEVICE			288 Insulation Washer.....	8	28A
243 Series Coil and Connection Bars.....	5	26	289 Potential Coil.....	9	28A
244 Core.....	41	26	290 Pin and Cotter Pin.....	10	28A
245 Screws Hex. Hd. 3/8"-16 x 1-1/4 with Lockwasher.....	3	26	291 Armature Assembly.....	11	28A
246 Supports.....	2	26	292 Frame.....	12	28A
247 Upper Connection Bar Support.....	40	26	293 Pivoted Armature.....	22	28A
248 Screws R.H. 1/4"-20 x 1" with Lockwashers and Nuts... and Insulating Washers and Bushings.....	4	26	294 Stop Pin.....	13	28A
249 Screws Hex. Hd. 3/8"-16 x 1-1/2" with Washer, Lockwasher and Nut.....	6	26	295 Trigger.....	18	28A
250 Lower Stud.....	7	26	296 Bearing Plate.....	20	28A
251 Insulation Tube.....	42	26	297 Screws R.H. #10-32 x 3/8" with Lockwasher.....	21	28A
252 Insulation Washers.....	11	26	298 Calibration Plate.....	14	28A
253 Screws, Hex. Hd. 5/16-18 x 1-1/4 with Lockwashers.....	1	26	299 Calibration Spring.....	15	28A
254 Armature Shaft.....	14	26	300 Calibration Knob.....	16	28A
255 Rear Bronze Bearing.....	38	26	301 Calibration Index and Screw..	17	28A
256 Screws, Hex. Hd. 5/16-18 x 7/8" with Lockwashers.....	37	26	302 Reset Crank.....	25	28B
257 Front Bronze Bearing.....	33	26	303 Screw Hex. Hd. 1/4"-20 x 1/2" with Lockwasher.....	24	28B
258 Studs.....	34	26	304 Insulation Link.....	26	28B
259 Nuts, Hex. 5/16-18 with Lockwashers.....	31	26	305 Link.....	27	28B
260 Spacers with Nut Housings...	32	26	306 Pin and Cotter Pins.....	28	28B
261 Thrust Washer and Insulation Washers.....	35	26	307 Torsion Spring.....	29	28B
262 Grommet.....	36	26	308 Reset Lever.....	30	28B
263 Armature.....	45	26	309 Crank and Clamp.....	31	28B
264 Coil.....	44	26	310 Screws Hex. Hd. 1/4-20 x 5/8" with Lockwasher.....	32	28B
265 Pole Shoes.....	43	26	SHUNT TRIP		
266 Dust Covers.....	46	26	311 Coil.....	4	29
267 Screws, R.H. Self-Tapping #8 x 3/8" with Washer and Lockwasher.....	47	26	312 Guide Tube.....	5	29
268 Escutcheon Plate.....	30	26	313 Washer.....	6	29
269 Posts.....	29	26	314 Trip Armature.....	7	29
270 Trip Crank.....	13	26	315 Button.....	8	29
271 Screw, Hex. Hd. #10-32 x 9/16" and Lockwasher.....	15	26	316 Magnet.....	9	29
272 Set Screw, Cup Point #8-36 x 1/8".....	16	26	317 Cotter Pin and Washer.....	10	29
273 Calibration Spring.....	20	26	BELL ALARM DEVICE		
274 Calibration Index.....	19	26	318 Bracket.....	7	30
275 Calibration Plate.....	18	26	319 Screws R.H. #10-32 x 5/16" with Lockwashers.....	4	30
276 Screws, R.H. #10-32 x 3/8" with Lockwasher.....	28	26	320 Adjusting Screw Hex. Hd. #10-32 x 1-1/8" with Lockout.....	6	30
277 Calibration Screw Hex. Hd. Washer and Cotter Pin.....	17	26	321 Yoke with Boss and Groov Pins.....	8	30
278 Compression Spring.....	21	26	322 Rod.....	9	30
279 Stop Screw with Lockwasher and Nut, Reverse.....	12	26	323 Button and Lockwasher.....	10	30
280 Stop Screw with Lockwasher and Nut, Normal.....	22	26	324 Spring.....	11	30
281 Pin, Washer and Cotter Pin..	26	26	325 Trip Rod Assembly.....	12	30
282 Spacer.....	27	26	INTERLOCK FOR ENCLOSED BREAKERS		
283 Trip Rod Assembly.....	25	26	326 Bracket.....	2	31
284 Trip Lever.....	24	26	327 Screw R.H. #10-32 x 5" with Lockwasher.....	3	31
REVERSE CURRENT TRIP DEVICE (HINGED ARMATURE)			328 Trip Rod.....	5	31
285 Laminated Section of Magnet.	2	28A	329 Compression Spring.....	6	31
286 Solid Section of Magnet.....	6	28A	330 Molded Trip Rod Guide.....	7	31
287 Screw Fil. Hd. A, 1/4"-20 x 3/4".....	7	28A	331 Compression Spring.....	8	31
			332 Molded Handle.....	9	31
			333 Screws, R.H. #4 x 3/16" Self-Tapping with Lockwasher.....	10	31
			334 Nameplate.....	11	31
			335 Felt Washer.....	13	31
			336 Steel Washer.....	14	31
			337 Molded Support.....	15	31
			338 Compression Spring.....	16	31

<u>Item</u>	<u>Pt.</u>	<u>Fig.</u>	<u>Item</u>	<u>Pt.</u>	<u>Fig.</u>
339 Screws, R.H. #8-36 x 1/2" with Washer and Lockwasher....	17	31	365 Support for Arc Chute.....	3	35
DISCONNECTS FOR ENCLOSED BREAKERS			366 Riveted Pin.....	4	35
340 Screws, Hex. Hd. 1/4"-20 x 4 with Nuts.....	1	32	367 Screws, R.H. Self-Tapping #6 x 1".....	5	35
341 Springs.....	2	32	368 Base.....	6	35
342 Contact Fingers.....	3	32	369 Upper Stud and Contact and Nuts.....	7	35
343 Stationary Stud Terminal.....	4	32	370 Magnet.....	8	35
344 Screws Hex. Hd. 5/16-18 x 3/4 with Lockwasher.....	5	32	371 Riveted Pin.....	9	35
345 Swivelled cable clamp.....	6	32	372 Screws R.H. Self-Tapping #8 x 3/8".....	10	35
346 Washers and Shims.....	7	32	373 Lower Stud and Nuts.....	11	35
347 Retaining Ring.....	8	32	374 Screws R.H. #10-32 x 5/8" with Lockwasher and Nut.....	13	35
348 Breaker Lower Stud.....	9	32	375 Crank.....	14	35
349 Breaker Upper Stud.....	10	32	376 Pin and Spacer.....	15	35
350 Enclosed Case Base.....	12	32	377 Torsion Spring.....	16	35
MANUAL OPERATING HANDLE ASSEMBLY FOR SWITCH-BOARD FRONT PLATES			378 Link.....	17	35
351 Coupling.....	1	33	379 Screws, Hex. Hd. 1/4"-20 x 5/8" with Lockwasher.....	19	35
352 Set Screw.....	3	33	380 Crank and Clamp.....	20	35
353 Shaft and Plate.....	4	33	381 Pin, Cotter Pins and Spacer..	21	35
354 Clamp Ring.....	5	33	382 Screw, R.H. #10-32 x 5/8" with Lockwasher and Nut.....	22	35
355 Steel Washer.....	7	33	383 Frame.....	23	35
356 Screws R.H. #8-36 x 1/2 with Lockwashers.....	8	33	384 Rivet and Washers.....	24	35
357 Nameplate.....	9	33	385 Rivet.....	25	35
358 Washer.....	10	33	386 Spring Rod.....	26	35
359 Molded Handle.....	11	33	387 Pin, Cotter Pins and Spacer..	27	35
360 Knob.....	12	33	388 Catch.....	28	35
361 Shim.....	13	33	389 Rivet Stop.....	29	35
362 Washer.....	14	33	390 Compression Spring.....	30	35
FIELD DISCHARGE SWITCH			391 Washer.....	31	35
363 Barrier for Arc Chute.....	1	35	392 Pin.....	32	35
364 Pole Piece for Arc Chute.....	2	35	393 Locknuts and Lockwasher.....	33	35
			394 Contact Arm and Flexible Connection.....	34	35
			395 Barrier.....	35	35