
SIEMENS-ALLIS

Installation • Operation • Maintenance • Parts

Instructions

**FB-500A1, FC-500B and
FC-750B Air Magnetic
Circuit Breakers
SG-3208**

CONTENTS

TABLE OF CONTENTS

Introduction

Field Service Operation	1
Warranty	1
Receiving	1
Storage	1
Circuit Breaker Preparation	1
Handling Instructions	2

Circuit Breaker Description

Arc Interruption	5
Operator	5
Stored Energy Operator — Components	
Nomenclature	5
Stored Energy Operator	6
Reclosing Control	6
Auxiliary Equipment	8
Auxiliary Switch	8
Capacitor Trip Device	9
Trip Solenoid	9
Arc Chute Assembly	9
Circuit Breaker Operation	13

Stored Energy Operator Description of Operation

Spring Charging Cycle	14
Reclosing Control	14
Breaker Closing Cycle	15
Spring Recharge After Closing	15
Tripping Cycle	15
Electrical Control	15
Spring Charging	15
Closing Circuit	15
Close Latch — Mechanical and Electrical	
Interlocks	17

Adjustments

Circuit Breaker Timing	18
Phase Barrier Assembly	18
Tilting Arc Chutes	19

Barrier Stacks	19
Contact Pressure of Hinge Joint	19
Arcing Contact Hinge Joint	19
Contact Alignment and Replacement	19
Auxiliary Switch	20
Interlock Plunger	20
Trip Latch Adjustments	21
Trip Latch Check Sensor Adjustments	22
Manual Charging of Closing Springs	23
Maintenance Slow Close	23
Removal of Spring Blocking Device	23
Removal of Closing Springs	25
Motor Cutoff Switch	25
Motor Cutoff Switch Adjustment	26
Close Latch Bite Adjustment	26
Close Latch Check Switch Adjustment	26
Free Height Adjustment	26
Trip Adjustment	26
Overtravel	26
Close Latch Mechanical Interlock	29

Maintenance and Testing

General	31
"As Found" Tests	31
Periodic Inspection and Maintenance	31
Contacts	31
Disconnect Arm Hinge Joint	32
Arc Chutes	32
Mechanism — Stored Energy Operator	32
Lubrication	33
Air Puffers	33
"As Left" Tests	35

Parts

Instructions	38
--------------------	----

CONTENTS

ILLUSTRATIONS

Figure 1.	Circuit Breaker Handling Instructions	2	Figure 13.	Maintenance Close Spring Blocking Device Insertion	24
Figure 2.	Typical Circuit Breaker Assemblies	3	Figure 14.	Motor Cutoff Switch	25
Figure 2A.	Arc Chute Support in Position	4	Figure 15.	Close Latch Bite and Check Switch Adjustments	27
Figure 3.	515-2 Operator Left Hand View	6	Figure 15A.	Spring Release Solenoid Armature Cap Adjustment	28
Figure 4.	Breaker Contacts	7	Figure 16.	Closing Spring Discharge Mechanism	29
Figure 5.	Type Q-10 Auxiliary Switch	8	Figure 17.	Close Latch Mechanical Interlock	30
Figure 6.	Arc Chutes	9	Figure 18.	Frame and Operator, Drive Assembly and Linkage Assembly Lubrication ...	34
Figure 7.	515-2 Operator Right Hand View	11	Figure 19.	Lubrication Points on Breaker	35
Figure 8.	515-2 Operator Front View	12	Figure 20.	Lubrication Chart	36
Figure 9.	Control Scheme for Stored Energy Operator	16			
Figure 10.	Stud and Support Assembly	18			
Figure 11.	Trip Latch Clearance Adjustment	21			
Figure 12.	Trip Latch Bite and Check Switch Adjustments	22			

INTRODUCTION

Page 1

This instruction manual contains installation, operation and maintenance information for Types FB-500A1 7.2 kV, FC-500B 13.8 kV, and FC-750B 13.8 kV stored energy operated air magnetic circuit breakers.



DANGER!

Due to the nature of electrical equipment of this voltage class, there is inherent danger through improper use resulting in possible exposure to high electrical voltage. Only qualified persons thoroughly familiar with these instructions should be allowed to operate these devices. Improper use or procedures can result in serious personal injury or death.

FIELD SERVICE OPERATION

Siemens-Allis can provide competent, well-trained Field Service Representatives to provide technical guidance and advisory assistance for the installation, overhaul, repair and maintenance of Siemens-Allis equipment, processes and systems. Contact regional service centers, sales offices or factory for details.

WARRANTY

The sales contract carries all information on warranty coverage.

RECEIVING

Circuit breakers are shipped from the factory completely assembled. Observe weight markings on crates and ensure that capable handling equipment is used.

Remove crating carefully with the correct tools. Check each item with the shipping manifest. If any shortage or damage is found, immediately call it to the attention of the local freight agent handling the shipment. Proper notation should be made by him on the freight bill. This prevents any controversy when claim is made and facilitates adjustment.

When handling breaker (Fig. 1) with a crane or hoist, lifting cables should completely encircle breaker frame. Use a

chutes. Do not attach lifting hooks, rope, etc., to bushings, insulating parts, fittings, etc. Do not slide breaker off shipping skid without using ramp blocks (T-Shaped pieces provided) as interlock plunger and linkage may be damaged.

STORAGE

Indoor — The circuit breaker should be installed as soon as possible. If storage is necessary, it should be kept in a clean dry place where it will not be exposed to dirt, corrosive atmospheres or mechanical abuse.

Outdoor — Outdoor storage of circuit breakers is not recommended. If breakers must be stored outdoors, they must be covered completely and a heat source provided to prevent condensation and subsequent corrosion.

If the circuit breaker must be stored for some time, "As Found" tests are desirable. (See page 19.)

CIRCUIT BREAKER PREPARATION


Prepare the circuit breaker for insertion into its cubicle as follows:

1. Remove Packaging. Note: Breakers are shipped in closed position with the trip rod and foot lever enclosed by packaging to prevent opening during shipment. (See Fig. 1.)
2. Push manual trip rod to open breaker.
3. Remove phase barriers and unfasten both front and rear blowout coil connections. (See "Phase Barrier Assembly," page 11.)
4. With arc chute support in place at the rear of the breaker, tilt the arc chutes (refer to page 15 for details) to expose contact area.
5. Remove dust, foreign particles, etc., from breaker.
- 5A. Inspect ceramics for possible shipping damage.
6. Check for mechanical freedom of disconnect arm movements by slowly closing the breaker. Reference page 15 for Slow Close Procedure.
7. Trip breaker by depressing trip rod, Figure 2, Item 43.
8. Return arc chutes to upright position, FASTEN BOTH


INTRODUCTION

Page 2


HANDLING INSTRUCTIONS



A Move breaker to location with crane or fork lift. Carefully remove protective plastic cover or crate.



B Remove ramp pieces nailed to the pallet at the front and rear of the breaker.




D Place ramp pieces in front of the pallet in line with breaker wheels and nail to pallet as shown by arrows.




DANGER!

REMOVE PACKAGING. BREAKERS ARE SHIPPED IN CLOSED POSITION WITH THE TRIP ROD AND FOOT LEVER ENCLOSED BY PACKAGING TO PREVENT OPENING DURING SHIPMENT (C).



C Remove hold down bolts located on each side of breaker.



E Slowly roll breaker off pallet.

FC-500A, FB-500A-1

BESURE THAT THE SMALL BRASS SPACER WASHER IS INSTALLED NEXT TO CUP INSERT IN CONTACT ASSEMBLY TO ALLOW FOR FLOATING ACTION OF ASSEMBLY. THIS IS REQUIRED AS PART OF SELF-ALIGNING FEATURE.

Diagram of the piston and spring assembly. Labels include: Puffer, Ty-Rap, See Note 2, Spring, Hose, Clamp, and View "B".




Figure 2. Typical Circuit Breaker Assemblies

INTRODUCTION

Page 4



Figure 2A. Arc Chute Support in Position

TIONS and replace phase barriers. Be sure screws on all phases are tightened securely.

9. Install plug jumper and energize control. (Springs should charge.)
10. Close breaker.
11. Trip breaker.
12. Depress foot lever and close electrically (*).

13. Release foot lever and repeat steps 10 (#) and 11.
14. De-energize control power and remove plug jumper.
15. Coat movable primary and secondary disconnects with a light film of S-A contact lubricant, 15-171-370-002.
16. Insert breaker into its cubicle to "disconnect" position and close manually (*).
17. Complete movement of breaker to "test" position and repeat steps 10 (#) and 11.
18. Check for proper alignment between stationary and movable secondary contacts. Check for proper alignment between auxiliary switch bayonet on cubicle wall and operating fork on breaker.



DANGER!

Before proceeding with step 19 check to insure that line and bus circuits are not energized. Failure to do so may result in electrical shock or burn causing death or serious personal injury and property damage.

19. With line and bus de-energized, rack breaker into fully connected position. Close and trip breaker from main control panel. If bus or line are energized, get clearance before beginning this step.
20. Lock out Kirk interlock (if provided) and repeat step 10 (*).
21. Open interlock and repeat steps 10 (#) and 11.
22. Breaker is now ready for normal operation.

- (*) Breaker is trip free.
(#) Breaker will close.

CIRCUIT BREAKER DESCRIPTION

Page 5

A typical circuit breaker consists of primary disconnect, arc chute, and operator sections. The primary disconnect section contains the main contact which supplies power to the load. The arc chute section dissipates the power arc energy drawn during the opening of the main contacts. The operator section contains the mechanism used to close and open the main contacts. This mechanism consists of a stored energy operator with its associated control circuitry.

ARC INTERRUPTION

Arc interruption is accomplished in free air at atmospheric pressure with the aid of a self-induced, magnetic blowout field and forced air draft. When the trip solenoid is energized, load current is being carried by the main contacts. As the contacts open, the main contacts part first and the current is transferred to the arcing contacts. When the arcing contacts part, an arc is established between them.

The arc between the arcing contacts is transferred to the arc runners as the arcing contacts open. The transfer of the arc to the arc runner establishes full current flow through the blowout coils, setting up a strong magnetic field. The magnetic field, accompanied by the natural thermal effects of the heated arc, tends to force the arc upward into the barrier stack. The large surfaces of the barrier stack cool and de-ionize the arc, while the V-shaped slots in the stack reduce its cross-section and elongate it, leading to rapid extinction. The arc runners are made of wide, heavy material for maximum heat dissipation and for minimum metal vaporization.

A puffer mechanism provides a forced air draft through the main contact area. This aids the magnetic blowout field and natural thermal effects in forcing the arc into the barrier stack for easy extinction.

OPERATOR

The breaker is closed by the stored energy operator straightening a toggle in the four-bar linkage (12, Fig. 7). The operator is powered by precharged springs (stored energy).

STORED ENERGY OPERATOR - COMPONENTS NOMENCLATURE

To be used with "Description of Operation" Figures 3, 7 and 8.

1. Spring Charging Motor
2. Driving Pawl
3. Eccentric Drive Shaft
4. Ratchet Wheel
5. Holding Pawl
6. Closing Springs
7. Cams
8. Spring Release Rollers
9. Close Latch
10. Motor Cutoff Switch
11. Linkage Reset Spring
12. Four Bar Linkage
13. Spring Release Solenoid
14. Cam Follower Rollers (Main Toggle Roll)
15. Radius Arm
16. Close Latch Check Switch
17. Trip Solenoid
18. Trip Latch
20. Latch Roller
22. Spring Discharge Roller Free Height Adjustment
23. Spring Discharge Close Latch Yoke End Adjustment
24. Spring Discharge Roller
25. Charge Discharge Indicator
26. Discharge Indication Adjustment
27. Charge Indication Adjustment
28. Mechanical Charging Interlock Adjustment
29. Manual Charging Shaft and Gear Box
30. Anti-Pumping Relay
31. Trip Latch Bite Adjusting Screw
32. Trip Latch Bite Adjusting Screw Locking Nut
33. Close Latch Bite Adjusting Screw
34. Close Latch Bite Adjusting Screw Locking Nut
35. Motor Cutoff Switch Actuator
36. Lower Link Stop
37. Roll Pin Striker
38. Aluminum Spring Drive Blocks
39. Spring Discharge Connecting Rod

*See Figures 9 and 12 for Trip Latch Check System.

CIRCUIT BREAKER DESCRIPTION

Page 6

STORED ENERGY OPERATOR

The stored energy operator (Fig. 3) uses charged springs to power the closing operation. Opening is spring-powered also, but not with the same springs used for closing. A stored energy operator consists of three systems: spring charging drive, cam and ratchet assembly, and the four bar toggle linkage (A-D, Fig. 4). These systems are disengaged from each other except while performing their specific functions. For example — the spring charging drive and cam-ratchet assembly are disengaged except when the cam-ratchet arrangement is being charged. Similarly, the cam-ratchet and four bar linkage are free of each other except during closing.

Stored energy operated breakers normally require a single commercial relay for control. This relay is furnished to match the control voltage.

RECLOSING CONTROL (OPTIONAL — FOR RECLOSING APPLICATIONS ONLY)

The trip latch check system provides the necessary control to perform the reclosing function when the switchgear is equipped with reclosing relays.

The system is comprised of three elements; a magnetic actuator, a non-contacting magnetically operated Hall effect switch (sensor) and a timer module. The system




Figure 3. 515-2 Operator Left Hand View

CIRCUIT BREAKER DESCRIPTION

Page 7




Figure 4. Sequence of Operation

CIRCUIT BREAKER DESCRIPTION

Page 8

performs two distinct functions prior to enabling the reclosing operation.

1. It senses that the trip latch has returned to its reset position, and is ready to receive a reclosing operation.
2. Imposes a delay following latch reset to insure the linkage assembly has fully reset and then applies power to the spring release coil.

The non-contacting magnetically operated Hall effect switch and magnet actuator combine to perform proximity detection of the trip latch tail. The speed of operation and life expectancy of this proximity sensor system is not limited by mechanical actuation as no physical contact between the actuating magnet and Hall switch exist. The switch consists of a Hall sensor, trigger, and amplifier

integrated on a silicon chip. Its complete encapsulation isolates the device from environmental effects.

AUXILIARY EQUIPMENT

AUXILIARY SWITCH

Mounted on the breaker, the auxiliary switch is normally used to open the trip circuit when the circuit breaker is opened. As this multi-stage switch operates from the breaker disconnect blades, circuitry dependent on the position of the breaker, such as indicator lights, etc., is wired through this switch. The individual stages are easily converted to "a" or "b" without disassembling the switch (Fig. 5).




Figure 5. Type Q-10 Auxiliary Switch

CIRCUIT BREAKER DESCRIPTION

CAPACITOR TRIP DEVICE

A capacitor trip device is commonly used with circuit breakers having an ac control supply installed in remote locations or unattended substations where battery cost and maintenance are undesirable.

In these cases, the capacity trip device may be charged from the same stepdown transformer that is used to energize the breaker control. This stepdown transformer should be connected to the LINE side of the breaker.

To apply the capacitor trip device to existing breakers originally shipped with dc trip coils, contact your Siemens-Allis sales representative.

TRIP SOLENOID

Normal electrical tripping (opening) is caused by the trip solenoid (17, Fig. 8) which is designated 52TC on the schematic of Figure 9. The trip solenoid is energized by operation of the circuit breaker control switch and the protective relays which are mounted on the switchgear.

ARC CHUTE ASSEMBLY

Each arc chute (Fig. 6) consists of a frame retardant envelope which provides phase isolation for interruption and venting of the by-product gases of interruption. The arc chute contains —

1. The stationary end arc runner (4) and moving end arc runner (3) to which the arc terminals transfer from the arcing contacts. The arc runners form paths for the arc terminals to travel up the arc chute.
2. The stationary end blowout coil (15) and moving end blowout coil (13) which connect their respective arc runners to the top and bottom bushings. The current in these coils creates the magnetic flux which passes through cores (18), pole pieces (22) and the space between the pole pieces. The action of this flux on the arc forces the arc up the barrier stack.
3. The barrier stack (23) consisting of a number of refractory plates, with "V-shaped" slots, cemented




Figure 6. Arc Chutes

CIRCUIT BREAKER DESCRIPTION

Page 10




Figure 6. Arc Chutes (continued)

CIRCUIT BREAKER DESCRIPTION

Page 11




Figure 7. 515-2 Operator Right Hand View

together. The barrier stack cools, squeezes and stretches the arc to force a quick interruption.

4. The barrier (1) containing coolers (6) through which the by-product gases of interruption pass, completes the cooling and deionizing of the arc products.

WARNING

Never tilt arc chutes back without first having the arc chute support firmly in place. This arc chute support is supplied as a standard accessory.

Arc chutes can be tilted to expose contact area and for inspection of barrier stack (23). The arc chutes may also be lifted and removed for the breaker. Unfasten front and rear coil connections before tilting or removing arc chutes.

NOTE

After arc chutes have been tilted back to their normal position, make sure that all screws have been replaced and tightened securely on all phases before phase barriers are replaced. Also ensure that blowout coils have been reconnected.

CIRCUIT BREAKER DESCRIPTION

Page 12



DANGER!

Proper circuit breaker operation in terms of dielectric integrity and interruption performance requires that the blowout coils be reconnected, and that all barriers be replaced and supported with appropriate fasteners. Failure to do so may result in a catastrophic failure causing electrical shock or burn resulting in death or serious personal injury and property damage.




Figure 8. 515-2 Operator Front View

OPERATION — CIRCUIT BREAKER

Page 13

NORMAL

Normal circuit breaker operation is controlled by cubicle mounted controls or other control devices. The closing springs of stored energy operated breakers will charge as soon as the breaker control is energized.

OPENING BREAKER

Stored energy operated breakers can be tripped manually by depressing the trip rod (43, Fig. 2), or electrically by

energizing the trip circuit. This rotates the latch that allows the closing linkage to collapse and reset.

CLOSING BREAKER

When the springs of a stored energy operated breaker are fully charged, it can be closed by pulling the manual close pull rod (21, Fig. 7) or electrically by energizing the closing circuit. This rotates the latch that allows the springs to close the breaker.

OPERATION — STORED ENERGY OPERATOR

Page 14



CAUTION

DO NOT WORK ON THE BREAKER OR OPERATING MECHANISM WHILE THE BREAKER IS IN THE CLOSED POSITION. DO NOT WORK ON THE BREAKER OR OPERATOR WHILE THE CLOSING SPRINGS ARE CHARGED.

SPRING CHARGING CYCLE

Energization of the Breaker Control Circuit will cause the spring charging motor (1, Fig. 7) to start charging the closing springs (6, Fig. 3). The spring charging motor (1) will drive the driving pawl (2, Fig. 3) through an eccentric drive shaft (3, Fig. 3). The driving pawl (2) will turn the ratchet wheel (4, Fig. 3) counterclockwise one tooth at a time. The holding pawl (5, Fig. 3) will hold the ratchet in position between driving strokes of driving pawl (2). This charging operation will continue turning the ratchet wheel (4) counterclockwise a tooth at a time until the closing springs (6) are fully charged (dead center). The motor will drive the ratchet wheel past this dead center position and the closing springs (6) will aid rotation driving the ratchet wheel and cams counterclockwise until spring release rollers (8, Fig. 8) on the inside surfaces of cams (7, Fig. 7) engage the spring release latch (9, Fig. 7). This arrests the motion of the ratchet wheel (4) and the cams (7) and holds the operator in the fully charged position. As the cams and ratchet wheel go over center, the motor cutoff switch (10, Fig. 3) is actuated to de-energize the spring charging motor (1). The spring charging motor then coasts to a stop, driving pawl (2) oscillating freely in the smooth toothless section of the ratchet wheel.

The motor cutoff switch (10) has four functions:

1. It de-energizes the spring charging motor (1);
2. It opens a contact in the anti-pump relay circuit;
3. It sets up the closing coil circuit;
4. It can be used to energize an indicating light to indicate that the closing springs (6) are fully charged.

NOTE

The close latch check switch (16, Fig. 3) is in the motor circuit. The close latch check switch monitors the position of the close latch (9) and will prevent charging of the closing springs (6) electrically unless the close latch (9) is in the correct position.

As energy is stored in the closing springs, the four bar linkage (12, Fig. 7) will be positioned by the linkage reset spring (11, Fig. 8) which acts to cause cam follower rollers (14, Fig. 7) to follow the surface of cam (7, Fig. 7) until the links are in a reset position, and allowing latch rollers (20, Fig. 7) to be positioned in front of trip latch (18, Fig. 7).

See Figure 4 for sequence of operation.

RECLOSING CONTROL

(OPTIONAL — FOR RECLOSING APPLICATIONS ONLY)

The electronic solid state time delay module works in concert with the trip latch sensor system. The time delay module consists of an electronic timer and an electromagnetic relay. The diagram, Figure 9, shows the timer module receiving power between terminals 1 and 3. Terminal 3 is connected to the common side of the closing control source. Terminal 1 is connected to the high side of the closing control source. Terminal 1 is connected to the high side of the closing control source thru auxiliary contact (52B) and the closing source contact "CSC". The trip latch sensor system consists of the magnetic actuator and the Hall effect switch.

The time delay module is not energized until the breaker is charged, open and the closing source switch "CSC" is closed. With the latch reset at the instant "CSC" closes, the timer module's internal relay with normally open contact operates with no intentional delay (40ms electro-mechanical delay) to connect the spring release solenoid thru timer module terminal 2 to the high side of the closing source initiating the breakers closing sequence.

If at the time the closing source is applied, the trip latch is not reset, the timer module will assume a delaying mode of

OPERATION — STORED ENERGY OPERATOR

Page 15

operation. Upon latch reset a predetermined delay will be imposed before the timer's relay closes energizing the spring release solenoid. The complete trip latch check system is not affected by broad variation of closing source voltage. The time delay error caused by temperature extremes of -40° to 65°C is a minus 3% to plus 5%.

BREAKER CLOSING CYCLE

Energizing the spring release solenoid (13, Fig. 7) will drive the close latch (9, Fig. 7) away from the spring release rollers (8, Fig. 8) on the cams (7, Fig. 7) releasing the stored energy in the closing springs (6, Fig. 7). The closing springs (6) will drive the ratchet wheel (4, Fig. 3) and the cams (7, Fig. 7) counterclockwise at a high rate of speed. The cams (7) will engage the cam follower rollers (14, Fig. 7) of the four bar linkage (12, Fig. 7) and drive them forward causing the four bar linkage to become straight. As the four bar linkage (12) becomes straight, it drives the radius arm (15, Fig. 7) upward causing the breaker contacts to close and the opening springs to be charged. The cams (7) drive the four bar linkage (12) over toggle and against the frame thereby latching the breaker contacts in the closed position.

SPRING RECHARGE AFTER CLOSING

When the closing cycle has been initiated and the cams (7, Fig. 7) begin to turn, the motor cutoff switch (10, Fig. 3) resets itself. A "b" aux. switch of the breaker opens de-energizing the closing solenoid (13, Fig. 7). The close latch (9, Fig. 7) returns to its reset position and the close latch check switch (16, Fig. 3) closes and energizes the spring charging motor (1). The closing springs (6) are then recharged as described earlier.

TRIPPING CYCLE

Energizing the trip solenoid (17, Fig. 3) will drive the trip latch (18, Fig. 3) away from latch roller (20, Fig. 3) on the four bar linkage (12, Fig. 3). This allows the four bar linkage to collapse and the breaker contacts will open. If the closing springs (6) are in the charged position, the linkage reset spring (11, Fig. 8) will immediately reset the four bar

linkage (12). If the closing springs (6) are not charged, the linkage reset spring (11) will not reset the four bar linkage (12) until just before the closing springs (6) are completely charged.

ELECTRICAL CONTROL

The normal control for this operator is contained in a control panel mounted at the rear of the unit. It consists of motor cutoff switch (10, Fig. 3), anti-pumping relay (30, Fig. 3), and the close latch check (16). The typical control arrangement's elementary diagram is shown in Figure 9. (Check schematic furnished with switchgear as wiring arrangements may vary.)

SPRING CHARGING

The spring charging motor power is supplied through terminals 3 and 4, Figure 9. The mechanical interlock is a switch operated by the breaker release lever (foot lever) which opens the motor circuit when the lever is depressed. The close latch check switch is closed when the close latch (9, Fig. 3) is in the reset position. The 88 switches are shown with the closing springs discharged. When the control is energized, the motor starts to charge the springs. The 88 switch is operated by a roll pin striker (37, Fig. 3) mounted in the ratchet wheel (4, Figs. 3 and 14). As the ratchet wheel and drive blocks charge the springs, the ratchet wheel revolves to the position of full compression, dead center. Beyond dead center position, the springs aid rotation and cause the motor cutoff switch striker to depress the actuator (35, Fig. 3) of the 88-1 switch, opening the motor circuit and the 88-3 contact in the anti-pumping relay circuit. The spring charging motor coasts to a stop with the driving pawl (2, Fig. 3) oscillating freely on the smooth portion of the ratchet wheel.

CLOSING CIRCUIT

The standard control circuit for a stored energy operator is shown in Figure 9. When the close control switch is closed, the circuit from terminal 7 through 88-2 and 52Y1 to 52B through trip latch timer, Figure 12 (when furnished), to terminal 6 energizes the closing coil, closing the breaker. As soon as the closing springs are discharged, and 88-3 switch contact closes to energize the 52Y relay. If the close control switch remains closed, the 52Y relay remains picked up through contact 52Y2. Control switch has to be released to reset control for another closing operation. This forms the anti-pumping relay cir-

Page 16



OPERATION — STORED ENERGY OPERATOR

Page 17

circuit which prevents the circuit breaker from reclosing immediately after a trip free operation. If control power is momentarily lost during closing, upon re-energization, the 52Y relay picks up instantaneously through contact 88-3 maintaining the anti-pumping relay circuit prior to complete spring charging.

CLOSE LATCH — MECHANICAL AND ELECTRICAL INTERLOCKS

The close latch (9, Fig. 3) must be fully reset to receive the cam mounted spring release rollers at the end of the charging cycle. To insure the close latch is in this fully reset position, an electrical and mechanical interlock is provided.

The close latch check switch (16, Fig. 3 and 15) consists of snap-action type switch mounted in close proximity to the close latch. A striker plate at the tail of the close latch engages the switch's actuator slightly before the fully

reset position is achieved and actuates the switch prior to the latches reaching the fully reset position. At the time of actuation, a contact closes initiating the charging sequence. The switch operates with very small differential, and this sensitivity coupled with the close latch biased engagement of the spring release rollers provides a positive sensitive interlock.

The mechanical interlock (Fig. 17) prevents manual charging of the breaker if the close latch is not adequately reset. A linkage attached by a clevis to the close latch, extends down the side of the breaker frame to the driving pawl mechanism. An extension of the interlock linkage passes above the driving pawl constant force return spring. If the close latch fails to return to a fully reset position, the linkage extension thrusts the driving pawl's return spring downward preventing the driving pawl's engagement of the ratchet wheel, thus mechanically inhibiting either manual or electrical spring charging.


Page 18

The following will help you make the correct adjustments when replacing a broken or worn part.

A comparison of circuit breaker timing at any period of maintenance with that taken when the breaker was new will indicate the operational condition of the breaker mechanism. A time variance of more than 1/2 cycle on opening and 2 cycles on closing indicates a maladjustment or friction buildup. A hole in the movable contact arm is provided for connection of a speed analyzer (29, Fig. 10).

To return phase barriers to normal position, replace parts in reverse order. Make sure that barriers are seated properly and that channels (9) are located inside of washers (8).

Never tilt arc chutes back without first having the arc chute support firmly in place. This arc chute support is supplied as a standard accessory. See Figure 2A.



ADJUSTMENTS

Page 19

TILTING ARC CHUTES

Remove phase barriers as described under "Phase Barriers Assembly." Refer to Figure 2. Remove screws (1, 37) on each phase. Remove screw (39).

Position arc chute support at the rear of the breaker and tilt back the arc chutes as shown in Figure 2A.

After arc chutes are tilted back to their normal position, make sure all screws are tightened securely on all phases before phase barriers are replaced.

NOTE MAKE SURE THAT BLOWOUT COILS HAVE BEEN RECONNECTED.



DANGER!

Proper circuit breaker operation in terms of dielectric integrity and interruption performance requires that the blowout coils be reconnected, and that all barriers be replaced and supported with appropriate fasteners. Failure to do so may result in a catastrophic failure causing electrical shock or burn resulting in death or serious personal injury and property damage.

BARRIER STACKS

The barrier stacks (Fig. 6) are fragile and must be handled carefully. Inspect the barrier stacks for erosion of the plates in the areas of the slots. The barrier stacks should be replaced when a milky glaze appears on the full length of the edges of most of the slots. They should also be replaced if plates are broken or cracked. When cleaning the breaker and cubicle, inspect for pieces of barrier stack refractory material which would obviously indicate breakage.

To remove the barrier stacks, tilt back the arc chutes, remove four screws (26), two barriers (1) from each arc chute. Remove barrier assembly and slide barrier stack (23) through top of arc chute. When replacing barrier stack be sure the v-shaped slots go in first.

CONTACT PRESSURE OF DISCONNECT ARM HINGE JOINT

The hinge joint contact pressure is in proper adjustment when a pull of 2 to 4 pounds (0.91–1.82 kg) is required to move the disconnect toward the open position.

This measurement is obtained as follows: (Fig. 10)

Remove pin (46) and detach link (47) from the disconnect arms (18) and (19). Move the disconnect to a position just short of contact make. Attach a spring scale to the disconnect 10-1/2 inches (266.7 mm) above screw (24), and in a direction perpendicular to the longest edge of the disconnect arm. Measure the pull to move the disconnect toward the open position. Read scale while disconnect is moving through normal opening stroke.

Adjustment is made by tightening (or loosening) nut (14).

Before attaching link (47) to disconnect arms (18 and 19), check contact alignment and arcing contact lead (below and next page).

ARCING CONTACT HINGE JOINT

The arcing contact hinge joint (Fig. 10) is in proper adjustment when each spring washer (15) is deflected approximately 0.015 inches (0.4 mm).

This adjustment is obtained by tightening nut (4) until all parts just touch, then tighten the nut 3/4 to 1 turn more.

CONTACT ALIGNMENT AND REPLACEMENT

The main and arcing contacts are an integral part of the bushing assemblies and are carefully aligned with the upper and lower bushings before shipment. Normally, no further adjustment is necessary.

Use these procedures if it becomes necessary to change contacts or reset contact alignment (refer to Fig. 10).

PROCEDURE A. HORIZONTAL ALIGNMENT

1. Push stationary contact fingers as far back (tap with soft mallet) as they will go on stud (11, Fig. 10).

ADJUSTMENTS

Page 20

2. Using maintenance closing procedure, move the disconnect towards the closed position until it touches a main contact finger (view A-A, Main Contacts Engaging, Fig. 10). Dimension "C" should be no greater than .020 (0.51 mm) with one contact touching.
3. Adjustment is made by removing two nuts (100) and bumper assembly (101), loosening two nuts (22) and rotating the entire contact assembly. Check alignment (dimension "C") after nuts (22) are tightened. Install bumper (101) and nuts (100). Tighten securely.
4. Alignment is checked and adjusted on each phase separately. Be sure there is no binding between contacts (11) that could prevent wiping action with the disconnect arm.

PROCEDURE B. CONTACT PENETRATION (STROKE)

1. Contact penetration should be checked and adjusted only when the contacts are properly aligned.
2. Check that open gap "d" is approximately correct to avoid over penetration (see Procedure D).
3. Using power closing procedures, close and latch breaker. The spread of the contacts (view "A-A", Breaker Latched) should be 1/8 to 3/16 inch (3.2-4.8 mm). This is the total of the two gap dimensions "a" measured on each side of the contact centering tube between the brass tube and the flat top surface on the contact. Each "a" dimension is normally 1/16 to 3/32 inch (1.6-2.4 mm).
4. With the breaker open, adjust by increasing or decreasing length of link (47) by turning nut (13). Adjust each phase separately.

PROCEDURE C. ARCING CONTACT LEAD

Arcing contacts are adjusted only after the main contacts have the proper alignment and penetration. The arcing contacts should make before the main contacts. To measure and adjust each phase:

1. Push stationary contacts back on stud.
2. Using the maintenance closing procedure, slowly move the disconnect arms toward the closed position until a dimension of $1/4" \pm 1/32$ (6.4 \pm 0.8 mm) can be measured between the lower stationary main fingers and the disconnect arms of the closest phase. (See Fig. 10 dim. b view A-A arcing contact engaging.) The moving disconnect arms should be pushed back when making the measurement.

3. With the disconnect arms in proper position established in step 2, adjust nut (1) to have the moving arcing contact touch the stationary arcing contacts. (Push the moving arcing contact back when setting.)
4. Advance maintenance closing to obtain proper individual positions of the other phase disconnect arms in accordance with step 2 and set arcing contact lead in accordance with step 3. (Simultaneous touching of arcing contacts on all three phases is not required. Do not impair penetration of arcing contact lead setting in an attempt to optimize.)

PROCEDURE D. CHECK BREAKER OPEN POSITION

Dimension "d" (Breaker Open illustration of Fig. 10) is measured between the disconnect arm and the bottom of the second finger in the main contact assembly. The open position is determined by the setting of the rod end (40, Fig. 2) at the top of the puffer piston rod. The rod end (if set too low) can affect the trip latch roller clearance (Fig. 11). The optimum setting is to obtain the maximum open contact gap "d" while maintaining the specified trip latch roller clearance (see trip latch adjustment page 14). A dimension "d" of less than 5-11/16 in. (144.5 mm) indicates improper adjustment.

AUXILIARY SWITCH

The type Q-10 auxiliary switch has been tested and adjusted at the factory. Contacts used in the breaker control circuit should not require further adjustment.

The switch (Fig. 5) is designed so that the individual contacts may be repositioned in fifteen degree steps without disassembling the switch.

Using long-nosed pliers, move the rotor contact (16) in the slot of the shell (14), compressing spring (15). This will free the rotor from the retainer (17). Rotate the rotor to the desired position and release. Be sure the rotor springs solidly back against the retainer to fully engage the rotor and retainer teeth.

INTERLOCK PLUNGER

The foot lever interlock release (20, Fig. 2) operates the interlock plunger (18, Fig. 2) as well as the trip latch.

ADJUSTMENTS

Depressing the lever trips the breaker and raises the plunger. This frees the breaker so that it can be moved in its cubicle. The interlock system is in proper adjustment when the plunger is positioned 1-11/16 to 1-13/16 inch above the floor line, and causes tripping of breaker contacts when it is raised to a level not more than 2-1/16 inch above the floor line. The latch tripping rod associated with the foot lever should be clear of the trip latch (18, Fig. 3) by 1/32 to 1/16 inch in the relaxed position.

The foot lever can be padlocked by matching holes in the breaker frame with those in the lever arm. In the padlocked position, the foot lever will be halfway down; the breaker will be trip-free; the interlock plunger will be between 2 and 2-1/4 inches from the floor line and will hold the breaker in any of the three positions within the cubicle.

TRIP LATCH ADJUSTMENTS

TRIP LATCH CLEARANCE ADJUSTMENT (FIG. 11)

This adjustment is to be performed after completing the arcing contact touch and main contact penetration adjustments referenced above.

This adjustment is necessary to insure proper clearance between the trip latch and trip latch rollers. The puffer (or snubber) height adjustment will accomplish this purpose, and in no way will affect the penetration adjustment.

Loosen Lower Link Stop (36, Fig. 11) and rotate to permit maximum Lower Trip Link movement. Adjust puffer (or




Figure 11. Trip Latch Clearance Adjustment

ADJUSTMENTS

Page 22

snubber) (16, Fig. 2) height to rotate radius arm and four bar linkage until a .030" to .060" gap appears between the latch and latch roller. Lock in place. Rotate Lower Link Stop until it touches lower link and lock in place. Recheck dimension "d" as described in procedure D, page 13.

TRIP LATCH BITE ADJUSTMENT

Trip latch bite is established by setting the latch tails top surface $.500 \pm .015$ below surface as shown in Figure 12-(A). Lock securely with jam nut. One turn of adjusting screw will alter the gap 0.062 inches. This adjustment will produce a latch bite of approximately 0.259 to 0.111 inches as shown in Figure 12-(C).

TRIP LATCH CHECK SENSOR ADJUSTMENTS

(FIGURE 12(B) AND 12(D))

This adjustment is to be completed only after establishing the "bite" adjustment described above.

The magnetically operated Hall effect switch (sensor) and actuating magnet are to be preassembled to the operator. The unit can be adjusted by advancing the threaded bushing through the tapped hole in shelf until a gap of .040 -




Figure 12. Trip Latch Bite and Check Switch Adjustments

ADJUSTMENTS

Page 23

.000 + .015 inches is achieved between the surface of the switch and the top of the shrink tubing holding the magnet actuator assembly to the trip latch. With this gap achieved, the sensor may be locked in place.

Functional electrical test on breaker may be made to confirm sensors operation. The timing modules nameplate and rated voltage should be checked to insure it matches breaker closing control voltage. The timers delay adjustment has been previously set and should not be altered. Remove wire from terminal 2 on timer module and insulate. Open breaker and charge opening springs.

Apply closing voltage and observe light emitting diode (led) adjacent to delay adjustment. The led should be brightly illuminated when the trip latch is fully reset. Depress latch with manual trip lever and observe the led goes out. Release trip lever and the led should come on. This sequence confirms sensors operation. Do not apply closing control voltage for longer than two minutes while performing this test.

MANUAL CHARGING OF CLOSING SPRINGS

To charge the closing springs manually, disconnect control power before inserting the manual charging crank in the socket located in the center of the left hand operator panel. Turn the crank in a counterclockwise direction to charge the springs. The effort to charge the closing springs will fluctuate and will increase to a peak and then decrease. At the point of least effort an audible click will be heard and the effort to turn the crank will drop to near zero. The mechanism is now fully charged. Remove manual charging crank. The breaker may be closed by pulling the manual close pull rod.

CAUTION

During manual charging procedure the crank will be under torsional tension, springback can be expected. Maintain a firm grip on crank. Failure to do so may result in personal injury.

The closing springs are charged through the driving pawl and ratchet wheel and are thereby indexed by the holding pawl. Some springback can occur between tooth positions on the ratchet wheel.

MAINTENANCE SLOW CLOSE

With the breaker removed from the cubicle, manually charge the closing springs as previously described and remove charging handle. Then, from the rear or stud side of the breaker, attach the spring blocking device, Figure 13, by fastening it in the slots in the closing spring tubes.

Stay clear of the breaker contacts and pull the manual close pull rod at the front of the breaker. This will discharge the closing springs against the spring blocking device during which the breaker contacts will move slightly toward the closed position.

Place the manual spring charging crank back in the socket at the lower left corner of the breaker. By turning the crank counterclockwise the breaker contacts may be slowly closed for checking contact alignment.

CAUTION

Maintain a firm grip on crank.


As the contacts will close in increments predicated by the teeth on the ratchet wheel, springback will occur between tooth positions.

REMOVAL OF SPRING BLOCKING DEVICE


To remove the closing spring blocking device, Figure 13, the closing spring must be fully charged. The spring may be charged manually by inserting the charging crank and continuing counterclockwise rotation. The main contacts will go fully closed as the four bar linkage toggles. Upon continued rotation, the closing springs will be picked-up as noted by increased effort in cranking. Continue rotation until the springs are fully charged. A sharp click will be heard as the spring release rollers engage the close latch indicating full spring charge has been achieved. The spring blocking device may now be easily removed by pulling the blocking portion from the slots in the spring tubes.

ADJUSTMENTS


Page 24




Breaker Charged and Ready to Receive Spring Blocking Device.



Spring Blocking Device in Correct Position for Insertion.



Insertion of the Spring Blocking Device. Note: Spring Blocking Device Must Be Diagonally Inserted to Clear Breaker Frame.



Spring Blocking Device in Place Ready for Closing Spring Release.

Figure 13. Maintenance Close Spring Blocking Device Insertion

REMOVAL OF CLOSING SPRINGS - SPRINGS MUST BE DISCHARGED

The closing springs may be quickly and safely removed from the breaker. Remove two of the four bolts holding the spring bearing block at the rear of the breaker. These bolts should be diagonally opposite each other. Insert studs approximately 6" long in place of bolts. Remove the remaining two bolts by shifting the spring lead to the 6" long studs. The spring bearing block can then be backed off by alternating backing off the studs. To install the power spring the reverse procedure should be used. The

spring bearing block top surface should be even with the bracket of the frame. The four bolts should be torqued to 50 ft. lbs.

If the charging ratchet and cams are to be revolved with springs removed, it is advisable to remove two aluminum spring drive blocks (38, Fig. 8) secured to the ratchet and cam crankpins by retaining rings. These pins if not removed or held essentially in a horizontal position may jam while revolving the cam and ratchet assembly.

MOTOR CUTOFF SWITCH

The 88 motor control switch assembly (Fig. 14) is factory adjusted. If it should become inoperative, entire unit must




Figure 14. Motor Cutoff Switch

ADJUSTMENTS

Page 26

be removed and inspected for contact wear. Replacement may be necessary.

MOTOR CUTOFF SWITCH ADJUSTMENT

This adjustment is most conveniently performed before installing the charging springs.

Advance ratchet and cam assemblies to position shown (Fig. 14). The holding pawl must occupy the ninth (9) tooth position on the ratchet as counted counterclockwise from area on ratchet periphery which lacks two teeth.

With ratchet in the position described above, adjust the motor cutoff switch vertically until its actuator makes positive contact with the rollpin striker. Lock switch assembly in this position.

ADJUSTMENTS

Check lateral movement of actuator. Lateral play at end of actuator (tip) should be no more than 1/16" max. If adjustment is necessary, snug pivot screw to just bind actuator, and then back off 1/16 to 1/8 turn. Rotate ratchet and cam assembly to insure actuator rides in gap between ratchet and cam without striking or binding.

CLOSE LATCH BITE ADJUSTMENT

Free jam nut and place latch in horizontal position (Fig. 15). Visual accuracy. Measure "D" directly above latch pivot. Reproduce this dimension plus 0.062" at the latch face as shown in the figure above by rotating the adjustment screw. Secure jam nut. This adjustment should produce a latch bite of 0.151 to 0.216 inches.

CLOSE LATCH CHECK SWITCH ADJUSTMENT (FIG. 15)

This adjustment is to be performed only after completing the latch bite adjustment described above.

A clearly audible "click" should be heard from the switch as latch is moved 1/32" from latch adjustment screw. The latch switch actuator may be bent slightly to obtain switch operation at this point. Maximum permissible bend is 1/8" as shown.

If switch actuator is bent, observe latch fully closed against adjusting screw and make certain the switch actuator has not contacted the switch body. A 1/64" clearance should exist as shown above.

FREE HEIGHT ADJUSTMENT (FIG. 16)

This is achieved by blocking the actuating roller to the indicated height and adjusting a pair of jam nuts, located on the manual closing pull rod, to maintain the roller in this position with blocking removed. Return spring adjusting nut should be set to produce $0.5 \pm .06$ inch deflection in return spring.

The following adjustments are to be made only after completing the close latch bite adjustment described on the previous page and after adjusting connecting link as shown on Figure 16.

TRIP ADJUSTMENT (FIG. 16)

This is made by varying the penetration of the "curved actuating rod" in its attachment clevis. A 5/16" (.312) drill is placed between the upper latch surface and the latch adjusting bolt. A 2.906" block is to be inserted between the actuating roller and floor. The "curved" rods upper yoke is nested against a forward roll pin in the closing latch and the lower clevis is adjusted to insure the closing latch will not move more than 1/16 (.062) inches as measured between adjusting screw and latch surface when the 1/4" (.250") drill is removed.

SPRING RELEASE ARMATURE ADJUSTMENT (FIG. 15A)

This adjustment is to be performed only after completing the spring release latch bite adjustment.

The purpose of this adjustment is to establish an armature gap of 3/16 (.187) to 1/4 (.250) inches. A suitable feeler gage of optimum thickness, 7/32 (.218), should be inserted in the armature gap. That is, the space between the ground surfaces of the solenoid frame and ground "T" shaped extensions of the solenoid plunger.

The connecting link between the solenoid plunger and spring release latch should be adjusted to maintain the plunger in this position. The locking screw is released and the adjusting cap shifted until the effective length of the link supports the plunger within the indicated range.

OVERTRAVEL (FIG. 16)

No adjustment required. Check with 3.125" blocking below actuating roller. Closing solenoid link should provide freedom of latch movement without jamming.

ADJUSTMENTS




Figure 15. Close Latch Bite and Check Switch Adjustments

ADJUSTMENTS




Figure 15A. Spring Release Solenoid Armature Cap Adjustment

ADJUSTMENTS




Figure 16. Closing Spring Discharge Mechanism

CLOSE LATCH MECHANICAL INTERLOCK (FIG. 17)

This adjustment is to be undertaken only after completing the close latch bite adjustment described above, Figure 15.

Adjust actuator rod displacement from support angle to $1.06 \pm .015$ inches. See detail of adjusting nut "A" (Fig. 17).

Insert a 1/4 (.250) drill between upper surface of close latch and latch adjustment screw.

Check guide bushings to insure they stand off the frame 1/4" as shown.

Free Nut "B" below attachment clevis, and adjust Nuts "B" and "C" to depress pawl return spring and pawl until 1/16

to 3/32 clearance is obtained between tip of pawl as its tip is toward the ratchet (power stroke).

The pawl must be rotated using a 1/2" square insert in the eccentric drive shaft or by low voltage (slow rotation) of drive motor or manual charging.

Return the jam nut "C" attachment clevis to bottom on bracket, and tighten external jam nut "B" securely. **MAINTAIN CLEVIS PARALLEL TO FRAME.**

Remove 1/4" (.250) drill, restoring latch to its normal position. Again rotate eccentric drive shaft. The tip of the drive pawl should engage the full face of each ratchet tooth with a clearance of .030" between the base of the tooth and the engaged tip of the drive pawl.

ADJUSTMENTS

Page 30




Figure 17. Close Latch Mechanical Interlock

MAINTENANCE AND TESTING

Page 31



DANGER

Do not work on energized equipment. Unauthorized personnel should not be permitted near energized equipment.

Plan the time for maintenance with operating personnel so that the switchgear can be deenergized, and safely grounded.

GENERAL

Thorough, periodic inspection is important to satisfactory operation. Inspection and maintenance frequency depends on installation, site, weather and atmospheric conditions, experience of operating personnel and special operation requirements. Because of this, a well-planned and effective maintenance program depends largely on experience and practice.

ALWAYS INSPECT A BREAKER WHICH HAS INTERRUPTED HEAVY FAULT CURRENT. All contacts, arc runners and arc chutes should be examined to determine if repair or replacement of parts is required. Inspect for pieces of barrier stack refractory material in the cubicle as well as the circuit breaker.

"AS FOUND" TESTS

Some users perform "As Found" insulation tests using a megger or Dobel testing to give an "As Found" value for future comparative indication of insulation change. This is desirable for new circuit breakers if they are to be stored for extended periods, and may absorb moisture and contaminants. Contact resistance tests can also be made using a ductor.

Since wide variations can occur in insulation values and contact resistance because of atmospheric conditions, contamination and test equipment, discrete values cannot be given. However, making and recording these tests on new equipment, and at regular intervals will give a comparative indication of insulation and/or contact resistance change. Maintaining a permanent record of these values for each circuit breaker should be part of the Maintenance Program.

PERIODIC INSPECTION AND MAINTENANCE

Prior to performing any maintenance work, make certain all control circuits are open, and that the breaker has been completely withdrawn from the metal-clad unit.

CAUTION

DO NOT WORK ON THE BREAKER OR OPERATING MECHANISM WHILE THE BREAKER IS IN THE CLOSED POSITION. DO NOT WORK ON THE BREAKER OR OPERATOR WHILE THE CLOSING SPRINGS ARE CHARGED.

1. Remove interphase barriers (Refer to Page 11, Phase Barrier Assembly) and clean them and all other insulating surfaces with dry compressed air — a vacuum cleaner, or clean lint free rags. Inspect for signs of corona, tracking or thermal damage.
2. Tilt the arc chutes to expose the main contacts. (Refer to Page 11, Tilting Arc Chutes).
3. Contacts

Examine the contacts, Figure 10. The major function of the air circuit breaker depends upon correct operation of its contacts. These circuit breakers have two distinct sets of contacts — main and arcing — on each pole. When closed, practically the entire load current passes through the main contacts. If the resistance of these contacts becomes high, they will overheat. Increased contact resistance can be caused by pitted contact surfaces, corrosion of contact surfaces, or weakened contact spring pressure. This will cause excessive current to be diverted through the arcing contacts, with consequent overheating and burning. Verify proper main contact pressure by checking penetration (Refer to Page 13, Procedure B).

Arcing contacts are the last to open, and arcing originates on them. In circuit interruption, they carry current only momentarily, but that current may be equal to the interrupting rating of the breaker. In closing against a short circuit, they are the first to close and may momentarily carry considerably more than the short circuit interrupting rating. Therefore, they must make contact prior to the main contacts. If not, the main contacts can be badly burned.

MAINTENANCE AND TESTING

Page 32

On the magnetic blow-out air circuit breaker, the arc is quickly removed from the arcing contacts by magnetic forces and transferred to arc runners in the arc chute (Fig. 6). The arcing contacts are expendable and may eventually burn enough to require replacement.

The main and arcing contacts are made of tungsten alloy to resist deterioration due to arcing. If the surfaces are only roughened or slightly pitted, they can be smoothed with crocus cloth or draw filed. Be careful not to remove much material, as this would shorten the contact life. If significant erosion has occurred, the arcing contact lead must be checked and adjusted using Procedure C on Page 13.

If they are badly pitted or burned, they should be replaced. (Refer to Page 12).

The main contacts may be lubricated per Figure 20, but **DO NOT LUBRICATE THE ARCING CONTACTS.**

4. Disconnect Arm Hinge Joint

Check contact pressure of the disconnect arm hinge joint per Page 12. If the pull is within the 2 to 4 pound (0.91-1.82 kg) acceptable range, the joint should be satisfactory. If not, then it should be maintained as follows:

Refer to Figure 10. Remove disconnect arms as a unit by removing screw (24), nut (14) and spring washer (23). Carefully inspect all contact surfaces in hinge joint. Replace any damaged parts. Silver washer (25) and adjacent surfaces should be clean and free of roughness or galling. However, discoloration of the silvered surfaces is not usually harmful unless caused by sulfide (insulating) deposits. These should be removed with alcohol or a silver cleaner. Lubricate silver washer and mating surfaces by applying electrical contact lubricant (Fig. 20, J). Reassemble hinge joint. Tighten screw (24) and nut (14). Spring washer (23) and silver washer (25) must be assembled in their original position to assure proper adjustment. Adjust per Page 12, "Contact Pressure of Disconnect Arm Hinge Joint and Arcing Contact Hinge Joint".

5. Arc Chutes

Inspect the arc chutes. This includes inspection of the ceramic parts (barrier stack and flash plates) for breakage, erosion and dirt; inspection of the blowout coil insulation; and of the entire arc chute for dirt, moisture or contaminants which might affect insulation strength

Dirt or contaminants may be removed from the barrier stack with a cloth, by light sanding or by scraping with the end of a file. Wire brushing or emery cloth is not approved because metallic particles may become embedded in the insulating material.

Arc flash plates in the lower portion of the arc chute may be cleaned by sand blasting or by sanding with coarse grain paper, to remove glaze and metal deposits from the surface.

Blow out particles with dry compressed air.

Small cracks or pieces chipped or broken from ceramic parts may be ignored. A barrier stack split vertically along a rope seam may be repaired with epoxy cement. A barrier stack split horizontally or one with several broken plates should be replaced.

The action of the arc on ceramic causes slight melting. Small milky glass nodules on the edges and surfaces of the ceramic barrier stack plates are normal after interruption. With severity and number of operations, this melting and glazing increases. When barriers are heavily glazed (milky white along the edges of the V slots) the barrier stacks should be replaced.

Blowout coil and core insulation should be inspected for evidence of abrasion, heating or mechanical stress which could lead to electrical discharge between coil and core.

Mechanically damaged, burned or punctured blowout coils and core insulation should be repaired or replaced.

6. Mechanism — Stored Energy Operator

The circuit breaker mechanism should be inspected at 2000 operation intervals. This inspection should check for loose hardware and any broken parts. The control wiring should be checked for loose connections and frayed or damaged insulation. The "spring release latch check switch", "trip latch check system" (if furnished), and "mechanical interlock" switch should be checked for mounting tightness. The satisfactory operation of each switch element should be assured with a continuity meter and manual manipulation of the switching element, and adjusted if necessary. Verify that operation of "Close Latch Mechanical Interlock" is proper (Refer to Page 17 and Fig. 17).

After 10,000 operations, the operating mechanism should be given a general overhaul and all worn parts replaced. Excessive wear will usually be indicated when adjustments can no longer be satisfactorily

MAINTENANCE AND TESTING

made. The general overhaul will require disassembly of the operating mechanism. All bearings and surfaces receiving wear should be examined carefully and re-lubricated in accordance with lubrication instructions which follow.

The removal of the closing springs will be necessary in order to permit overhaul of the breaker. These springs may be removed as described on Page 16.

7. Lubrication

NOTE The lubricant supplied with the accessories is intended to be used exclusively on the contacts and must not be used on any part of the circuit breaker mechanism.

Recommended circuit breaker lubrication points are shown in Figures 18 and 19. The chart (Fig. 20) outlines two methods of lubrication. Refer to this chart for recommended lubricant and points of application. The first method requires no disassembly and is suggested for the prevention of problems which could be caused by severe environmental or operating conditions. The second method follows procedures similar to those performed on the breaker at the factory. Follow this procedure only in case of a general overhaul or disassembly.

Needle and roller bearings are factory lubricated for life and should not require attention. However, the best of greases are affected by time and atmospheric conditions and may require service.

To lubricate these bearings when parts are disassembled, the following procedure is recommended. Clean in solvent, wash in alcohol, spin in light machine oil, drain and repack with Beacon P-325 grease. **DO NOT REMOVE NEEDLE BEARINGS FROM THE RETAINING PART.**

8. Air Puffers

Air puffers (E, Fig. 19) are important to the interruption process because they provide a flow of air which assists in controlling the shape of the arc column at low current values. This control causes the arc to make an earlier transfer to the arc runners, thereby energizing the magnetic circuit which drives the arc into the barrier stack. This action produces a shorter arcing time than would be possible by relying only on the thermal effects of the arc to achieve the transfer to the arc runners.

Puffers should be inspected during regular breaker maintenance periods. Hoses should be checked for flexibility, freedom from kinking or collapse and soundness of connection to mating parts. Also make sure that Ty-rap is in place and tight as shown in View B, Figure 2. Cylinders should be checked for cleanliness and freedom from deposits which might retard the motion of the piston. Pistons should be checked for free movement within the cylinder and that the seals are flexible and contact the walls of the cylinder. Transformer oil is used on felt seals to keep the material pliable, reduce shrinkage and to provide lubrication. The oil should moisten but not saturate the felt.

Replace seal material if it becomes inflexible or does not make contact with the cylinder walls.

The air output from the puffer nozzle may be checked with the arc chutes tilted (refer to "Tilting Arc Chutes", Page 11 and Figure 2A). Crush a 4-1/2 x 4-1/2 inch sheet of tissue paper, place it in the nozzle opening and check to see that it is dislodged when the breaker is opened.

9. Inspect for foreign objects which may have been left in the circuit breaker during previous steps. Check for loose hardware.
10. Check for mechanical freedom of disconnect arm movements by slowly closing the breaker. Reference Page 15 for "Maintenance Slow Close" Procedure.
11. Trip breaker by depressing trip rod (43, Fig. 2).
12. Return arc chutes to upright position, fasten both front and rear blowout coil connections and replace phase barriers. Be sure screws on all phases are tightened securely.



DANGER

Proper circuit breaker operation in terms of dielectric integrity and interruption performance requires that the blowout coils be reconnected, and that all barriers be replaced and supported with appropriate fasteners. Failure to do so may result in a catastrophic failure causing electrical shock or burn resulting in death or serious personal injury and property damage.

MAINTENANCE AND TESTING

Page 34




Figure 18. Lubrication Points on Frame and Operator (View A) Drive Assembly (View B) and Linkage Assembly (View C)

MAINTENANCE AND TESTING




Figure 19. Lubrication Points on Breaker

13. "As Left" Tests

- a. Insulation resistance tests should be made to verify the insulation integrity. These can include megger or Dobel tests. If possible, a high-potential test should be made for one minute at values shown below. With the breaker open, check each phase across the open contacts by connecting from the upper to the lower primary disconnects. With the circuit breaker closed, check phase-to-phase and each phase-to-ground.

	HI-POT. TEST KV	
	AC	DC
FB-500A1	14.3	20.2
FC-500B	27.0	38.2
FC-750B	27.0	38.2

MAINTENANCE AND TESTING

Page 36

Lubri- cation Key	Part Description	Suggested Lubrication at Every 2000 Operations or Once Every Year	Alternate Lubrication (Requires Disassembly) Recommended After Every 10,000 Operations
A	Ground surfaces such as latches, rollers, props, etc.	Wipe clean and spray with *Molycote 557* 15-171-270-001.	Wash clean and spray with *Molycote 557* 15-171-270-001.
B	Nylon sleeve bearings, such as: the contact arm hinge pin.	No lubrication required.	No lubrication required.
C	Sleeve bearings and pivot pins, rotating parts such as drive pinion, driving cranks, slide and pivot pins.	Light application of *Molycote Penelube* 15-171-270-002.	Remove pins or bearings, clean per instructions and apply *Beacon P-290* 00-337-131-001.
D	Sliding surfaces.	Light application of *Molycote 557*.	Wipe clean and apply *Molycote 557* liberally.
E	Air puffer cylinders.	Wipe clean and apply transformer oil #3 to felt. 15-171-729-001.	Wash clean and wet felt ring in transformer oil #3.
F	Roller and needle bearings.	No lubrication required.	Clean per instructions and repack with *Beacon P-325*.
G	Dry pivot points.	No lubrication required.	No lubrication required.
H	Primary and secondary disconnect fingers, arcing contact hinge, grounding contact and aux. switch contacts.	Wipe clean and apply a film of Siemens-Allis contact lubricant 15-171-370-002.	
I	Arcing contacts.	Do not lubricate.	Do not lubricate.
J	Disconnect arm hinge joint silver washer between bushing and the contact arm.	Wipe clean and apply a film of Siemens-Allis contact lubricant 15-171-370-002.	
K	Charging springs & spring retainers	No lubrication required.	Wipe clean and coat with *Beacon P-325*.
L	Manual charging bevel gear train, FB & FC series only.	Remove snap on cover & coat teeth lightly with *Beacon P-325*.	Remove snap on cover & coat teeth lightly with *Beacon P-325* 15-337-131-001.
M	Arcing contact hinge assembly.	Wipe clean and apply a film of Siemens-Allis contact lubricant 15-171-370-002.	

Figure 20. Lubrication Chart

MAINTENANCE AND TESTING

CAUTION

Certain control devices such as, charging motors, pushbuttons, bell alarms, etc., may have only a 900 volt rating. 75% of 900V would allow a field Hi-POT of only 675 volts AC or 954 volts DC.

- b. A dielectric test on secondary and control circuits should be made at 1200 volts.
 - c. If desired, contact resistance tests can be made using a Ductor.
 - d. Make a permanent record of all tests performed.
 - e. Compare with prior tests. (See "As Found" Tests on Page 19).
14. Inspect the primary disconnect contact finger assemblies (3, Fig. 2).

The main contact surfaces should be clean and bright. However, discoloration of the silvered surfaces is not usually harmful unless caused by sulfide (insulating) deposits. These should be removed with alcohol or a silver cleaner. Slight impressions on the contacts will be caused by the pressure and wiping action of the contacts. Minor burrs or pitting can be allowed and projecting burrs may be removed by dressing. Nothing more abrasive than crocus cloth should be used on the silvered contact surfaces. Where serious overheating is indicated by discoloration of metal and surrounding insulation, the contacts and spring assemblies should be replaced. In this case, also investigate the cubicle mounted stationary disconnects, (with the switchgear de-energized) determine the cause of overheating, and take corrective action.

15. Prepare the circuit breaker for service by repeating steps 9 through 22 on Page 2.

PARTS

Page 38

HOW TO USE YOUR RENEWAL PARTS ORDERING GUIDE

1. Locate the part or parts to be replaced in one of the drawings in this manual. Refer to the usage code table on page ii for drawings applicable to your breaker.
2. Identify each part by item number, description and part number. Give drawing figure number in which part is shown.
3. Include breaker type, rating and breaker serial number with your order.
4. Place order with your Siemens-Allis representative.

ORDERING EXAMPLE

Type	<u>FB-500A1</u>	Rated Amps	<u>1200</u>	Serial Number	<u>S77679A-3</u>
Type of Operator:		Stored Energy	515-2		
Instruction Book	<u>SG-3208</u>				

	<u>Fig.</u>	<u>Item</u>	<u>Description</u>	<u>Part Number</u>	<u>Quantity</u>
	4	1	Barrier Stack	71-303-149-501	1
	2	10	Contact Assembly	18-657-372-501	1

IF REQUIRED PART IS NOT IDENTIFIED IN THIS MANUAL —

1. Make a copy of the drawing figure in which the part would appear.
2. Indicate with arrows or other markings location of part.
3. Describe or sketch required part.
4. Include breaker type, rating and breaker serial number with your order.
5. Place order with your Siemens-Allis representative.

PARTS

TABLE OF CONTENTS

	Figure	Page
Stored Energy Breaker Assembly	1	40
Breaker Assembly	2	43
Stud and Support Assembly	3	47
FB-500A1 Arc Chute	4	50
FC-500B Arc Chute	5	52
FC-750B Arc Chute	6	54
Stored Energy Frame and Operator Assembly	7	56
Type 515-2 Stored Energy Operator Assembly	8	61

USAGE CODE TABLE

FC-500B	1200 AMP	Stored Energy	18-471-611-601	A
FC-500B	1200 AMP (60 KA)	Stored Energy	18-471-611-602	B
FC-500B	1200/2000 AMP	Stored Energy	18-471-611-603	C
FC-500B	2000 AMP (60 KA)	Stored Energy	18-471-611-604	D
FB-500A1	1200 AMP	Stored Energy	18-468-620-608	E
FB-500A1	1200/2000 AMP	Stored Energy	18-468-620-609	F
FB-500A1	2000 AMP	Stored Energy	18-468-620-610	G
FC-750B	1200 AMP	Stored Energy	18-473-236-601	E
FC-750B	1200/2000 AMP	Stored Energy	18-473-236-602	F
FC-750B	2000 AMP	Stored Energy	18-473-236-603	G

*If no usage code appears in the "USAGE" column of the following parts lists, the part is used on all assemblies listed in the figure title.

PARTS

Page 40




Figure 1. Stored Energy Operated Breaker Assembly (Codes A through G)

PARTS

Item	Description	Part Number	Usage
	Contact Finger Assy.	18-657-456-579	ABCEF
	18-657-456-576	CF
	18-723-565-501	DG
	18-723-599-003	ABCD
	18-723-599-005	EFG
6	Arc Chute Assembly	18-471-243-515	ABCD
	71-401-440-503	EFG
7	Washer	71-019-219-015	ABCD
	71-019-219-020	EFG
8	Washer	71-107-100-002	
	Label	15-171-383-002	
	Indicator	71-111-259-001	
	71-206-907-503	ABCD
	71-113-600-001	
	71-114-302-001	
14	Indicator	71-167-932-001	
15	Connector	71-208-263-002	
16	Breaker Nameplate	18-723-585-000	
17	Block	71-117-870-001	EFG
18	Cover	18-657-769-363	
19	Strap	71-115-588-001	EFG
	Support	71-115-645-001	EFG
	18-731-409-002	BD
	18-731-409-002	EFG
	71-302-650-001	ABCD
	71-302-903-001	EFG
23	Block Assembly	18-657-410-597	
24	Block Assembly	18-657-410-598	
25	Label	71-113-871-001	
26	Screw	00-615-114-375	
27	Panel Assembly	71-206-907-507	EFG
28	Basic Breaker Assy.	18-468-621-504	A
	(Includes Items 30	18-468-621-505	B
	thru 42 below)	18-468-621-506	C
	18-468-621-507	D
	18-468-621-508	E
	18-468-621-509	F
	18-468-621-510	G
29	Frame & Operator	18-468-619-501	
30	Pipe Strap	00-691-051-008	
31	Shim	71-110-641-003	
32	Shim	71-110-641-004	
33	Link	71-113-440-001	
34	Shim	71-113-679-001	
35	Angle	18-657-765-163	
36	Barrier	71-113-804-001	
37	Barrier	71-113-805-001	
38	Guard	71-118-452-001	
39	Lock Nut	15-171-063-004	

PARTS

Page 42

Item	Description	Part Number	Usage
	71-164-152-008	
	71-208-524-001	
	71-401-626-501	A
	71-401-626-503	B
	71-401-626-508	C
	71-401-626-502	D
	71-401-626-506	E
	71-401-626-510	F
	71-401-626-507	G
45	Screw	00-611-315-375	
46	Lock Nut	15-171-063-004	
47	Rd. Washer	00-651-007-160	
48	Screw	00-611-315-468	EFG
49	Lock Washer	00-655-017-032	EFG
50	Rd. Washer	00-651-007-230	EFG
51	Screw	00-611-447-463	
52	Screw	00-615-644-373	
53	Cotter Pin	00-671-195-193	
54	Pin	15-171-497-002	
55	Clamp	15-171-070-002	
56	Tyrap	15-171-053-002	
57	Arrow Label	15-171-120-004	
58	Auto Switch	71-208-922-504	
59	Seal Pin	72-120-237-501	
60	Cover	18-657-469-286	
63	Label	71-114-294-001	
64	Washer	00-651-007-214	DG
65	Washer	00-651-017-214	DG
66	Screw	00-611-315-419	
67	Rd. Washer	00-651-007-900	
68	Lockwasher	00-655-017-030	
69	Bearing Support	18-657-769-377	
70	Lockwasher	00-655-017-026	
71	Screw	15-171-738-002	
72	Timo Roll	18-723-584-502	CH
73	Screw	00-615-644-220	EFG
74	Washer	00-651-007-123	

PARTS




Figure 2A.

Item	Description	Part Number	Usage
1	Channel	71-208-670-004	
2	Angle Bracket	71-208-415-502	
3	Angle Bracket	71-208-415-503	
4	Channel	71-116-679-001	
5	Channel	71-113-398-001	
6	Channel	72-120-378-001	
7			
8			
9			
10	HH Cap Screw .312 x .75	00-611-315-419	
11	Washer	00-651-007-900	
12	Lockwasher	00-655-017-030	
13	HH Hd. Mach. Screw .25 x .75	00-617-475-375	
14	Washer	71-107-100-002	
15	Washer	15-171-033-002	
16	Angle Bracket	00-639-060-032	
17	HH Self Tap Screw #10	00-611-461-218	
18	Washer	00-651-027-008	

PARTS

Page 44




Figure 2B.

Item	Description	Part Number	Usage
1	Front Barrier	18-723-599-003	
2	Support Block	71-116-969-003	
3	Front Barrier	18-723-599-002	
4	Support Block	71-210-601-003	
5	Block	18-697-825-058	
8	HH Cap Screw .25 x 4.0	00-657-315-398	
9	Self Tap Screw	00-615-644-218	
10	HH Cap Screw .312 x .75	00-611-315-419	
11	Washer	00-651-007-900	
12	Lockwasher	00-655-017-030	
13	HH Cap Screw .375 x .75	00-611-315-463	
14	Washer	00-651-007-230	
15	Lockwasher	00-655-017-032	

PARTS




Figure 2C.

Item	Description	Part Number	Usage
1	Angle Bracket	71-208-670-004	
2	HH Cap Screw .375 x 1.25	71-208-415-501	
3	Washer .375	71-116-681-501	
4	Lockwasher .375	71-116-670-001	
5	Strap	71-113-358-001	
6	Well Nut .25	71-115-588-001	
7	Washer .25	15-171-033-002	
8	Rd. Hd. Mach. Screw .25 x .75	71-107-100-002	
9	Washer #10	00-617-475-375	
10	Angle Bracket	00-651-027-088	
11	HH Cap Screw .375 x 1.25	00-639-080-032	
12	Washer .375	00-611-481-218	
13	Lockwasher .375	00-611-315-418	
14	Strap	00-651-007-900	
15	Well Nut .25	00-655-017-032	
16	HH Cap Screw .375 x 1.25	00-611-315-468	
17	Washer .375	00-651-007-230	
18	Lockwasher .375	00-655-017-032	

Page 46



Item	Description	Part Number	Usage
	Rear Bar	18-723-599-005	
	Phase Bar	71-116-969-003	
	Front Bar	18-723-599-004	
	Strip	71-115-588-001	
7	Block	18-657-825-058	
8	Support	18-657-825-061	
9	Screw #10-32 x 1.75	15-615-513-001	
10	Stop Nut #10-32	00-633-039-210	
11	Screw #10-16 x 1.62	00-615-644-230	
12	Screw #10-16 x .5	00-615-644-218	
13	HH Cap Screw .31 x .75	00-611-315-419	
14	Washer .31	00-651-007-900	
15	Lockwasher .31	00-655-017-030	
16	HH Cap Screw .375 x 1.25	00-611-315-468	
17	Washer .375	00-651-007-230	
18	Lockwasher .375	00-655-017-032	

PARTS

Page 47




Figure 3. Stud and Support Assembly (All Codes)

PARTS

Page 48

Item	Description	Part Number	Usage
1	Support Assembly	72-320-044-001	AB
		72-320-044-002	CD
		18-721-438-501	E
		18-721-438-502	FG
2	Top Stud Assembly	71-208-214-503	B
		71-208-214-502	DG
		71-208-214-508	CF
		71-208-214-501	A
		71-208-214-507	E
3	Low Stud Assembly	71-208-196-501	AB
		71-208-196-503	E
		71-208-196-504	DG
		71-208-196-506	CF
4	Tube	71-113-488-001	ABE
		71-113-896-001	CDFG
5	Tube	71-113-488-002	ABE
		71-113-896-002	CDFG
6	Tube	71-170-947-007	AB
		71-170-947-008	CDFG
7	Spacer	71-107-716-008	AB
		71-107-716-007	CD
8	Disc Arm Assembly	71-208-255-504	CDEFG
		71-208-255-514	AB
9	Disc Arm Assembly	71-208-255-503	CDEFG
		71-208-255-513	AB
9A	Disc Arm Assy.	71-208-255-501	B
9B	Disc Arm Assy.	71-208-255-502	B
10	Contact Finger Assy.	18-657-372-501	
10A	Contact Finger Assy.	18-657-372-505	B
11	Screw	00-615-261-231	A
12	Tubing	72-120-735-002	B
		72-120-735-001	A
		72-120-735-003	CDEFG
13	Screw	00-611-315-461	
14	Washer	71-916-992-002	
15	Plate	71-112-910-001	
16	Nozzle	71-210-349-001	
17	Spacer	71-107-716-007	
18	Rod	71-110-282-002	
19	Strip	71-113-681-001	
20	Spring Washer	71-167-537-001	
21	Washer	71-177-196-003	
22	Arcing Contact Assy.	71-112-913-501	ABCD
22A	Arcing Contact Assy.	71-112-913-502	EFG
22B	Arcing Contact Assy.	71-112-913-503	EFG
23	Yoke	71-112-934-001	ABCD
		18-657-777-565	EFG
24	Tubing	71-172-682-010	
25	Bar	71-113-038-001	

PARTS

Item	Description	Part Number	Usage
26	Spacer	71-112-948-001	
27	Washer	71-140-901-001	
28	Washer	71-177-196-005	ABCD
	71-114-701-001	EFG
29	Washer	71-158-647-015	
30	Spring	72-120-400-001	
31	Link	71-118-284-001	
32	Arcing Contact	71-112-966-501	ABCD
	71-112-966-502	EFG
33	Channel	18-657-377-501	
34	Plate	71-112-911-001	
35	Barrier	71-112-971-001	
36	Strip	71-114-147-001	
37	Insulation	71-114-148-001	
38	Washer	00-651-017-179	
39	Spacer	71-115-589-001	EFG
40	Washer	71-115-941-001	EFG
41	Roll Pin	00-671-176-350	
42	Nut	15-171-063-006	
43	Cotter Pin	00-671-195-119	
44	Pin	00-957-211-902	ABCD
45	Screw	15-611-318-428	
46	Nut	15-171-063-005	
47	Screw	15-611-318-556	ABE
48	Screw	00-611-318-558	CDFG
49	Nut	15-171-063-008	
50	Screw	00-615-245-227	
51	Nut	00-633-039-210	
52	Screw	00-615-114-438	A
53	Screw	15-171-433-001	CDFG
54	Screw	00-615-114-440	BE
55	Screw	00-611-375-227	
56	Washer	00-651-017-087	
57	Screw	00-615-249-239	CDEFG
58	Screw	00-615-249-235	B
59	Rd. Washer	00-651-017-087	
60	Lockwasher	00-655-017-022	
61	Screw	00-611-315-373	
62	Lockwasher	00-655-017-026	
63	Bolt	15-171-769-001	EFG
64	Washer	00-651-007-230	EFG
65	Nut	15-171-063-011	EFG
66	Bumper Block	18-657-780-198	ABCD FG
67	Cushion	18-657-780-197	ABCD FG
68	Bumper	18-657-780-196	ABCD FG
69	Screw	00-615-345-229	ABCD FG
70	Rd. Washer	00-651-007-900	
71	Washer	00-651-017-913	

Page 50



PARTS

Item	Description	Part Number	Usage
1	Barrier Stack	71-303-149-501	
2	Core	71-200-806-504	
3	Barrier Assembly	71-209-698-501	
4	Coil (Rear)	71-208-896-501	
5	Coil (Front)	71-208-896-502	
6	Pole Piece	71-116-426-501	
7	Core	71-115-647-501	
8	Tube	71-111-912-001	
9	Plate	71-112-771-002	
10	Block	71-112-993-002	
11	Band	71-915-843-005	
12	Block	71-115-643-001	
13	Channel	71-115-644-002	
14	Plate	71-115-646-001	
15	Arc Runner	71-115-648-001	
16	Spacer	71-209-188-003	
17	Spacer	71-209-188-002	
18	Channel	71-302-529-005	
19	Channel	71-302-529-006	
20	Arc Runner	71-302-914-001	
21	Support	71-303-029-001	
22	Wedge	71-116-550-001	
23	Arc Chute Assembly (Rear)	71-401-440-503	
24	Coil (Sleeve)	18-726-294-002	
25	Plate	71-208-887-001	
26	Plate	71-208-888-001	
27	Washer	71-105-182-007	
28	Bar	71-116-815-001	
29	Support	71-114-756-002	
30	Bushing	15-171-038-004	
31	Screw	00-615-071-424	
32	Screw	00-615-662-377	
33	Nut	00-639-030-016	
34	Screw	00-611-315-378	
35	Screw	00-611-315-400	
36	Screw	00-611-315-496	
37	Screw	00-615-644-218	
38	Screw	00-615-413-220	
39	Screw	00-615-644-220	
40	Screw	00-615-662-229	
41	Nut	15-171-063-004	
42	Nut	15-171-063-011	
43	Nut	00-633-039-210	
44	Washer	00-651-007-230	
45	Washer	00-655-017-026	
46	Washer	71-112-773-001	
47	Adhesive	15-333-031-002	

PARTS

Page 52




Figure 5. FC-500 B Arc Chute (Codes A through D)

PARTS

Item	Description	Part Number	Usage
1	Arc Chute Assem.	18-471-243-515	
1	Channel, L.H.	18-728-500-572	
2	Channel, R.H.	18-728-500-573	
3	Barrier Stack	71-302-838-501	
4	Bar	71-112-987-001	
5	Screw	00-611-315-419	
6	Washer	00-651-007-900	
7	Lockwasher	00-655-067-180	
8	Block	71-112-993-001	
9	Block	71-112-989-001	
10	Self Tp. Scr.	00-615-644-218	
11	Arc Runner	18-396-437-501	
12	Self Tap Scr.	15-171-074-008	
13	Self Tap Scr. Flat Hd.	00-615-413-218	
14	Fibre Strap	71-915-843-014	
15	Coil Rear	71-208-183-001	
16	Coil Front	71-302-562-001	
17	Coil Sleevng	18-726-294-001	
18	Core Assy.	18-730-618-502	
19	Pole Piece	18-730-883-001	
20	HH Screw	00-611-315-494	
21	Washer	00-651-007-214	
22	Lk. Nut Stover	15-171-063-011	
23	Pan Hd. Scr.	00-615-662-900	
24	Stop Nut	00-633-039-210	
25	Block	18-657-825-058	
26	Self Tap Scr.	00-615-644-220	
27	Support	71-210-601-003	
28	Barrier	71-208-427-501	
29	Roll Pin	00-671-171-900	
30	HH Screw	00-611-315-396	
31	HH Screw	00-611-315-397	
32	Washer	00-651-007-146	
33	Lk. Nut Stover	15-171-063-004	
34	Spacer BKK	18-730-885-001	
35	Support	18-730-886-001	
36	Connecting Rod	18-730-887-003	
37	Flat Hd. Scr.	00-615-331-426	
38	Flat Hd. Scr.	00-615-331-422	
39	Lk. Nut Stover	15-171-063-006	
40	Channel, L.H.	71-302-529-002	
40A	Channel, R.H.	71-302-529-001	
41	Plate	71-112-996-001	
42	Plate	71-112-994-001	
43	Plate	71-112-996-003	
44	Arrow Label	15-171-120-004	
45	Adhesive	15-333-031-002	

PARTS

Page 54





Figure 6. FC-750B Arc Chute

PARTS


Item	Description	Part Number	Usage
	Channel Assy - R.H.	18-397-371-502	
	Channel Assy - L.H.	18-397-371-501	
	Spacer	71-209-188-003	
	Spacer	71-209-188-002	
	Barrier Assy	18-728-500-588	
7	Barrier Assy	18-728-500-588	
8	Block	71-115-643-001	
9	Block	71-112-993-002	
10	Pole Piece	18-730-882-001	
11	Tape .006 x .75 3M #27	00-455-081-006	
12	Coil (Rear)	71-208-896-501	
13	Coil (Front)	71-208-896-502	
	Core	18-730-618-501	
	Air Pump Assy	18-393-215-501	
	Spacer	18-657-825-130	
24	Band	71-915-843-015	
25	Coil Sleaving	18-726-294-002	
26	Spacer	18-657-825-061	
27	Block	18-657-825-058	
32	Cross Support	18-730-886-002	
33	Spacer Block	18-730-885-002	
34	End Tie Bar	18-730-887-002	
35	Fl. Hd. Scr., 31 x 1.5	00-615-331-426	
36	.312 Rd. Washer	00-651-007-900	
37	Stover Locknut, .31	15-171-063-006	
38	Fl. Hd. Scr., .31 x 1.0	00-615-331-422	
40	Stud Assy.	18-657-813-508	
41	.25-20 x 4.5 Hex Hd. Cap Scr.	00-611-315-400	
42	.38-16 Stover Nut	15-171-063-011	
43	.25-20 Stover Nut	15-171-063-004	
44	.38 Rd. Washer	00-651-007-230	
45	Washer	71-112-773-001	
49	.25 Lockwasher	00-655-017-026	
50	#10-32 x 1.5 Pan Hd. Mach. Scr.	00-615-662-229	
51	#10-16 x .62 Fl. Hd. Self Tap Scr.	00-615-413-220	
55	#10-16 x 1.62 Self Tap Scr.	00-615-644-230	
56	#10-16 x .50 Self Tap Scr.	00-615-644-218	
57	#10-32 x 1.75 Rd. Hd. Mach. Scr.	15-615-513-001	
58	#10-32 Elastic Stop Nut	00-633-039-210	
63	.25-20 x .75 Button Hd. Scr.	00-615-015-375	
64	Arrow Label	15-171-120-004	

PARTS

Page 56



SIDE VIEW



FRONT VIEW

Figure 7. Stored Energy Frame & Operator Assembly




Figure 7. Stored Energy Frame & Operator Assembly (continued)

PARTS

Page 58

Item	Description	Part Number	Usage
9	Plunger Assembly	18-657-657-527	
10	Guide Assembly	71-302-796-562	
11	Indicator Arm Assembly	18-723-509-561	
12	Piston Assembly	18-724-407-501	
13	Guide Assembly	18-391-037-501	
14	Ground Contact Assy.	71-113-437-501	
15	Bracket Assembly	18-657-852-548	
16	Stop	72-120-568-502	
17	Foot Assembly	18-657-506-562	
18	Frame Assembly	72-320-035-502	
19	Socket	71-204-604-028	
20	Stud	18-292-228-031	
21	Pin	71-104-754-034	
23	Pin	71-104-754-040	
24	Shoulder Stud	71-108-105-003	
25	Oper. Counter	71-110-940-002	
26	Plunger	71-113-442-001	
27	Stop	71-113-478-001	
28	Yoke End	71-113-487-002	
29	Angle	71-113-530-001	
30	Rod End	71-113-541-003	
31	Spring	71-113-621-001	
32	Rod End	71-113-633-001	
33	Spring	71-113-669-001	
34	Cup	71-114-151-001	
35	Comp. Spring	71-114-153-001	
36	Bumper	71-114-154-001	
37	Cylinder	71-114-155-003	
38	Racking	71-114-156-001	
39	Valve Disc	71-115-244-001	
40	Rod	72-120-329-001	
41	Comp. Spring	71-140-125-001	
42	Spring	71-153-031-001	
43	Bracket	72-120-708-001	
44	Pin	18-657-523-124	
45	Angle	18-657-765-237	
46	Pull, Rod	18-657-229-198	
47	Washer	71-152-809-002	
49	Bracket	18-657-522-326	
50	Crank Assembly	18-723-508-501	
51	Roller	72-120-706-001	
52	Hex Hd. Bolt	00-611-343-030	
53	Bracket	18-723-506-002	
54	Handle	15-171-175-001	
55	Arm	72-120-399-001	

PARTS

Item	Description	Part Number	Usage
	Switch	15-171-044-004	
	Round (Rod)	71-104-107-021	
	Needle Bearing	00-813-119-814	
	Yoke End Adj.	00-691-701-901	
	Yoke End Adj.	00-691-701-903	
68	Self Tap SCR	00-615-573-172	
69	Hex Hd. Cap SCR	00-611-315-378	
70	Hex Hd. Cap SCR	00-611-315-468	
71	Hex Hd. Cap SCR	00-611-315-422	
72	Hex Hd. Cap SCR	00-611-315-424	
	Hex Hd. Cap SCR	00-611-315-465	
	Hex Hd. Cap SCR	00-611-315-466	
	Hex Hd. Cap SCR	00-611-315-546	
	Hex Hd. Cap SCR	00-611-315-548	
	Hex Hd. Cap SCR	00-611-315-562	
79	Cap	00-633-182-060	
80	Hex Hd. Cap SCR	00-611-315-382	
81	Hex Nut	00-631-003-204	
82	Hex Nut	00-631-059-106	
84	Locknut	15-171-063-006	
	Locknut	15-171-063-011	
	Locknut	15-171-063-012	
	Locknut	15-171-063-010	
	Nut	00-633-083-105	
	Nut	00-633-025-220	
90	Jam Nut	00-631-171-108	
91	Jam Nut	00-631-171-110	
92	Cotter Pin	00-671-195-049	
93	Cotter Pin	00-671-195-115	
94	Cotter Pin	00-671-195-119	
95	Cotter Pin	00-671-195-191	
96	Roll Pin	00-671-176-377	
97	Clevis Pin	00-957-211-901	
98	Clevis Pin	00-957-211-903	
99	RD Washer	00-651-007-146	
100	RD Washer	00-651-007-900	
101	RD Washer	00-651-007-214	
102	RD Washer	00-651-007-285	
103	Lockwasher	00-655-017-026	
104	Lockwasher	00-655-017-032	
105	Lockwasher	00-655-017-040	
106	Wheel	15-171-067-002	
107	Spring	15-171-700-001	
108	Jam Nut	00-631-171-104	
109	Hex Hd. Cap SCR	00-611-315-468	
121	Pin	18-657-464-105	
122	Retaining Ring	00-673-165-075	
123	Washer	71-152-809-026	
124	Indicator	71-101-247-001	

PARTS

Page 60

Item	Description	Part Number	Usage
133	Roll Pin	00-671-176-453	
134	Bracket	18-724-562-001	
135	Drive Support	18-657-768-200	
136	Drive Shaft	18-724-563-001	
137	Drive Shaft	18-724-563-002	
143	V Joint	18-657-768-261	
144	Bearing	00-815-081-040	
145	Roll Pin	00-671-171-313	
147	Cap Screw	00-611-315-369	
148	RD Washer	00-651-007-160	

*Consists of Item 134 to 148.





Figure 8. Type 515-2 Stored Energy Operator Assembly


PARTS

Page 62




SIDE VIEW

View B




FRONT VIEW



View C

PARTS



PARTS

Page 64

Item	Description	Part Number	Usage
	Stop Bracket Assembly	18-469-163-501	
	Slit Spacer	00-813-119-810	
	Collar	00-813-119-814	
	Inner Race **	00-813-119-821	
	Spacer	18-657-852-536	
6	Stop Bracket Assembly	18-657-852-582	
8	Slit Spacer	18-657-800-113	
9	Collar	18-657-467-290	
10	Inner Race **	18-467-478-335	
11	Spacer	18-158-935-009	
		00-815-225-131	
		15-813-119-003	
		18-657-463-368	
		18-657-463-389	
		18-657-463-390	
17	Pin	18-657-464-012	
18	Pin	18-657-523-064	
19	Shaft	18-657-463-389	
20	Motor*	18-469-223-001	48V DC
		18-469-223-002	115 AC
			125V DC
		18-469-223-003	230V
		18-657-463-385	250V
		18-657-463-390	
23	Interlock Rod	18-657-522-269	
24	Roller Bearing	15-813-073-003	
25	Torsion Spring	18-657-466-081	
26	Torsion Spring	18-657-466-080	
27	Pawl Return Spring	18-657-229-240	
	Complete Spring	15-837-321-008	
	Rolling Pin	00-673-165-062	
	Screw	18-158-935-011	
		18-657-205-390	
		00-671-176-325	
33	Roll Pin	00-671-176-325	
34	Roll Pin	00-671-176-383	
35	Roll Pin	671-173-002	
36	Roll Pin	00-671-171-375	
37	Washer	18-657-522-303	
38	Washer	15-171-091-005	
39	Screw	00-615-245-218	
40	Lockwasher	00-655-017-022	
	Screw	00-613-375-392	
	Washer	00-655-017-026	
43	Lockwasher	00-655-017-026	
44	Elastic Stop Nut	00-633-025-116	
45	Jam Nut	00-631-143-104	

PARTS

Item	Description	Part Number	Usage
41	Roll Pin	00-671-176-373	
42	Roll Pin	00-671-171-379	
43	Spacer	18-657-523-278	
44	Roll Pin	00-671-176-189	
45	Roll Pin Assembly	18-390-202-501	
52	Cam Assembly	18-389-061-501	
53	Cam Assembly	18-389-061-502	
54	Linkage Assembly (Consists of items 104 to 113A)	18-469-116-501	
55	Motor & Closing Control. Control Consists of items 115 to 135	18-390-246-501	
56	Indicator Assembly	18-723-511-502	
57	Control Switch & Mfg.	18-395-321-801	
58	Control Switch Assembly	18-724-690-003	
59	Control Switch Assembly	18-657-770-518	
62	Clevis Pin	15-171-751-001	
63	Solenoid Closing*	15-171-339-001	48V DC
63A		15-171-339-002	125V DC
63B		15-171-339-003	250V DC
63C		15-171-339-004	120V AC
		15-171-339-005	240V AC
		15-171-339-012	24V DC
		15-171-339-006	24V DC
		15-171-339-007	48V DC
		15-171-339-008	125V DC
64C		15-171-339-009	250V DC
64D		15-171-339-017	120V AC
64E		15-171-339-011	230V AC
65	Trip Latch Switch*	18-657-657-565	AC
66	Strip	18-657-467-239	
67	Screw	00-615-223-172	
68	Lockwasher	00-655-017-020	
69	Screw	00-615-245-222	
70	Lockwasher	00-655-017-022	
71	Screw	15-171-738-001	
72	Term. Block Supp. Bracket	18-657-524-111	
73	Term. Block	15-171-051-007	
74	Screw	00-615-471-124	
75	Lockwasher	00-655-047-060	
80	Chain Link	00-831-349-065	
81	Retaining Ring	18-657-464-105	
82	Washer	00-673-165-075	
83	Screw	71-152-809-026	
84	Washer	15-171-059-005	
85	Washer	18-657-464-118	
86	Washer	00-655-067-200	
87	Washer	00-651-027-087	
89	Grease (1 lb. container)	00-337-131-001	
90	Spring Retainer	18-657-523-038	

PARTS

Page 66

Item	Description	Part Number	Usage
		18-657-463-369	
		18-657-942-303	
		18-733-219-001	
		15-171-323-001	
		15-171-323-001	
96	Retaining Ring	00-673-165-100	
97	Retaining Ring	00-673-165-087	
98	Shim	18-657-784-007	
101	Washer	71-114-297-001	
102	U Joint	18-657-768-261	
		00-671-176-187	
		71-101-258-504	
		18-657-510-524	
		15-171-074-001	
		18-657-463-369	
108	Spring	18-657-523-331	
109	Washer	71-152-809-026	
110	Spring Holder	18-657-523-332	
111	Retaining Ring	00-673-165-075	
112	Spring Anchor	18-657-523-333	
		18-657-800-115	
		15-171-129-004	
		00-612-119-813	
		18-657-564-001	
		00-612-119-813	
117	Closing Latch Check Switch	15-171-323-001	AC
118	Closing Latch Check Switch	15-171-323-001	DC
120	Shield	18-657-468-090	
122	Screw	00-615-471-130	
123	Washer	00-655-047-060	
		14-147-052-002	
		00-617-247-470	
		00-631-171-106	
		00-655-017-032	
		00-655-017-032	
129	Screw	00-615-471-124	
130	Screw	00-615-485-216	
131	Washer	00-655-017-022	
132	Washer	00-651-007-907	
133Y	Relay, Anti-Pump	00-871-797-107	125V DC
	Relay, Anti-Pump	00-871-797-108	250V DC
	Relay, Anti-Pump	00-871-797-109	48V DC
	Relay, Anti-Pump	00-871-797-115	24V DC
		15-171-405-002	120V AC
		15-171-405-001	230V AC
135	Screw	00-615-291-171	
137	Capacitor Trip Device *	71-301-550-502	
138	Bumper (Inside of item 28)	18-657-822-286	
139	Washer	71-163-273-001	

PARTS

Page 67

Item	Description	Part Number	Usage
140	Washer	71-140-443-001	
141	Washer	18-657-765-121	
142	Switch	18-736-827-502	125V DC
143	Switch	18-394-426-544	250V DC
	Screw	00-611-315-470	
144	Nut	00-631-059-106	
145A	Latch Check	18-471-853-501	24V DC
145B	Relay	18-471-853-502	48V DC
145C	Reclose Duty	18-471-853-503	125V DC
145D	Only	18-471-853-504	250V DC
145E	18-471-853-505	120V AC
145F	18-471-853-506	240V AC

SIEMENS-ALLIS

Siemens-Allis, Inc.
Switchgear Division
P.O. Box 29503
Raleigh, NC 27626
(919) 365-6660