

# INSTRUCTIONS

*for*  
the Installation, Care and Operation  
of Circuit Breakers and Accessories

TYPE "HJ" MOVABLE PORTION

SECTION 1: TYPE AM-150C RUPTAIR  
MAGNETIC VERTI-LIFT  
BREAKER AND AUXILIARY  
EQUIPMENT


SECTION 2: TYPES JAY-802, JDY-801,  
JDY-802, & JY-8 RELAYS

BOOK BWX-6347-4 3

These instructions are not intended to cover all details or variations that may be encountered in connection with the installation, operation, and maintenance of this equipment. Should additional information be desired contact the Allis-Chalmers Mfg. Company.

**ALLIS-CHALMERS MFG. CO.**  
BOSTON WORKS • BOSTON • MASS.


17  
ALLIS-CHALMERS  CIRCUIT BREAKER EQUIPMENT



1M-7-55-BBP-440748

Illustration 160388

**ALLIS-CHALMERS**  **CIRCUIT BREAKER EQUIPMENT**




1M-7-55-BBP-440748

*Illustration 160386*

ALLIS-CHALMERS



CIRCUIT BREAKER EQUIPMENT



1M-7-55-BBP-440748

Illustration-160433

# ALLIS-CHALMERS MANUFACTURING COMPANY

INDEX TO INSTRUCTION BOOK  
NO. BWX-6347 COVERING THE  
ALLIS-CHALMERS TYPE "HJ" MOVABLE PORTION  
CONSISTING OF  
THE TYPE AM-150C RUPTAIR MAGNETIC VERTI-LIFT BREAKERS  
AND AUXILIARY EQUIPMENT

## SECTION I

<u>CONTENTS</u>	<u>PARAGRAPH</u>
<u>GENERAL</u>	
	1-10
PROPER CARE IS ESSENTIAL TO GOOD SERVICE	1-4
INSPECTION	5
RECEIPT	6
STORAGE	7
HANDLING	8
INSTALLATION	9-10
<u>DESCRIPTION</u>	
	11-19
GENERAL	11-12
CONTACTS	13
ARC-CHUTE ASSEMBLY	14
PHASE BARRIERS	15
BREAKER MECHANISM	16
SOLENOID OPERATOR	17
AUXILIARY EQUIPMENT	18
METHOD OF ARC INTERRUPTION	19
<u>OPERATION</u>	
	20-23
CLOSING	20-21
OPENING	22-23
<u>ADJUSTMENTS</u>	
	24-37
GENERAL	24-25
CONTACT ALIGNMENT	26
IMPULSE SPRINGS	27
STROKE	28
CONTACT ADJUSTMENTS	29
CONTACT PRESSURE OF ISOLATING SWITCH CONTACT BLADES	30
TOGGLE SETTING	31
OPERATOR MECHANISM LATCH	32
AUXILIARY SWITCH	33
LIMIT SWITCH	34
LATCH CHECK SWITCH	35
INTERLOCK CRANK	36
TRIPPING UNIT	37

# ALLIS-CHALMERS MANUFACTURING COMPANY

Index to BWX-6347-3 (Cont'd)

## CONTENTS.

## PARAGRAPH

### FINAL INSTALLING INSPECTION

38-46

CHECK WITH APPROVED ARRANGEMENT DRAWING  
LUBRICATION AND OPERATION  
WIRING  
CHECKING IN CUBICLE  
GROUNDING CONTACTS  
ENGAGEMENT OF PRIMARY AND SECONDARY CONTACTS  
MECHANICAL INTERLOCK  
OPERATION IN TEST POSITION  
FASTENINGS

38  
39  
40  
41  
42  
43  
44  
45  
46

### MAINTENANCE

47-51

GENERAL  
CONTACTS  
BARRIER STACK  
BREAKER TIMING  
LUBRICATION

47  
48  
49  
50  
51

### REPLACEMENT PARTS

HOW TO ORDER  
RECOMMENDED SPARE PARTS LIST

52-54  
88

### INSTALLATION OF REPLACEMENT PARTS

55-87

GENERAL  
PHASE BARRIERS  
ARC-CHUTE ASSEMBLY  
BARRIER STACK  
FRONT AND REAR ARC RUNNERS AND BLOW OUT COILS  
FLASH PLATES  
ARCING CONTACTS  
MAIN CURRENT CARRYING CONTACTS  
DISCONNECT CONTACT ARMS  
MAGNETIC BLOWOUT PLATES  
BUSHING ALIGNMENT  
FRONT BUSHING STUD  
FRONT BUSHING SUPPORT INSULATOR  
REAR BUSHING STUD  
REAR BUSHING SUPPORT INSULATOR  
CLOSING COIL  
TRIP COIL - SHUNT TRIP

55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65-67  
68-73  
74-75  
76-80  
81-83  
84-86  
87

### SECTION II

INSTRUCTION BOOK FOR TYPES JA-802,  
JD-801, JD-802, and JY-8 RELAYS

---

# ALLIS-CHALMERS MANUFACTURING COMPANY

LIST OF  
ILLUSTRATIONS FOR  
INSTRUCTION BOOK BWX-6347-3  
TYPE AM-150C RUPTAIR MAGNETIC BREAKER

<u>FIGURE</u>	<u>DESCRIPTION</u>
1	Typical "HJ" Movable Portion
2	Typical Ruptair Magnetic Breaker Assembly
3	Typical Solenoid Operator Assembly
4, 5, & 6	Typical Operator Linkage Diagrams for Type AM-150C Magnetic Breaker
7	Typical Front Bushing and Contact Assembly
8	Typical Arc-Chute Assembly
9	Typical Rear Bushing and Disconnect Contact Assembly
10	Typical Auxiliary Switch and Plugging Device Assembly
11	Typical Puffer Assembly

INSTRUCTIONS  
FOR THE INSTALLATION AND OPERATION  
OF  
ALLIS-CHALMERS TYPE AM-150C RUPTAIR  
MAGNETIC VERTI-LIFT BREAKER AND  
AUXILIARY EQUIPMENT

GENERAL

PROPER CARE IS ESSENTIAL TO GOOD SERVICE

1. The Allis-Chalmers type AM-150C Ruptair Magnetic Breaker is an integral unit consisting of a power circuit breaker complete with relays, auxiliary switches and equipment necessary for its operation and control. When supplied with primary and secondary disconnecting contacts, it becomes the complete movable portion for Allis-Chalmers Verti-Lift type switchgear and is usually referred to as the "Movable Portion".
2. The successful operation of this unit depends on proper installation and maintenance, as well as proper design and manufacture.
3. The information and instructions included in this book are to aid you in installing and maintaining these units so that you will obtain the highly satisfactory service of which they are capable.
4. Please pass this information along to your engineers and erection and service men who will then be better able to aid you in realizing the best service from these units.

INSPECTION

5. Before leaving the factory, each movable portion has been carefully inspected and packed by workmen experienced in the proper handling of electrical equipment.

RECEIPT

6. Upon receipt of the movable portion remove all packing traces and examine the breaker and auxiliary equipment carefully to see that no damage has occurred during transit. If any injury is disclosed, a claim for damages should be filed at once with the transportation company and the Allis-Chalmers Manufacturing Company notified.

STORAGE

7. If the movable portion cannot be set up immediately in its permanent location, and it is necessary to store the equipment, it should be kept in a clean dry place and protected from dust, the action of corrosive gases, from coal combustion products, etc., and from mechanical injury.

## HANDLING

8. In removing an AM-150C breaker from its crate and handling same with a crane or hoist, a spreader should be used to prevent lateral distortion of the lift hooks. Avoid short hitches which could place strain on and damage insulating parts, fittings, arc-chutes, etc.

## INSTALLATION

9. The Allis-Chalmers type AM-150C breaker is designed such that it is particularly suitable for application within a fixed portion or metal clad switchgear cubicle. Before installing a breaker in a cubicle, such cubicle should be cleaned of all dirt and foreign material. Insulation should be wiped clean and checked for dielectric strength before energization. In the case of verti-lift gear, the lift mechanism should be lubricated and checked for proper operation.

10. The movable portion should be inspected thoroughly to see that packing braces used to hold moving parts during shipment are removed.

**CAUTION: BREAKER IS SHIPPED LOCKED IN CLOSED POSITION AND WITH BARRIER STACKS ITEM 8-231 PACKED IN SEPARATE SHIPPING CONTAINERS. BARRIER STACKS MUST BE INSTALLED BEFORE BREAKER IS ENERGIZED.**

To remove breaker locking means, remove the solenoid operator cover item 2-15 and cut the wire which is wrapped around the latch plate item 3-131. To install barrier stacks, merely lift off the upper arc chute assembly (see Fig. 8), place barrier stacks in position, and replace upper arc chute assembly. Barrier stacks must be handled with care to avoid damaging the ceramic plates.

The breaker insulating surfaces, and bushings must be dry and clean, adjustments checked, fastenings made secure, if necessary, moving parts properly lubricated and breaker operation tried. When installing the movable portion in cubicle for the first time make sure that the lifting hooks and pins on breaker frame engage properly with the mating parts of lift mechanism. As breaker is then raised into position, check to see that the grounding contacts at rear of breaker make properly with the stationary contacts in cubicle, and that primary and secondary contacts are in alignment for proper contact engagement. Make sure that there is no interference between breaker phase barrier and primary insulator tubes and shutters if used. Also, before lowering movable portion it is advisable to properly align the swivel casters to facilitate withdrawal of the unit from the cell.

## DESCRIPTION

### GENERAL

11. The Allis-Chalmers type "HJ" movable portion shown in Fig. 1 consists of an AM-150C Ruptair magnetic circuit breaker for verti-lift applications, with auxiliary equipment suitably arranged for best function and easy installation in a

metal-clad cubicle. As part of standard equipment, each order is furnished with one maintenance operating device. THIS DEVICE IS NOT SUITABLE FOR ACTUATING THE BREAKER ON AN ENERGIZED CIRCUIT. A transfer handle for moving the breaker is also provided.

12. The Ruptair magnetic circuit breaker differs essentially from oil breakers and air-blast breakers in that it does not depend on any stored medium such as oil or compressed air for interruption. Referring to Figure 2, the component parts of the breaker are mounted in a structural steel frame. The operator, the operating shaft and connecting links are mounted on the lower front section of breaker frame and are well shielded. The vertical terminal studs which are insulated with bakelite tubing extend upward through the insulating breaker top plates and support the other parts of the electrical circuit. Interruption occurs within the arc chute assemblies which are mounted at the top between the front and rear bushings.

#### CONTACTS (Figs. 7 & 9)

13. The stationary contact structure of each phase is made up of two sets of contacts, namely; main current carrying, and arcing, which are mounted on the front bushing terminal. The movable contacts are attached to contact arms that pivot from the lower end of the rear bushing stud. Transfer areas of current carrying contacts are silver plated, and arcing contact surfaces are of a silver-tungsten alloy. The main current carrying contacts and arcing contacts are finger type. The main arcing contacts are in front of the blowout coils and above the main contacts and are connected to the front bushing studs. All contacts are backed by steel springs giving positive contact pressure when engaged.

#### ARC-CHUTE ASSEMBLY (Fig. 8)

14. Each arc-chute assembly consists of a two section tube of arc resistant material which provides phase isolation for interruption, and venting of the by-product gases of interruption. The lower half of the arc-chute contains:

- (1) The blowout coils, front (8-236) and rear (8-245) which are locked in place by their cores (8-246) fitting into holes in the flash plate supports (8-234).
- (2) The front and rear arc runners (8-232 & 8-250) which are connected to the blowout coils and fastened to the ends of the tube for support.
- (3) The flash plate supports and refractory flash plates (8-242) mounted on the inside and on each side of the tube in the area of arcing.

Resting on the flash plate supports (8-234) is an arc chute barrier stack (8-231) bounded at either end by the head and tail arc runners and blow out coils. The barrier stack is made up of a number of refractory plates having "Vee-shaped" slots of varying height arranged in spaced relation and cemented into a unit. The barrier stack is mounted with slots facing downward such as to expose the "Vee" sections to the arcing area, with the top end being vented. The refractory compo-

sition is essentially non-gas forming and is highly resistant to heat shock. Also resting a-top the bottom section of the arc-chute tube and encasing the barrier track and arc runners in the top section of the arc-chute tube to which are fastened four blow out side plates (8-251) which contact the ends of the round cross cores (8-246), completing the magnetic blowout circuit. The upper section tube is provided with handles (8-260) to facilitate removal, thus making contact parts readily accessible for inspection.

#### PHASE BARRIERS

15. Full size barriers (2-35 & 2-21) of high dielectric material isolate each phase and are arranged for easy removal.

#### BREAKER MECHANISM

16. The breaker mechanism consists essentially of movable contact arms and insulating links which connect the contact arms to the operator mechanism.

#### SOLENOID OPERATOR (Fig. 3)

17. The AM-150C magnetic breaker is equipped with a solenoid operator which is an integral part of the breaker unit. It is mounted at lower front section of breaker and is contained within the breaker frame. The operators are furnished with a mechanically trip-free mechanism consisting of a toggle linkage so designed as to provide quick and positive tripping at any position of the closing stroke. The mechanism is of low inertia, capable of quick acceleration and is equipped with a low energy trip device and opening coil, designed to provide high speed release of the trip mechanism upon energization of the trip coil.

#### AUXILIARY EQUIPMENT (Fig. 1)

18. The auxiliary equipment consists of a plugging device (1-4) control relay (1-6), capacitor trip device (1-7) and closing rectifier (1-9) as required. The first three devices are mounted on the front control panel while the latter is mounted on the lower plate at rear of breaker. The plugging device houses the auxiliary switch, which is wired to the bayonet contacts of plugging device such that when movable portion is raised into operating position in the cubicle the bayonet contacts engage the stationary contacts to complete the control circuit for operation of the breaker.

#### METHOD OF ARC INTERRUPTION

19. The Ruptair magnetic circuit breaker does not depend on any prestored medium, such as oil or compressed air, for arc interruption. Interruption is accomplished in air at atmospheric pressure, with the aid of a self induced magnetic blowout field and air draft. At the time the trip coil is energized, current is being carried through the main contacts. As the movable contact blade separates from the main contact, the current is transferred to the arcing contact to protect the main current carrying surfaces. As the arcing contacts part a power arc is drawn which is transferred first to the head and then the tail arc runners as

the moving contact passes close to them on its opening stroke. The transferral of the arc to the arc runners establishes the full flow of current through the blowout coils, setting up the magnetic field, which in accompaniment with natural thermal effects of the heated arc, configuration of the current carrying circuit, etc., tend to force the arc upward into the barrier stack. The cool surfaces of the barrier stack tend to cool and deionize the arc while the "Vee" slots in the stack reduce its cross section and elongate it. The arc runners are made of wide, heavy material for maximum heat dissipation and help to minimize metal vaporization. All of the above effects work together to increase the resistance of the arc and enable it to be extinguished at an early current zero. On recent breakers, a puffer assembly, Fig. 11, is provided to aid interruption at low currents. Normally, low currents do not produce a magnetic blowout effect strong enough to move the arc quickly, and interruption may take in the order of thirty cycles. The puffer reduces this to within the eight cycle rating normal on higher currents. As the breaker opens, the opening springs move piston assembly (11-364) in cylinder (11-363) to direct a small amount of air through tube (11-361) and nozzle (11-360) into the arcing area. This air assists in moving the arc into the barrier stack and thereby facilitates an early current interruption.

#### OPERATION

##### CLOSING (Fig. 4)

20. Figure 4 shows the mechanism of the operator in the open position; points "A", "B", "C" and "D" are fixed centers about which crank arms (6) and (7), links (8), latch (9) and trip plate (10) rotate respectively. Center "E" is a temporarily fixed center being restrained as long as pressure latch (9) is in contact with roll (5).

21. The closing force is applied at the toggle roll (2) by means of the armature ram (1). For maintenance closing, the closing force is applied on toggle link (3). The toggle linkage (3) and (4) in moving to the final over-center position rotates crank arms (6) and (7), which are secured to a common shaft, in a counter-clockwise direction. The rotation of crank arm (7) causes through connection rod (30) the movable contact arms to rotate counter-clockwise, thus closing the breaker. Also, with the rotation of crank arm (7) the accelerating springs (11) and (12) are compressed. The breaker is held in the closed position by the over-center positioning of toggle links (3) and (4) against stop plate, point "E" being held stable by pressure latch (9) as shown in Fig. 5.

##### OPENING (Fig. 5)

22. Opening of the breaker is accomplished either manually or electrically. Manually, the breaker is tripped by pushing on extension of trip plate (10) which is easily accessible through the front panel (See Fig. 4) where directions for operation are clearly indicated. Electrically, a trip coil is energized which lifts its armature and trip pin to strike against and rotate the trip bracket (10) counter-clockwise. With this rotation the striker rod (13) pushes downward on tail of latch (9) to rotate it counter-clockwise. The rotation of latch (9) frees the temporarily fixed center "E" allowing the link (8) to rotate clockwise, thus releasing the closing force from cranks (6 and 7) such that springs (11 and 12) drive the crank arms (6) and (7) clockwise, thus

rendering the mechanism completely trip-free. The rotation of crank arm (7) acts thru connecting rod (30) to rapidly open the breaker contacts.

23. With the lifting of latch (9), the temporarily fixed center "E" is driven upward and to the front of operator forcing the toggle to break back off center allowing point "E" to be forced back into its normal reset position through the action of link (8) which is spring biased in a counter-clockwise direction. Latch (9), being spring biased clockwise resumes its position behind roll (5), holding center "E" stable for the next closing operation.

### ADJUSTMENTS

#### GENERAL

24. The breaker has been completely set up, adjusted and tested at the factory. However, adjustments or fastenings may be changed or become loosened during shipment, storage or installation and should be checked and corrected, if necessary, before breaker is operated electrically. Manual operation (use maintenance closing handle) of breaker should be used for preliminary operation to see that all parts are free and work smoothly. The bushings and other insulating parts should be clean and dry. All contact surfaces should be inspected to see that they are clean and smooth. (Do not dress silver surfaces). Removal of all phase barriers and removal of arc-chute assemblies as per Paragraphs 57 and 58 gives access to breaker for checking adjustments.

CAUTION: DO NOT ATTEMPT TO RAISE BREAKER IN CUBICLE WITHOUT FIRST REMOVING TRANSFER HANDLE.

NOTE THAT THE MAINTENANCE CLOSING HANDLE IS NOT SUITABLE FOR ACTUATING THE BREAKER ON AN ENERGIZED CIRCUIT.

25. The paragraphs immediately following give the proper adjustments and methods of making same on the Allis-Chalmers type AM-150C Ruptair Air Magnetic Power Circuit Breaker.

#### CONTACT ALIGNMENT

26. The contacts are an integral part of the bushing assemblies and are carefully aligned with the front and rear bushings before shipment and no further adjustment should be necessary. Procedure for alignment of bushings is given in Paragraphs 70-72, and all that is required for proper contact alignment is that the moving contact operates in a plane relatively parallel to the fixed stationary contacts and that all the stationary fingers are engaged.

#### IMPULSE SPRINGS (Fig. 3)

27. The impulse springs (3-113) are factory adjusted such that with the breaker in the fully closed position the springs will be compressed to a length of 5-1/8" - 5-3/16" in order to provide an opening velocity of 14-16 feet per second in the first three inches of movement, measured at the radius of the arcing contact "make"

point. After properly positioning the locknuts (3-112), they are staked in place to insure permanence of adjustment. The contact pressure of the isolating switch contact blades (See Paragraph 30) should be properly adjusted before the accelerating springs are set, since this has some effect on opening velocity.

28. The stroke of the main contact (9-279) is controlled through adjustment of operating arm (2-22). Proper adjustment is obtained when, with the breaker closed, the arcing contact (9-282) bumper surface is not binding tightly on bumper (7-211), and the main contact (9-279) has the maximum possible positive wiping action on the main contact fingers (7-208). Note that the main contacts engage in a "heel and toe" action, first touching at the bottom and then coming to final position at the top, while the bottom initial contact points separate. The described adjustment will provide a separation of the initial contact points of at least  $1/64$ " , usually more, up to approximately  $3/64$ ". Adjustment is obtained by removing pin that fastens connecting rod (2-22) to crank arm (3-117) loosening checknut and adjusting the length of connecting rod by screwing the rod end in or out until with the closing of the breaker the above conditions of adjustment exist on all three phases. After proper adjustment, make sure that the checknut is made up tight and that cotter pins are properly spread. This adjustment should not be made before the accelerating springs are adjusted (See Paragraph 27).

#### CONTACT ADJUSTMENT (Fig. 2, 7 & 9)

29. The contacts are carefully adjusted before shipment and no further adjustment should be necessary. However, it would be well to check the adjustment of the arcing and main contacts before installation and periodically thereafter to insure continuous good service. The arcing and main contacts are adjusted as follows: With the stroke set per Par. 28 adjust the stationary arcing contact (7-213) so that it engages the moving arcing contact (9-282) at a point in the stroke when there is  $1/4$ " plus .000 minus  $1/16$ " air gap between the main contact fingers (7-208) and the moving contact (9-279). In general, this gap (arcing contact lead) will decrease slightly with successive adjustments as the arcing contacts wear in service and should not be permitted to become less than  $3/16$ ". The adjustment should be made individually on each phase, the  $1/4$ " plus .000" minus  $1/16$ " setting being obtained for each phase by positioning with the maintenance closing device. Each arcing contact will then have approximately the same lead, but all will not necessarily make contact at exactly the same time. The arcing contacts should engage freely and not show any tendency to "stub" when making contact.

#### CONTACT PRESSURE OF ISOLATING SWITCH CONTACT BLADES (Fig. 9)

30. The contact pressure of the isolating switch contact blades should be adjusted with reference to Figure 9. Proper adjustment is to have the hinge joint adjusted so that with isolating switch just out of contact, a pull of 6 to 10 pounds will move the contacts toward the open position. In order to measure the required pounds, pull to move the contact. It is suggested that one end of a wire or cord be fastened around the movable arcing contact (9-282) just below the arcing contact surface, and the wire or cord extended through back of breaker frame and attached to a spring scale. The pull must be made approximately perpendicular to the contact. Adjustment is made by positioning the "Stover" locknut (9-288) on

cap screw (9-290) until the pull registers 6 to 10 pounds. Where "Stover" locknuts have been "staked" in position they should be restaked after any change in adjustment to insure permanence of setting.

#### TOGGLE SETTING (Fig. 3)

31. With the breaker in the full closed position, i.e. with toggle roll (3-97) against stop plate (3-93) there must be a minimum clearance of 1/16" between roll (3-97) and end surface of ram (3-102) when armature (3-109) is solidly against the pole head. The toggle roll (3-97) should also be approximately 1/8" in the over-center position. Adjustments if necessary are made by adding or removing shims (3-96) in back of stop plate (3-93). To remove stop plate simply take out cap screws (3-94). However, a check for proper clearance must be made before electrical operation of breaker is attempted. If adjustment is found necessary make sure that all fastenings are secure on completion.

#### OPERATOR MECHANISM LATCH (Fig. 3)

32. The operator mechanism trip latch (3-89) should be set such that the latch pressure is applied at a point approximately 7/32" above the bottom edge of the latch. This may vary slightly due to the requirements of minimum tripping voltage and operator stability on full voltage electrical closure. A check must be made for proper latching before breaker is operated electrically. A suggested method for checking latch position is as follows: With the breaker in the open position chalk the latching surface of latch and then, with maintenance closing handle, apply pressure such that a line of contact between latch roll (3-87) and latch (3-89) will be indicated on chalked surface. Check latching surface and note whether latch is making contact at a point approximately 7/32" above the bottom edge of the latch. If adjustment is found to be necessary it is made by raising or lowering the rubber stop (3-91) in its clamp, or in the case where latch is riding higher than permissible, by carefully cutting off some of the rubber. Very slight change in position of rubber stop results in a greater increment of change at end of latch. Thus care must be exercised in adjustment of rubber stop. After setting rubber stop to correct height make sure that it is set square in clamp as stop will tend to crawl when clamp is tightened. Make sure that clamp is tightened evenly and securely.

#### AUXILIARY SWITCH (Fig. 2 & 10)

33. The auxiliary switch located within the box of the plugging device (1-4) has been adjusted at the factory and as normal installations should not require further adjustments, care should be exercised in making any changes. However, before the breaker is placed in service a check should be made to see that the combination crank and position indicator (10-348) throws approximately equal distances on either side of a horizontal centerline. The adjustment for throw of lever is made by positioning clevis on connecting rod (2-16). After correct adjustment is made, make sure all fastenings and locknuts are secure. Each rotor (10-341) can be adjusted individually in steps of 22-1/2 degrees (see cut) merely by pressing the contact to one side against the spring and rotating it within its insulated rotor housing until it snaps into the desired position.

### LIMIT SWITCH (Fig. 3)

34. The limit switch is located on the lower left side of the operator frame and contains both the "a-a" and "b-b" stages of limit switch contacts. The switch has been adjusted correctly before leaving the factory. However, a check should be made to see that with the solenoid de-energized screw (3-128) is adjusted such that "b-b" contacts are making with approximately 1/32" additional follow up. Adjustment is made by loosening checknut (3-129) and positioning screw (3-128) such that positive contact is obtained with 1/32" follow up. Then check to see that additional overtravel of the contact plunger (3-130) is possible. After screw (3-128) has been positioned correctly, lock in place with checknut (3-129).

### LATCH CHECK SWITCH (Fig. 3)

35. The latch check switch (when furnished) is mounted on the left side of operator frame and the switch operating crank (3-121) is pinned to the crank pin (3-83). Proper adjustment has been made prior to shipment. However, a check should be made to see that contacts are closed only when trip latch (3-89) is in the latched or normal position. When in this position there should be 1/32" positive overtravel of plunger after contact is made. The making of contact with 1/32" overtravel is controlled by setting of screw (3-123). If adjustment is found necessary, make sure that checknut (3-122) is made up tight on completion.

### INTERLOCK CRANK (Fig. 2)

36. The mechanical interlock crank (2-18) located at front right hand side of breaker has been properly adjusted at the factory and no further adjustment should be necessary. However, a check should be made to see that the breaker trips in the first 3/8" of linear travel of roll as crank rotates away from breaker, and that there is 1/16" minimum overtravel. Also, with this setting of interlock crank the breaker must trip within the first 5/16" of movement as the movable portion is lowered from its fully raised position in cubicle. Correct adjustment is made simply by adjusting clevis (2-37) on trip interlock rod such that the above requirements are fulfilled. Care should be taken to insure that the trip interlock arm (2-36) rests on the trip coil housing (3-119) when the breaker is in the fully raised position. After correct adjustment has been made, lock clevis in position with checknut and make sure that cotter pins are spread properly. If with this adjustment the breaker fails to trip in the first 5/16" as it is lowered from fully raised position in cubicle, slightly earlier tripping can be obtained by lengthening the trip rod (3-78). When in adjustment lock in position with checknut.

NOTE: To insure mechanical stability on closing, there should be a nominal 1/16" clearance between trip rod (3-78) and trip latch (3-89).

### TRIPPING UNIT (Fig. 3)

37. The shunt trip or standard trip application as shown on Fig. 3 is factory set and should need no further adjustment. In nominal adjustment, trip pin (3-132) should float freely on its spring and should not bear against trip bracket (3-130).

## FINAL INSTALLING INSPECTION

### CHECK WITH APPROVED ARRANGEMENT DRAWING

38. Make sure that the Ruptair magnetic breaker is properly set up in accordance with the approved arrangement drawing.

### LUBRICATION AND OPERATION

39. Check to see that the mechanism operates freely and that all shaft bearings have been lubricated with a light film of Gargoyle A- No. 0 grease or equal. Prior to shipment the engaging areas of main current carrying contact fingers, movable arcing contact, hinge area of contact arms and solenoid armature have been rubbed with MICROFINE DRY GRAPHITE and all excess wiped off. If occasion arises when any of the above mentioned parts have to be replaced in field they should be treated with the graphite before installation.

CAUTION: GRAPHITE MUST BE KEPT OFF ALL INSULATION UNDER PENALTY OF REPLACING INSULATION AS IT CANNOT BE WIPED OFF SURFACE.

### WIRING

40. Inspect all insulated wiring and check on all terminal connections. Test the wiring for possible grounds or short circuits.

### CHECKING IN CUBICLE

41. Check to see that when installing the movable portions in cubicle the lift pins and hooks on breaker frame engage properly with mating parts of lifting gear.

### GROUNDING CONTACTS

42. Check to see that the grounding contacts at rear of breaker make proper contact with stationary contact in cubicle as breaker is raised into position.

### ENGAGEMENT OF PRIMARY AND SECONDARY CONTACTS

43. As the movable portion is raised into final position, check to see that the primary and secondary contacts are in alignment for proper contact engagement. With breaker fully raised against stop in cell, there should be 5/16" plus or minus 1/16" clearance between bakelite plates of movable and stationary portions of secondary disconnect device.

### MECHANICAL INTERLOCK

44. Check to see that the roll end of the mechanical interlock operating crank at front of breaker falls into slot of tripping cam in fixed portion when breaker has been raised to its final position in cubicle. Check to see if breaker can be closed only in either its test position or in its final raised position.

#### OPERATION IN TEST POSITION

45. The breaker should be operated several times in the test position to see that all parts are working smoothly before it is placed in service.

#### FASTENINGS

46. Check to make sure that all fastenings are secure.

#### MAINTENANCE

##### GENERAL

47. Upon the proper operation of the circuit breaker depends the safety of the operators and the successful functioning of the connected apparatus, therefore, the breaker should have regular systematic, thorough understanding inspection and maintenance. Be sure that the breaker and its mechanism is disconnected from all electric power before any maintenance is attempted. Inspect the breaker and auxiliary equipment mechanically and electrically at least once every six months.

##### CONTACTS

48. Inspect all contacts frequently, depending on severity of service. Replace badly pitted or burned contacts before they are damaged to such an extent as to cause improper operation of the breaker.

##### BARRIER STACKS

49. The arc-chute barrier stacks are very fragile and should be handled carefully. The barrier stacks (8-231) should be inspected for erosion of the plates in the areas of the slots. Stacks should be replaced when erosion progresses to a point such that the slots of the shortest plates have been extended to the lowest hole through the plate above the slot. They should be likewise replaced if plates are broken in vicinity of the slots.

##### BREAKER TIMING

50. Check the contact adjustment and breaker timing occasionally, also check adjustments of auxiliary equipment and see that they function properly. A comparison of breaker timing at any period of maintenance with that taken new, will immediately indicate a condition of maladjustment or friction should the timing vary more than 1/2 cycle on opening or 2 cycles on closing with the same coils.

##### LUBRICATION

51. Keep shaft bearings of breaker mechanism adequately lubricated with a light film of Gargoyle A - No. 0 or its equal.

#### REPLACEMENT PARTS

##### HOW TO ORDER

52. When ordering replacement parts, refer to Figs. 1, 2, 3, 7, 8, 9, 10 and to

the following parts list. Specify quantity, reference numbers, and give description of parts required. Also, give type, amperage, voltage and serial number of breaker on which parts are to be used.

EXAMPLE:- 3 - arcing contact, reference 7-213, for use  
on type AM-150C, 1200 amp., 4160 volts,  
Serial Number 295500, Ruptair Circuit Breaker.

53. A sketch of the part wanted will help materially if any uncertainty exists.

54. It is recommended that sufficient parts be carried in stock to enable operators of circuit breakers to replace without delay any worn, broken, or damaged parts. In the last two columns of the Spare Parts List are given quantities of the parts which are recommended to be kept in stock.

### INSTALLATION OF REPLACEMENT PARTS

#### GENERAL

55. Before removing part to be replaced, observe its function and adjustment. By so doing, it is usually possible to avoid any appreciable amount of adjustment work after the installation of the replacement parts.

CAUTION: BEFORE REMOVING ANY PART, MAKE SURE THAT THE BREAKER AND ITS OPERATING MECHANISM IS DISCONNECTED FROM ALL ELECTRIC POWER.

#### PHASE BARRIERS (Fig. 2)

56. The outside phase barriers (2-21) and inter-phase barriers (2-35) can be removed by simply withdrawing them from the top of breaker. On replacement make sure that the barriers are fully inserted and set in their respective locating slots.

#### ARC-CHUTE ASSEMBLY (Fig. 2 & 8)

57. When removing an arc-chute assembly, remove the phase barriers adjacent to that particular phase, lift off top section of arc-chute tube, remove barrier stack, disconnect blowout coil leads from front and rear bushings, and then lift out lower section of arc-chute tube.

CAUTION: ON INSTALLING MAKE SURE BLOWOUT COIL LEADS ARE FASTENED SECURELY.

#### BARRIER STACK (Fig. 2 & 8)

58. For replacing an arc-chute barrier stack remove top section of arc-chute tube as outlined in Paragraph 57 and lift out barrier stack. On installation make sure that the barrier stack is inserted with the "Vee" shaped slots toward the bottom of the chute.

#### FRONT AND REAR ARC RUNNERS AND BLOWOUT COILS (Fig. 8)

59. Should it be found necessary to replace an arc runner, remove the top section of the arc chute tube and barrier stack as outlined in Paragraphs 57 and 58. Then after the blowout coil leads have been disconnected from the bushings lift out the lower section of the arc-chute tube, remove side plate (8-239) and remove screws holding arc runners (8-232) in place, remove blowout coil (8-246), then remove coil and connected arc runner. To reassemble reverse procedure.

#### FLASH PLATES (Fig. 8)

60. Should it be found necessary to replace a flash plate, remove top section of arc-chute tube, barrier stack, lower section of arc-chute tube, blowout coils and arc runners as described in Paragraphs 57-59, and the desired side of the lower arc-chute tube. The flash plate may then be unfastened from the support plate. To reassemble reverse procedure.

#### ARCING CONTACTS (Fig. 7)

61. To remove the stationary arcing contact remove phase barriers and arc-chute assembly as described in Paragraph 57, and the adjusting screw (7-214) in the arcing contact. The contact may then be pushed from its slot. To reassemble reverse the procedure and adjust contact as outlined in Paragraphs 28 & 29 making sure that all connections are made, springs in place, and fastenings secure. Care should be taken to insure that spacer (7-217) is in place between arcing contact (7-213) and spring (7-202).

#### MAIN CURRENT CARRYING CONTACTS (Fig. 7)

62. To remove the main current carrying contacts, remove the phase barriers and arc-chute assemblies as outlined in Paragraphs 57-58. Remove the bakelite cover plates (7-203) from the front contact block, after which the contact fingers can be pushed from the retaining slot. On replacement make sure springs, spacers, and contact fingers are in proper relationship and free of binds and that all connections are made and fastenings secure.

#### DISCONNECT CONTACT ARMS (Fig. 9)

63. The disconnect contact arms are fastened to the rear stud by means of a bolt and stover lock nut and may be removed by removing the bolt (9-290) and inner bearing tube (9-289). Care should be taken on reassembly to set the hinge joint pressure as described in Paragraph 30. The arcing contact (9-282) may be removed from the disconnect arms by removing the two screws (9-281) holding it in place.

#### MAGNETIC BLOWOUT PLATES (Fig. 8)

64. The magnetic blowout cores (8-251), right and left hand, front and rear, are bolted to the outside of the top section of the arc-chute tube and may be removed by unfastening guide (8-261) from tube after it has been removed from the breaker.

### BUSHING ALIGNMENT (Fig. 2)

65. Proper bushing alignment is of extreme importance for the easy and exact mating of primary contacts as the movable portion is raised into service position in the cubicle. Bushings have been jig aligned with greatest care at the factory prior to shipment. If the occasion arises in the field where alignment of bushings has to be disturbed such as for replacement of bushing studs, support insulators, etc., re-alignment will have to be done by taking exacting measurements with reference to view showing bushing locations on Fig. 2.

66. When it is necessary to remove or disturb a front bushing for replacement purpose, the rear bushings should not be disturbed in any manner in order that they can be used for reference points when taking measurements for alignment. The reverse is true when a rear bushing has to be replaced or disturbed.

67. After bushings have been properly aligned and secured the movable portion should be raised slowly into position in cubicle and the centering of finger contacts in stationary tubes observed. If misalignment is noted, the movable portion should be removed from cubicle, bushing alignment checked, and corrections made.

### FRONT BUSHING STUD (Figs. 2 & 7)

68. When it is found necessary to replace a front bushing stud (7-219), remove the phase barriers and arc-chute assemblies (Refer to Paragraphs 56 & 57) from all phases for ease of access.

**CAUTION:** WHEN REMOVING A FRONT BUSHING STUD DO NOT DISTURB THE FRONT OR REAR BUSHING PLATES AS REAR BUSHINGS MUST BE HELD IN CORRECT POSITION FOR PROPER ALIGNMENT OF FRONT BUSHING AFTER REPLACEMENT.

69. To remove a front bushing stud (7-219), first remove primary contact fingers (1-3) from phase being replaced, and remove bushing tube (7-220) and cap screw (7-221). The stud may now be lifted clear of support insulator (7-201) and removed through the side or the top of the breaker.

70. With the bushing assembly on a bench remove the arcing and main contact fingers as described in Paragraphs 61-62 to assemble parts on new bushing stud. Refer to Fig. 7 and reverse procedure for dismantling.

71. For installation of bushing assembly in breaker refer to Fig. 2 and reverse procedure outlined in Paragraphs 68 & 69.

72. Align bushings and contacts in accordance with Paragraphs 65 thru 67 and Paragraph 26. Refer to cut in Figure 2 for dimensions.

73. Make sure all fastenings and connections are secure and finally install arc-chute assemblies (2-34) and phase barriers (2-21 and 2-35).

FRONT BUSHING SUPPORT INSULATOR (Fig. 2)

74. To remove a front bushing support insulator (7-201), first remove arc chute and phase barriers from all phases. Next remove operating arm (2-22) from phase being worked on. After removing cap screw (7-221) the front stud assembly may be raised clear of insulator, permitting insulator to be removed. Shims under insulator must not be lost. Replacement will be made easier if the exact location of the insulator is marked before it is removed.

75. To install bushing support insulator (7-201) reverse procedure outlined in Paragraph 74 and align in accordance with Paragraphs 65 thru 67 and 26, using the same thickness of shims as was removed from insulator. Make sure all fastenings and electrical connections are secure.

REAR BUSHING STUD (Figs. 2 & 9)

76. For the removal of a rear bushing stud (9-283) remove the phase barriers (2-21 and 2-35), arc-chute assembly (2-34) as outlined in Paragraphs 56-57.

CAUTION: WHEN REMOVING A REAR BUSHING STUD DO NOT DISTURB THE FRONT BUSHING TOP PLATE AS FRONT BUSHING MUST BE HELD IN CORRECT POSITION FOR PROPER ALIGNMENT OF REAR BUSHING AFTER REPLACEMENT.

77. Remove primary contact finger (1-3) and then remove rear bushing tube (9-284) by lifting it up over stud, remove top plate (2-32). Disconnect the operating arm (2-22) from contact arm (9-277, 9-278) by taking out pin (2-23) remove bolt (9-293) on phase from which stud is to be removed, loosen bolts (9-293) on other two phases so that bushings can be tilted forward to permit bottom plate (2-28) to clear top of breaker frame, and then lift out through top of breaker, the rear bushing stud, movable contact, and bottom bushing plate as a unit.

78. With the rear bushing stud assembly on a bench, first remove plate (2-28) from stud, next remove contact arms (9-277, 9-278) from stud by taking out cap screws (9-290) to free spring washers (9-287), and finally withdraw tube (9-289) to free contact arms.

79. The assembly of the contact arms on stud is obvious. However, do not tighten nut on cap screw (9-290) at this time. Place bottom plate (2-28) over stud and as a unit install stud, movable contact and plate in breaker. Bolt stud to support bushing (use washers (9-292) if breaker is 1200 ampere size) but do not make up tight. Install top plate (2-32) and bushing tube (9-284) but do not make bolting secure. Connect up movable contacts and connecting rod by means of pin (2-23).

80. Using the front bushings as an index align the rear bushings as outlined in Paragraphs 65-67 and make all fastenings secure. Contact alignment must be checked in accordance with Paragraph 26. Install arc-chute assemblies and barriers, operate breaker with maintenance closing handle and electrically and finally check breaker in cubicle.

### REAR BUSHING SUPPORT INSULATOR (Figs. 2 & 9)

81. For the removal of a rear bushing support insulator (9-276) remove phase barriers and arc-chute assemblies as outlined in Paragraphs 58 and 59.

82. Remove cap screw (9-293) from phase from which support insulator is to be removed, back out cap screws fastening insulator to breaker frame, freeing support insulator, and then work insulator toward back of breaker until free of support angle, pull downward until tongue on insulator is free of stud and withdraw from breaker. Do not lose or mislay shims used under insulator.

83. The installation of the new support insulator is obvious. However make sure that the same number of shims are used under new insulator as was removed from under old one. Secure insulator in place using cap screws and the necessary shims and spacer bar. Bolt bushing stud and support insulator together with cap screw (9-293) (use spacers (9-292) if breaker is 1200 ampere size). Check alignment of rear bushings as outlined in Paragraphs 65-67 and check for contact alignment as outlined in Paragraph 26. Make all fastenings secure and install arc-chute assemblies and phase barriers.

### CLOSING COIL (Figs. 2 & 3)

84. To remove the closing coils (3-106) the breaker should be blocked up at least 10 inches off the floor to facilitate the removal of coils through bottom of breaker frame. The phase barriers (2-21 and 2-35) and arc-chute assemblies (2-34) for all phases should be removed for working clearance. For removal of above parts refer to Paragraphs 56 and 57.

85. Remove the bolts (3-107) on plate (3-111) and bracket (3-110), disconnect coil leads, undo wrapping binding leads together, bend metal tabs provided to prevent coil rotation into hole in shell for coil leads, take hold of tape loops on coil and withdraw first coil section, then withdraw second section of coil.

86. On replacing coils the first coil section must be installed with the lead end of coil facing back of breaker and when in place, the leads are to be pulled through opening in coil housing. Next the cork washer (3-108) is positioned. Leads of the second coil section must be pushed through the hole in the shell and then the coil slipped on over the end of the brass tube. Cut leads to length, connect them to terminal block, wrap leads together and then pull coil tabs through hole and bend tabs over the outside of shell to prevent coil rotation. Install cork washer (3-108) between coil and back plate and bolt back plate and bracket securely in position. When bolting plate in position make sure that the shell is fitted into the groove in the plate.

### TRIP COIL - SHUNT TRIP (Fig. 3)

87. To remove a trip coil (3-80) from shunt trip application, remove the bracket (3-76) by taking out the two screws (3-82), withdraw the tripping unit assembly (3-81), disconnect coil leads and remove coil. Replacement is obvious. However, make sure that trip coil spacers (3-79) are in position on bottom of coil, that tab on coil is

---

in slot of spacers and that all fastenings and coil connections are secure.

Allis-Chalmers Mfg. Company  
Boston Works  
Boston, Mass.

SEPTEMBER, 1952

RETYPE MARCH, 1955

BWX-6347-3

-17-


RECOMMENDED SPARE PARTS LIST  
FOR  
TYPE AM-150C RUPTAIR MAGNETIC BREAKER

Fig. No.	Item	Description	Quantity Per Brkr.	Recommended Stock for	
				1 Brkr.	5 Brkrs.
1	2	Grounding Contact Fingers	1	1	1
1	3	Primary Contact Fingers	6	2	6
1	6	Control Relay (With Coils (Specify Voltage)	1	1	1
2	21	Outside Phase Barrier	2		2
2	35	Inter Phase Barrier	2		2
2	22	Operating Arm	3	2	4
3	80	Trip Coil (Specify Voltage)	1	1	2
3	89	Trip Latch	1	1	1
3	106	Closing Coil (Specify Voltage)	2	2	2
3	120	Limit Switch	1	1	3
3	120	Latch Check Switch	1		
7	201	Support Insulator (Front)	3	1	3
7	208	Main Contacts	18	18	18
7	213	Arcing Contact	3	3	6
7	219	Stud	3	1	3
7	220	Tube	3	1	3
8	231	Barrier Stack	3	1	3
8	232	Arc Runner	3	3	3
8	250	Arc Runner	3	3	3
8	236	Blowout Coil Front	3	1	3
8	245	Blowout Coil Rear	3	1	3
8	242	Flash Plate	6	2	6
9	276	Support Insulator (Rear)	3	1	3
9	277	Disconnect L.H.	3	1	3
9	278	Disconnect R.H.	3	1	3
9	279	Main Contact	3	1	3
9	282	Arcing Contact	3	3	6
9	283	Rear Stud	3	1	3
9	284	Bushing Tube	3	1	3
9	285	Contact Ring	6	2	6
9	287	Spring Washer	12	4	12
10	340	Operation Counter	1	1	1
10	345	Stationary Contact (Assembled)	16	4	8
10	341	Rotor (Assembled)	8	2	4

NOTE: REFER TO PARAGRAPHS 52-54 FOR INSTRUCTIONS ON HOW TO ORDER SPARE PART ITEMS.



# ALLIS-CHALMERS MANUFACTURING COMPANY




**FIG. 2**  
 TYPICAL RUPTAIR MAGNETIC BREAKER ASSEMBLY  
 NOVEMBER 12, 1952  
 FI-500-007-408






# ALLIS-CHALMERS MANUFACTURING COMPANY



## FIG. 7

TYPICAL FRONT BUSHING  
AND CONTACT ASSEMBLY  
NOVEMBER 14, 1952 71-400-019


# ALLIS-CHALMERS MANUFACTURING COMPANY



## FIG. 8

TYPICAL ARC-CHUTE ASSEMBLY

# ALLIS-CHALMERS MANUFACTURING COMPANY




**FIG. 9**

TYPICAL REAR BUSHING AND DISCONNECT CONTACT ASSEMBLY

NOVEMBER 7, 1952

71-400-014 MK.401


# ALLIS-CHALMERS MANUFACTURING COMPANY



**FIG. 10**

TYPICAL AUXILIARY SWITCH AND  
PLUGGING DEVICE ASSEMBLY  
9-4-52 BK-10-1995

**ALLIS-CHALMERS**  **MANUFACTURING COMPANY**



**FIG. II**  
**TYPICAL**  
**PUFFER ASSEMBLY**  
DECEMBER 2, 1954 71-300-819