



GE Consumer & Industrial  
Multilin



**METER SETUP AND DATA ACQUISITION  
SOFTWARE**

# Instruction Manual

GE Communicator EXT revision: 1.0x

GE publication code: GEK-113307

Manual Part Number: 1601-9020

Copyright © 2007 GE Multilin

GE Multilin

215 Anderson Avenue, Markham, Ontario

Canada L6E 1B3

Tel: (905) 294-6222 Fax: (905) 201-2098

Internet: <http://www.GEmultilin.com>



GE Multilin's Quality  
Management System is  
registered to ISO9001:2000

QMI # 005094  
UL # A3775



# Table of Contents

## 1: INSTALLING GE COMMUNICATOR EXT 1.1

SYSTEM REQUIREMENTS .....	1 - 1
INSTALLING GE COMMUNICATOR EXT SOFTWARE .....	1 - 2
GE COMMUNICATOR EXT BASIC SCREEN ELEMENTS .....	1 - 3
MENU BAR ICONS .....	1 - 4
COMPUTER STATUS BAR (MODEM) .....	1 - 5
COMPUTER STATUS BAR (NETWORK) .....	1 - 6
HELP .....	1 - 7
HELP MENU .....	1 - 7
SOFTWARE LICENSE .....	1 - 8
FEATURE COMPARISON FOR ADVANCED MODELS .....	1 - 10
OPTIONS .....	1 - 12

## 2: CONNECTING TO A GE METER

OVERVIEW .....	2 - 1
DIRECT SERIAL (RS-232, RS-485) AND NETWORK CONNECTIONS .....	2 - 3
SERIAL CONNECTIONS .....	2 - 3
NETWORK CONNECTIONS .....	2 - 4
SERIAL (RS-232, RS-485) MODEM CONNECTIONS .....	2 - 6
BEFORE SETTING THE GENERAL CONFIGURATION .....	2 - 6
AT THE REMOTE (METER) SITE... ..	2 - 6
ON THE ORIGINATING COMPUTER... ..	2 - 7
HANDLING MULTIPLE LOCATIONS .....	2 - 8
SETTING UP THE ORIGINATE (COMPUTER) MODEM .....	2 - 9
ADDING NEW DEVICES (METERS) TO A LOCATION .....	2 - 9
IF THE CONNECTION FAILS .....	2 - 10
RS-485 INTERNAL MODEM OPTION CONNECTION .....	2 - 11
AT THE REMOTE (METER) SITE... ..	2 - 11
ON THE ORIGINATING COMPUTER... ..	2 - 11
ADDING A LOCATION .....	2 - 12
HANDLING MULTIPLE LOCATIONS .....	2 - 13
SETTING UP THE ORIGINATE (COMPUTER) MODEM .....	2 - 13
ADDING NEW DEVICES (METERS) AT ONE LOCATION .....	2 - 14
IF THE CONNECTION FAILS .....	2 - 15
INTERNAL NETWORK OPTION CONNECTION .....	2 - 16
TO SET THE CONFIGURATION .....	2 - 16
ADDING A LOCATION .....	2 - 17
HANDLING MULTIPLE LOCATIONS .....	2 - 18
ADDING NEW DEVICES (METERS) AT ONE LOCATION .....	2 - 18
TROUBLESHOOTING THE CONNECTION .....	2 - 20
CHANGING THE PRIMARY DEVICE .....	2 - 22
DISCONNECTING FROM A GE METER .....	2 - 23
DEVICE STATUS .....	2 - 24

## 3: CONFIGURING THE EPM 9450/9650 METER

OVERVIEW .....	3 - 1
RETRIEVE AND SEND DEVICE PROFILES .....	3 - 3
USING THE REPORT PAGE .....	3 - 4
GENERAL SETTINGS .....	3 - 6

CT AND PT RATIOS AND SYSTEM HOOKUP .....	3 - 6
ONE AMP CURRENT INPUT ADDENDUM (MODIFICATION NUMBER M10.0) .....	3 - 9
LIMIT AND WAVEFORM FULL SCALES .....	3 - 11
TIME SETTINGS .....	3 - 13
LABELS .....	3 - 16
COMMUNICATIONS .....	3 - 17
DNP CUSTOM CLASS MAP .....	3 - 21
CUSTOM MODBUS MAP .....	3 - 23
<b>REVENUE AND ENERGY SETTINGS .....</b>	<b>3 - 28</b>
DEMAND INTEGRATION INTERVALS .....	3 - 28
INTERNAL KYZ OUTPUTS (AND TEST LED SETTINGS) .....	3 - 30
EXTERNAL DISPLAY OPTIONS .....	3 - 30
PROGRAMMING TRANSFORMER LOSS COMPENSATION .....	3 - 31
TRANSFORMER LOSS COMPENSATION FOR ENHANCED UNITS .....	3 - 34
COLD LOAD PICKUP .....	3 - 35
CUMULATIVE DEMAND TYPE .....	3 - 36
ENERGY, PULSES AND ACCUMULATIONS IN THE INTERVAL .....	3 - 37
PULSE ACCUMULATIONS .....	3 - 37
PRIMARY HOUR READINGS ROLLOVER .....	3 - 39
<b>POWER QUALITY AND ALARM SETTINGS .....</b>	<b>3 - 40</b>
LIMITS .....	3 - 40
ELECTROLOGIC RELAY CONTROL .....	3 - 44
PQ THRESHOLDS (WAVEFORM RECORDING) .....	3 - 45
EN 50160 FLICKER .....	3 - 48
I SQUARED T AND V SQUARED T THRESHOLDS .....	3 - 49
HIGH SPEED INPUTS .....	3 - 49
TRENDING PROFILE SETTINGS AND LOAD PROFILE RECORDING .....	3 - 50
PROGRAMMING THE TRENDING LOG TIME INTERVALS .....	3 - 50
PROGRAMMING THE TRENDING SETUP FOR HISTORICAL LOGS 1 AND 2 .....	3 - 51
PAD MISSING RECORDS FOR HISTORICAL LOGS .....	3 - 53
<b>EXTERNAL DEVICES .....</b>	<b>3 - 54</b>
<b>SET AND RETRIEVE METER TIME .....</b>	<b>3 - 55</b>
<b>RESET METER INFORMATION .....</b>	<b>3 - 56</b>
<b>MANUAL WAVEFORM CAPTURE .....</b>	<b>3 - 58</b>

#### 4: CONFIGURING THE EPM 9800 METER

<b>OVERVIEW .....</b>	<b>4 - 1</b>
<b>RETRIEVE AND SEND DEVICE PROFILES .....</b>	<b>4 - 3</b>
<b>GENERAL SETTINGS .....</b>	<b>4 - 6</b>
CT AND PT RATIOS AND SYSTEM HOOKUP .....	4 - 6
ONE AMP CURRENT INPUT ADDENDUM (MODIFICATION NUMBER M10.0) .....	4 - 8
LIMIT AND WAVEFORM FULL SCALES .....	4 - 9
TIME SETTINGS .....	4 - 11
LABELS .....	4 - 13
COMMUNICATIONS .....	4 - 15
DNP CUSTOM CLASSES MAP .....	4 - 19
CUSTOM MODBUS MAP .....	4 - 19
<b>REVENUE AND ENERGY SETTINGS .....</b>	<b>4 - 24</b>
ENERGY SCALING .....	4 - 25
PROGRAM DEMAND INTEGRATION INTERVALS (DEMAND INTERVALS) .....	4 - 29
INTERNAL KYZ OUTPUTS (AND TEST LED SETTINGS) .....	4 - 31
DISPLAY CONFIGURATION .....	4 - 32
CT AND PT COMPENSATION .....	4 - 35
TRANSFORMER/LINE LOSS COMPENSATION .....	4 - 36



COLD LOAD PICKUP .....	4 - 38
CUMULATIVE DEMAND TYPE .....	4 - 39
ENERGY, PULSES AND ACCUMULATIONS IN THE INTERVAL .....	4 - 39
PULSE ACCUMULATIONS .....	4 - 39
POWER QUALITY AND ALARM SETTINGS .....	4 - 42
LIMITS .....	4 - 42
ELECTROLOGIC RELAY CONTROL .....	4 - 46
PQ THRESHOLDS (WAVEFORM RECORDING) .....	4 - 47
EN 50160 FLICKER .....	4 - 50
I SQUARED T AND V SQUARED T THRESHOLDS .....	4 - 51
HIGH SPEED INPUTS .....	4 - 51
TRENDING PROFILE SETTINGS AND LOAD PROFILE RECORDING .....	4 - 53
TRENDING LOG TIME INTERVALS .....	4 - 53
TRENDING SETUP .....	4 - 54
PAD MISSING RECORDS FOR HISTORICAL LOGS .....	4 - 56
EXTERNAL DEVICES .....	4 - 57
SET AND RETRIEVE METER TIME .....	4 - 58
RESET METER INFORMATION .....	4 - 59
MANUAL WAVEFORM CAPTURE .....	4 - 61
TEST MODE PRESET ACCUMULATORS .....	4 - 62
CT AND PT COMPENSATION .....	4 - 64

## 5: CONFIGURING THE EPM 6000 PANEL METER

INTRODUCTION .....	5 - 1
EPM 6000 CONFIGURATION .....	5 - 2
QUICK CONNECT .....	5 - 2
CONNECTION MANAGER .....	5 - 3
DISCONNECT FROM A GE METER .....	5 - 8
CHANGE THE PRIMARY DEVICE .....	5 - 8
MERGE CONNECTION DATABASES .....	5 - 9
CONFIGURE THE EPM 6000 DEVICE PROFILE .....	5 - 11
CONFIGURE SETTINGS .....	5 - 12
CONFIGURE COMMUNICATIONS .....	5 - 15
CONFIGURE ENERGY AND DISPLAY .....	5 - 16
CONFIGURE SCALING .....	5 - 17
USING EPM 6000 POLLING AND TOOLS MENUS .....	5 - 19
USING EPM 6000 POLLING MENU .....	5 - 19
USING EPM 6000 TOOLS MENU .....	5 - 19
REAL-TIME POLL .....	5 - 20
TOOLS .....	5 - 21
SET DEVICE TIME .....	5 - 22
RETRIEVE DEVICE TIME .....	5 - 23
RESET DEVICE INFORMATION .....	5 - 24
RETRIEVE DEVICE STATUS .....	5 - 25
LOW LEVEL ACCESS .....	5 - 26

## 6: TOTAL WEB SOLUTIONS

OVERVIEW .....	6 - 1
SYSTEM COMPONENTS .....	6 - 2
HARDWARE CONNECTION .....	6 - 4
SOFTWARE CONNECTION .....	6 - 5
SETTING UP THE 10/100BASET CONNECTION .....	6 - 11
DHCP SETUP .....	6 - 11
SERVICES & SECURITY .....	6 - 13

COMPUTER NAME / DNS .....	6 - 14
AUTO TFTP DOWNLOAD .....	6 - 15
WEBALARM/EMAIL .....	6 - 15
FTP CLIENT .....	6 - 16
INP 102 ETHERNET/MODEM COMBINATION .....	6 - 18
DNP FOR LAN/WAN .....	6 - 21
CUSTOMIZING SCREENS .....	6 - 24
CONFIGURING WEBEXPLORER© .....	6 - 24
CONFIGURING WEBXML© .....	6 - 28
CONFIGURING WEBREACHER© .....	6 - 36
CONFIGURING WEBMOD© .....	6 - 38
CONFIGURING WEBALARM© .....	6 - 39
FTP SERVER .....	6 - 43
UPDATE NETWORK CARD FIRMWARE FROM A BROWSER (IN RUNTIME MODE ONLY) 6 -	
44	
UPDATE NETWORK CARD FIRMWARE FROM GE COMMUNICATOR EXT .....	6 - 46
WEBXML FLOW CHART .....	6 - 49
WEBEXPLORER FLOW CHART .....	6 - 50
WEBALARM FLOW CHART .....	6 - 51

## 7: REAL-TIME POLLING

OVERVIEW .....	7 - 1
REAL TIME READINGS .....	7 - 3
INSTANTANEOUS POLLING .....	7 - 3
POLL MAX AND MIN READINGS .....	7 - 3
POLL READING GRID .....	7 - 5
POLL MULTIPLE DEVICES .....	7 - 6
POLL EXTERNAL ANALOG INPUTS .....	7 - 7
REVENUE, ENERGY AND DEMAND READINGS .....	7 - 8
POWER .....	7 - 8
DEMAND .....	7 - 9
ENERGY .....	7 - 13
ENERGY, PULSE AND ACCUMULATIONS IN THE INTERVAL .....	7 - 16
INTERNAL KYZ OUTPUT ACCUMULATIONS .....	7 - 20
TOTAL AVERAGE POWER FACTOR .....	7 - 21
TIME OF USE REGISTERS .....	7 - 22
POLL PULSE ACCUMULATIONS .....	7 - 22
POWER QUALITY AND ALARMS .....	7 - 24
PHASORS .....	7 - 24
POLL HARMONICS .....	7 - 26
FLICKER .....	7 - 27
ALARM STATUS .....	7 - 28
POLL DEVICE CONTROL STATUS .....	7 - 29
POLL INTERNAL INPUTS .....	7 - 30
POLL EXTERNAL DIGITAL INPUTS .....	7 - 31
POLL REAL TIME TRENDS .....	7 - 32

## 8: VIEWING LOGS

OVERVIEW .....	8 - 1
PROGRAMMING AND RUNNING LOGS .....	8 - 4
RETRIEVING LOGS .....	8 - 5
VIEWING LOGS WITH GE COMMUNICATOR EXT'S LOG VIEWER .....	8 - 7
VIEWING HISTORICAL TRENDS AND SNAPSHOTS .....	8 - 11
SORT .....	8 - 12

	VIEWING TRENDING AND DEMAND GRAPHS (XY AND CIRCULAR) .....	8 - 13
	VIEWING THE LIMITS LOG .....	8 - 18
	VIEWING THE WAVEFORM LOG .....	8 - 19
	VIEWING WAVEFORM GRAPHS .....	8 - 20
	INTERHARMONIC ANALYSIS .....	8 - 30
	VIEWING THE POWER QUALITY LOG .....	8 - 33
	VIEWING THE POWER QUALITY GRAPH .....	8 - 34
	DATABASE STATUS .....	8 - 36
	AIREPORTS .....	8 - 37
	PQDIF CONVERTER .....	8 - 38
	COMTRADE CONVERTER .....	8 - 39
	STATUS CHANGE LOG (INPUTS) .....	8 - 41
	CONTROL OUTPUT LOG (RELAYS) .....	8 - 42
<b>9: TIME-OF-USE</b>	GENERAL PROCEDURE .....	9 - 1
	CREATING A TOU CALENDAR PROFILE .....	9 - 3
	UPDATE A TOU CALENDAR PROFILE .....	9 - 12
	VIEWING TOU ACCUMULATED DATA .....	9 - 14
<b>10: EXTERNAL I/O MODULES</b>	OVERVIEW .....	10 - 1
	OUTLINE OF THE PROCEDURE FOR INSTALLING I/O MODULES .....	10 - 2
	USING MULTIPLE I/O MODULES .....	10 - 3
	STEPS TO DETERMINE POWER NEEDED .....	10 - 4
	I/O MODULES' FACTORY SETTINGS AND VA RATINGS .....	10 - 5
	ADDITIONAL POWER SOURCE FOR I/O MODULES .....	10 - 5
	ASSIGNING ADDRESSES AND BAUD RATES TO AN I/O MODULE .....	10 - 8
	ENTERING I/O MODULES IN THE EPM METER'S DEVICE PROFILE .....	10 - 10
	CONFIGURING THE ANALOG OUTPUT MODULE .....	10 - 12
	CONFIGURING THE ANALOG INPUT MODULE .....	10 - 14
	CONFIGURING THE KYZ OUTPUT MODULE .....	10 - 16
	CONFIGURING THE DIGITAL OUTPUT MODULE .....	10 - 18
	CONFIGURING THE RELAY OUTPUTS .....	10 - 19
	USING THE DIGITAL INPUT MODULE .....	10 - 20
	I/O DEVICE STATUS .....	10 - 22
	QUERY I/O—LOCATING AN UNKNOWN ADDRESS AND BAUD RATE .....	10 - 23
	LOCATOR UTILITY—THROUGH METER METHOD .....	10 - 25
	LOCATOR UTILITY—STAND ALONE METHOD .....	10 - 27
	STAND ALONE PROGRAMMER .....	10 - 31
<b>11: PASSWORDS</b>	OVERVIEW .....	11 - 1
	ENABLING PASSWORDS .....	11 - 3
	PASSWORD STATUS .....	11 - 5
	DISABLING PASSWORDS .....	11 - 6
	LOGGING ON AND OFF .....	11 - 7
	CHANGING PASSWORDS .....	11 - 8
<b>12: FLASH UPGRADING</b>	OVERVIEW .....	12 - 1
	FLASH UPGRADING THE EPM UNIT .....	12 - 3
	FLASH UPGRADING THE GE COMM AND GE DSP FIRMWARE .....	12 - 7
	FLASH UPGRADING THE GE EXTERNAL DISPLAY .....	12 - 11

	FLASH UPGRADING THE INTERNAL MODEM CARD .....	12 - 16
	FLASH UPGRADING THE INTERNAL NETWORK OPTION .....	12 - 19
<b>13: ENERGY BILLING MODULE</b>	<b>OVERVIEW .....</b>	<b>13 - 1</b>
	MANAGING YOUR LOAD PROFILE .....	13 - 1
	<b>BASIC ENERGY MANAGEMENT .....</b>	<b>13 - 3</b>
	BASIC ENERGY TERMS .....	13 - 3
	<b>COST ALLOCATION .....</b>	<b>13 - 6</b>
	COST ALLOCATION STEPS .....	13 - 6
	COST ALLOCATION SYSTEM .....	13 - 6
	<b>SYSTEM CONFIGURATION .....</b>	<b>13 - 7</b>
	SETUP REQUIREMENTS FOR EPM 9450, 9650 AND 9800 .....	13 - 7
	SETUP REQUIREMENTS FOR EPM SERIES 7000 METERS .....	13 - 7
	<b>OPERATION OVERVIEW .....</b>	<b>13 - 9</b>
	CREATING A DEMAND DATABASE .....	13 - 9
	USING THE EXCEL SPREADSHEET .....	13 - 9
	<b>HARDWARE AND SOFTWARE INSTALLATION AND SETUP .....</b>	<b>13 - 10</b>
	<b>USING THE ENERGY BILLING MODULE .....</b>	<b>13 - 11</b>
	<b>DEMAND GRAPHS .....</b>	<b>13 - 12</b>
	<b>DEMAND STATISTICS .....</b>	<b>13 - 14</b>
	<b>BILL VERIFICATION .....</b>	<b>13 - 15</b>
	<b>NOTES .....</b>	<b>13 - 17</b>
	EXCEL 2002 .....	13 - 17
	TROUBLE SHOOTING .....	13 - 17
<b>14: SCRIPT &amp; SCHEDULER PROGRAM</b>	<b>OVERVIEW .....</b>	<b>14 - 1</b>
	FEATURES .....	14 - 2
	USING THE GE SCHEDULER .....	14 - 2
	<b>OPERATIONAL OVERVIEW .....</b>	<b>14 - 4</b>
	<b>SCRIPTS .....</b>	<b>14 - 6</b>
	<b>SCRIPT REPORT .....</b>	<b>14 - 8</b>
	FEATURES .....	14 - 8
	<b>SET UP A SCRIPT .....</b>	<b>14 - 9</b>
	<b>DEVICES .....</b>	<b>14 - 11</b>
	<b>ADDING A SCRIPT DEVICE .....</b>	<b>14 - 13</b>
	<b>EDITING A SCRIPT DEVICE .....</b>	<b>14 - 15</b>
	<b>SCRIPT COMMANDS .....</b>	<b>14 - 16</b>
	<b>ADD A SCRIPT COMMAND .....</b>	<b>14 - 17</b>
	ADD A SCRIPT COMMAND .....	14 - 17
	ADD AN EPM 7000 SERIES DEVICE SCRIPT COMMAND .....	14 - 17
	<b>EDIT A SCRIPT COMMAND .....</b>	<b>14 - 18</b>
	EDIT AN ADVANCED SCRIPT COMMAND .....	14 - 18
	EDITING A DATA SWITCH OR SYSTEM DEVICE COMMAND .....	14 - 19
	EDITING A EPM+ DEVICE COMMAND .....	14 - 19
	<b>DELETE A SCRIPT COMMAND .....</b>	<b>14 - 20</b>
	<b>ADD SCRIPTS TO THE SCHEDULER .....</b>	<b>14 - 21</b>
	<b>EDIT SCHEDULER SCRIPTS .....</b>	<b>14 - 23</b>
	<b>DELETE SCHEDULER SCRIPTS .....</b>	<b>14 - 25</b>
	<b>STATUS .....</b>	<b>14 - 26</b>
	<b>EXIT .....</b>	<b>14 - 28</b>

<b>15: FLICKER</b>	OVERVIEW ..... 15 - 1	15 - 1
	THEORY OF OPERATION ..... 15 - 2	15 - 2
	INSTANTANEOUS FLICKER EVALUATION ..... 15 - 2	15 - 2
	SHORT-TERM FLICKER EVALUATION ..... 15 - 2	15 - 2
	LONG-TERM FLICKER EVALUATION ..... 15 - 3	15 - 3
	SETUP ..... 15 - 5	15 - 5
	SOFTWARE - USER INTERFACE ..... 15 - 6	15 - 6
	LOGGING ..... 15 - 10	15 - 10
	POLLING ..... 15 - 11	15 - 11
	LOG VIEWER ..... 15 - 12	15 - 12
	PERFORMANCE NOTES ..... 15 - 13	15 - 13
<b>16: CUSTOMIZING DNP V3.0 CONFIGURATION USING GE COMMUNICATOR EXT</b>	CONNECTING TO GE COMMUNICATOR EXT ..... 16 - 1	16 - 1
	BINARY INPUT ..... 16 - 3	16 - 3
	ANALOG INPUT (OBJECT 30) ..... 16 - 4	16 - 4
	BINARY COUNTER (OBJECT 20) ..... 16 - 7	16 - 7
	BINARY OUTPUT (OBJECT 10) ..... 16 - 10	16 - 10
	GLOBAL VALUES ..... 16 - 13	16 - 13
	DNP SETTINGS ..... 16 - 14	16 - 14
<b>APPENDIX A: GE SCRIPT &amp; SCHEDULER COMPONENT FILES</b>	GE SCRIPT & SCHEDULER COMPONENT FILES ..... A - 1	A - 1
<b>APPENDIX B: TRANSFORMER/LINE LOSS COMPENSATION CALCN. WORKSHEETS</b>	INTRODUCTION ..... B - 1	B - 1
	TRANSFORMER/LINE LOSS COMPENSATION ..... B - 3	B - 3
	TRANSFORMER / LINE LOSS COMPENSATION ..... B - 4	B - 4
	LOSS COMPENSATION IN THREE ELEMENT INSTALLATIONS ..... B - 4	B - 4
	THREE ELEMENT LOSS COMPENSATION WORKSHEET ..... B - 5	B - 5
	MS EXCEL SPREADSHEET WITH EXAMPLE NUMBERS ..... B - 9	B - 9
<b>APPENDIX C: GE COMMUNICATOR EXT COMMAND LINE ARGUMENTS V 1.11</b>	SCRIPT COMMAND LINE METHODS ..... C - 1	C - 1
	APPLICATION COMMAND LINE METHODS ..... C - 2	C - 2
<b>APPENDIX D: TFTP SERVER PROGRAM SETUP</b>	TFTP SERVER PROGRAM SETUP ..... D - 1	D - 1
<b>APPENDIX E: DNP CUSTOM CLASS MAP READINGS</b>	AVAILABLE DNP CLASS MAP READINGS FOR EPM9450Q: ..... E - 1	E - 1
<b>APPENDIX F: APPLICATION NOTES</b>	TOTAL WEB SOLUTIONS MEGA PAGE ..... F - 1	F - 1
	MODIFY JAVASCRIPT ..... F - 2	F - 2
	CHANGE BROWSER SETTINGS ..... F - 3	F - 3

---

APPENDIX G: ETHERNET NETWORK ERROR CODES	NETWORK ERROR CODES ..... G - 1
	NETWORK ERROR CODES REPORTED BY SOFTWARE THAT USES ETHERNET (INCLUDING GE COMMUNICATOR EXT) ..... G - 1

---

GLOSSARY: GLOSSARY



1  
011  
101110011100  
01100111110001  
000111010110110  
11110001001101  
010101110010  
011  
1

# GE Communicator EXT

## Chapter 1: Installing GE Communicator EXT 1.1


---

### 1.1 System Requirements

- IBM-PC Compatible, Pentium 200MHz or better
- Windows® 98 with Service Pack 1 or Release 2; NT 4 with Service Pack 5; Windows® 2000 with at least Service Pack 1
- 32 MB RAM
- XGA Card and Monitor with 1024x768 and 65k colors
- Available RS-232 Serial Port 1.2:

## 1.2 Installing GE Communicator EXT Software

GE Communicator EXT can be used with the following GE meters: All EPM 4000, 5000, 6000, 7000 and 9000 Series Meters.



- ▷ Double-click on the GE Communicator EXT Setup.exe icon and follow the on-screen instructions.

The Read Me File provides Version Numbers and Dates for the GE Communicator EXT Setup and the component files.



If necessary, Setup will update your computer's Windows® files to make them compatible with GE Communicator EXT. After the Windows® files have been updated, GE Communicator EXT may sometimes have to be installed a second time. Screen messages will guide you through this process.



## 1.3 GE Communicator EXT Basic Screen Elements

**Start up Screen:** Displays the version number of the GE Communicator EXT software. To view a similar screen at any time, select Help, About GE Communicator EXT. An additional button, **System Info**, can provide Microsoft system information. Click **OK** to exit the screen.


**Menu Bar:** Accesses all GE Communicator EXT commands and screens.

**Computer Status Bar:** Displays communication information about the *computer* — *not the meter connected to it*. Enable or disable the Status Bar from the View menu.



FIGURE 1–1: GE Communicator EXT Start-up Screen

### 1.3.1 Menu Bar Icons




Access to all GE Communicator EXT features:

- **Profile:** Retrieves the Device Profile from the currently connected meter.  
Same as selecting **Tools > Edit Current Device Profile**.  
Use to configure the meter. (See Chapters 3, 4, 5.)
- **Retrieve Logs:** Downloads logs from the currently connected meter to the computer.  
Same as selecting **Logs > Retrieve Log(s) from Device**. (See Chapter 8.)
- **Open Log:** Opens a previously retrieved EPM Log File.  
Same as selecting **File > Open > EPM Log File**. (See Chapter 8.)
- **Connection Manager:** Establishes communication between the computer and multiple meters at local or remote sites.  
Same as selecting **Connection > Connection Manager**. (See Chapter 2.)
- **Connect:** Establishes communication between the computer and one directly connected meter.  
Same as selecting **Connection > Quick Connect**. (See Chapter 2.)
- **Disconnect:** Terminates the connection between the computer and the currently connected meter(s).  
Same as selecting **Connection > Disconnect**. (See Chapter 2.)
- **Polling:** Displays instantaneous polling data from the currently connected meter.  
Same as selecting **Real-Time Poll > Instantaneous Polling**. (See Chapter 7.)
- **Energy:** Displays Power and Energy readings from the currently connected meter.
- **THD:** Displays magnitude and angle readings for Volts and Current values.  
*Spectrum* presents selected magnitude in a bar graph. *Waveform* combines magnitudes and angles in a graph.
- **Phasors:** Displays a three-phase phasor diagram and data from the currently connected meter.  
Same as selecting **Real-Time Poll > Phasors**. (See Chapter 7.)
- **EN 50160 Flicker:** Displays Instantaneous, Short Term and Long Term Readings.  
Same as selecting **Real Time Poll > Power Quality & Alarms > Flicker**. (See Chapter 16.)
- **Log Status:** Displays logging statistics for the currently connected EPM meter.  
Same as selecting **Logs > Statistics**. (See Chapter 8.)
- **Device Status:** Displays list of the currently connected meter(s).  
Same as selecting **Tools > Device Status**. (See Chapter 2.)
- **Alarms:** Displays the Limit Status Screen for EPM 9450Q, 9650Q, 9800Q, 7450D and 5300P.  
Same as selecting **Real Time Poll > Power Quality & Alarms > Alarm Status**. (See Chapter 9.)

### 1.3.2 Computer Status Bar (Modem)


When using **Serial Port** or **Modem Connection** to the meter:



- **Connection Status:** displays either "Connected", "Disconnected" or "Not Found".
- **Communication Port:** displays the computer port currently in use for the connection.
- **Baud Rate:** displays the baud rate of the computer's communication port.
- **Device Address:** displays the address of the connected device.
- **Device Name:** displays the name of the connected device.
- **Communication Protocol:** displays the communication protocol currently in use.
- **Date and Time:** displays the computer's current date and time.
- **Protection Status:** displays whether the password protection feature is enabled or disabled.


### 1.3.3 Computer Status Bar (Network)

When using **Network Connection** to the meter:



- **Connection Status:** displays either "Connected", "Disconnected" or "Not Found".
- **Communication Port:** displays the computer port currently in use for the connection.
- **Network Protocol:** displays the protocol being used for communication to the network.
- **Device Address:** displays the (network) address of the connected device.
- **Device Name:** displays the name of the connected device.
- **Communication Protocol:** displays the protocol used for communication to other devices.
- **Protection Status:** displays whether the password protection feature is enabled or disabled.
- **Low Battery / Modem Battery Status:** displays "Low Bat EPM" on the EPM 9800 when the meter requires a battery and if the Internal or Modem battery is low, dead or missing.

## 1.4 Help



### 1.4.1 Help Menu

Displayed above; it provides the following sources of information:

#### Contents

- ▷ Click on the **Contents** button to display the Index Page of the Help Files.
- ▷ To access Links to Topics, click on the **Bookmarks** tab and scroll through **Chapters**.
- ▷ Double-click on **Chapter** to view all topics in that chapter.
- ▷ Click on **Topic** to view **Help** on that topic.

#### Check for Software Updates

- ▷ Click on **Software Updates**. GE Communicator EXT will automatically search the **GE website** for updates for you. If the software does find updates, GE Communicator EXT will ask you if you would like to “**Update Now?**”
- ▷ You can click **Yes** or **No**.



Average File Size is 20MB. High Speed Internet access is recommended.

#### About GE Communicator EXT

Screen displays software version number and Microsoft® systems information. It is similar to the Start Up screen discussed in section 1.3.

## 1.5 Software License

GE Communicator EXT V3.0 is shipped to the user in **DEMO MODE**. While the software is in DEMO MODE, it can be installed into your computer and used with a GE meter. However, while in DEMO MODE, some features are disabled or limited. A list of those features appears below.

Installation is easy. An installation screen will walk you through the simple process. Once installation is complete, you will have to restart your computer to finish the installation.

### Enter Registration Number for Full Access

- ▷ To access all the features of the software, you must enter a Registration Number (see below). The Registration Number is a 20-digit number supplied to the licensee by GE at the time software is purchased.

### How to purchase software

- ▷ Contact your Regional Sales Representative

### How to Enter the Registration Number

- ▷ From the Help Menu, click Software License.
- ▷ Type in the 20-digit Registration Number. After Registration Number is entered, a small screen appears validating registration.



### DEMO MODE - Disabled and Limited Features

1. **No Device Address greater than "1" can be used and no I/O Modules can be used.**  
If you change the address to anything but "1", you will not be able to communicate with the meter.
2. **Some Log Viewer Features are disabled:**
  - Cannot view data from multiple devices.
  - Cannot run multiple instances.
  - Cannot print pages to a printer.

3. **Script & Scheduler Features disabled:**
  - Cannot print pages to a printer.
4. **Script & Scheduler Features Limited:**
  - Scheduler only runs one script.
  - Each Script only allows one device at Address 1.

## 1.6 Feature Comparison for Advanced Models

Advanced Meters are available in three models, each with an array of features. The Table below shows the Advanced Models with possible features for each model.

**Table 1–1: Advanced Meter Models with Features**

Feature	EPM 9450*****	EPM 9650*****	EPM 9800*****
Waveform Full Scales	Yes	Yes	Yes
Transformer Loss Compensation	Yes	Yes	Yes
*Trending Setup for Historical Logs	Yes	Yes	Yes
**PQ & Waveform Thresholds	Yes	Yes	Yes
Pulse Accumulations	Yes	Yes	Yes
Program External I/O Modules	Yes	Yes	Yes
Programmable Onboard Display			Yes
Test Mode			Yes
DNP Level 1 + Custom Class Map	Yes		
DNP Level 2 + Custom Class Map		Yes	Yes
Internal KYZ Output Option			Yes
Custom Modbus Map Level	1	2	2
***Network Card Runtime Update	Yes	Yes	Yes
INP2 Modem with Dial Out Option	Yes	Yes	Yes
INP100 Total Web Solutions	Yes	Yes	Yes
INP102 Combo Card			Yes
****View Logs	Yes	Yes	Yes
Flicker		Yes	Yes
****Energy Billing Module	Yes	Yes	Yes
****Script & Scheduler	Yes	Yes	Yes
17V Internal Power for I/O Modules to 12VA	to 12VA	to 12VA	
Scaled Energy			Yes
Programmable Rollover	Yes	Yes	



\* With 512 K or higher memory.

\*\* With 2 MEG or higher memory.

\*\*\* INP10, INP100 and INP102 Only.


\*\*\*\* MUST use Licensed version of GE Communicator EXT to access this feature.

## 1.7 Options

- ▷ Select Options from the **View** menu.
- ▷ Click tabs to show the following screens:

### Paths

- ▷ View or change the paths Communicator EXT uses to store any copied, exported or retrieved data.



## Data Scan Mode

Select **Normal Scan Rate** or create **Custom Scan Rate** between 0 and 65535 scans per millisecond.

The screenshot shows the 'GE Options' dialog box with the 'Data Scan Mode' tab selected. The 'Normal Scan Rate' radio button is selected. The 'Custom Scan Rate' option is disabled, with a text box showing '0' and the label 'milliseconds'. Below the radio buttons, a message states: 'Valid Scan Rate Range (0 - 65535ms). Scan Rate of 0 will perform one scan only. Due to the time it takes to transmit and receive data, scan values less than 200 ms will make no difference.' At the bottom right are 'OK', 'Cancel', and 'Apply' buttons.

## Tech Mode Settings

- ▶ Enter Password to enable Tech Mode. If a Password is not entered, Tech Mode will remain disabled.

The screenshot shows the 'GE Options' dialog box with the 'Tech Mode Settings' tab selected. The main area displays 'Tech Mode Disabled' and 'Enter Password to Enable Tech Mode' followed by a text box. At the bottom left, there is an 'Extra Keys' label and a text box. At the bottom right are 'OK', 'Cancel', and 'Apply' buttons.

### Log Retrieval

- ▷ Click the first box on this screen to keep a log from being updated while it is being retrieved.
- ▷ Click the second box to disable **Backup** of the retrieved log file.
- ▷ Click the third box to enable the software to insert missing records (from when meter is not in Normal Operation Mode and therefore not recording) with value of 0 for each log retrieval process.

### Energy Billing Module

- ▷ Click the box on this screen to enable the **Energy Billing Module**. The Energy Billing Module can help you manage your Load Profile. (See Chapter 14.)

### Miscellaneous

- ▷ Click the box on this screen to enable the Kh/Ke Test Pulse Calculation screen. Set the **Ethernet Packet Delay** in milliseconds. Some systems may require a longer delay if they are slow.
- ▷ Make any adjustments using the **Browse** buttons.
- ▷ Click **Apply** to execute the changes.
- ▷ Click **OK** to return to the main GE Communicator EXT screen.



1  
011  
101110011100  
01100111110001  
000111010110110  
11110001001101  
010101110010  
011  
1

## GE Communicator EXT

# Chapter 2: Connecting to a GE Meter

---

### 2.1 Overview

There are six ways to connect to a GE Meter:

- RS-232 Direct Connect (section 2.2)
- RS-485 Direct Connect (section 2.2)
- RS-232 Modem Connect (section 2.3)
- RS-485 Modem Connect (section 2.3)
- RS-485 Internal Modem Option (section 2.4)
- RS-485 Internal Network Option (section 2.6)

**Direct Connections** made through GE Communicator EXT must use either Modbus RTU or Modbus ASCII protocol. Modbus RTU is recommended.

**Modem Connections** (Internal or External) made through GE Communicator EXT must use Modbus ASCII only.

**Network Connections** made through GE Communicator EXT must use Modbus TCP.

Section 2.5 details connecting to multiple meters on an RS-485 bus.

Consult the meter's Installation and Operation Manual for details of the hardware requirements for each configuration.



EPM 9650 and EPM 9800 include customizable DNP V3.00 Level 2.



If you are using the **Connection Manager** to connect a PC to a meter, you may want to copy the Connection Manager Settings to other PCs. Simply copy the file **Cnexcom.mdb** from Computer A to Computer B using the same directory for source and destination. Use the following steps:

- ▷ Using the originate computer, go to the drive where the file is installed.  
For example: C:\Program Files\GE\GE Communicator directory.
- ▷ Copy the file **Cnexcom.mdb** (this is the database that contains the Connection Manager Settings).
- ▷ Replace the **Cnexcom.mdb** file on the destination computer with the copy from the previous step.



Make sure GE Communicator EXT is not running on the destination computer when replacing the file.

## 2.2 Direct Serial (RS-232, RS-485) and Network Connections

This section details connecting **directly** to one GE device. See sections 2.3 and 2.4 for modem connections.

To connect to multiple GE units on an RS-485 bus, see sections 2.4 and 2.5.

### 2.2.1 Serial Connections

- ▷ Insert an RS-232 or RS-485 cable into an available serial port on the computer.
  - **RS-232:** Insert the opposite end of the cable into the GE Meter's RS-232 port (9450/9650 - Port 1; 9800 - Optical Port). Set 9450/9650 selector switch.  
See Chapter 6 of the EPM 9800 Installation and Operation Manual for details on the special Optical Port connection.
  - **RS-485:** Insert the opposite end of the (RS-232) cable into the RS-232 port of an RS-232/RS-485 converter, if required. (See the meter's Installation and Operation Manuals for details).  
Use an RS-485 cable to connect the RS-485 converter output to any port on the EPM 9450 or 9650. If you use Port 1, set the selector switch to RS-485. For EPM 9800, use Port 1 or Port 4.
- ▷ Click the **Connect** button on the tool bar or select **Connect > Quick Connect**. The screen below appears.



If you click the **Network** button, the screen changes to the Network screen.

The screenshot shows a 'Connect' dialog box with a blue header. There are two tabs: 'Serial Port' (selected) and 'Network'. Below the tabs are five labeled fields, each with a dropdown menu: 'Device Address' (value: 1), 'Baud Rate' (value: 9600), 'Port' (value: COM1), 'Protocol' (value: Modbus RTU), and 'Flow Control' (value: None). At the bottom of the dialog are three buttons: 'Connect', 'Cancel', and 'Help'.

- ▷ Enter settings for **Serial Port Connection**:
  - In the **Device Address** field, enter the address of the device's port to which the computer is connected. Meters are programmed for your specific applications. Some EPM 9800 units are shipped programmed with the following preset addresses and baud rates:

**Port 1:** Address 1, 57600 baud (first time connection, leave Address set at 1)

**Port 2:** Address 1, 57600 baud (fixed Optical Port on EPM 9800)

**Port 3:** Address 1, 9600 baud (EPM 9450/9650 Only) (for External Display or I/O Modules)

**Port 4:** Address 1, 57600 baud, Master/Slave (for External I/O Modules)



You may use a connected External Display to view each port's baud rate, address and communication protocol. See the meter's Installation and Operation Manuals for details. See Chapter 3 (EPM 9450/9650), Chapter 4 (EPM 9800) and Chapter 5 (EPM 4000, 5000, 6000, 7000 Series Meters) for details of how to configure the meter's communication ports.

- ▷ In the **Baud Rate** field, enter a baud rate that matches the baud rate of the device's port to which your computer is connected. The port's baud rate, address and protocol must always match the baud rate, address and protocol of the computer.
- ▷ In the **Serial Port** field, enter the computer's communication port into which the RS-232 cable is inserted. Most computers use Com 1 or Com 2 for the serial port.
- ▷ In the **Protocol** field, enter the type of communication the GE Meter port is using. Direct Connections made through GE Communicator EXT must use either Modbus RTU or Modbus ASCII. Modbus RTU is recommended. All meter port defaults are Modbus RTU and the meters are shipped set to Modbus RTU.
- ▷ In the **Flow Control** field, enter None or Hardware. EPM setting should be None. PM 6000 IrDA setting is Hardware.

**Example:** in the sample screen above, the computer's Com Port 2 has been set to operate at 57600 baud, using Modbus RTU to communicate with a meter port located at address 1. The baud rate, address and protocol set for the computer's Com Port 2 match those of the meter port.

If the connection fails, make sure an approved Category 5 Cable is connected to the Network Jack and that the Link Light on the GE Device is illuminated.

## 2.2.2 Network Connections

### At the Remote (Meter) Location

- ▷ Insert an RJ-45 line into the RJ-45 port on the face of an EPM 9450/9650 Meter that has an Internal Network Option. A connection for an EPM 9800 Meter with the Ethernet Option is made by inserting an RJ-45 line into the RJ-45 Network port. Make an RJ-45 connection for other GE meters.



### At the Originating (Computer) Location

The screenshot shows a 'Connect' dialog box with a blue background. At the top, there are two radio buttons: 'Serial Port' and 'Network'. The 'Network' radio button is selected and highlighted with a dashed border. Below the radio buttons, there are four labeled text input fields: 'Device Address' containing '1', 'Host' containing '127.0.0.0', 'Network Port' containing '502', and 'Protocol' containing 'Modbus TCP' with a dropdown arrow. At the bottom of the dialog, there are three buttons: 'Connect', 'Cancel', and 'Help'.

- ▷ Click the **Network** radio button on this screen.  
The screen changes for Network settings.
- ▷ Enter settings for **Network Connection**. (See your Network Administrator for correct settings.)
- ▷ In the **Device Address** field, enter 1.
- ▷ In the **Host** field, enter an IP Address or a Registered Name. (See your Network Administrator).
- ▷ In the **Network Port** and **Protocol** fields, the example settings are probably correct.  
Check with your Network Administrator to be sure.
- ▷ Click **Connect**.  
GE Communicator EXT locates the meter and the Device Status screen appears, confirming the connection. (See section 2.8 for details).
- ▷ Click **OK**.  
The computer is now connected to the meter.

The **Computer Status Bar** at the bottom of the screen confirms the computer's connection parameters. Status Bars will differ slightly for the two connections.



You may use an internal or external display to view the baud rate, address and communication protocol of each port.  
See Chapters 3,4,5 for details of how to configure the meter's communication ports.



For details on Network Hardware Connections, refer to the **Network** sections of the meter's Installation and Operation Manuals.

## 2.3 Serial (RS-232, RS-485) Modem Connections



For an RS-485 Internal Modem Option Connection see section 2.4 below.

### Modem Connections Require Modbus ASCII Protocol.

The meter's communication port that you use for the modem connection, must be configured to speak/listen to Modbus ASCII and operate at either 9600 baud or match the speed of the remote modem.



Modbus RTU does not support modem communication. If you use Modbus RTU to communicate with a modem, it will fail or be unreliable.

### 2.3.1 Before Setting the General Configuration

- ▷ Establish a direct RS-232 or RS-485 connection to the meter. (See section 2.2.)
- ▷ After you have established a direct connection, refer to Chapter 3 (EPM 9450/9650) and Chapter 4 (EPM 9800) for details on how to configure the meter's communication ports.
- ▷ Set the port to Modbus ASCII at 9600 baud. (If you are connecting to multiple meters on a bus, you must also assign a unique address to each meter; see section 2.5.)
- ▷ Install the modem connected to the computer (the "originate modem") and the modem connected to the GE meter (the "remote modem").  
See the Installation and Operation Manuals for the meter(s) in use for details of the hardware requirements.

### 2.3.2 At the Remote (Meter) Site...

If you are using RS-232 communications without a Modem Manager:

- ▷ Set the remote modem to operate at 9600 baud (remote and originating).
- ▷ Disable Hardware Flow Control (remote and originating).

If you are using RS-485 Communication with a Modem Manager (recommended by G.E.):

- ▷ Set the baud rate for the meter higher (up to 38400).  
Generally, it will provide reliable communication.
- ▷ Enable Flow Control (remote and originating).




Because a GE meter's four ports operate independently, you need only configure the address and baud rate of the port that will be connected to the bus.

### 2.3.3 On the Originating Computer...


- Click on the **Connection Manager** icon, or select **Connection > Connection Manager**.

The following screen appears: (To copy the Connection Manager Settings to other PCs, see Note on page 2-1.)



#### Adding a Location

- Click on the **Add** button.  
The **Location Editor** screen appears, displaying the computer's communications settings and the location name "New Location":



- ▷ Enter your Location Name in the **Location Name** field at the top of the screen, replacing "New Location".

### 2.3.4 Handling Multiple Locations

If you already have several locations on your List of Locations:

- ▷ To add additional locations, click on the **Add** Button.
- ▷ To sort locations, use the pull-down menu to select a sort method, A to Z, Z to A, Newest-->Oldest or Oldest-->Newest, and click **Sort By**.
- ▷ To remove locations, select and click **Remove**.
- ▷ Click once on the location to which you would like to connect your computer.  
*You may only connect to one location at a time.*
- ▷ To change to a different location, you must first disconnect from the current location by clicking on the **Disconnect** button or by selecting **Disconnect** from the Connection menu.
- ▷ Choose your new location.
- ▷ Click **Connect**.  
The computer begins dialing.

When GE Communicator EXT has located the GE meter(s) at the selected location, the **Device Status** screen appears, confirming the connection (see section 2.8 for details). The Computer Status Bar at the bottom of the screen confirms the computer's connection parameters.

### 2.3.5 Setting Up the Originate (Computer) Modem

- ▷ In the **Com Port** field, enter the computer's communication port connected to the computer's modem (the "originate" modem).
- ▷ In the **Baud Rate** field, enter a baud rate for the computer's modem, that will match the baud rate of the "remote" modem and the meter port.
- ▷ In the **Flow Control** field, select the remote (meter) modem's configuration.
- ▷ Leave the **Data Bits** field at 8 for Modbus ASCII. Other protocols may require a different setting.
- ▷ Leave the **Parity** field at None for Modbus ASCII. Other protocols may require a different setting.
- ▷ Click the **Use Modem** box.
- ▷ Enter the **Phone Number** of the remote modem.
- ▷ Enter a setup string in the **Setup String** field if this originate modem has been used for another program and needs to be reset.
- ▷ Use the **Data Switch** section to send any Data Switch strings to the remote modem.  
The typical Data Switch string from a meter to the Substation Multiplexor to a PC: „%%%,PTnn
- ▷ Check the manual for the device you are using in order to create the **Data Switch String** appropriate for this device.  
Typical characters used include:
  - , (pause one second)
  - %%% (escape sequence or switch to command mode)
  - PTnn (command) (number 01-16)
  - Enter ( <CR> ASCII character 13 )

### 2.3.6 Adding New Devices (Meters) to a Location

- ▷ Click on the **Add** button in the Devices at Location section to add meters to this location.
- ▷ Select the new device and click on the **Edit** button to edit its location information.  
The Location Device Editor screen appears, displaying the meter's communications settings.

The screenshot shows a Windows-style dialog box titled "Connection Manager Location Device Editor". It has a tab labeled "Device Properties" and a sub-tab labeled "Network". The main area contains several labeled fields: "Address" with the value "3", "Name" with "Device 3", "Description" with "Device 3", "Protocol" with a dropdown menu showing "Modbus RTU", "Device Type" with a dropdown menu showing "Shark 100", and "Comm Port" with the value "1". At the bottom of the dialog are two buttons: "Close" and "Help".

- ▷ In the **Device Address** field, enter the address assigned to the meter port you will use for this connection.  
If you are connecting to multiple meters, each one should have a unique address. See section 2.5.
- ▷ In the **Name** field, enter a unique name for the device at the location.
- ▷ In the **Protocol** field, select MODBUS ASCII.  
Be sure the port has been previously set to Modbus ASCII, as detailed in Step 1.
- ▷ Leave the **Device Type** field set to type of meter.
- ▷ Set the **Com Port**.
- ▷ Click on the **Close** button when all information is entered.

### 2.3.7 If the Connection Fails

- ▷ Check that all cables are secure.
- ▷ Check that the RS-232 cable is connected to the correct Com Port on the computer
- ▷ Check that the computer and the GE device(s) are set at 9600 baud using Modbus ASCII.

## 2.4 RS-485 Internal Modem Option Connection

### Internal Modem Option Connection Requires Modbus ASCII Protocol.

Some meter models offer an **Internal Modem Option**, which eliminates all the modem hardware and cable that used to be required for a modem connection. A modem connection to the meter is now as simple as plugging in a phone line.

At the originate end, simply install a modem inside the computer (the originate modem) and connect a phone line. At the remote (meter) end, the meter must be configured to speak Modbus ASCII. (Modbus RTU does not support modem communication. If you use Modbus RTU to communicate with a modem, it will fail or be unreliable.) The meter's Internal Modem Option may operate at a programmable baud rate up to 57600. We recommend this baud rate.

To set the overall configuration, you must:

- ▷ Install the computer's modem (the "originate modem").  
See the Installation and Operation Manual for the meter in use, for details of computer's hardware requirements.
- ▷ Set the originate modem to operate at 57600 baud
- ▷ Enable **Hardware Flow Control**.  
See **Note** about Baud Rate in Step 5 below.

### 2.4.1 At the Remote (Meter) site...

- ▷ Plug a phone line into the meter.  
The address will be **1**. (If you are connecting to multiple units on a bus, you must also assign a unique address, other than 1, to each additional unit. See section 2.5.)




Because a GE meter's four ports operate independently, you need only configure the address and baud rate of the port that will be connected to the bus.

### 2.4.2 On the Originating Computer...


- ▷ Click on the **Connection Manager** icon, or select **Connection > Connection Manager**.  
The following screen appears: (To copy the Connection Manager Settings to other PCs, see **Note** on page 2-1.)

### 2.4.3 Adding a Location

- Click on the **Add** button.  
The **Location Editor** screen appears, displaying the computer's communications settings and the location name "New Location":



- Enter your Location Name in the **Location Name** field at the top of the screen, replacing "New Location":





### 2.4.4 Handling Multiple Locations

If you already have several locations on your List of Locations:

- ▷ To add additional locations, click on the **Add** Button.
- ▷ To sort locations, use the pull-down menu to select a sort method, A to Z, Z to A, Newest-->Oldest or Oldest-->Newest, and click Sort By.
- ▷ To remove locations, select and click **Remove**.
- ▷ Click once on the location to which you would like to connect your computer.  
*You may only connect to one location at a time.*
- ▷ To change to a different location, you must first disconnect from the current location by clicking on the **Disconnect** button or by selecting Disconnect from the Connection menu.
- ▷ Choose your new location.
- ▷ Click **Connect**.  
The computer begins dialing.

When GE Communicator EXT has located the GE meter(s) at the selected location, the **Device Status** screen appears, confirming the connection (see section 2.8 for details). The Computer Status Bar at the bottom of the screen confirms the computer's connection parameters.

### 2.4.5 Setting Up the Originate (Computer) Modem

- ▷ In the **Com Port** field, enter the computer's communication port that is connected to the modem (the originate modem).
- ▷ In the **Baud Rate** field, enter 57600 (recommended baud rate for internal modem connections).



For modems prior to V.90, use a lower baud rate. **Example:** 38400 for a 33.6k modem, 19200 for a 14.4k modem.

- ▷ In the **Flow Control** field, select the originate modem's configuration - hardware flow control.
- ▷ Leave the **Data Bits** field at 8 for Modbus ASCII. Other protocols may require a different setting.
- ▷ Leave the **Parity** field at None for Modbus ASCII. Other protocols may require a different setting.
- ▷ Click the **Use Modem** box.
- ▷ Enter the **Phone Number** of the Internal Modem of the meter.
- ▷ Enter a Setup String in the **Setup String** field, if required.  
For U.S. Robotics modems, the data switch (Setup) string is: **&F1**

- ▷ Check with the manual for the device you are using in order to create the Data Switch String appropriate for the device.

#### 2.4.6 Adding New Devices (Meters) at one Location

- ▷ Click on the **Add** button in the Devices at Location section if you want to add (up to 31) GE units at that location.
- ▷ To remove devices, select and click **Remove**.
- ▷ Use Port 2 (EPM 9450/9650) or Port 3 (EPM 9800) of the **Internal Modem Option** meter to add additional units.
- ▷ Each unit must be configured to speak **Modbus ASCII** and set to the same baud rate as the primary unit.



Additonal units DO NOT have to be Internal Modem units.

- ▷ Select each new device and click on the **Edit** button to edit its location information.  
The **Location Device Editor** screen appears, displaying the GE unit's communication settings.

**Connection Manager Location Device Editor**

**Device Properties** Network

Address: 1

Name: Device 1

Description: Device 1

Protocol: Modbus RTU

Device Type: EPM 9800

Comm Port: 1

Close Help

- ▷ In the **Device Address** field, enter the address assigned to each additional GE unit.  
Each meter **MUST** have a unique address other than 1; see section 2.5.
- ▷ In the **Name** field, enter a name for the device that will differentiate it from others at that location.
- ▷ In the **Protocol** field, select MODBUS ASCII.
- ▷ Leave the **Device Type** field set to type of meter.

- ▷ Set the **Comm Port**.
- ▷ Click on the **Close** button when you have finished adding or removing devices.  
The first Connection Manager screen returns.

#### 2.4.7 If the Connection Fails

Check that all cables are secure; that the RS-485 cable is connected to the Modem Gateway on the Modem unit and that other GE units are set at 57600 baud using Modbus ASCII.

## 2.5 Internal Network Option Connection

### Internal Network Option Connection Requires Modbus TCP Protocol.

Some meter models offer an Internal Network Option, which allows them to communicate over a network. Connection to a network is now as easy as plugging in a phone. Simply connect a meter to a computer using Port 1 (EPM 9450/9650) or Port 3 (EPM 9800) to configure the network parameters and add a network connection. The meter must be configured to speak Modbus TCP. (Modbus TCP is the common protocol used for Modbus communication over a network.)




The Internal Network Option operates internally at a fixed Baud Rate of 115200. The Gateway operates as a Modbus RTU Master with a programmable Baud Rate up to 115200.



For Direct Connection, refer to section 2.2 of this manual.

### 2.5.1 To Set the Configuration

- ▷ Connect the network to the computer using Port 1.  
See the meter's Installation and Operation Manuals for details of the hardware requirements.
- ▷ At the RJ-45 Ethernet connection jack on the meter, plug in a network connection.
- ▷ Click on the **Connection Manager** icon, or select **Connection > Connection Manager**.  
The following screen appears: (To copy the Connection Manager Settings to other PCs, see Note on page 2-1.)



## 2.5.2 Adding a Location

- ▶ Click on the **Add** button.  
The **Location Editor** screen appears, displaying the computer's communications settings and the location name "New Location":
- ▶ Enter your Location Name in the **Location Name** field at the top of the screen, replacing "New Location":

The screenshot shows the "Connection Manager Location Editor" dialog box. At the top, the "Location Name" field contains "New Location". Below this, there are two radio buttons: "Serial Port" (selected) and "Network". Under "Serial Port", there are dropdown menus for "Com Port" (set to "COM1"), "Baud Rate" (set to "9600"), "Flow Control" (set to "None"), "Data Bits" (set to "8"), "Parity" (set to "None"), and "Stop Bits" (set to "1"). There are also checkboxes for "Use Modem" and "Use Password", with corresponding text input fields for "Phone Number", "Setup String", and "Password". To the right of these settings, there is a section titled "Use Data Switch String(s)" with two text input fields labeled "Connect" and "Disconnect". At the bottom of the dialog, there is a section titled "Devices At Location" with two buttons: "Add Serial" and "Add Net". The "Close" and "Help" buttons are at the very bottom of the dialog.

- ▶ Click on the **Network** button.  
The screen will change to the following:

Connection Manager Location Editor

Location Name: Substation #1

☒ Serial Port ☐ Network

Host: 10.0.0.1  
Network Port: 302

☐ Use Data Switch String(s)

Connect: [Empty List Box]  
Disconnected: [Empty List Box]

Devices At Location

Device Address	Device Name	Description
1	Device 1	Device 1
2	Device 2	Device 2
3	Device 3	Device 3

Buttons: Add Serial, Add Net, Remove, Edit, Close, Help

- ▷ In the **Host** field, enter the meter's IP Address.
- ▷ In the **Network Port** field, enter 502 (assigned port for Modbus TCP).

### 2.5.3 Handling Multiple Locations

- ▷ Click once on the location to which you would like to connect your computer.  
*You may only connect to one location at a time.*
- ▷ To change to a different location, you must first disconnect from the current location by clicking on the **Disconnect** button or by selecting **Disconnect** from the Connection menu.
- ▷ Click **Connect**.  
The computer connects to the meter via the network.

When GE Communicator EXT has located the device(s) at that location, the Device Status screen appears, confirming the connection (see section 2.9 for details). The Computer Status Bar at the bottom of the screen confirms the computer's connection parameters.

### 2.5.4 Adding New Devices (Meters) at one Location

- ▷ To add or remove devices to the network, click on the Add button.
- ▷ To remove a device, select and click Remove.

- ▷ If you are adding a device, click on **Edit** to change the device Name, Address and/or Description.  
The following screen will appear:

Ethernet Gateway (Port 2 - EPM 9450/9650) (Port 3 - EPM 9800) of the Internal Network Option meter is used to add multiple additional units. Additional units must be configured to speak Modbus RTU and set to the same Baud Rate (up to 115200) as the Internal Network Option meter (set in section 3.5 (EPM 9450/9650) or 4.5 (EPM 9800).




A computer “talks” to the Internal Network Option meter via Modbus TCP. This meter receives data in Modbus TCP “incoming message format” and communicates with other devices via Modbus RTU. The other meters do not have to be Internal Network Option units.

- ▷ If additional devices are required, in the **Device Address** field, enter the Address assigned to the additional unit.  
Each unit **MUST** have a unique address other than 1; see section 2.5. “1” is reserved as the address of the primary unit connected to the network.
- ▷ In the **Name** field, enter a name for the device that will differentiate it from any others at that location.
- ▷ In the **Protocol** field, select Modbus TCP.
- ▷ Leave the **Device Type** field set to Type of meter.
- ▷ Set the IP Address and the Network Port.
- ▷ Click on the **Close** button when all information is entered.

If you are connecting to multiple units at this location, repeat the above process for all units. Each device **MUST** have a unique address.

- ▷ Click on the **Close** button when you have finished adding or removing devices.  
The first Connection Manager screen returns.



### 2.5.5 Troubleshooting the Connection

If the connection fails, check the connection at the Internal Network Option meter first. Once that connection is confirmed, check the connections with other devices. Suggested checkpoints:

#### Internal Network Option Meter

- ▷ Check cables
- ▷ Check IP Address, Subnet Mask and Default Gateway settings configured in section 3.5.
- ▷ Check that the Address is 1 (this section).
- ▷ Check that Modbus TCP was selected in Device Properties (this section).

#### Other Devices

- ▷ Check all the above except for the address, which must be unique and not set to 1.
- ▷ Check that the Baud Rate settings for the Ethernet Gateway (Port 2 - EPM 9450/9650) (Port 3 - EPM 9800) and the Devices are the same (configured in section 3.5 or 4.5).



## Pinging

Try “Pinging” to a known good network device, such as another computer, to verify that your computer is connected properly to the network.

▷ Go to the DOS Prompt (or, Console, if you are using Windows® NT).

▷ Ping IP Address.


**Example:** “Ping 135.15.173.19”.

## 2.6 Changing the Primary Device

One copy of the GE Communicator EXT connected to multiple GE devices (section 2.5) may only view data or edit Device Profiles from one device at a time—the Primary Device. (An exception is the Poll Multiple Devices screen; see Chapter 7 for details.)

To change the Primary Device:

- ▷ Select **Connection > Change Primary Device**.  
The following screen appears.



- ▷ Enter the unique address of the device you would like to designate as the Primary Device.
- ▷ Click OK.

The Device Status screen, reached by clicking on the **Device Status** button or by selecting **Tools > Retrieve Device Status**, will now list the new Primary Device first. See section 2.9 for details on the Device Status screen.

---

## 2.7 Disconnecting from a GE Meter

To disconnect from a GE meter or to disconnect from a location, do one of the following:

- ▷ Click on the **Disconnect** icon, or from the menu bar select **Connection > Disconnect**.
- ▷ Click on the **Connection Manager** icon, or from the menu bar select **Connection > Connection Manager**.
- ▷ Select the Location from the List of Locations and click the **Disconnect** button.




When using a modem, it is important to disconnect from communicating so that the remote modem receives a “hang up” command. Some modems may “freeze” when improperly disconnected.

## 2.8 Device Status

The Device Status screen displays information about the GE devices connected to your computer.

- ▷ To access, click on the **Device Status** button or select **Tools > Retrieve Device Status**.



Device Status - Network - IP Address: 3.94.246.209:502

**List of Currently Connected Devices**

Device	Device Type	Boot	Run-time	DSP Boot	DSP Run-time	Comm State	DSP State	On Time	Serial #	NVRAM	Pro
121689	EPM 9650	601	618	600	628	Healthy	Healthy	9/15/2006 20:10:37.33	00121689	4 MB	Full

◀ ▶

Poling Device Info 1

OK Help

- **Device:** The Primary Device is listed first. See section 2.5 for details.
- **Device Name:** The name you give to the Primary Device.
- **Boot:** Version number of the GE Initialization and Diagnostic Firmware. This firmware runs first on power-up. This firmware is not field-upgradeable.
- **Run-time:** Version number of the GE Communicator EXT Operating Firmware. See Chapter 13 for details on upgrading firmware.
- **DSP Boot:** Version number of the DSP Initialization and Flash Reprogrammer. This firmware runs first on power-up (as part of the Boot). This firmware is not field-upgradeable.
- **DSP Run-time:** Version number of the DSP operating firmware. See Chapter 13 for details on upgrading firmware.
- **Com State:** Health status of the communication processor.
- **DSP State:** Health status of the DSP processor.
- **On Time:** Date and Time at which the GE meter was last powered up.
- **Serial Number:** The device's Unique Identification Number.
- **NVRAM:** Amount of NVRAM (nonvolatile RAM) available to the device. This memory is used for Logs.
- **Protection:** Status of the Password Protection function (see Chapter 12). Scroll to the right to find this section of the Device Status Bar.




1  
011  
101110011100  
01100111110001  
000111010110110  
11110001001101  
010101110010  
011  
1

## GE Communicator EXT

### Chapter 3: Configuring the EPM 9450/9650 Meter

#### 3.1 Overview

GE Communicator EXT lets you configure an EPM 9450/9650 meter's Programmable Settings, which are stored in the unit's Device Profile. Click on the +/- in front of each group of settings to view the menu..



The following is an overview of the procedure for configuring a meter:

1. **Retrieve** the meter's Device Profile (see section 3.2);
2. **Configure** the Programmable Settings stored in the Device Profile (sections 3.3 to 3.7);
3. **Send** the new Device Profile back to the meter (section 3.2).



If you click the Save, Load or Update buttons, you **MUST** have a unique Meter Destination Label so that the file is saved, loaded or updated to the intended device.

This chapter also details:

- Resetting Meter Information (section .10) and Manual Waveform Capture (section 3.11).
- Setting and Retrieving Meter Time (section 3.9) and Options (section 3.12).



Actual programming screens may vary depending on the options ordered with your meter.



The settings shown are Initial Settings for the EPM 9650 meter, unless otherwise noted. Most 9450 Meter settings are similar to the 9650 meter settings.


**The EPM 9650 Meter supports DNP Level 2.** For details on DNP Level 2, see chapter 16 of the GE Communicator EXT User Guide.

## 3.2 Retrieve and Send Device Profiles

- Click on the Profile button, or select Tools > Edit Current Device Profile.  
GE Communicator EXT retrieves the programmable settings from the currently connected meter. The following screen appears:



A dialogue box appears to confirm that the profile was retrieved successfully. Then, the Device Profile screen appears:



This screen contains all the programmable settings currently stored in the connected meter. Double-click on the +/- in front of each group to view the settings in that group.

- Configure each of the programmable settings by clicking on the +/- icon then double-clicking on the selected parameter. (See sections 3.3 to 3.7 for details on editing each setting.)

After you have finished configuring any or all of the programmable settings, use the **BUTTONS** at the bottom of the screen to execute the following tasks:

- ▷ **Implement the changes** by clicking on the **Update Device** button. This sends the new, edited Device Profile to the meter. **YOU MUST UPDATE THE METER DEVICE PROFILE FOR ANY OF THE PROGRAMMABLE SETTINGS TO TAKE EFFECT.** A **warning** will appear asking you if you want to Save Connected Device Settings. Click on the settings you would like to save, then proceed with the Update.
- ▷ **Store the profile for later use** by clicking on the **Save** button. A dialogue box will ask where you would like to save the profile.
- ▷ **Open a previously saved profile** by clicking on the **Load** button. A dialogue box will ask for the location of the saved profile.
- ▷ **Print a copy of the profile** by clicking on the **Report** button. The Report screen will appear:

Device Profile Report

Client: 3.0.20 ProComm

### Device Profile Report

Model:	EPM 9650		
ID Number:	Offline saved profile		
Name:	Nexus 1		
NRAM:	N/A		

**Firmware Versions**

Firmware	Boot	Runtime	Xilinx
Comm			
DSP			

**Communications Settings**

Item	Port 1	Port 2	Port 3	Port 4
Address	1	1	1	1
Baud Rate	57600	57600	9600	57600
Data Bits	8	8	8	8
Parity	None	None	None	None
Stop Bits	1	1	1	1
Tx Delay	0ms	0ms	0ms	0ms
Protocol	Modbus RTU	Modbus RTU	Modbus RTU	Modbus RTU
Mode	Modbus RTU	Modbus RTU	Slave	Slave

**System Setup**

CT Ratio:	1.00	1.00
PT Ratio:	1.00	1.00
CT Ratio Aux:	1.00	1.00
PT Ratio Aux:	1.00	1.00

Hookup: WYE

Frequency Range: 20Hz to 65Hz

Voltage Back: 150 V

Power Direction Label: Quadrant 1 + 4 = Delivered and Quadrant 2 + 3 = Received

Pwr Factor Display Method 2 Q1 +Lag, Q2 -Lead, Q3 +Lag, Q4 -Lead

**Time Setup**

Time Zone:	-5.0
DST Enabled:	Auto DST
DST Start:	
DST End:	
Line Sync:	Disable
Frequency:	

**Demand Setup**

Thermal Averaging Window	00h, 15m, 00s
Block Averaging Window	00h, 15m, 00s
Rolling Averaging Subinterval Window	00h, 05m, 00s
Rolling Subinterval	1
Resistive Rolling Window Average	100.00

**Block Window Sync**

Line Sync Pulse	No
High Speed Input #	N/A
Generate End of Interval Pulse	N/A
Relay #	N/A
Pulse Width (m.s)	N/A

Page 1 of 21 06-14-2006 11:22:24

Page 1 of 21 Zoom Whole Page

Print Range 1 to 21 Copies 1

Print Page(s)

Print

Save Done

### 3.2.1 Using the Report Page

**Page Arrows:** Select a page to view.

**Zoom:** Adjust the Viewing Magnification.



**Print Pages:** Adjust the Range of Pages to be printed at 100%.

**Buttons:**

**Copies:** How many copies do you want to print?

**Print Pages:** Select individual pages to print. Separate numbers by commas.

**Print:** This screen sends you to Print Setup screen where you select printer, properties, paper and orientation. Click OK to Print.

**Save:** Save these selections for future use.


**Done:** Exit the screen and return to the Device Profile screen.



If you change the Com settings for the meter, you will not be able to communicate with the meter. You will have to sign off and sign on again with the new settings.

### 3.3 General Settings

- ▷ From the Device Profile screen (see section 3.2), click on the **+/-** button or double-click on the **General Settings** line. All of the settings in the General Settings group are listed.




- ▷ Click on the particular programmable setting you would like to program. The settings will be detailed in the order on the Device Profile screen.

#### 3.3.1 CT and PT Ratios and System Hookup

- ▷ From the Device Profile screen (see section 3.2), click on the **+/-** button for General Settings, then double-click on the **CT, PT Ratios and System Hookup** line.

The following submenu appears:



This screen displays the current Device Profile's settings for CT, PT ratios and connection type. The values shown are for example only.

- ▷ Double-click on any of the settings; the CT and PT Ratios screen appears:


Make changes to this screen according to the requirements of your application:

- ▷ When you change a PT or CT Ratio, GE Communicator EXT updates the corresponding Full Scale value entered in the Limit and Waveform Full Scales setting.
- ▷ When you click **OK** on this screen, GE Communicator EXT opens the Limit & Waveform Full Scales window so that you can verify the settings (see section 3.3.2).
- ▷ Using the pull down menu, choose the hook up mode that matches the connection you have to the meter.  
Choose from one of the following: 4-Wire 3-Element Direct Voltage (4 CTs), 4-Wire 2.5 or 3 Element Wye (3 or 4 CTs), 3-Wire Delta (2 or 3 CTs), 3-Wire Delta Direct Voltage (3 CTs) or 4-Wire Grounded Delta (4 CTs). See the *EPM 9650 Installation and Operation Manual* for diagrams.




Changes to the Operational Frequency Range do not change the Full Scale value for Frequency. Changes must be made in the "Limits and Waveform Full Scales" screen. Like voltage and current, the nominal value should be used. For example, 50 for 50Hz.

- ▷ Click **OK**.  
The following screen asks you to verify the Kh/Ke Ratio for the Test Pulse Setting. Kh/Ke Ratio is Secondary watthour constant over kWh (the energy).



If the Ke screen does not appear, go to View>Options>Misc. Enable the Ke screen.

- ▷ Click **Yes**. Or, Click **No** and re-enter values in the CT & PT Ratio screen.
- ▷ Click **OK** on the CT & PT Ratio screen.
- ▷ If changes have been made, verify Full Scale values and click **OK**.
- ▷ Select the "G" option ONLY if you have a "G" Option Meter.  
**Warning : Only Select The 300 Volt Option If You Ordered The Meter With The "G" Option!!!** If you connect 300 volts to a meter that does not have the "G" option, you will damage the meter. Please check the **end label** on your meter and your invoice to make sure you have the "G" Option!



"G" must be in the part number for a 300 volt direct connection. Max Voltage also shows the max voltage the unit can measure. To select the 300 Volt Option, check the "300 Volt Secondary" box. Are you **sure** you want to select this box?

- ▷ When all changes are entered, click **OK** to return to the main Device Profile screen.
- ▷ For these changes to take effect, you must click on the **Update Device** button. This sends the new profile to the meter. Then, Reset Logs.




**Warning:** Resetting Logs clears Logs and Accumulations. Be sure to capture needed meter information before updating the Device. Data will no longer be available after the Reset. The meter will be prepared for new installation.

### 3.3.2 One Amp Current Input Addendum (Modification Number M10.0)

**For special circumstances, the meter can be ordered with one amp current transformers.**

This will give the meter a range of 0 - 1 amps with an additional over-range of 1 amp. This option is used where 1A IEC meters are required or extended low current performance is needed and higher current performance is not needed. This option is not used for most 1A

installations. The standard Meter has the capability of very accurability monitoring 1A loads and providing extended current overload. This section shows how to change the CT Ratios in the Meter (ONLY EPM 9450 Hardware Rev. A) to reflect the hardware change:



In order to maintain maximum accuracy with one (1) amp current inputs, the wire is wound around the internal toroids five (5) times, instead of the usual one time. This effectively multiplies the current input by five (5) times, to maintain maximum resolution.

#### Configuring CT Ratios with Modification Number M10.0 (EPM 9450 Hardware Rev. A):

EPM 9650 (and other Hardware Revs) adjust internally for the hardware change.

Because the GE Communicator EXT “sees” the one (1) amp input as five (5) amps, it is necessary to configure the CT secondary to five (5) amps.

##### Example:

Normal One Amp CT Ratio - 1000:1

Meter M10.0 One Amp CT Ratio - 1000:5

The CT Ratio screen shows the correct input for the typical one amp user:

PLEASE NOTE: This adjustment is for EPM 9450 Hardware Rev. A ONLY.



Even though the software is configured from 1000:5, it is actually displaying current from 1000:1 amps. If you are not concerned with maximum accuracy, you can use the standard Meter (without specially ordering the M10.0 option) to display readings from a 0 to 1 amp CT.


### 3.3.3 Limit and Waveform Full Scales

All Limit and Waveform settings (sections 3.10 and 3.14, respectively) are based on a percentage of the Full Scale. Full Scales are based on the CT and PT ratios (see section 3.3).

#### Be sure to set the CT and PT ratios first

GE Communicator EXT automatically recalculates the Full Scales every time the CT and PT ratios change and should be verified every time CT and PT Ratios are changed. NOTE: Changing the CT and PT Ratios Resets the meter, clearing Logs and stored data. This action prepares the meter for placement in a new installation or change of the Instrument Transformers.

- From the Device Profile screen (see section 3.2), click on the **+/-** button beside “Limit and Waveform Full Scales” or double-click on the **Limit and Waveform Full Scales** line.  
The following submenu appears:




This screen displays the current Device Profile's settings for the Limit and Waveform Full Scales. The values shown are for example only.



Frequency and Voltage values are nominal values. The Phase Powers are computed using nominal voltage and rated maximum current.

- Double-click on any of the settings.  
The Limit and Waveform Full Scales screen appears.



- Enter the Full Scale for each parameter:




- The Limits and Waveform settings (section 3.10 and 3.14, respectively) will be based on a percentage of the Full Scales entered here.
  - GE Communicator EXT automatically recalculates the Full Scale Voltages, Currents and Power every time the CT and PT ratios change. Frequency is not changed, even if the Range Selection is changed. Frequency must be changed on the Limits screen.
  - Power Phase is the amount of power per each phase.
  - Power Total is the power of all phases combined.
- ▷ When all changes are entered, click **OK** to return to the main Device Profile screen.
- ▷ For these changes to take effect, you must click on the **Update Device** button. This sends the new profile to the meter.

Reset Logs after changing any settings that will effect the Logs

- ▷ From the Menu Bar select **Tools > Reset Meter** Information.
- ▷ Click **Reset All Logs**.
- ▷ Click **OK**. (See section 3.25)

### 3.3.4 Time Settings

#### To Edit a Device Profile's Time Settings:



- ▷ From the Device Profile screen (see section 3.2), click on the **+/-** button in front of **General Settings**.
- ▷ Double-click on the **Time Settings** line. The above submenu appears.



DST=Daylight Savings Time.

- ▷ Double-click on any of the programmable settings  
The Time Settings screen appears.

- ▷ Make changes to this screen according to the requirements of your application

**Zone Descriptor:** A Zone Descriptor sets the Time Zone for the EPM Monitor.



0 = Greenwich Mean Time

See the chart below for the Zone Descriptor for your Time Zone.

**Table 3–1: Greenwich Mean Time (GMT) Table (Dublin, London)**

-1:00	Azores	+1:00	Brussels, Paris, Warsaw
-2:00	Mid-Atlantic	+2:00	Athens, Cairo, Helsinki
-3:00	Buenos Aires, Georgetown	+3:00	Baghdad, Kuwait, Moscow, Teheran
-4:00	Atlantic Time (Canada), Santiago	+4:00	Kabul, Baku
-5:00	Eastern Time (US & Canada), Lima	+5:00	Karachi
-6:00	Central Time (US & Can), Mx City	+6:00	Daka
-7:00	Mountain Time (US & Canada)	+7:00	Bankok, Hanoi, Jakarta

**Table 3–1: Greenwich Mean Time (GMT) Table (Dublin, London)**

-8:00	Pacific Time (US & Can), Tijuana	+8:00	Beijing, Hong Kong, Singapore
-9:00	Alaska	+9:00	Osaka, Sapporo, Seoul
-10:00	Hawaii	+10:00	Brisbane, Melbourne, Guam, Hobart
-11:00	Midway Island	+11:00	Magadan, Solomon Islands
-12:00	Eniwetok	+12:00	Auckland, Fiji

### Daylight Savings Information

**Enable:** Enables an automatic adjustment for daylight savings.

**Disable:** Disables an automatic adjustment for daylight savings.

**Auto DST:** Sets Daylight Savings Time automatically for the United States only. Time changes automatically occur at 2:00 AM (your local time), on the first Sunday in April and the last Sunday in October.

**User Defined:** Allows you to set the Daylight Savings Time manually.

**Start::** Set the Month, Day and Hour when the adjustment for Daylight Savings will commence.

**End:** Set the month, day and hour when the adjustment for Daylight Savings will conclude.

### Line Synchronization - Set Enable or Disable and Frequency

The basic function of Line Synchronization is to adjust the real time clock to track the time based on the power line frequency. For this purpose, Phase A voltage ONLY is used.

Line Sync is disabled if a GPS signal is present.

### How Time is Adjusted

After the clock is synced to the line, the meter periodically checks the cumulative difference between the real time clock in cycles and the line cycle count. If the absolute difference is greater than 50 (60) cycles, the clock is adjusted + / - 1 second accordingly.

- ▷ To set the meter's on board clock, use Set Meter Time from the Tools Menu.
- ▷ When all changes are entered, click OK to return to the main Device Profile screen.
- ▷ For these changes to take effect, you must click on the Update Device button. This sends the new profile to the meter.


### 3.3.5 Labels

Labels are user-defined names for the meter, the Auxiliary Voltage terminal and the I N Measured terminal.



It is important to label the meter (under “Meter Designation”) with a Unique Name because that label will become the name of the file for any logs retrieved from that meter. Duplicate meter designations interfere with retrieved log databases.

- ▷ From the Device Profile screen (section 3.2), click on the **+/-** button beside General Settings.
- ▷ Double-click on the **Labels** line.  
This submenu appears:



- ▷ Double-click on any of the Designation Names.  
The following screen appears:

- ▷ Enter the labels in the appropriate fields. Meter Designation **MUST** be set for Partial Log Retrieval.
- ▷ When all changes are entered, click **OK** to return to the main Device Profile screen.
- ▷ For these changes to take effect, you **MUST** click on the **Update Device** button. This sends the new profile to the meter.




For Meter Designations, you can use any character allowed by Windows Operating System for a File Name (since that Meter Designation will be used as the File Name). In English versions the following characters will not work: \ / : \* ? " < > |.

**For meters used internationally by multilingual users, it is recommended that you use ONLY alphanumeric characters allowed by your Operating System.**

### 3.3.6 Communications

- ▷ From the Device Profile screen (see section 3.2), click on the +/- button beside General Settings and double-click on the **Communications** line.

This submenu appears:



This screen displays the current Device Profile's settings for the meter's four Communications Ports: Address, Baud Rate, Data Bits, Parity, Stop Bits, Transmit Delay, Communication Protocol, Network Option and Internal Modem Option. You may use a connected External Display to learn the current baud rate, address and communication protocol of each meter port. See *EPM 9450/9650 Installation and Operation Manual* for details.

- Port 2 settings are ignored when the Internal Network and Internal Modem options are installed and the address is 1.
- Port 3 is factory set to the External Display's baud rate of 9600.
- The External Display only communicates to Address 1.
- You must use Port 3 or Port 4 to connect any external devices, such as a External I/O module.
- Port 3 and Port 4 are Master/Slave selectable. If you use Port 3 as a Master Port, you can use one of the other ports for the display (change the baud rate to 9600 and set address to 1).
- For all External I/O Devices, set the Communication Protocol to Modbus RTU.

- ▷ Double-click on any of the settings ("Serial Port 1").  
The Communications Settings screen appears:

**Device Profile: Communications Settings**

Port 1	Port 2	Port 3	Port 4(Ext Devices)
Address: 1	Address: 1	Address: 1	Address: 1
Baud Rate: 57600	Baud Rate: 57600	Baud Rate: 9600	Baud Rate: 57600
Data Bits: 8	Data Bits: 8	Data Bits: 8	Data Bits: 8
Parity: None	Parity: None	Parity: None	Parity: None
Stop Bits: 1	Stop Bits: 1	Stop Bits: 1	Stop Bits: 1
Tx Delay: 0ms	Tx Delay: 0ms	Tx Delay: 0ms	Tx Delay: 0ms
Protocol: Modbus RTU	Protocol: Modbus RTU <small>If the Modem or Network option is installed, Port 2 settings here will not be used. See below</small>	Protocol: Modbus RTU	Protocol: Modbus RTU
		Mode: Slave	Mode: Slave

**Network Settings (If Network Option was purchased)**

IP Address	10	0	0	1
Subnet Mask	255	255	255	0
Default Gateway	0	0	0	0

**Advanced Settings**

Ethernet Gateway

Baud Rate: 57600

Delay: 10 x 15 ms

**Internal Modem Settings (If Internal Modem Option was purchased)**

Answer Phone on: 3 Rings

Modem Gateway Baud Rate: 57600


Dial Out Profile

OK Cancel Help

Make changes to this screen according to the requirements of your application by clicking on the box or pull-down menu of any of the following settings:

- ▷ **Address:** Assign an address to each port to communicate with other devices. Multiple meters on an RS-485 bus must each have a unique address set for the port that is connected to the bus. Type in unique address.
- ▷ **Baud Rate:** The baud rate entered in this field must match the baud rate of the device that will be connected to the Primary Meter at this port.  
Use 9600 for modem connections.  
From the pull-down menu, select 4800, 9600, 19200, 38400, 57600, or 115200.
- ▷ **Data Bits:** for Modbus RTU and ASCII, leave the Data Bits at 8. Other protocols may require a different setting.  
Use the pull-down menu to select from: 5, 6, 7 or 8.
- ▷ **Parity:** for Modbus RTU and ASCII, leave the Parity at None. Other protocols may require a different setting.  
Use the pull-down menu to select from: None, Even, Odd, Mark or Space.

- ▷ **Stop Bits:** for Modbus RTU and ASCII, leave the Stop Bits at 1. Other protocols may require a different setting.  
Use the pull-down menu to select from: 1, 1.5 or 2.
- ▷ **TxDelay** (Transmit Delay): leave the TxDelay at 0ms unless you are using equipment that requires a delay in the response time, such as a radio modem.  
Use the pull-down menu to select from: 0ms, 10ms, 20ms, 30ms, 40ms, 50ms, 60ms, 60ms or 70ms.
- ▷ **Protocol:** Direct Connections made through GE Communicator EXT must use either Modbus RTU or Modbus ASCII protocol (Modbus RTU is recommended). Modem Connections made through GE Communicator EXT **must use Modbus ASCII only**.  
Use the pull-down menu to select from: Modbus RTU, Modbus ASCII or DNP 3.0. See Chapter 2 for details.
- ▷ **Mode** (Port 3 or Port 4 only): If you are using I/O modules, set one of these ports in Master mode. Set the port to operate at 57600 baud. To change the setting, use the pull-down menu to select Slave or Master.  
Make other changes for your application.
- ▷ **Internal Network Option:** If your meter has the Internal Network Option, see your Network Administrator for the correct settings. Settings will vary from network to network.  
If your meter has the INP100 Option (10/100BaseT) and you click on the Advanced Settings button, this set of screens will appear:



The meter is shipped with initial settings, or you can fully configure the settings using these screens and FTP Client. The process is detailed in Chapter 6 of the GE Communicator EXT User Guide.



These screens are **not** supported by meters with the INP10 Option.

- ▷ **Internal Modem Option:** If your meter has this option, set the number of Rings to Answer from the pull-down menu. Set the Baud Rate to 57600, or to match your system baud rate.
- ▷ **Dial Out Profile:** Click the Dial Out Profile button and the following screen appears. Details on programming this screen and on the Modem Dial In/Dial Out Function are in Chapter 9 of the GE Communicator EXT User Guide .

**Modem Programming**

**Primary phone number settings**

Number:

Retry delay:  Minutes

Retry limit:  Attempts

Connection type:

**Secondary phone number settings**

Number:

Retry delay:  Minutes

Retry limit:  Attempts

Connection type:

**Communications settings**

Inactivity timeout limit:  Minutes

Call delay timer limit:  Seconds

Callback type:

Call failure reset limit:  Hours

Share the phone line: ☐

**Modem settings**

Rings to answer:  Rings

Identification:

Password:

Enable password: ☐

Violation limit:  Attempts

Violation lockout time:  Hours

**Dial out on the following conditions**

☐ Limits status change ☐ CDEMA Power quality event ☐ Cycling of control power

☐ High speed input change ☐ Control output change ☐ Modem password failure

☐ Waveform record captured ☐ Filling of meter memory ☐ Failure of communication with 9650

Log full limit threshold (All Logs):  %



Any changes you make here may adversely affect communications. For example, if you change the baud rate of the port connected to a computer, be sure to make the same change to the computer port's baud rate. If you change a port's address, be sure to update the address settings of any device that communicates with the port. The baud rate of the port used by the meter's external display should always be set to 9600 and the address set to 1.

The **Edit Gateway Port Devices** button at the bottom of the screen is used to enable up to 8 devices connected to the gateway to be monitored. When the user clicks the **Edit Gateway Port Devices** button, this screen is displayed:



Device Number	Enable Device	Device Address
1	<input type="checkbox"/>	
2	<input type="checkbox"/>	
3	<input type="checkbox"/>	
4	<input type="checkbox"/>	
5	<input type="checkbox"/>	
6	<input type="checkbox"/>	
7	<input type="checkbox"/>	
8	<input type="checkbox"/>	


- ▷ Click on the box next to the Device to be monitored.  
A Device Address will appear next to the Enabled Device.
- ▷ Change the **Device Address**, if needed, to any address except **1**.  
The Number 1 is always reserved for the Primary Device.
- ▷ Click **OK** to return to the Modem Programming screen.
- ▷ When all changes are entered, click **OK** to return to the main Device Profile screen.
- ▷ For these changes to take effect, you **MUST** click on the **Update Device** button.  
This sends the new profile to the meter.

### 3.3.7 DNP Custom Class Map

The DNP Custom Class Map is a useful tool for prioritizing the readings in your system and the frequency of the readings. The DNP Custom Classes Map also keeps your system free from thousands of unwanted readings. For a list of available readings, see Appendix E in the GE Communicator EXT User Manual.

- ▷ From the Device Profile screen (section 3.2), click on the **+/-** button beside “General Settings”.
- ▷ Click on the **DNP Custom Classes Map +/-** button.
- ▷ Double-click on the **DNP** line.

The EPM 9650 supports DNP V3.00 Level 2, and this screen appears:



For details on programming the DNP Level 2 screens, see Chapter 17 of this manual.

The EPM 9450 supports DNP V3.00 Level 1. The lower screen shown here appears if the connected device is an EPM 9450:

- ▷ Click on the arrow to the right of the **Edit/View** window.
- ▷ Select the type of reading you want to edit or view.
- ▷ Select a **Port** and a **Class** (0, 1, 2 or 3) for that reading.

A Compressed Map creates a number sequence (starting with 0) for only those points selected for a Class.

A Non-Compressed Map (like the one shown) follows exactly the original DNP Mapping. The Compressed Map is a more efficient way to search for assigned values. Refer to EPM DNP Manual Revision 1.4 for details.

- ▷ Click **Enable DNP Time Synchronization**, if you would like to set the time through DNP.

When Time Synchronization is Enabled, a Sync Interval pull-down menu appears. The Sync Interval can be set from 1 Minute up to 1 Day in 1-minute intervals. The Factory Initial Setting is 1 Day. The EPM 9450 meter initiates the Time Synchronization sequence by sending the appropriate response to the Master connected to the meter. The meter continues to synchronize time by sending the appropriate response to the Master every time the Selected Interval is reached.

- ▷ When all changes are entered, click **OK** to return to the main Device Profile screen.

For these changes to take effect, you must click on the **Update Device** button. This sends the new profile to the meter.

**Example:** The DNP Level 1 screen shown here displays a selection of 1 Second Readings from Port 1 with No Class selected. A Class can be assigned to certain readings. Those readings will be collected by an RTU (or similar device) and displayed on your PC. Other readings will be displayed in other classes at other frequencies or not at all.

### 3.3.8 Custom Modbus Map

The Custom Modbus Map for EPM 9650 can position up to 256 Registers (or the equivalent of 2K, whichever is lower) to readily provide the functionality you want from your Meter. In addition, you can customize selected values for Format Type, Scaling, Byte Order, Data Size, etc.

- ▷ From the Device Profile screen (section 3.2), click on the +/- button beside “Custom Modbus Map” or double-click on the **Custom Modbus Map** line.

This screen appears:

Item	Modbus Map Line	Point	Number of Registers	Start Register	Group	Channel	Format
1	18	0	2	412289	Tenth Second Phase to Neutral Volts	Volts AN	Unsigned Integer
2	18	1	2	412291	Tenth Second Phase to Neutral Volts	Volts BN	Unsigned Integer
3	18	2	2	412293	Tenth Second Phase to Neutral Volts	Volts CN	Unsigned Integer
4	20	2	1	412295	Tenth Second Current(A, B, C)	IC	Unsigned Integer
5	20	2	2	412296	Tenth Second Current(A, B, C)	IC	Unsigned Integer
6	34	0	2	412298	One Second Phase to Neutral Volts	Volts AN	Unsigned Integer
7	34	1	2	412300	One Second Phase to Neutral Volts	Volts BN	Unsigned Integer
8	34	2	2	412302	One Second Phase to Neutral Volts	Volts CN	Unsigned Integer
9	35	0	2	412304	One Second Auxiliary Volts	V Aux	Unsigned Integer
10	36	0	2	412306	One Second Current(A, B, C)	IA	Unsigned Integer
11	36	1	2	412308	One Second Current(A, B, C)	IB	Unsigned Integer
12	36	2	2	412310	One Second Current(A, B, C)	IC	Unsigned Integer
13	37	0	2	412312	One Second Measured N Current	INm	Unsigned Integer
14	38	0	2	412314	One Second Calculated N Current	INc	Unsigned Integer
15	39	0	2	412316	One Second Phase to Phase Volts	Volts AB	Unsigned Integer
16	39	1	2	412318	One Second Phase to Phase Volts	Volts BC	Unsigned Integer
17	39	2	2	412320	One Second Phase to Phase Volts	Volts CA	Unsigned Integer

Data entry is straightforward. Each type of data is described below. Note that not all selections will appear on the screen at the same time. You have to scroll the screen from right to left to reach some of the functions. Certain entries (such as Format, Data Size, etc.) have different allowable selections depending on the data point used. The pull-down menu will automatically adjust to provide the appropriate selections for that data point.



Most Frequently Used Custom Modbus Map Readings are shown on table 3.2 below.

#### Data Point Selection

There are two different ways to select a Data Point:

- ▷ Refer to the **Modbus Map** and find the associated Line and Point for the value you want.  
When you enter those values into the table, the software will complete the associated Group and Channel.

OR

- ▷ Double-click the **Group** field.
- ▷ From the pull-down menus, select a **Group** and **Associated Channel** value.  
The software will complete the Map and Line values.

## Number of Registers

The number of registers polled for this Data Point is automatically computed. The number is dependent on the Data Size selected in the Data Size column.

## Start Register

Start Register numbers are automatically assigned. The registers are assigned and adjusted automatically to take into account previous entries and data sizes. This is the Start Number for the first register to use in polling.

## Format

From the pull-down menu, select a type of Format for a value such as Floating, Integer, etc.

## Data Size

From the pull-down menu, select the Number of Bytes you want to represent the Data Point.

## Unit

If the polled value is viewed as an integer, the Unit field tells you where to place the decimal point.

### Examples:

If you select .01, a polling value 1234 would be interpreted as 12.34.

If you select 100, a polling value 1234 would be interpreted as 123400.

## Pri/Sec

The meter normally computes values in secondary units. Where applicable, you may select primary or secondary. If Primary is selected, the value is multiplied by the appropriate CT and/or PT values.

## Sign/Abs

Where appropriate, you may have the option of having the data point computed as a signed or absolute value.

## Byte Order

For most of the Data Points, the user can select the polling order of the number of bytes selected by the Data Size field.

**Example:** For a four-byte Data Point, the bytes can be arranged in any order for polling.

## Display/Modulo/Offset

Depending on the Data Point, select one or more additional options with appropriate subsections.

### Display

For certain Data Points, interpretation and display options are offered.

Example: For An Angle values, you can represent and display as 0 to 360 degrees or -180 to +180 degrees, etc. Selections will appear in a pull-down menu for the associated point.

### Modulo

Certain values are cumulative and can roll over and start recounting from zero. For those values, where required, you can enter a point at which the rollover will occur.

### Offset

Where allowed, you can enter a value (offset) which will be added to the data point when it is computed.

## EPM 9450 Custom Modbus Map

This screen appears if the connected device is an EPM 9450.

Item	Modbus Map		Registers	Modbus Register	Description	Channel
	Line	Point				
1	0	0	8	412289	Device Name	
2	9	0	4	412297	1 Cycle Block Time Stamp	Time Stamp
3	12	0	2	412301	1 Cycle Current(A, B, C)	IA
4	12	1	2	412303	1 Cycle Current(A, B, C)	IB
5	12	2	2	412305	1 Cycle Current(A, B, C)	IC
6	13	0	2	412307	1 Cycle Measured N Current	INm
7	14	0	2	412309	1 Cycle Calculated N Current	INc
8	20	0	2	412311	Tenth Second Current(A, B, C)	IA
9	20	1	2	412313	Tenth Second Current(A, B, C)	IB
10	20	2	2	412315	Tenth Second Current(A, B, C)	IC
11	22	0	2	412317	Tenth Second Phase to Phase Volts	Volts AB
12	22	1	2	412319	Tenth Second Phase to Phase Volts	Volts BC
13	22	2	2	412321	Tenth Second Phase to Phase Volts	Volts CA
14	25	0	2	412323	Tenth Second VAR (A, B, C)	VAR A
15	25	1	2	412325	Tenth Second VAR (A, B, C)	VAR B
16	25	2	2	412327	Tenth Second VAR (A, B, C)	VAR C
17	27	0	2	412329	Tenth Second Watts (A, B, C)	Watts A
18	27	1	2	412331	Tenth Second Watts (A, B, C)	Watts B

- ▷ Type in the **Line** and **Point** (a Most Frequently Used List is below) for the reading you would like to view.
- ▷ Click **Enter**.  
The Description automatically appears.

Table 3–2: Most Frequently Used Custom Modbus Readings

Line	Point	Description
34	0	One Second Phase to Neutral Volts: Volts AN
34	1	One Second Phase to Neutral Volts: Volts BN
34	2	One Second Phase to Neutral Volts: Volts CN
35	0	One Second Auxiliary Volts: V Aux
36	0	One Second (A, B, C): 1A
36	1	One Second (A, B, C): 1B

Table 3–2: Most Frequently Used Custom Modbus Readings

36	2	One Second (A, B, C): 1C
37	0	One Second Measured N Current: 1Nm
38	0	One Second Calculated N Current: 1Nc
39	0	One Second Phase to Phase Volts: Volts AB
39	1	One Second Phase to Phase Volts: Volts BC
39	2	One Second Phase to Phase Volts: Volts CA
40	0	One Second VA (A, B, C): VA A
40	1	One Second VA (A, B, C): VA B
40	2	One Second VA (A, B, C): VA C
41	0	One Second VA Total: VA Total
42	0	One Second One Second VAR (A, B, C): VAR A
42	1	One Second One Second VAR (A, B, C): VAR A
42	2	One Second One Second VAR (A, B, C): VAR A
43	0	One Second VAR Total: VAR Total
44	0	One Second One Second Watts (A, B, C): Watts A
44	1	One Second One Second Watts (A, B, C): Watts B
44	2	One Second One Second Watts (A, B, C): Watts C
45	0	One Second Watts Total: Watts Total
46	0	One Second Frequency: Frequency
47	0	One Second Power Factor (A, B, C): PF A
47	1	One Second Power Factor (A, B, C): PF B
47	2	One Second Power Factor (A, B, C): PF C
48	0	One Second Power Factor Total: PF Total
49	0	One Second Imbalance: Voltage
49	1	One Second Imbalance: Current
216	2	Block Window Average Watt
217	3	Maximum Block Window Positive Watt
217	4	Maximum Block Window Negative Watt
218	3	Minimum Block Window Positive Watt
218	4	Minimum Block Window Negative Watt
194	4	Phase A-N/Phase A-B Voltage THD
195	0	Phase B-N/Phase B-C Voltage THD

**Table 3–2: Most Frequently Used Custom Modbus Readings**

196	0	Phase C/Phase C-A Voltage THD
197	0	Phase A Current THD
198	0	Phase B Current THD
199	0	Phase C Current THD


## 3.4 Revenue and Energy Settings

### 3.4.1 Demand Integration Intervals

- ▷ From the Device Profile screen (see section 3.2), click on the **+/-** button beside **Revenue and Energy Settings**.
- ▷ Double-click on the **Demand Integration Intervals** line. The following submenu appears:




- ▷ Double-click on any of the settings ("Rolling Sub-Intervals", etc.) The Demand Integration Programming screens appear:




Make changes to the screens according to the requirements of your application:

- **Block Averaging Time Interval Window:** Sets the length of the Block Interval used for Demand Calculation and other Interval-based functions.





- **Block Window Sync:** Synchronizes the meter with pulses from a High Speed Input connected to another meter. Click the Use Sync Pulse box and select the Input number (Block Window Demand Only).
- **Rolling Subinterval Window:** Sets the length of the Demand Subinterval when Rolling Demand is used. (Subinterval Length X Number of Subintervals = Length of Demand Interval Window)



- **Rolling Subintervals:** Set the number of Rolling Demand Subintervals in the Rolling Demand Window. (Subinterval Length X Number of Subintervals = Length of Demand Interval Window.)
- **Predictive Rolling Window Average:** Increasing the length of the Predictive Demand Window increases the accuracy of the prediction by including more of the current Demand Window up to 100%. Decreasing the length of the Prediction Window gives earlier warnings of High Demands.
  - ▷ When all changes are entered, click **OK** to return to the main Device Profile screen.
  - ▷ For these changes to take effect, you **MUST** click on the **Update Device** button to send the new profile to the meter.

### 3.4.2 Internal KYZ Outputs (and Test LED Settings)

The EPM 9450/9650 has no Internal KYZ Outputs. The Internal KYZ Outputs settings allow you to assign a channel and determine other settings for the Heartbeat LED. (The EPM 9800 is available with the KYZ Output Option.)

- ▷ From the Device Profile screen (section 3.2), click on the **+/-** button beside “Internal KYZ Settings” or double-click on the **Internal KYZ Settings** line.

This screen appears:

KYZ Output	Assigned Channel	Watt Hour Per Pulse	Pulse Width(ms)	Mode	Form
HB LED	Quad (1 + 4) Watthour	1.8000	100	Enable	Pulse (Form A)

OK Cancel Help

- ▷ Using the pull-down menu next to HB LED, assign a channel to the Heartbeat LED.
- ▷ Make changes to Watt Hour per Pulse, Pulse Width and Mode for the Heartbeat LED.  
There may also be a Form column on your screen. Form A = Transition. Form C = Pulse.
- ▷ When all changes are entered, click **OK** to return to the main Device Profile screen.
- ▷ For these changes to take effect, you **MUST** click on the **Update Device** button. This sends the new profile to the meter.




For EPM 9650 Only: To make the EPM 9650 follow the settings on this screen, go to the Test Pulse screen after the Device Profile has been updated. On the Test Pulse screen, click the **On** button. Ignore the settings on this screen (see section 3.26).

### 3.4.3 External Display Options

This setting of the Device Profile configures the Meter’s External Display to read either Primary or Secondary volts. All other readings will be in the Primary, regardless of this setting.

Many utility companies want to read secondary volts and primary power readings. This feature allows them to do this.

- From the Device Profile screen (see section 3.2), double-click on **External Display Options** line.



- Use the pull down menu to select either Primary or Secondary units for voltage.
- Click **OK** to return to the main Device Profile screen.
- For these changes to take effect, you **MUST** click on the **Update Device** button. This sends the new profile to the meter.

### 3.4.4 Programming Transformer Loss Compensation

- From the Device Profile screen (see section 3.2), click on the **+/-** button beside **Transformer Loss Compensation** or double-click on the **Transformer Loss Compensation** line.  
The following submenu appears:



This screen displays the current values for the meter's Transformer Loss Compensation.

- %LWFE = Percent Loss of Watts due to Iron
- %LVFE = Percent Loss of Vars due to Iron
- %LWCU = Percent Loss of Watts due to Copper
- %LVCU = Percent Loss of Vars due to Copper

Consult Appendix B of the GE Communicator EXT User Guide for an overview of Transformer Loss Compensation.

- If you have a *Standard Unit*, double-click on any loss value, “%LWFE” etc.  
This screen appears:

- Click on TLC Calculator to find the values to enter into the Percent Loss windows.  
The Calculator button will launch an Excel Spreadsheet which will do the calculations for you once the required data is entered. A copy of the Excel Spreadsheet is in Appendix B of the GE Communicator EXT User Guide.



WARNING

GE Communicator EXT will automatically launch the Excel Spreadsheet as part of its software package. But, for the TLC Button to work, you must have the Excel program in your system. If you do not have Excel software or if the spreadsheet file is not in the Communicator directory, a warning will be displayed instead of the worksheet. You can do your own calculations using the hardcopy Transformer Loss Compensation Worksheet in Appendix B of the GE Communicator EXT User Guide.



NOTE

For most Excel users, the spreadsheet will not run until permission is given to run the Macros contained in the sheet. This is done by changing the Excel Security Setting from High to Medium.

**The Excel Commands are:**

- From the Excel Toolbat, select **Tools>Security>Options**
- On the Security Tab Page, click on the **Macro Security** button.
- Select **Medium Security**.  
This setting will allow Excel to run in GE Communicator EXT.

In the Device Profile: Transformer and Line Loss Compensation Window (above)

- ▷ Enter the percent Loss of Watts and Vars for copper and iron in the appropriate fields.
- ▷ Enable or Disable Transformer Loss Compensation with the top pull-down menu.
- ▷ Click **Disable**, or, to Enable, click one of the following: **Fe only**, **Cu only** or **Both Fe and Cu**.
- ▷ With the second pull-down menu select from the following:
  - Add to Watts and Subtract from VAR.
  - Subtract from Watts and Add to VAR.
  - Add to Watts and VAR.
  - Subtract from Watts and VAR.



Enhanced "E" 9650 Units have additional choices and firmware to support the additional features. A warning may appear if you DO NOT have an Enhanced Unit.



**Warning:** The last Watt-VAR Combinations are only available if you have an Enhanced Unit or the DSP Firmware Version is greater than 212. Check with Technical Support if you have a question.

- ▷ When all settings are complete, click **OK** to return to the main Device Profile screen.
- ▷ For these changes to take effect, you **MUST** click on the **Update Device** button. This sends the new profile to the meter.

### 3.4.5 Transformer Loss Compensation for Enhanced Units

- ▷ If you have an Enhanced “E” 9650 Unit, double-click on any loss value, “%LWFE” etc.  
A similar Transformer Loss Compensation screen appears but with additional calculation choices.

- ▷ Click on **TLC Calculator** to find the values to enter into the Percent Loss windows.

The Calculator button will launch an Excel Spreadsheet which will do the calculations for you once the required data is entered. A copy of the Excel Spreadsheet is in Appendix B of the GE Communicator EXT User Guide.



**Warning!** GE Communicator will automatically launch the Excel Spreadsheet as part of its software package. But, for the TLC Button to work, you must have the Excel program in your system. If you do not have Excel software or if the spreadsheet file is not in the Communicator directory, a **Warning** will be displayed instead of the worksheet. You can do your own calculations using the hardcopy Transformer Loss Compensation Worksheet in Appendix B.

(See **NOTE** in section 3.4.4 regarding Excel.)

- ▷ Enter the **Percent Loss of Watts** and **Vars** for copper and iron in the appropriate fields.
- ▷ Enable or Disable **Transformer Loss Compensation** with the top pull-down menu.
- ▷ Click **Disable**, or, to **Enable**, click one of the following: **Fe only**, **Cu only** or **Both Fe and Cu**.
- ▷ With the second pull-down menu select from the following:

- Add to Watts and Subtract from VAR.
- Subtract from Watts and Add to VAR.
- Add to Watts and VAR.
- Subtract from Watts and VAR.

The “Enhanced” 9650 has a third pull-down menu to apply the loss based on the power flow direction.

▷ From the menu select one of the following:

- Both +Watts and -Watts.
- Watts only.
- +Watts only.




**Warning!** Do NOT use the last settings if you do not have the appropriate firmware. Check with Technical Support if you have a question.

- ▷ When all settings are complete, click **OK** to return to the main Device Profile screen.
- ▷ For these changes to take effect, you **MUST** click on the **Update Device** button. This sends the new profile to the meter.

### 3.4.6 Cold Load Pickup

- ▷ From the Device Profile screen (see section 3.2), click on the **+/-** button beside **Cold Load Pickup** or double-click on the **Cold Load Pickup** line.

The following submenu appears:



On this screen the user sets the Cold Load Pickup Delay in minutes. This value is the delay from the time control power is restored, to the time at which the user wants to resume demand accumulation.


- ▷ Double-click on one of the parameters.  
The following screen appears:



- **Cold Load Pickup:** Delay can be 1 to 60 minutes or Disabled.
- **Minimum time control power must be off before using Cold Load Pickup:**  
Value is set from 0 to 255 seconds.
  - ▷ When all changes are entered, click **OK** to return to the main Device Profile screen.
  - ▷ For these changes to take effect, you **MUST** click on the **Update Device** button to send the new profile to the meter.

### 3.4.7 Cumulative Demand Type

- ▷ From the Device Profile screen (see section 3.2), click on the **+/-** button beside **Cumulative Demand Type** or double-click on the **Cumulative Demand Type** line.  
The following submenu appears:




- ▷ Click the radio button in front of **Rolling** (sliding) **Window** or **Block** (fixed) **Window** to select Cumulative Demand Type.
- ▷ Click **OK** to exit the screen and return to the main GE Communicator EXT screen.



### 3.4.8 Energy, Pulses and Accumulations in the Interval

- ▷ From the Device Profile screen (see section 3.2), click on the +/- button beside “**Energy, Pulses and Accumulations in the Interval**” or double-click on the **Energy, Pulses and Accumulations in the Interval** line.

This window appears:



- ▷ Set the number of minutes for the Energy Interval.
- ▷ Click **OK** to close the window and return to the main GE Communicator EXT screen.

### 3.4.9 Pulse Accumulations

This section of the Device Profile displays a series of eight running totals. Each total can be added to (or subtracted from) other totals. This allows you to set the High Speed Inputs located directly on the meter to pulse accumulate.



If you use these inputs for pulse accumulations, **do not set them to record waveforms**. If you do, you will record endless waveforms.

- ▷ From the Device Profile screen (see section 3.2), click on the **+/- Revenue and Energy Settings** button and double-click on the **Pulse Accumulations** line.

The following screen will appear:

Device Profile: Internal Input Pulse Accumulators Setup

Source	Units/Count	Aggregator	User Assigned Label	Mode
1	1	None	Byte me	Transition (Form C)
2	1	None	Assigned: WAV/PQ	Transition (Form C)
3	1	None	Assigned: WAV/PQ	Transition (Form C)
4	1	None	Assigned: WAV/PQ	Transition (Form C)
5	1	None	Assigned: WAV/PQ	Transition (Form C)
6	1	None	Assigned: WAV/PQ	Transition (Form C)
7	1	None	Assigned: WAV/PQ	Transition (Form C)
8	1	None	Assigned: WAV/PQ	Transition (Form C)

Source	Hour Reading	Aggregator
Device	Quadrant(1 - 4) Watt Hour	None

Aggregator	User Assigned Label
1	Accumulator 1
2	Accumulator 2
3	Accumulator 3
4	Accumulator 4

OK Cancel Help

### Purpose of Pulse Accumulations:

Pulse Accumulators are used to accumulate Pulse information from External Devices such as gas, water or electricity meters, energy management systems, SCADA devices or any pulse generating device. Pulse Accumulation is a very flexible way to accumulate information from external devices.

Pulses from other meters can be algebraically combined with the host meter's pulse accumulations to generate one reading for a set of meters in a complex arrangement.

**Source:** This is the particular input on the meter which will be accumulated.

**Units/Pulse:** This is the scale factor which normalizes the pulses so that they can be aggregated, if desired. Pulses are stored in primary values.

**Accumulator:** This allows you to place the pulse register into a separate accumulation register, which can aggregate or net values.

**User assigned label:** This window allows a user to enter a label designation so that when reading the Aggregator, the meter will display the source.

- ▷ *To add or subtract data, use pull down menu in each window of Accumulator column(s).*




EPM 9450 does not support Averaging for Total Values that are NEGATIVE.  
EPM 9650 DOES support that type of Averaging.

- ▷ *When all data has been entered, click OK to return to the main Device Profile screen.*
- ▷ *For these changes to take effect, you MUST click on the **Update Device** button. This sends the new profile to the meter.*

### 3.4.10 Primary Hour Readings Rollover

- From the Device Profile screen (see section 3.2), click on the **+/-** button beside **Primary Hour Readings Rollover** or double-click on the **Primary Hour Readings Rollover** line.

This window appears:



- Set the number at which the Rollover will occur.
- Click **OK** to close the window and return to the main GE Communicator EXT screen.

## 3.5 Power Quality and Alarm Settings

This is the third group of settings in the Device Profile.

- ▷ From the Device Profile screen (see section 3.2), click on the **+/-** button or double click on the **Power Quality and Alarm Settings** line.



- ▷ Click on the **Programmable Setting** you would like to configure. The settings are detailed in the order they appear in the Device Profile.

### 3.5.1 Limits

Limit settings are based on a percentage of the Full Scales (% of FS), which are set in the Limit and Waveform Full Scales section of the Device Profile. Full Scales are based on CT and PT ratios set in the CT, PT Ratios and System Hookup section of the Device Profile (section 3.3.1).

- ▷ **Before programming Limits, set the CT and PT ratios first, then, set the Limit and Waveform Full Scales.**  
The software automatically updates the Full Scale. However, you can set it separately from the CT and PT Ratios.
- ▷ From the Device Profile screen (see section 3.2), click on the **+/-** button beside **Limits** or double click on the **Limits** line.  
The following submenu appears:



This screen displays the current Device Profile's settings for Limits. Not all limits are shown above; "Limit ID" extends to 32.

- Double-click on any of the settings ("Limit ID 01:", etc.).  
The Limits screen appears.

Device Profile: Limits								
Limit ID	Assigned Item	Setting	Limit 1		Setting	Limit 2		Combination Limit 3
			% of FS	Primary		% of FS	Primary	
1	Fifty Millisecond Updated:Voltage A-N	Above	101.10	280.05	Below	98.90	273.95	OR
2	Fifty Millisecond Updated:Voltage B-N	Above	101.10	280.05	Below	98.90	273.95	OR
3	Fifty Millisecond Updated:Voltage C-N	Above	101.10	280.05	Below	98.90	273.95	OR
4	Fifty Millisecond Updated:Current A	Above	102.00	5.10	Below	98.00	4.90	OR
5	Fifty Millisecond Updated:Current B	Above	102.00	5.10	Below	98.00	4.90	OR
6	Fifty Millisecond Updated:Current C	Above	102.00	5.10	Below	98.00	4.90	OR
7	One Second Updated:VA Total	Above	110.00	4570.50	Below	90.00	3739.50	OR
8	One Second Updated:Var Total	Above	25.00	1038.75	Below	21.00	872.55	OR
9	One Second Updated:Watt Total	Above	95.00	3947.25	Below	92.00	3822.60	OR
10	Fifty Millisecond Updated:Power Factor To	Above	24.65	0.986 LAG	Below	25.35	-0.986 LEAD	AND
11	Fifty Millisecond Updated:VA Total	Above	101.20	4204.86	Below	98.80	4105.14	OR
12	Fifty Millisecond Updated:Var Total	Above	20.00	831.00	Below	16.00	664.80	OR
13	Fifty Millisecond Updated:Watt Total	Above	101.20	4204.86	Below	98.80	4105.14	OR
14	One Second Updated:THD Current A	Above	3.00	3.00	Above	3.00	3.00	OR

Channels	Primary Values at 100%
I A, B, C, Nc	5.00
I Nm	5.00
V Phase to Neutral	277.00
V Aux	277.00
V Phase to Phase	480.00
Power Phase	1385.00
Power Total	4155.00
Frequency	60.00

**Percentage of Full Scale settings:** The limits are set in % of full scale (% of FS) so that when a user creates a profile, that limit setting will be constant. This is true even though the CT and PT Ratios change when the meter (or a new meter) is placed in a different location. Changing the CT and PT Ratios will not effect the % of full scale limits previously set. This is useful when using large numbers at meters.

Make changes to this screen according to the requirements of your application:

- To set the type of limit and the channel assigned to it, double click in either the **Type** or **Channel** column.
- From the pop-up menu, choose the desired settings and click **OK**.
- To designate the limit as either Above or Below a percentage of the Full Scale, click once in each Settings column and select the desired setting from the pull-down menu.
- To set the percentage of the Full Scale at which the limit will trip, enter the value in the % of FS column.  
GE Communicator EXT automatically calculates the Primary value.
- The Combination Limit 3 is the logical combination of Limit 1's state and Limit 2's state.

Device Profile: Limits								
Limit ID	Assigned Item	Setting	Limit 1		Setting	Limit 2		Combination Limit 3
			% of FS	Setpoint Primary		% of FS	Setpoint Primary	
1	Fifty Millisecond Updated:Voltage A-N	Above	101.10	280.05	Below	98.90	273.95	OR
2	Fifty Millisecond Updated:Voltage B-N	Above	101.10	280.05	Below	98.90	273.95	OR
3	Fifty Millisecond Updated:Voltage C-N	Above	101.10	280.05	Below	98.90	273.95	OR
4	Fifty Millisecond Updated:Current A	Above	102.00	5.10	Below	98.00	4.90	OR
5	Fifty Millisecond Updated:Current B	Above	102.00	5.10	Below	98.00	4.90	OR
6	Fifty Millisecond Updated:Current C	Above	102.00	5.10	Below	98.00	4.90	OR
7	One Second Updated:VA Total	Above	110.00	4570.50	Below	90.00	3739.50	OR
8	One Second Updated:Var Total	Above	25.00	1038.75	Below	21.00	872.55	OR
9	One Second Updated:Watt Total	Above	95.00	3947.25	Below	92.00	3822.60	OR
10	Fifty Millisecond Updated:Power Factor To	Above	24.65	0.986 LAG	Below	25.35	-0.986 LEAD	AND
11	Fifty Millisecond Updated:VA Total	Above	101.20	4204.86	Below	98.80	4105.14	OR
12	Fifty Millisecond Updated:Var Total	Above	20.00	831.00	Below	16.00	664.80	OR
13	Fifty Millisecond Updated:Watt Total	Above	101.20	4204.86	Below	98.80	4105.14	OR
14	One Second Updated:THD Current A	Above	3.00	3.00	Above	3.00	3.00	OR

Channels	Primary Values at 100%
I A, B, C, Nc	5.00
I Nm	5.00
V Phase to Neutral	277.00
V Aux	277.00
V Phase to Phase	480.00
Power Phase	1385.00
Power Total	4155.00
Frequency	60.00

OK Cancel Help

**Example 1:**

Limit ID 1:

Type: 1 Second Readings

Channel: Volts AN

Limit 1 Setting: Limit exceeded if Volts AN is below 12V.

Limit 2 Setting: Limit exceeded if Volts AN is above 132V.

Combination Limit 3 Setting: AND

If Limit 1 **AND** Limit 2 are exceeded then Limit 3 is exceeded.**Example 2:**

Limit ID 1:

Type: 1 Second Readings

Channel: Volts AN

Limit 1 Setting: Limit exceeded if Volts AN is below 12V.

Limit 2 Setting: Limit exceeded if Volts AN is above 132V.


Combination Limit 3 Setting: OR

If Limit 1 **OR** Limit 2 are exceeded then Limit 3 is exceeded.

To combine Limits of different Limit IDs, use the Relay Logic Diagrams.

Full Scale settings are shown in the lower left of the screen. These values are set in the Limits and Waveform Full Scales section of the Device Profile (section 3.4).

- ▷ To set the Power Factor Limits, double click on any of the Power Factor settings in the Limit 1 or Limit 2 Column.  
The Power Factor Programming Screen will appear:



Power Factor is broken into four quadrants. The screen lets you set a limit in two of the four quadrants.

To set a limit:

- ▷ From the pull-down menus, select a Quadrant and Less Than or Greater Than (Full Scales).
- ▷ Type in the Power Factor number.  
The graph will illustrate your selections by shading the Out of Limit bands. The area of the graph not covered by shading is within Normal Operational Range. Method 1 Quadrants: Q1 +Lag, Q2 -Lag, Q3 -Lead, Q4 +Lead.
- ▷ To display a graph of Method 2 Quadrants: Q1 +Lag, Q2 -Lead, Q3 +Lag, Q4 -Lead, go to the Programming Labels screen (section 3.18) of the Device Profile.
- ▷ In the lower drop down menu, click on **Method 2**, then, return to the Limits screen.
- ▷ Click on any **PF** setting.



This meter is a real four quadrant meter. Therefore, limits can be set for capacitive and inductive PF when generating or consuming power.

- ▷ When all settings are complete, click **OK** to return to the main Device Profile screen.
- ▷ For these changes to take effect, you **MUST** click on the **Update Device** button. This sends the new profile to the meter.

(Make sure you save Connected Device Settings.) A pop-up screen will ask if you want to Reset Logs. It is recommended that you reset logs when you change any settings that effect logs. See sections 3.2 and 3.2.5.




### 3.5.2 ElectroLogic Relay Control

To edit a Device Profile's GE Relay settings:

- From the Device Profile screen (see section 3.2), click on the **+/-** button or double-click on the **GE Relay** line.



The following screen appears. This screen displays the current Device Profile's settings:



- To assign an item to the Relay Logic Tree, select an **Input** for the tree by clicking on a bullet next to numbers 1 through 8.
- Choose **Limits** or **Digital Inputs** by clicking on the bullet in front of the word.
- Select the **Limit** or **Input** you want to assign to the Relay Logic Tree Input you selected.
- Press **Set** to confirm your selection.  
The software will place the selection in the appropriate window in the screen.
- After you have assigned all the Relay Logic Inputs, select the gates that will be used to combine the logic to trigger the relay.
- To select a gate, click on the gate or choose one from the pulldown menu below the gate.



To change items on the Relay Logic Tree, use the following steps:

- ▷ To change the selected relay and/or relay modules, select from the drop-down menu at the upper right hand corner of the screen.
- ▷ To change the relay Set Delay, select from the drop-down menu to the right of the Set Delay Label.
- ▷ To change the Relay Reset Delay, select from the drop-down menu to the right of the Reset Delay Label.
- ▷ To clear an item from the Relay Tree, click on that item then click the Clear Button.
- ▷ To clear ALL ITEMS from the Relay Tree, click the **Clear Assigned Items Button**.



In order to use this screen, you must have purchased at least one External Relay Out module.

For more details about External Modules, see Chapter 11 of this manual.

### 3.5.3 PQ Thresholds (Waveform Recording)

The Power Quality (PQ) and Waveform Thresholds setting determines at what point the meter will execute a waveform capture and/or record a power quality event. See Chapter 8 for how to view logs.

PQ and waveform thresholds are given as a percentage of the Full Scale (% of FS). Set the Full Scale in the Limits and Waveform Full Scales section of the Device Profile (section 3.4). Full Scales are based on the CT and PT ratios set in the CT, PT Ratios and System Hookup (section 3.3).

- ▷ **Before programming the PQ and Waveform Thresholds, set the CT and PT ratios.**
- ▷ **Set the Limits and Waveform Full Scales.**

**Caution:** Changing the CT & PT Ratios will reset the meter and clear all Logs and Accumulations.



#### Note on Sampling Rate

A higher sampling rate allows for transients to be monitored. Generally, users will set the meter to 128 samples per cycle for this purpose. Lower sampling rates have advantages because they allow you to record more cycles of information per event screen. Low sampling rates are better for long duration events, like motor starts or distribution faults.

The meter enables users to tailor the recording for both these applications. For more information on Sampling Rate, see the graph later in this section.

- From the Device Profile screen (see section 3.2), double-click on the **PQ Thresholds (Waveform Recording)** line.  
The Waveform—CBEMA Profile screen appears:

Channel	Waveform Above Setpoint		Waveform Below Setpoint		PQ Enable
	Value(%)	Enable	Value(%)	Enable	
Volts AN	120.00	<input checked="" type="checkbox"/>	80.00	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Volts BN	120.00	<input checked="" type="checkbox"/>	80.00	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Volts CN	120.00	<input checked="" type="checkbox"/>	80.00	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
IA	120.00	<input checked="" type="checkbox"/>	0.00	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
IB	120.00	<input checked="" type="checkbox"/>	0.00	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
IC	120.00	<input checked="" type="checkbox"/>	0.00	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
INm	10.00	<input checked="" type="checkbox"/>	0.00	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Input Assigned to: 1 Waveform / PQ Trigger, 2 Waveform / PQ Trigger, 3 Waveform / PQ Trigger, 4 Waveform / PQ Trigger, 5 Waveform / PQ Trigger, 6 Waveform / PQ Trigger, 7 Waveform / PQ Trigger, 8 Waveform / PQ Trigger

Sampling Rate: 120 Samples / Cycle @ 60Hz  
8 Cycles Captured Per Window @ 60Hz  
Total Capture Windows Per Event: 1

A limit value of 100 % equals the following primary value —  
I A.B.C: 5.00 V P-N: 277.00 V P-P: 480.00

OK Cancel Help

## Software Triggers

To set the threshold for a PQ Event and Waveform capture, enter the desired percentage of Full Scale in the Value (%) column of the Above Setpoint and Below Setpoint sections. Full Scales are shown in the lower right corner of the screen.



### Note on CBEMA

The CBEMA plotting is a power quality standard known world-wide for recording the amount of damage voltage transient conditions have done to the equipment being monitored. The meter automatically records this information.

For CBEMA purposes, the user programs internal set points for voltage below 90% and above 110% of full scale (+/- 10% from the nominal voltage). These setpoints are defined by the ITI (CBEMA) specification. The ITI (CBEMA) Curve is published by Information Technology Industry Council (ITI) and is available at: [http://www.itic.org/iss\\_pol/techdocs/curve.pdf](http://www.itic.org/iss_pol/techdocs/curve.pdf).

A user can set a recording with tighter voltage limits to trigger a waveform recording. However, CBEMA plotting will be based only on the limits internally set.



### Note on Setting the EPM 9450/9650 Meter to Record Current Faults

As discussed, the voltage setpoints are used to record voltage type events, such as voltage surges, sags and transients. The current settings are used to record faults on the line or in-rush currents from devices such as motors.

Typically, to catch these events, set the limit to above 200% of full scale.

### Waveform Clipping Threshold

- EPM 9450/9650 5 Amp Standard Hardware - 61.9437A Peak before clipping.
- EPM 9450/9650 1 Amp Hardware - 12.09A Peak before clipping

### Hardware Triggers

To enable a waveform or PQ recording for any of the 8 High Speed Inputs, click in the appropriate box. This will trigger a recording based on a contact trigger. This is useful to monitor an open device and to capture the waveform during that operation.

### Samples per Cycle

To choose the Samples per Cycle to be recorded at 60 Hz, click on the Sampling Rate pull down menu. Choose from 16, 32, 64, 128, 256 and 512 samples per cycle. The number of samples per cycle you choose will inversely effect the number of cycles per capture.

- If you select 256, a Capture Only pop up screen will ask you to select Volts A, B, C or I A, B, C.
- If you select 512, a Capture Only pop-up screen will ask you to select one of the individual channels.

As you increase the number of samples, you will record more detailed information. The table below illustrates the “Effects of Sampling Rate” on the number of cycles captured. Increasing Sampling Rate increases waveform definition but reduces the length of the observed window. The approximate length of the observed window is shown in the last column.

For **example**: For observed events of approximately 1/2 second, a sampling rate of 32 samples should be used.

**Table 3–3: Effects of Sampling Rate**

Samples per Cycle	Channels		Samples per Channel	Cycles per Capture	Time (Approx.)
	Analog	HSI			
16	7	8	1024	64	1 second
32	7	8	1024	32	1/2 second
64	7	8	1024	16	1/4 second
128	7	8	1024	8	1/8 second
256	3	8	2048	8	1/8 second
512	1	8	4096	8	1/8 second



### Note on Waveform Event Captures

A screen of data is one capture. If you set Total Captures to 3 and you are recording at 16 samples per cycle, you will record:

$$16 \text{ Samples: } 3 \times 64 = 192 \text{ cycles of recorded waveforms}$$

128 Samples:  $3 \times 8 = 24$  cycles of recorded waveforms

With the 2 MB module, you can have a total of 64 captures. With the 4 MB module, you can have a total of 96 captures. You can partition the memory in any fashion required for the specific application. There is no limitation on the number of cycles that can be recorded per event.

- ▷ To choose the total amount of captures, click on the **Total Captures** pull down menu.
- ▷ Select from **0 to 96** captures.  
The higher the number, the more information you will be “stringing together”.
- ▷ When all changes are entered, click **OK** to return to the main Device Profile screen.
- ▷ For these changes to take effect, you **MUST** click on the **Update Device** button. This sends the new profile to the meter.
- ▷ **Reset Logs**.

### 3.5.4 EN 50160 Flicker

With the Flicker Settings screen, the user can set the test times for the Flicker function.

- ▷ From the Device Profile screen (section 3.2), click on the **+/-** button beside **Flicker Settings** or double-click on the **Flicker Settings** line. This screen appears:



- ▷ From the pull down menus, select a **Short term test time** and a **Long term test time**.
- ▷ From the Frequency pull-down menu, select **50** or **60** Hz.
- ▷ When all changes are entered, click **OK** to return to the main Device Profile screen.
- ▷ For these changes to take effect, you **MUST** click on the **Update Device** button. This sends the new profile to the meter.



Flicker is discussed in detail in Chapter 15 of the GE Communicator EXT User Guide.

### 3.5.5 I Squared T and V Squared T Thresholds

With the I Squared T and V Squared T Thresholds screen, the user can set at what point the Current and Voltage should accumulate.

- ▷ From the Device Profile screen (section 3.2), click on the **+/-** button beside **I Squared T and V Squared T** or double-click on the **I Squared T and V Squared T** line.

This screen appears:

- ▷ Input the desired thresholds.
- ▷ Click **OK** to exit the screen and return to the GE Communicastor EXT main screen.


### 3.5.6 High Speed Inputs

This section of the Device Profile enables you to label the eight High Speed Inputs.

Use of this storage field allows a user to label the inputs so that when the data is later analyzed, the user knows the source of the status change.

- ▷ From the Device Profile screen (see section 3.2), click on the **+/-** button or double-click on the **Digital Inputs** line and double-click on **High Speed Inputs**.

The following submenu appears:



- Double-click on **High Speed Inputs**.  
The following submenu appears.

Input ID	Name	Open Label	Shorted Label	Normal Condition	Input Type
1	HSI Input 1	Open_1	Closed_1	Open	Waveform / PQ Trigger
2	HSI Input 2	Open_2	Closed_2	Open	Waveform / PQ Trigger
3	HSI Input 3	Open_3	Closed_3	Open	Waveform / PQ Trigger
4	HSI Input 4	Open_4	Closed_4	Open	Waveform / PQ Trigger
5	HSI Input 5	Open_5	Closed_5	Open	Waveform / PQ Trigger
6	HSI Input 6	Open_6	Closed_6	Open	Waveform / PQ Trigger
7	HSI Input 7	Open_7	Closed_7	Open	Waveform / PQ Trigger
8	HSI Input 8	Open_8	Closed_8	Open	Waveform / PQ Trigger

- Double-click on the input you would like to label.
- Enter text in each field.
- Click **OK** to return to the main Device Profile screen.
- Click **Update Device Profile** to send the new profile to the meter.

### 3.5.7 Trending Profile Settings and Load Profile Recording

This section of the Device Profile enables you to set the Trending Profiles for historical logs.

- From the Device Profile screen (see section 3.2), click on the **+/-** button beside **Trending Profile Settings** or double-click on the **Trending Profile Settings** line.  
The following submenu appears:



- Double-click on one of the **Trending** topics to access the programming screens.

#### Load Profile Recording - Definition

Load Profile Recording is a subset of the meter's more general Logging and Trending capability. The same screens are used for setup but Load Profile Recording deals only with Accumulated Values, Energy (Wh), Reactive Energy (VARh) and Apparent Power (VAh).

Historically, Load Profile Recording referred to recording of Quadrant 1 Energy (Wh) because electromechanical meters only measured energy and were detented to prevent reverse rotation outside of Quadrant 1.

### 3.5.8 Programming the Trending Log Time Intervals

Trending Log Time Intervals determine the interval at which Historical Logs 1 and 2 will take a snapshot. To set the parameters for the logs, see section 3.12.


See Chapter 8 of the GE Communicator EXT User Guide, for how to view and retrieve logs.

- From the Device Profile screen (see section 3.2), click on the **+/-** button beside **Trending Log Time Intervals** or double-click on the **Trending Log Time Intervals** line.  
The following submenu appears:



This screen displays the current Device Profile's Trending Log Time Intervals. The values shown are for example only.

- Double-click on either **Log 1 Interval** or **Log 2 Interval**.  
The Interval Log Setting screen appears:



- Enter the hours, minutes and seconds for each log.  
The logs will be time-stamped based on the meter's time, which is set using the Tools menu. See section 3.2.5.
- When all changes are entered, click **OK** to return to the main Device Profile screen.
- For these changes to take effect, you **MUST** click on the **Update Device** button. This sends the new profile to the meter.
- **Reset Logs**.

### 3.5.9 Programming the Trending Setup for Historical Logs 1 and 2

The Trending Setup controls the channel assignments for Historical Logs 1 and 2. To set the Time Intervals for these Logs, see section 3.12. See Chapter 8 of the GE Communicator EXT User Guide, for how to view logs.

- From the Device Profile screen (see section 3.2), click on the **+/-** button beside **Trending Setup** or double-click on the **Trending Setup** line.  
The Trending submenu appears.
- To change the settings for Log 1 double-click on **Log 1**.

- ▷ To change the settings for Log 2 click on **Log 2**.

The Snapshot Channel Assignment Log 1 or 2 screen appears:

Make changes to this screen according to the requirements of your application:

- ▷ **Type:** Using pull down menu, select the type of snapshot.
- ▷ **Channel:** Using pull down menu, select a channel for the snapshot.
- ▷ Click on **Add** to include the selections in the Log; click on **Remove** to delete.
- ▷ To remove multiple items, hold **Control** while clicking items to be removed. Click **Remove**.
- ▷ To remove a range of items, click the first item, hold **Shift**, then click the last item. Click **Remove**.
- ▷ When all changes are entered, click **OK** to return to the main Device Profile screen.
- ▷ Click on the **Update Device** button.  
This sends the new profile.
- ▷ **Reset Logs.**

Total bytes used and Bytes remaining screens display the memory status for that particular file. meter assumes 256 bytes of memory for each file. Total memory is determined at time of purchase.



### 3.5.10 Pad Missing Records for Historical Logs

When the meter is not in normal operation, it will not record any data for Log 1 and Log 2. For example, during firmware updates or loss of power, data will not be saved. Some applications may require data logs to contain those missing records.

To remedy this problem, you can:

- ▷ **Enable the feature in Options > Log Retrieval > Pad Log File.**
- ▷ **Click the box in front of the feature.**
- ▷ **Click OK.**

This feature pads missing records for the Meter's Log 1 and Log 2. The software causes the Log Converter program to automatically pad the missing records with a value of 0 for each log retrieval process and stores them in the Log DB file. By default, if the meter's Trending Interval is set for Greater than 1 Hour, the meter will always save a record on the hour in the Trending Logs.

### 3.6 External Devices

The setting of the Device Profile configures the meter’s External Devices, a variety of I/O Modules configurable using the screen below.

- From the Device Profile screen (see section 3.2), double-click on the **External I/O Modules** line.  
The following screen appears:

Module Number	Type	Assigned Address	EPM Settings	Module Settings	EPM Port	Log / Limit ID
1	4RQ1: Digital Output	159	Ed	Ed	3	DO Module 1
2	No Device Assigned				4	
3	No Device Assigned				4	
4	No Device Assigned				4	
5	No Device Assigned				4	
6	No Device Assigned				4	
7	No Device Assigned				4	
8	No Device Assigned				4	
9	No Device Assigned				4	
10	No Device Assigned				4	
11	No Device Assigned				4	
12	No Device Assigned				4	
13	No Device Assigned				4	
14	No Device Assigned				4	
15	No Device Assigned				4	
16	No Device Assigned				4	

- Click in the **Type** column and use the pull down menu to select the specific I/O you wish to add and enter a unique address for each.
- Use the **Edit** buttons to configure each module further.
- Click **OK** to return to the main Device Profile screen.
- For these changes to take effect, you **MUST** click on the **Update Device** button. This sends the new profile to the meter.  
For more details on I/O Modules, refer to Chapter 10 of the GE Communicator EXT User Guide.

### 3.7 Set and Retrieve Meter Time

The meter uses its on-board clock for time-stamping any logs it is recording. To set the meter's clock:

- ▷ Select **Tools > Set Meter Time**.

The meter's On-board Clock screen appears:


- ▷ To synchronize the meter with your computer, leave the **Use PC Time** box checked.
- ▷ To set the date and time to be independent from the PC, deselect the **Use PC Time** box and enter the time and date settings.
- ▷ Click the **Send** button to update the meter's time settings.

#### To retrieve the meter's current time and date settings:


- ▷ Select **Tools >, Retrieve Meter Time**. The following screen appears. Date and Running Time are displayed in LEDs. *If the IRIG-B signal is present on the IRIG-B Input of the Device, a green IRIG-B appears next to the time.*
- ▷ Click **OK** to return to the main GE Communicator EXT screen.


## 3.8 Reset Meter Information

- ▷ From the menu bar select **Tools > Reset Meter Information**.  
The following set of screens appears:



- ▷ Click in the tabs to navigate between screens.





- ▷ Click on the box beside the value(s) you would like to reset.
- ▷ Click **OK**.



If you click Reset Logs, a **warning** will appear asking you if you want to **Save Connected Device Settings**. Click on the settings you would like to save, then proceed with the Update. If you do not save the settings, they will be overwritten.

For each box you select, a window will appear which states that the “Reset is Completed”. **Click OK**. The reset is completed.

You can password protect this feature by enabling the Password feature of the Meter. (See Chapter 12 of the GE Communicator EXT User Guide, for details).

## 3.9 Manual Waveform Capture

- ▷ From the Menu bar, click on **Tools > Manual Waveform Capture**.  
The Manual Waveform Capture screen appears:

Manual Waveform Capture							
Waveform Log Statistics							
Log	Records	Memory Used	Newest Record Time	Oldest Record Time	Record Size	Max Records	Memory
Waveform Triggers	11	12%	05/31/2006 17:39:05.12	04/12/2006 16:52:16.51	256	95	32K
Waveform Samples	11	12%	05/31/2006 17:39:05.12	04/12/2006 16:52:16.51	16384	95	1536K

OK Trigger Now Help

This screen displays the Waveform Log Statistics of the logs that have possible Waveform Triggers.

- ▷ Click the **Trigger Now** button at the bottom of the screen to create a waveform.  
GE Communicator EXT creates a waveform in the Meter's memory. The Records on the screen will increase by 1.
- ▷ To retrieve the Waveform, from the Menu Toolbar, click **Logs > Retrieve Log from Device**.
- ▷ Click **OK** to return to the main Device Profile screen.




1  
011  
101110011100  
01100111110001  
000111010110110  
11110001001101  
010101110010  
011  
1

## GE Communicator EXT

# Chapter 4: Configuring the EPM 9800 Meter

### 4.1 Overview

GE Communicator EXT enables you to configure an EPM 9800 Socket Meter's programmable settings, which are stored in the unit's Device Profile. The Device Profile has four sections (below) plus I/O Modules.



Following is an overview of the procedure for configuring an EPM 9800 Meter:

1. **Retrieve** the meter's Device Profile (section 4.2)
2. **Configure** the programmable settings stored in the Device Profile (sections 4.3–4.7)
3. **Send** the new Device Profile back to the Meter (section 4.2).



If you click the **Save**, **Load** or **Update** buttons, you **MUST** have a unique meter Destination Label so that the file is saved, loaded or updated to the intended device.



This chapter also covers:

- Resetting Meter Information (section 4.9)
- Setting and Retrieving Meter Time (section 4.10)
- Test Mode Preset Accumulators (section 4.14) and Options (section 4.15)



Actual programming screens may vary depending on the options ordered with your meter.




The settings shown are for the **EPM 9800, which supports DNP Level 2**. For a Feature Comparison of GE models, refer to section 1.6 of the GE Communicator EXT Guide. For details on DNP Level 2, see Chapter 17 of the GE Communicator EXT Guide. The External Devices section of the Device Profile is covered in Chapter 11 of this same guide.



## 4.2 Retrieve and Send Device Profiles


- Click on the **Profile** button, or select **Tools > Edit Current Device Profile**. GE Communicator EXT retrieves the programmable settings from the currently connected meter.

The following screen appears:



When the settings have been retrieved successfully, the Device Profile screen appears. This screen contains all the programmable settings currently stored in the connected meter.

- Configure each of the programmable settings by clicking on the **+/-** icon and then double-clicking on the selected parameter. (See sections 4.3–4.25 for details on editing each setting.)



After you have finished configuring any or all of the programmable settings, use the **BUTTONS** at the bottom of the screen as follows:

- Click on the settings you would like to save, then proceed with the **Update**.

- Implement the changes by clicking on the **Update Device** button. This sends the new, edited Device Profile to the meter.



You must update the Meter Device profile for any of the programmable settings to take effect.

A **Warning** will appear asking you if you want to Save Connected Device Settings.

- Store the profile for later use by clicking on the **Save** button. A dialogue box will ask where you would like to save the profile.
- Open a previously saved profile by clicking on the **Load** button. A dialogue box will ask for the location of the saved profile.
- Print a copy of the profile by clicking on the **Report** button. The Report screen will appear as shown here:

Device Profile Report

Comment: 3.0.20 Document

### Device Profile Report

Model:	EPM 9800		
ID Number:	00121689		
Name:			
NVRAM:	4 MB		

#### Firmware Versions

Firmware	Boot	Runtime	Xilinx
Comm	601	618	3
DSP	600	628	0

#### Communications Settings

Item	Port 1	Port 2	Port 3	Port 4
Address	1	1	1	1
Baud Rate	57600	57600	9600	57600
Data Bits	8	8	8	8
Parity	None	None	None	None
Stop Bits	1	1	1	1
Tx Delay	0ms	0ms	0ms	0ms
Protocol	Modbus RTU	Modbus RTU	Modbus RTU	Modbus RTU
Mode			Slave	Slave

#### System Setup

CT Ratio:	1.00	1.00
PT Ratio:	1.00	1.00
CT Ratio Aux:	1.00	1.00
PT Ratio Aux:	1.00	1.00
Hookup:	WYE	
Frequency Range:	20Hz to 65Hz	
Voltage Back:	150 V	
Power Direction Label:	Quadrant 1 + 4 = Delivered and Quadrant 2 + 3 = Received	
Pwr Factor Display Method:	2 Q1 + Lag, Q2 - Lead, Q3 + Lag, Q4 - Lead	

#### Time Setup

Time Zone:	-5.0
DST Enabled:	Auto DST
DST Start:	
DST End:	
Line Sync:	Disable
Frequency:	

#### Demand Setup

Therm # Averaging Window:	100, 15m, 00s
Block Averaging Window:	100, 15m, 00s
Rolling Averaging Sub-Interval Window:	100, 05m, 00s
Rolling Sub-Intervals:	3
Predictive Rolling Window Average:	100.00

#### Block Window Sync

Use Sync Pulse:	No
High Speed Input #:	N/A
Generate End of Interval Pulse:	N/A
Pulse #:	N/A
Pulse Width (ms):	N/A

Page 1 of 20      06-19-2006    11:20:37

Page 1 of 20    Zoom: Whole Page

Print Range: 1 to 20    Copies: 1

Print Page(s):

Print    Save    Done

### Using the Report Page:

**Page Arrows:** Select a page to view.

**Zoom:** Adjusts the Viewing Magnification.

**Print Range:** Adjusts the Range of Pages to be printed at 100%.

**Buttons:**

**Copies:** How many copies do you want to print?

**Print Pages:** Select individual pages to print. Separate Page Numbers by Commas.

**Print:** This button sends you to Print Setup screen where you select printer, properties, paper and page orientation. Click OK to Print.

**Save:** Save these selections for future use.

**Done:** Exit the screen and return to the Device Profile screen.




If you change the Com settings for the meter, you will not be able to communicate with the meter. You will have to sign off and sign on again with the new settings.

## 4.3 General Settings

“General Settings” is the first group of settings in the Device Profile.


- ▷ From the Device Profile screen (see section 4.2), click on the (+/-) button or double-click on the “General Settings” line. All of the settings in the General Settings Group are listed.



- ▷ Click on the particular Programmable Setting you would like to configure. The settings will be detailed in the order they appear on the Device Profile screen.

### 4.3.1 CT and PT Ratios and System Hookup

- ▷ From the Device Profile screen (see section 4.2), click on **General Settings**
- ▷ Double-click on the **CT, PT Ratios and System Hookup** line. The following submenu appears:



This screen displays the current Device Profile's settings for CT, PT ratios and the meter form used for hookup. The values shown are for example only.

- ▷ Double-click on any of the settings.
- The CT and PT Ratios screen appears:

Make changes to this screen according to the requirements of your application.


- When you change a PT or CT ratio, GE Communicator EXT updates the corresponding Full Scale value entered in the Limits and Waveforms Full Scale setting.
- Using the pull-down menu, choose the hook up service that matches the connection you have to the EPM 9800. Selections may include: 9S 4-Wire Wye or Delta, 36S 4-Wire Wye, 39S 4-Wire Wye and 45S 3-Wire Delta or 4-Wire Wye. The Device Profile screen, including the Form above the connection window, will reflect your selection.



Changes to the Operational Frequency Range do not change the Full Scale Value for Frequency. Changes must be made in the “Limits and Waveform Full Scale Settings” screen. Like Voltage and Current, the nominal value should be used. For example, 50 for 50Hz circuits.

- ▷ Click **OK**.

The following screen asks you to verify the Kh/Ke Ratio for the Test Pulse Setting. Kh/Ke Ratio is Secondary Watthour Constant over kWh (the energy).



- ▷ Click **Yes**, or Click **No**, and re-enter values in the CT & PT Ratio screen.
- ▷ When all changes are entered, click **OK** to return to the main Device Profile screen.
- ▷ Click on the **Update Device** button.  
This sends the new profile to the Meter.
- ▷ **Reset** Logs, clearing logs and accumulations.




Be sure to capture needed meter information before updating the device. Data will no longer be available after the Reset. The meter will be prepared for new installation.

### 4.3.2 One Amp Current Input Addendum (Modification Number M10.0)

For special circumstances, the Meter can be ordered with one amp current transformers. This will give the Meter a range of 0 to 1 amps with an additional over-range of 1 amp.

This option is used where 1A IEC meters are required or extended low current performance is needed and higher current performance is not needed. This option is not used for most 1A installations. The standard Meter has the capability of very accurately monitoring 1A loads and providing extended current overload.

The following shows the change made to the toroid to adjust for the modification.



In order to maintain maximum accuracy with one (1) amp current inputs, the wire is wound around the internal toroids five (5) times, instead of the usual one time. This effectively multiplies the current input by five (5) times, to maintain maximum resolution.

- ▷ **No modification is required to the CT Ratios because EPM 9800 CT Ratios automatically adjust internally for this modification.**



Use of the M10.0 Option is not recommended unless direct 1A IEC meter replacement of very extended low current performance is needed.

### 4.3.3 Limit and Waveform Full Scales


All Limit and Waveform settings (sections 4.5.1 and 4.5.3, respectively) are based on a percentage of the Full Scale. Full Scales are based on the CT and PT ratios (see section 4.3.1).

- ▷ **Be sure to set the CT and PT ratios first**  
GE Communicator EXT automatically recalculates the Full Scales every time the CT and PT ratios change and should be verified every time CT and PT Ratios are changed.



Changing the CT and PT Ratios will reset the meter, clearing logs and stored data. This action prepares the meter for placement in a new installation or changing of the Instrument Transformers.

- ▷ From the Device Profile screen (see section 4.2), click on the **+/-** button beside **General Settings**
- ▷ Click on the **Limit and Waveform Full Scales** line.  
The following submenu appears:




The EPM 9800 screen displays the Device Profile's settings for the Limit and Waveform Full Scales.



Frequency and Voltage values are nominal values. The Phase Powers are computed using nominal voltage and rated maximum current.

- ▷ Double-click on any of the settings.  
The Limit and Waveform Full Scales screen appears.



- ▷ Enter the Full Scale for each parameter:




- The Limit and Waveform settings (section 4.5.1 and 4.5.3, respectively) will be based on a percentage of the Full Scales entered here.
  - GE Communicator EXT automatically recalculates the Full Scales Voltages, Currents and Power every time the CT and PT Ratios change. Frequency is not changed, even if the Range
  - Selection is changed. Frequency must be changed on the Limits screen. i Power Phase is the amount of power per each phase.
  - Power Total is the power of all phases combined.
- ▷ When all changes are entered, click **OK** to return to the main Device Profile screen.
- ▷ For these changes to take effect, you must click on the **Update Device** button.  
This sends the new profile to the meter.
- ▷ To **Reset Logs**, see section 4.26

#### 4.3.4 Time Settings

To edit a Device Profile's time settings:

- ▷ From the Device Profile screen (see section 4.2), click on the **+/-** button or double-click on the **Time Settings** line.  
The following submenu appears:



This screen displays the current Device Profile's time settings.  
(DST=Daylight Savings Time.)

- ▷ Double-click on a programmable setting (eg: **Time Zone**).  
The Time Settings screen appears.

**Device Profile: Time Settings**

Zone Descriptor: -5.0

Daylight Savings Information: Auto DST

Line Synchronization:

Enable: No

Frequency: 60Hz

OK Cancel Help

- ▷ Make changes to this screen according to the requirements of your application:
- **Zone Descriptor:**  
Sets the Time Zone for the Meter. (0=Greenwich Mean Time).

**Table 4-1: Greenwich Mean Time (GMT) Table (Dublin, London)**

-1:00	Azores	+1:00	Brussels, Paris, Warsaw
-2:00	Mid-Atlantic	+2:00	Athens, Cairo, Helsinki
-3:00	Buenos Aires, Georgetown	+3:00	Baghdad, Kuwait, Moscow, Teheran
-4:00	Atlantic Time (Canada), Santiago	+4:00	Kabul, Baku
-5:00	Eastern Time (US & Canada), Lima	+5:00	Karachi
-6:00	Central Time (US & Can), Mx City	+6:00	Daka
-7:00	Mountain Time (US & Canada)	+7:00	Bankok, Hanoi, Jakarta
-8:00	Pacific Time (US & Can), Tijuana	+8:00	Beijing, Hong Kong, Singapore
-9:00	Alaska	+9:00	Osaka, Sapporo, Seoul
-10:00	Hawaii	+10:00	Brisbane, Melbourne, Guam, Hobart

Table 4–1: Greenwich Mean Time (GMT) Table (Dublin, London)

-11:00	Midway Island	+11:00	Magadan, Solomon Islands
-12:00	Eniwetok	+12:00	Auckland, Fiji

- **Daylight Savings Information:**

**Enable:** Enables an automatic adjustment for daylight savings.

**Disable:** Disables an automatic adjustment for daylight savings.

**Auto DST:** Sets Daylight Savings Time automatically for the **United States only**. Time changes automatically occur at 2:00 AM (your local time), on the first Sunday in April and the last Sunday in October.

**User Defined:** Allows you to set the Daylight Savings Time manually.

**Start:** Set the Month, Day and Hour when the adjustment for Daylight Savings will commence.

**End:** Set the month, day and hour when the adjustment for Daylight Savings will conclude.

- **Line Synchronization:** Set Enable or Disable and Frequency.

The basic function of Line Synchronization is to adjust the real time clock to track the time based on the power line frequency. For this purpose, Phase A voltage ONLY is used. Line Sync is disabled if a GPS signal is present.

- **How Time is Adjusted:**

After the clock is synchronized to the line, the meter periodically checks the cumulative difference between the real time clock in cycles and the line cycle count. If the absolute difference is greater than 50 (60) cycles, the clock is adjusted  $\pm 1$  second accordingly.

- ▷ To set the meter on-board clock, use **Set Meter Time** from the Tools menu. (see section 4.26).
- ▷ When all changes are entered, click **OK** to return to the main Device Profile screen.
- ▷ For these changes to take effect, you must click on the **Update Device** button.  
This sends the new profile to the Meter.
- ▷ To **Reset Logs**, see later sections.


### 4.3.5 Labels

**Labels are user-defined names for the Meter, the Auxiliary Voltage terminal and the I N Measured terminal.**



It is important to label the meter (under **Meter Designation** because the label given will become the name of the file for any logs retrieved from that meter; see Chapter 8 of the GE Communicator EXT Guide for details on viewing stored logs.

- From the Device Profile screen (section xxx), click on the **+/-** button beside **General Settings**, then click on **Labels**.  
The following submenu appears:



- Double-click on any of the designation names.  
The following screen appears.

The 'Device Profile: Labels' dialog box is shown with the following fields and options:

- Meter Designation: 00121689
- V Aux: Vaux
- I N Measured: Inm
- Power Direction: Quadrant 1 + 4 = Delivered and Quadrant 2 + 3 = Received (dropdown menu)
- Power Factor Display: Method 2 Q1 +Lag, Q2 -Lead, Q3 +Lag, Q4 -Lead (dropdown menu)
- Memo Field: (empty text area)
- Buttons: OK, Cancel, Help

- Enter the labels in the appropriate fields.  
Meter Designation MUST be set for Partial Log Retrieval.

When all changes are entered,

- Click **OK** to return to the main Device Profile screen.
- Click on the **Update Device** button to effect changes.  
This sends the new profile to the meter.



For meter designations, you can use any character allowed by Windows Operating System for a File Name (since that meter designation will be used as the File Name).

In English versions the following characters will **not** work:


\ / : \* ? " < > | .

For meters used internationally by multilingual users, it is recommended that you use ONLY alphanumeric characters allowed by your Operating System.

### 4.3.6 Communications

- From the Device Profile screen (see section 4.2), click on the +/- button next to **General Settings**, then click on **Communications Ports**.

The following submenu appears:



- Double-click on the port you would like to change. The Communications Settings screen appears:

**Device Profile: Communications Settings**

Port 1	Port 4(Ext Devices)
Address: 61	Address: 1
Baud Rate: 57600	Baud Rate: 115200
Data Bits: 8	Data Bits: 8
Parity: None	Parity: None
Stop Bits: 1	Stop Bits: 1
Tx Delay: 0ms	Tx Delay: 0ms
Protocol: Modbus RTU	Protocol: Modbus RTU
	Mode: Slave

**Network Settings (If Network Option was purchased)**

IP Address	1	255	255	255
Subnet Mask	255	255	255	255
Default Gateway	255	255	255	255

**Internal Modem Settings (If Internal Modem Option was purchased)**

Answer Phone on: 3 Rings

Modem Gateway Baud Rate: 38400

Dial Out Profile

OK Cancel Help

This screen displays the Device Profile's settings for the meter's two programmable Communications Ports: Address, Baud Rate, Data Bits, Parity, Stop Bits, Transmit Delay, Communication Protocol, Network Option and Internal Modem Option.

You may use the on-board display or one of the meter's External Displays to learn the current baud rate, address and communication protocol of each meter port. **The settings for the Optical Port are fixed and cannot be changed.** Port 1 and Port 4 are the meter's RS-485 ports and are used for RS-485 communication with a variety of devices. Port 3 is an internal modem or Ethernet. Ports 1 and 4 are factory set at 115200 and 9600 baud rates, Modem Gateway is 38,400 maximum.


▷ **Make changes to this screen according to the requirements of your application, by clicking on the box or pull-down menu of any of the following settings:**

- **Address:** Assign an address to each port to communicate with other devices. Multiple Meters on an RS-485 bus must each have a unique address set for the port that is connected to the bus. Type in unique address.
- **Baud Rate:** The baud rate entered in this field must match the baud rate of the device that will be connected to the Meter at this port. Use 9600 for modem connections. From the pull-down menu, select 4800, 9600, 19200, 38400, 57600, or 115200.
- **Data Bits:** for Modbus RTU and ASCII, leave the Data Bits at 8. Other protocols may require a different setting. Use the pull-down menu to select from: 5, 6, 7 or 8.
- **Parity:** for Modbus RTU and ASCII, leave the Parity at None. Other protocols may require a different setting. Use the pull-down menu to select from: None, Even, Odd, Mark or Space. ¶
- **Stop Bits:** for Modbus RTU and ASCII, leave the Stop Bits at 1. Other protocols may require a different setting. Use the pull-down menu to select from: 1, 1.5 or 2.
- **TxDelay (Transmit Delay):** leave the TxDelay at 0ms unless you are using equipment that requires a delay in the response time, such as a radio modem. Use the pull-down menu to select from: 0ms, 10ms, 20ms, 30ms, 40ms, 50ms, 60ms, 60ms or 70ms.
- **Protocol:** Direct Connections made through GE Communicator EXT must use either Modbus RTU or Modbus ASCII protocol (Modbus RTU is recommended). Modem Connections made through GE Communicator EXT must use Modbus ASCII only. Use the pull-down menu to select from: Modbus RTU, Modbus ASCII or DNP 3.0. See Chapter 2 of the GE Communicator EXT Guide for details.
- **Mode (Port 4 only):** If you are using I/O modules, set this port to Master mode. Set the port to operate at 57600 baud. To change the setting, use the pull-down menu to select Slave or Master. Make other changes for your application.
- **Internal Network Option:** If your Meter has the Internal Network Option, see your Network Administrator for the correct settings. Settings will vary from network to network.

If your meter has the INP100 Option (10/100BaseT) and you click on the Advanced Settings button, the following set of screens will appear. The meter is shipped with initial settings, or you can fully configure the settings using these screens and FTP Client. The process is detailed in Chapter 6 of the GE Communicator EXT Guide.



This screen is **not** supported by meters with the INP10 Option



- **Internal Modem Option:** If your meter has this option, set the number of Rings to Answer from the pull-down menu. Set the Baud Rate to 57600, or to match your system baud rate.
- **Dial Out Profile:** Click the Dial Out Profile button and the following screen appears. Details on programming this screen and on the Modem Dial In/Dial Out Function are in Chapter 9 of this manual. This feature is ordered as INP 2.

**Modem Programming**

<p><b>Primary phone number settings</b></p> <p>Number <input type="text"/></p> <p>Retry delay <input type="text" value="5"/> Minutes</p> <p>Retry limit <input type="text" value="5"/> Attempts</p> <p>Connection type <input type="text" value="Computer"/></p>	<p><b>Secondary phone number settings</b></p> <p>Number <input type="text"/></p> <p>Retry delay <input type="text" value="5"/> Minutes</p> <p>Retry limit <input type="text" value="5"/> Attempts</p> <p>Connection type <input type="text" value="Computer"/></p>									
<p><b>Communications settings</b></p> <p>Inactivity timeout limit <input type="text" value="30"/> Minutes</p> <p>Call delay timer limit <input type="text" value="5"/> Seconds</p> <p>Callback type <input type="text" value="Playback"/></p> <p>Call failure reset limit <input type="text" value="1"/> Hours</p> <p>Share the phone line <input checked="" type="checkbox"/></p>	<p><b>Modem settings</b></p> <p>Rings to answer <input type="text" value="3"/> Rings</p> <p>Identification <input type="text"/></p> <p>Password <input type="text"/></p> <p>Enable password <input type="checkbox"/></p> <p>Violation limit <input type="text" value="3"/> Attempts</p> <p>Violation lockout time <input type="text" value="10"/> Hours</p>									
<p><b>Dial out on the following conditions</b></p> <table border="0"> <tr> <td><input type="checkbox"/> Limits status change</td> <td><input type="checkbox"/> CBEMA Power quality event</td> <td><input type="checkbox"/> Cycling of control power</td> </tr> <tr> <td><input type="checkbox"/> High speed input change</td> <td><input type="checkbox"/> Control output change</td> <td><input type="checkbox"/> Modem password failure</td> </tr> <tr> <td><input type="checkbox"/> Waveform record captured</td> <td><input type="checkbox"/> Filling of meter memory</td> <td><input type="checkbox"/> Failure of communication with Nexus</td> </tr> </table> <p>Log full limit threshold (All Logs) <input type="text" value="50"/> %</p> <p><input type="button" value="Edit gateway port devices"/></p>		<input type="checkbox"/> Limits status change	<input type="checkbox"/> CBEMA Power quality event	<input type="checkbox"/> Cycling of control power	<input type="checkbox"/> High speed input change	<input type="checkbox"/> Control output change	<input type="checkbox"/> Modem password failure	<input type="checkbox"/> Waveform record captured	<input type="checkbox"/> Filling of meter memory	<input type="checkbox"/> Failure of communication with Nexus
<input type="checkbox"/> Limits status change	<input type="checkbox"/> CBEMA Power quality event	<input type="checkbox"/> Cycling of control power								
<input type="checkbox"/> High speed input change	<input type="checkbox"/> Control output change	<input type="checkbox"/> Modem password failure								
<input type="checkbox"/> Waveform record captured	<input type="checkbox"/> Filling of meter memory	<input type="checkbox"/> Failure of communication with Nexus								
<p>OK Cancel Help</p>										



Any changes you make here may adversely affect communications. For example, if you change the baud rate of the port connected to a computer, be sure to make the same change to the computer port's baud rate. If you change a port's address, be sure to update the address settings of any device that communicates with the port. The baud rate of the port used by the Meter's External Display should always be set to **9600** and the address set to **1**.

- **Edit Gateway Port Devices:** The Edit Gateway Port Devices button at the bottom of the screen is used to Enable up to 8 devices that are connected the gateway and are to be monitored. When the user clicks the Edit Gateway Port Devices button, this screen is displayed:

Device Number	Enable Device	Device Address
1	<input checked="" type="checkbox"/>	2
2	<input checked="" type="checkbox"/>	2
3	<input checked="" type="checkbox"/>	2
4	<input checked="" type="checkbox"/>	2
5	<input checked="" type="checkbox"/>	2
6	<input checked="" type="checkbox"/>	2
7	<input checked="" type="checkbox"/>	2
8	<input checked="" type="checkbox"/>	2

OK Cancel

- ▷ Click on the box next to the Device to be monitored.  
A Device Address will appear next to the Enabled Device.
- ▷ Change the **Device Address**, if needed, to any address except **1**.  
The Number 1 is always reserved for the Primary Device.
- ▷ Click **OK** to return to the Modem Programming screen.
- ▷ When all changes are entered, click **OK** to return to the main Device Profile screen.
- ▷ Click on the **Update Device** button.  
This sends the new profile to the EPM 9800 Meter.
- ▷ **Reset Logs**.



### 4.3.7 DNP Custom Classes Map

The DNP Custom Class Map is a useful tool for prioritizing the readings in your system and the frequency of the readings. The DNP Custom Class Map also keeps your system free from thousands of unwanted readings.

- ▷ From the Device Profile screen (section 4.2), click on the **+/-** button beside **DNP Custom Class Map**.
- ▷ Double-click on a **DNP Custom Class Map** parameter.  
The following set of screens appears. (EPM 9800 meters support DNP V3.00 Level 2. See Chapter 16 of the GE Communicator EXT Guide for details.)

### 4.3.8 Custom Modbus Map

#### EPM 9800 Custom Modbus Map

You can select up to 256 Registers (or the equivalent of 2K, whichever is lower) to provide the functionality you want from your Meter. In addition, you can customize selected values for Format Type, Scaling, Byte Order, Data Size, etc.

- From the Device Profile screen (section 4.2), click on the **+/-** button beside **Custom Modbus Map** or double-click on the **Custom Modbus Map** line.  
The screen appears:

Item	Modbus Map Line	Point	Number of Registers	Start Register	Group	Channel	Format	Data Size	Unit	Primary / Secondary	Absolute Value	Byte Order	Split
1	65525	255	0	Not Assigned									
2	65526	255	0	Not Assigned									
3	65527	255	0	Not Assigned									
4	65528	255	0	Not Assigned									
5	65529	255	0	Not Assigned									
6	65530	255	0	Not Assigned									
7	65531	255	0	Not Assigned									
8	65532	255	0	Not Assigned									
9	65533	255	0	Not Assigned									
10	65534	255	0	Not Assigned									
11	65535	255	0	Not Assigned									
12	65536	255	0	Not Assigned									
13	65537	255	0	Not Assigned									
14	65538	255	0	Not Assigned									
15	65539	255	0	Not Assigned									
16	65540	255	0	Not Assigned									
17	65541	255	0	Not Assigned									

On Clear all Clear Cancel Print Help Registers: 1 of 256

Data entry is straightforward. Each type of data is described below. Note that not all selections will appear on the screen at the same time. You have to **scroll the screen from right to left** to reach some of the functions. Certain entries (such as Format, Data Size, etc.) have different allowable selections depending on the data point used. The pull-down menu will automatically adjust to provide the appropriate selections for that data point.



Table of the Most Commonly Used Modbus Map Readings on page 4-18.

**Data Point Selection**

(There are two different ways to select a Data Point.)

- Refer to the Modbus Map and find the associated Line and Point for the value you want.  
When you enter those values into the table, the software will complete the associated Group and Channel.
- OR
- Double-click the **Group** field.
- From the pull-down menus, select a **Group and Associated Channel** value.  
The software will complete the Map and Line values.
- **Number of Registers**  
The number of registers polled for this Data Point is automatically computed. The number is dependent on the Data Size selected in the Data Size column.
  - **Start Register**  
Start Register numbers are automatically assigned. The registers are assigned and adjusted automatically to take into account previous entries and data sizes. This is the Start Number for the first register to use in polling.
  - **Format**  
From the pull-down menu, select a type of Format for a value such as Floating, Integer, etc.

- **Data Size**  
From the pull-down menu, select the Number of Bytes you want to represent the Data Point.
- **Unit**  
If the polled value is viewed as an integer, the Unit field tells you where to place the decimal point.  
**Example:** If you select .01, a polling value 1234 would be interpreted as 12.34.  
**Example:** If you select 100, a polling value 1234 would be interpreted as 123400.
- **Pri/Sec**  
The meter normally computes values in secondary units. Where applicable, you may select primary or secondary. If Primary is selected, the value is multiplied by the appropriate CT and/or PT values.
- **Sign/Abs**  
Where appropriate, you may have the option of having the data point computed as a signed or absolute value.
- **Byte Order**  
For most of the Data Points, the user can select the polling order of the number of bytes selected by the Data Size field. Example: For a four-byte Data Point, the bytes can be arranged in any order for polling purposes.
- **Display/Modulo/Offset**  
Depending on the Data Point selected, you may select one or more additional options with the appropriate subselections.  
**Display:** For certain Data Points, interpretation and display options are offered.  
**Example:** For An Angle values, you can represent and display as 0 to 360 degrees or -180 to +180 degrees, etc. Selections will appear in a pull-down menu for the associated point.  
**Modulo:** Certain values are cumulative and can roll over and start recounting from zero. For those values, where required, you can enter a point at which the rollover will occur.  
**Offset:** Where allowed, you can enter a value (offset) which will be added to the data point when it is computed.

Table 4–2: Custom Modbus Readings

Line	Point	Description
34	0	One Second Phase to Neutral Volts: Volts AN
34	1	One Second Phase to Neutral Volts: Volts BN
34	2	One Second Phase to Neutral Volts: Volts CN
35	0	One Second Auxiliary Volts: V Aux
36	0	One Second (A, B, C): 1A
36	1	One Second (A, B, C): 1B
36	2	One Second (A, B, C): 1C

Table 4–2: Custom Modbus Readings

37	0	One Second Measured N Current: 1Nm
38	0	One Second Calculated N Current: 1Nc
39	0	One Second Phase to Phase Volts: Volts AB
39	1	One Second Phase to Phase Volts: Volts BC
39	2	One Second Phase to Phase Volts: Volts CA
40	0	One Second VA (A, B, C): VA A
40	1	One Second VA (A, B, C): VA B
40	2	One Second VA (A, B, C): VA C
41	0	One Second VA Total: VA Total
42	0	One Second One Second VAR (A, B, C): VAR A
42	1	One Second One Second VAR (A, B, C): VAR A
42	2	One Second One Second VAR (A, B, C): VAR A
43	0	One Second VAR Total: VAR Total
44	0	One Second One Second Watts (A, B, C): Watts A
44	1	One Second One Second Watts (A, B, C): Watts B
44	2	One Second One Second Watts (A, B, C): Watts C
45	0	One Second Watts Total: Watts Total
46	0	One Second Frequency: Frequency
47	0	One Second Power Factor (A, B, C): PF A
47	1	One Second Power Factor (A, B, C): PF B
47	2	One Second Power Factor (A, B, C): PF C
48	0	One Second Power Factor Total: PF Total
49	0	One Second Imbalance: Voltage
49	1	One Second Imbalance: Current
216	2	Block Window Average Watt
217	3	Maximum Block Window Positive Watt
217	4	Maximum Block Window Negative Watt
218	3	Minimum Block Window Positive Watt
218	4	Minimum Block Window Negative Watt
194	4	Phase A-N/Phase A-B Voltage THD
195	0	Phase B-N/Phase B-C Voltage THD
196	0	Phase C/Phase C-A Voltage THD

Table 4–2: Custom Modbus Readings


197	0	Phase A Current THD
198	0	Phase B Current THD
199	0	Phase C Current THD

- ▷ Use the buttons at the bottom of the screen to **Clear All**, **Clear**, **Cancel** or **Print** your selections.
- ▷ When all changes are entered, click **OK** to return to the main Device Profile screen.
- ▷ For these changes to take effect, you **MUST** click the **Update Device** button to send the new profile to the meter.

## 4.4 Revenue and Energy Settings

“Revenue and Energy Settings” is the second group of settings in the Device Profile.

- ▷ From the Device Profile screen (see section 4.2), click on the **+/-** button or double-click on the **Revenue and Energy Settings** line. All of the settings in the Revenue and Energy Settings Group are listed.



- ▷ Click on the particular programmable setting you would like to configure. The settings will be detailed in the order they appear on the Device Profile screen.

### 4.4.1 Energy Scaling

- ▷ From the Device Profile screen (see section 4.2), click on the **+/-** button or double-click on the **Energy Scaling** line.

The following set of screens appears:

**Energy Scale Settings**

Pulse Accumulations and Aggregations    I and V Squared T Readings    Q Hours

**Energy**    Uncompensated Energy    Test Mode Energy

Watt Hour    VA Hour    VAR Hour

Item	Digits	Decimal Places	Units	Example
Quadrant 1 Wh	7		2 kWh	99999.99
Quadrant 2 Wh	7		2 kWh	99999.99
Quadrant 3 Wh	7		2 kWh	99999.99
Quadrant 4 Wh	7		2 kWh	99999.99
Quadrant 1+4 Wh	7		2 kWh	99999.99
Quadrant 2+3 Wh	7		2 kWh	99999.99

Global Settings

OK    Cancel

- ▷ Using the EPM 9800 Energy Scale Setting screens, the user can select the Number of Digits, Decimal Point Placement and Energy Unit for displayed readings.
- ▷ Click on the tabs to navigate between screens, except for Global Settings. Click on **Global Settings** to access that screen.
  - **Energy**
    - Watt Hour (Above)
    - VA Hour
    - VAR Hour
  - **Uncompensated Energy**
    - VA, Watt and VAR readings not adjusted by Transformer Loss Compensation.

Energy Scale Settings

Pulse Accumulations and Aggregations

I and V Squared T Readings

Q Hours

Energy

Uncompensated Energy

Test Mode Energy

Item	Digits	Decimal Places	Units	Example
Quadrant 1+4 Wh	7		2 k	99999.99
Quadrant 2+3 Wh	7		2 k	99999.99
Quadrant 1+2+3+4 VAh	7		2 k	99999.99
Quadrant 1+2 VARh	7		2 k	99999.99
Quadrant 3+4 VARh	7		2 k	99999.99

Global Settings

OK

Cancel

- **Test Mode Energy**  
Energy Readings while in Test Mode.

Energy Scale Settings

Pulse Accumulations and Aggregations

I and V Squared T Readings

Q Hours

Energy

Uncompensated Energy

Test Mode Energy

Item	Digits	Decimal Places	Units	Example
Quadrant 1+4 Wh	7		2 k	99999.99
Quadrant 2+3 Wh	7		2 k	99999.99
Quadrant 1+2+3+4 VAh	7		2 k	99999.99
Quadrant 1+2 VARh	7		2 k	99999.99
Quadrant 3+4 VARh	7		2 k	99999.99

Global Settings

OK

Cancel

- **Pulse Accumulation**  
Accumulators  
Aggregators



**Energy Scale Settings**

Energy	Uncompensated Energy	Test Mode Energy
Pulse Accumulations and Aggregations	I and V Squared T Readings	Q Hours

Accumulators		Aggregators	
Item	Digits	Decimal Places	Units
Input 1	7	2	k
Input 2	7	2	k
Input 3	7	2	k
Input 4	7	2	k
Input 5	7	2	k
Input 6	7	2	k
Input 7	7	2	k
Input 8	7	2	k

Global Settings

OK Cancel

- I and V Squared T Readings**

$I^2T$ : Data will not accumulate until Current reaches programmed level.

$V^2T$ : Data stops accumulating when Voltage falls below programmed level.

**Energy Scale Settings**

Energy	Uncompensated Energy	Test Mode Energy
Pulse Accumulations and Aggregations	<b>I and V Squared T Readings</b>	Q Hours

Item	Digits	Decimal Places	Units	Example
I Squared T Phase A	7	2	k	99999.99
I Squared T Phase B	7	2	k	99999.99
I Squared T Phase C	7	2	k	99999.99
V Squared T Phase A	7	2	k	99999.99
V Squared T Phase B	7	2	k	99999.99
V Squared T Phase C	7	2	k	99999.99

Global Settings

OK Cancel

- Q Hours**

Q Hours are obtained by lagging the applied voltage to a wattmeter by 60 degrees.

Energy Scale Settings

Energy

Uncompensated Energy

Test Mode Energy

Pulse Accumulations and Aggregations

I and V Squared T Readings

Q Hours

Item	Digits	Decimal Places	Units	Example
+Qh	7		2 k	99999.99
-Qh	7		2 k	99999.99

Global Settings

OK

Cancel

- Global Settings**  
Settings configured on one screen apply to screens associated with filled-in rows. If a row is left blank, the associated screen is not modified.

Energy Scale Settings - Global

Item	Digits	Decimal Places	Units	Example
Quadrant 1+4 Wh				
Quadrant 2+3 Wh				
Quadrant 1+2 VARh				
Quadrant 3+4 VARh				
Quadrant 1+2+3+4 VAh				
Internal Input Accumulators				
Internal Input Aggregators				
I Squared T				
V Squared T				

Apply


Cancel

- ▷ When all changes are entered, click **OK** to return to the main Device Profile screen.
- ▷ Click on the **Update Device** button.  
This sends the new profile to the EPM 9800 Meter.


#### 4.4.2 Program Demand Integration Intervals (Demand Intervals)

See *EPM 9800 Installation and Operation Manual* for details on Demand Integration.

- ▷ From the Device Profile screen (see section 4.2), click on the **+/-** button or double-click on the **Demand Integration Intervals** line. The following submenu appears:



- ▷ Double-click on any of the settings and the Demand Integration Programming screens appear:




- ▷ Click on the tabs at the top of the screens to navigate from one screen to the others.
- ▷ Make changes to the screens according to the requirements of your application.


Following is a brief description of each setting and its function.

- **Thermal Averaging Time Interval Window** (above): Allows you to set hours, minutes and seconds for a precise thermal window of demand data.

- **Block Averaging Time Interval Window:** Sets the length of the Block Interval used for Demand Calculation and other Interval-based functions.



- **Block Window Sync:** Synchronizes the meter with pulses from a High Speed Input connected to another meter.
  - ▷ Click **Generate End of Interval Pulse** on the lower section of the above screen (not shown) to produce a synchronizing output and select a Relay and Pulse Width for the output.
- **Rolling Average Subinterval Window:** Sets the length of the Demand Subinterval when Rolling Demand is used. (Subinterval Length X Number of Subintervals = Length of Demand Interval Window)



- **Rolling Subintervals:** Sets the number of Rolling Demand Subintervals in the Rolling Demand Window. (Subinterval Length X Number of Subintervals = Length of Demand Interval Window)
- **Predictive Rolling Window Average:** Increasing the length of the Predictive Demand Window increases the accuracy of the prediction by including more of the Current Demand Window (up to 100%). Decreasing the length of the Prediction Window gives earlier warnings of high demands.

- ▷ When all changes are entered, click **OK** to return to the main Device Profile screen.
- ▷ For these changes to take effect, you **MUST** click on the **Update Device** button to send the new profile to the meter.

#### 4.4.3 Internal KYZ Outputs (and Test LED Settings)

The Internal KYZ Outputs Settings allow you to assign channels to the KYZ Outputs and to the Test LED Test. The Channel Selection sets the type of pulse that will be generated.

For example, the **Test LED** can generate Energy Pulses for conventional testing or Reactive (VARh) Pulses for complex testing and approvals. The settings also allow you to determine the frequency and the duration of the pulse for each output and for the Test LED.

- ▷ From the Device Profile screen (section 4.2), click on the **+/-** button beside **Internal KYZ Settings** or double- click on the **Internal KYZ Settings** line.

The screen appears:

KYZ Output	Assigned Channel	Watt Hour Per Pulse	Pulse Width(ms)	Mode	Form
HB LED	Quad (1 + 4) Watthour	1.8000	100	Enable	Pulse (Form A)

OK Cancel Help

- ▷ Click on the arrow of the pull-down menu next to KYZ Output to which you would like to assign a channel.
- ▷ Make changes to:
  - Watt Hour per Pulse,
  - Pulse Width,
  - Mode and Form,
 for each output and for the Test LED.
 

Note on Form: Form A = Transition. Form C = Pulse.
- ▷ When all changes are entered, click **OK** to return to the main Device Profile screen.
- ▷ For these changes to take effect, you **MUST** click on the **Update Device** button.  
This sends the new profile to the EPM 9800 Meter.



If your EPM 9800 meter is equipped with the **KYZ Output** Option, the KYZ Output Settings will appear. Otherwise, only the Test LED will appear on the screen.

4.4.4 Display Configuration

- From the Device Profile screen (section 4.2), click on the **+/-** button beside **Display Configuration** or double-click on the **Display Configuration** line.  
The following set of screens (Meter Display Programmable Settings) appears:
- Click tabs at the top of the screens to access the Programmable Settings.

**EPM 9800 Programmable Settings**

Display Modes | Power and Energy Display | Miscellaneous

Meter Display Mode Names | Screen Assignments

Enter Mode Label and Description for each mode

	Label	Line 1 Description	Line 2 Description
View Mode 1	Nrm	Normal	
View Mode 2	CD	Circuit	Diag
View Mode 3	TOU	Time of	Use

Update Display | Retrieve from Display | Cancel | Save | Load | Help

- **Display Modes:**
  - Enter a three-letter Label for each of the three View Modes.  
Enter a Description for each View Mode using the Line 1 and 2 Description windows.

**EPM 9800 Display Programmable Settings**

Display Modes | Power and Energy Display | Miscellaneous

Meter Display Mode Names | Screen Assignments

	Nrm Mode Screens	CD Mode Screens	TOU Mode Screens
1	kWh Delivered	Phase to Neutral Voltage	None
2	None	Phase to Phase Voltage	None
3	kWh Received	Phase Current	None
4	None	Phase Diagram	None
5	kVARh Delivered	Volts A Harmonics	None
6	kVARh Received	Volts B Harmonics	None
7	kW Demand Last Reset	Volts C Harmonics	None
8	Display Check	I A Harmonics	None
9	Optical Port Settings	I B Harmonics	None
10	None	I C Harmonics	None
11	None	kVAR, Power Factor, Frequency	None
12	None	None	None
13	None	None	None
14	None	None	None
15	None	None	None
16	None	None	None

Update Display | Retrieve from Display | Cancel | Save | Load | Help

- **Screen Assignments:**
  - ▷ Enter up to 16 screens for each View Mode.  
Your label for each View Mode appears at the top of each column.

- **Power and Energy Display:**
  - ▷ **Set Scale, Digits and Decimal Point.**  
Previews appear at the bottom of the screen.

Settings on this screen control the display of energy related numbers. Care should be given to match the values on the display with those in historical logs. These settings apply to VA-hours, Watt-hours (+/-), VARhours (+/-) and VAR-hours (quadrants) in the meter.


Scale factor is the user-programmable setting that determines how measurements made by the meter will be displayed. In most applications, the measurements made in the metering circuit on the secondary side on the Instrument Transformers are displayed as Primary Values using the Scale Factor.

The Scale Factor (Primary Value = Secondary Value X Scale Factor) and the Transformer Factor (TF = Voltage Transformer Ratio X Current Transformer Ratio) are the same for energy measurements.

For display of voltage and current measurements, VTR and CTR are used.



**Scale Factor takes precedence over all other settings**, i.e. - all other settings are based on this setting.



- **Miscellaneous:**
  - ▷ Set Screen Settings, Optical Port and User Inactivity Time-outs. The Screen Settings replace Adjustments Mode in the default profile.
- **Screen Settings:**
  - ▷ Set Back Light Level (brightness), Back Light Time (when Back Light shuts off), Contrast, Scroll Stop, Phasor Rotation and Cumulative Demand.
- **Cumulative Demand Settings:**
  - ▷ Set to:
    - Regular: Running Total
    - Continuous: Running Total + Current Max/Min.
- **Optical Port:**
  - ▷ Set Baud Rate and Optical Receive (Normal or Inverted). Inverted Operation is used with the Smart Coupler.
- **User Inactivity Time Outs:** (number of minutes since last user action when Mode reverts to View Mode 1).
  - **Settings are:**
    - 5 - 60 minutes.
    - Leave Test Mode After \_ Minutes: Reverts with or without energy accumulation.
    - Leave View Mode 2 or 3 After \_ Minutes: Reverts Automatically.
- **Use Buttons for Functions below:**
  - **Update Display:**
    - ▷ Must click to update the display. After settings update, View Mode 1 is displayed.
  - **Retrieve from Display:**
    - ▷ Click to retrieve existing settings.



- **Cancel:**
  - ▷ Cancel any new settings and return to main GE Communicator EXT screen.
- **Save:**
  - ▷ Save new settings to a file.
- **Load:**
  - ▷ Load saved settings from a file.
  - ▷ Click **Update Display** to send new display settings and return to main GE Communicator EXT screen.



See the *EPM 9800 Installation and Operation Manual* for further details.

#### 4.4.5 CT and PT Compensation

- ▷ From the Device Profile screen (see section 4.2), click on the **+/-** button beside **CT and PT Compensation** or double-click on the **CT and PT Compensation** line.  
The following screen appears:



- ▷ Check the **Enable CT** box to Enable CT and PT Compensation. (Leave unchecked to Disable. )
- ▷ Click **OK** to close the screen and return to the main GE Communicator EXT screen.



The term "Potential Transformer" was changed to "Voltage Transformer" by the IEEE in 1982. Most Instrument Transformers now use the term Voltage Transformer.

#### 4.4.6 Transformer/Line Loss Compensation

- ▷ From the Device Profile screen (see section 4.2), click on the **+/-** button beside **Transformer / Line Loss Compensation** or double-click on the **Transformer / Line Loss Compensation** line.  
The following submenu appears:



This screen displays the current values for the meter's Transformer Loss Compensation.

- %LWFE = Percent Loss of Watts due to Iron i
- %LVFE = Percent Loss of Vars due to Iron i
- %LWCU = Percent Loss of Watts due to Copper
- %LVCU = Percent Loss of Vars due to Copper
- ▷ Consult **Appendix B** of the GE Communicator EXT Guide, on **Transformer Loss Compensation** in the appendix pages of this manual.
- ▷ Double-click on any of the loss values, "%LWFE" etc.  
The Transformer and Line Loss Compensation screen appears (see next page).
- ▷ Click on **TLC Calculator** to find the values to enter into the Percent Loss windows.  
The Calculator button will launch an Excel Spreadsheet which will do the calculations for you once the required data is entered. A copy of the Excel Spreadsheet with example numbers is in **Appendix B** of the GE Communicator EXT Guide.



WARNING

GE Communicator EXT will automatically launch the Excel Spreadsheet as part of its software package. But, for the TLC Button to work, you must have the Excel program in your system. If you do not have Excel software or if the spreadsheet file is not in the GE Communicator directory, a Warning will be displayed instead of the worksheet. You can do your own calculations using the hardcopy Transformer Loss Compensation Worksheet in Appendix B of the GE Communicator EXT Guide.



NOTE

For most Excel users, this spreadsheet will not run until permission is given to run the Macros contained in the sheet. This is done by changing the Excel Security Setting from High to Medium.

Device Profile: Transformer and Line Loss Compensation

**Percent Loss of Watts**

Due to Iron: 0.000

Due to Copper: 1.000

**Percent Loss of VARS**

Due to Iron: 0.000

Due to Copper: 1.000

Cu only

Add to Watts and Subtract from VAR

Transformer and Line Loss Applies to

Both +Watts and -Watts

OK ILC Calculator Cancel Help

### The Excel Command

- ▷ From Excel Toolbar, select **Tools > Security > Options**.
- ▷ On the Security Tab Page, click on the **Macro Security** button.
- ▷ Select **Medium Security**.  
This setting allows Excel to run in GE Communicator EXT.
- ▷ Enter the percent Loss of Watts and Vars for copper and iron in the appropriate fields.
- ▷ Enable Transformer Loss Compensation by selecting **Iron only**, **Copper Only** or **Both Iron and Copper** from the pull-down menu at the bottom of the screen.
- ▷ With the second pull-down menu, select from the following:
  - Add to Watts and Subtract from VAR
  - Subtract from Watts and Add to VAR.
  - Add to Watts and VAR.
  - Subtract from Watts and VAR.
- ▷ With a third pull-down menu, apply the loss based on the power flow direction. From the menu select one of the following:
  - Both +Watts and -Watts.
  - -Watts only.
  - +Watts only.




Do NOT use the last settings if you do not have the appropriate firmware. Check with Technical Support if you have a question.

- ▷ When all settings are complete, click **OK** to return to the main Device Profile screen.
- ▷ For these changes to take effect, you **MUST** click on the **Update Device** button.  
This sends the new profile to the EPM 9800 Meter.

#### 4.4.7 Cold Load Pickup

- ▷ From the Device Profile screen (see section 4.2), click on the **+/-** button beside **Cold Load Pickup** or double-click on the **Cold Load Pickup** line.  
The following submenu appears, showing the current settings for Cold Load Pickup.



- ▷ Double-click on one of the parameters and the following screen appears:



- **Cold Load Pickup:** Delay can be 1 to 60 minutes or Disabled. This value is the delay from the time control power is restored to the time when the user wants to resume demand accumulation.
  - Minimum time control power must be off before using Cold Load Pickup: Value is set from 0 to 255 seconds.
- ▷ When all changes are entered, click **OK** to return to the main Device Profile screen.



For these changes to take effect, you must click on the Update Device button to send the new profile to the Meter

#### 4.4.8 Cumulative Demand Type

- From the Device Profile screen (see section 4.2), click on the **+/-** button beside **Cumulative Demand Type** or double-click on the **Cumulative Demand Type** line.

This window appears:




- Click the radio button in front of Rolling (sliding) Window or Block (fixed) Window to select Cumulative Demand Type.
- Click **OK** to exit the screen and return to the main GE Communicator EXT screen.

#### 4.4.9 Energy, Pulses and Accumulations in the Interval

- From the Device Profile screen (see section 4.2), click on the **+/-** button beside **Energy, Pulses and Accumulations in the Interval** or double-click on the **Energy, Pulses and Accumulations in the Interval** line.

This window appears:



- Set the number of minutes for the Energy Interval. This is the Demand and Accumulation Interval Duration.
- Click **OK** to close the window and return to the main GE Communicator EXT screen.

#### 4.4.10 Pulse Accumulations

This section of the Device Profile displays a series of eight running totals available on Meter. Each total can be added to (or subtracted from) other totals. This allows you to set the high speed inputs located directly on the meter to pulse accumulate.



If you use these inputs for pulse accumulations, do not set them to record waveforms. If you do, endless waveforms record.

- ▷ From the Device Profile screen (see section 4.2), click on the +/- button or double-click on the **Pulse Accumulations** line. The following screen will appear:

Device Profile: Internal Input Pulse Accumulators Setup

Source	Units/Count	Aggregator	User Assigned Label	Mode
1	1	None	Pulse Counter 1	Pulse (Form A)
2	1	None	Pulse Counter 2	Pulse (Form A)
3	1	None	Pulse Counter 3	Pulse (Form A)
4	1	None	Pulse Counter 4	Pulse (Form A)
5	1	None	Pulse Counter 5	Pulse (Form A)
6	1	None	Pulse Counter 6	Pulse (Form A)
7	1	None	Pulse Counter 7	Pulse (Form A)
8	1	None	Pulse Counter 8	Pulse (Form A)

Source	Hour Reading	Aggregator
EPM9800	Quadrant(1 + 4) Watt Hour	None

Aggregator	User Assigned Label
1	Accumulator 1
2	Accumulator 2
3	Accumulator 3
4	Accumulator 4

OK Cancel Help

Purpose of Pulse Accumulations

Pulse Accumulators are used to accumulate pulse information from external devices. These devices may be gas, water or electricity meters, energy management systems, SCADA devices or any pulse-generating device. Pulse accumulation is a very flexible way to accumulate information from external devices. Using the meter’s pulse accumulator, pulses from other meters can be algebraically combined with the host meter’s accumulations to generate one reading for a set of meters in a complex arrangement.

- **Source:** This is the particular input on the meter which will be accumulated.  
**Units/Pulse:** This is the scale factor which normalizes the pulses so that they can be aggregated, if desired. Pulses are stored in primary values.  
**Accumulator:** This allows you to place the pulse register into a separate accumulation register, which can aggregate or net values.  
**User assigned label:** This window allows a user to enter a label designation so that when reading the Aggregator, the meter will display the source.
  - ▷ To add or subtract data, use pull down menu in each window of Accumulator column(s).



EPM 9800 supports **Negative** Averaging for Total Values.

- ▷ When all data has been entered, click **OK** to return to the main Device Profile screen.
- ▷ For these changes to take effect, you **MUST** click on the **Update Device** button. This sends the new profile to the meter.

## 4.5 Power Quality and Alarm Settings

This is the third group of settings in the Device Profile.

- ▷ From the Device Profile screen (see section 4.2), click on the **+/-** button or double-click on the **Power Quality and Alarm Settings** line.  
All of the settings in this group are listed.



- ▷ Click on the particular Programmable Setting you would like to configure.  
The settings will be detailed in the order they appear on the Device Profile screen.


### 4.5.1 Limits

Limit settings are based on a percentage of the Full Scales (% of FS), which are set in the Limit and Waveform Full Scales section of the Device Profile (section 4.3.2). Full Scales are based on CT and PT ratios set in the CT, PT Ratios and System Hookup section of the Device Profile (section 4.3.1) (120V L-N, 208V L-L and 5A).

- ▷ Before programming Limits, set the CT and PT ratios first.
- ▷ **Then, set the Limit and Waveform Full Scales.**  
The software automatically updates the Full Scale. However, you can set it separately from the **CT and PT Ratios**.



- From the Device Profile screen (see section 4.2), click on the +/- button beside **Limits** or double click on the **Limits** line. The following submenu appears:



This screen displays the current Device Profile's settings for Limits. Not all limits are shown above; "Limit ID" extends to 32.

- Double-click on any of the settings ("Limit ID 01:", etc.) The Limits screen appears.

### Percentage of Full Scale settings

The limits are set in % of full scale (% of FS) so that when a user creates a profile, he can keep his settings. This is true, even though the CT and PT Ratios change when the meter (or a new meter) is placed in a different location. Changing the CT and PT Ratios will not effect the % of full scale limits previously set. This is useful when using large numbers at meters

Device Profile: Limits									
Limit ID	Assigned Item	Limit 1			Limit 2			Combination Limit 3	
		Setting	% of FS	Primary	Setting	% of FS	Primary		
1	Fifty Millisecond Updated: Voltage A-N	Above	120.00	15.84K	Below	90.00	10.56K	OR	
2	Fifty Millisecond Updated: Voltage B-N	Above	120.00	15.84K	Below	90.00	10.56K	OR	
3	Fifty Millisecond Updated: Voltage C-N	Above	120.00	15.84K	Below	90.00	10.56K	OR	
4	Fifty Millisecond Updated: Current A	Above	200.00	10.00	Below	98.00	4.90	OR	
5	Fifty Millisecond Updated: Current B	Above	200.00	10.00	Below	98.00	4.90	OR	
6	Fifty Millisecond Updated: Current C	Above	200.00	10.00	Below	98.00	4.90	OR	
7	Not Assigned	Above	110.00	110.00	Below	90.00	90.00	OR	
8	Not Assigned	Above	25.00	25.00	Below	21.00	21.00	OR	
9	Not Assigned	Above	95.00	95.00	Below	92.00	92.00	OR	
10	Not Assigned	Above	24.65	24.65	Below	25.35	25.35	AND	
11	Not Assigned	Above	101.20	101.20	Below	98.00	98.00	OR	
12	Not Assigned	Above	20.00	20.00	Below	16.00	16.00	OR	
13	Not Assigned	Above	101.20	101.20	Below	98.80	98.80	OR	
14	Not Assigned	Above	3.00	3.00	Above	3.00	3.00	OR	

Channels	Primary Values at 100%
I A, B, C, Ne	5.00
I Nn	5.00
V Phase to Neutral	13.20k
V A-n	13.20k
V Phase to Phase	22.80k
Power Phase	55.00k
Power Total	136.00k
Frequency	60.00

Make changes to this screen according to the requirements of your application:

- To set the type of limit and the channel assigned to it, double-click in either the **Type** or **Channel** column.
- From the pop-up menu, choose the desired settings and click **OK**.
- To designate the limit as either Above or Below a percentage of the Full Scale, click once in each **Settings** column and select the desired setting from the pull-down menu.

- To set the percentage of the Full Scale at which the limit will trip, enter the value in the % of FS column.  
GE Communicator EXT automatically calculates the Primary value.

The Combination Limit 3 is the logical combination of Limit 1's state and Limit 2's state.

#### Example 1:

Limit I D:

Type: 1 Second Readings

Channel: Volts AN

Limit 1 Setting: Limit exceeded if Volts AN is below 12V.

Limit 2 Setting: Limit exceeded if Volts AN is above 132V.

Combination Limit 3 Setting: **AND** If Limit 1 **AND** Limit 2 are exceeded then Limit 3 is exceeded.

#### Example 2:

Limit I D:

Type: 1 Second Readings

Channel: Volts AN

Limit 1 Setting: Limit exceeded if Volts AN is below 12V.


Limit 2 Setting: Limit exceeded if Volts AN is above 132V.

Combination Limit 3 Setting: **OR** If Limit 1 **OR** Limit 2 are exceeded then Limit 3 is exceeded.

To combine Limits of different Limit IDs, use the Relay Logic Diagrams.


Full Scale settings are shown in the lower left of the screen. These values are set in the Limits and Waveform Full Scales section of the Device Profile (section 4.4).

- To set the Power Factor Limits, double click on any of the Power Factor settings in the Limit 1 or Limit 2 column.  
The Power Factor Programming Screen will appear:



Power Factor is broken into four quadrants. The screen lets you set a limit in two of the four quadrants.

- ▷ To set a limit from the pull-down menus, select a Quadrant and Less Than or Greater Than (Full Scales).
- ▷ Type in the Power Factor Number.  
The graph will illustrate your selections by shading the Out of Limit bands. The area of the graph not covered by shading is within **Normal Operational Range. Method 1 Quadrants: Q1 +Lag, Q2 -Lag, Q3 -Lead, Q4 +Lead.**
- ▷ To display a graph of **Method 2 Quadrants: Q1 +Lag, Q2 -Lead, Q3 +Lag, Q4 -Lead**, go to the Programming Labels screen (section 4.19) of the Device Profile.  
In the lower drop down menu, click on Method 2.
- ▷ Return to the Limits screen.
- ▷ Click on any PF setting in the Limit 1 or Limit 2 column.



This meter is a real four quadrant meter. Therefore, limits can be set for capacitive and inductive PF when generating or consuming power.

- ▷ When all settings are complete, click **OK** to return to the main Device Profile screen.
- ▷ For these changes to take effect, you **MUST** click on the **Update Device** button.  
This sends the new profile to the Meter.
- ▷ You may **Reset Logs** after updating the device. See section 4.26.


### 4.5.2 ElectroLogic Relay Control

To edit a Device Profile's ElectroLogic Relay settings:

- ▷ From the Device Profile screen (see section 4.2), click on the **+/-** button or double-click on the **GE Relay** line.



The following screen appears. This screen displays the current Device Profile's settings:



To assign an item to the RelayLogic Tree:

- ▷ Select an Input for the tree by clicking on a bullet next to numbers **1** through **8**.
- ▷ Choose Limits or Digital Inputs by clicking on the bullet in front of the word.
- ▷ Select the Limit or Input you want to assign to the RelayLogic Tree Input you selected.
- ▷ Press **Set** to confirm your selection and the software will place the selection in the appropriate window in the screen.
- ▷ After you have assigned all the RelayLogic Inputs, select the gates that will be used to combine the logic to trigger the relay.
- ▷ To select a gate, click on the gate or choose one from the dropdown menu below the gate.

To change items on the RelayLogic Tree, use the following steps:

- ▷ To change the selected relay and/or relay modules, select from the drop-down menu at the upper right hand corner of the screen.
- ▷ To change the relay Set Delay, select from the drop-down menu to the right of the Set Delay Label.
- ▷ To change the Relay Reset Delay, select from the drop-down menu to the right of the Reset Delay Label.
- ▷ To clear an item from the Relay Tree, click on that item then click the **Clear** button.
- ▷ To clear ALL ITEMS from the Relay Tree, click the **Clear Assigned Items** button.



In order to use this screen, you must have purchased at least one External Relay Out module. For more details on External Modules, see Chapter 11 of the GE Communicator EXT Guide.

### 4.5.3 PQ Thresholds (Waveform Recording)

The Power Quality (PQ) and Waveform Thresholds setting determines at what point the Meter will execute a waveform capture and/or record a power quality event. See Chapter 8 of the GE Communicator EXT Guide for how to view logs.

PQ and waveform thresholds are given as a percentage of the Full Scales (% of FS). Set the Full Scales in the Limits and Waveform Full Scales section of the Device Profile (section 4.4). Full Scales are based on the CT and PT ratios set in the CT, PT Ratios and System Hookup.



Before programming the PQ and Waveform Thresholds, set the CT and PT ratios. Then, set the Limits and Waveform Full Scales.



**CAUTION:** Changing the CT and PT Ratios will Reset the meter and clear all logs and accumulations. Be sure to capture needed meter information before changing CT and PT Ratios.

#### Note on Sampling Rate

A higher sampling rate allows for transients to be monitored. Generally, users will set the monitor to 128 samples per cycle for this purpose. Lower sampling rates have advantages because they allow you to record more cycles of information per event screen. Low sampling rates are better for long duration events, like motor starts or distribution faults. The meter enables users to tailor the recording for both these applications. For more information on Sampling Rate, see the graph on page 4-39.

- From the Device Profile screen (see section 4.2), double-click on the **PQ Thresholds (Waveform Recording)** line;  
The Waveform—CBEMA Profile screen appears:

Device Profile: Waveform - CBEMA Profile Hookup: 2 1/2 Element Wye

Channel	Waveform Above Setpoint		Waveform Below Setpoint		PQ Enable
	Value(%)	Enable	Value(%)	Enable	
Volts AN	120.00	<input checked="" type="checkbox"/>	80.00	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Volts CN	120.00	<input checked="" type="checkbox"/>	80.00	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
IA	120.00	<input checked="" type="checkbox"/>	0.00	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
IB	120.00	<input checked="" type="checkbox"/>	0.00	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
IC	120.00	<input checked="" type="checkbox"/>	0.00	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
INm	10.00	<input checked="" type="checkbox"/>	0.00	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Input	Assigned to
1	Waveform / PQ Trigger
2	Waveform / PQ Trigger
3	Waveform / PQ Trigger
4	Waveform / PQ Trigger
5	Waveform / PQ Trigger
6	Waveform / PQ Trigger
7	Waveform / PQ Trigger
8	Waveform / PQ Trigger

Sampling Rate: 120 Samples / Cycle @ 60Hz  
8 Cycles Captured Per Window @ 60Hz  
Total Capture Windows Per Event: 1  
A limit value of 100 % equals the following primary value:  
I A.B.C: 5.00 VP-N: 13.20k VP-P: 22.96k

OK Cancel Help

#### 1. Software Triggers:

- To set the threshold for a PQ event and waveform capture, enter the desired percentage of Full Scale in the Value(%) column of the Above Setpoint and Below Setpoint sections.  
Full Scales are shown in the lower right corner of the screen.



#### Note on CBEMA

The CBEMA plotting is a power quality standard known world-wide for recording the amount of damage voltage transient conditions have done to the equipment being monitored. The meter automatically records this information. For CBEMA purposes, the user programs internal set points for voltage below 90% and above 110% of full scale (+/- 10% from the nominal voltage). These setpoints are defined by the ITI (CBEMA) specification. The ITI (CBEMA) Curve is published by Information Technology Industry Council (ITI) and is available at:

[http://www.itic.org/iss\\_pol/techdocs/curve.pdf](http://www.itic.org/iss_pol/techdocs/curve.pdf).

A user can set a recording with tighter voltage limits to trigger a waveform recording. However, CBEMA plotting will be based only on the limits internally set.



#### Note on Setting the Meter to Record Current Faults

As discussed, the voltage setpoints are used to record voltage type events, such as voltage surges, sags and transients. The current settings are used to record faults on the line or in-rush currents from devices such as motors. Typically, to catch these events, set the limit to above 200% of full scale.

2. **Waveform Clipping Threshold:** EPM 9800 Standard Hardware - 91.0924A Peak before clipping.

3. **Hardware Triggers:**

- ▷ To enable a Waveform or PQ recording for any of the 8 High Speed Inputs, click in the appropriate box.  
This will trigger a recording based on a contact trigger. This is useful to monitor an open device and to capture the waveform during that operation.

4. **Samples per Cycle:**

- ▷ To choose the Samples per Cycle to be recorded at 60 Hz, click on the **Sampling Rate** pull down menu.
- ▷ Choose from 16, 32, 64, 128, 256 and 512 samples per cycle.  
The number of samples per cycle you choose will inversely affect the number of cycles per capture.
  - If you select 256, a Capture Only pop up screen will ask you to select Volts A, B, C or I A, B, C.
  - If you select 512, a Capture Only pop up screen will ask you to select one of the individual channels.

As you increase the number of samples, you will record more detailed information. The Table below illustrates the “Effects of Sampling Rate” on the number of cycles captured. Increasing the Sampling Rate increases Waveform Definition but reduces the length of the observed window. The approximate length of the observed window is shown in the last column.

For example, to observe events of approximately 1/2 Second, a Sampling Rate of 32 Samples per Cycle or less should be used.

Table 4-3: Effects of Sampling Rates

Samples per Cycle	Channels		Samples per Channel	Cycles per Capture	Time (Approx.)
	Analog	HSI			
16	7	8	1024	64	1 second
32	7	8	1024	32	1/2 second
64	7	8	1024	16	1/4 second
128	7	8	1024	8	1/8 second
256	3	8	2048	8	1/8 second
512	1	8	4096	8	1/8 second

**Note on Waveform Event Captures**

A screen of data is one capture. If you set Total Captures to 3 and you are recording at 16 samples per cycle, you will record:

16 Samples:  $3 \times 64 = 192$  cycles of recorded waveforms

128 Samples:  $3 \times 8 = 24$  cycles of recorded waveforms



With the 2 MB module, you have a total of 64 total captures. With the 4 MB module, you have a total of 96 captures. You can partition the memory in any fashion required for the specific application. There is no limitation on the amount of cycles that can be recorded per event.

- ▷ To choose the total amount of captures, click on the **Total Captures** pull down menu.
- ▷ Select from **0 to 96** captures.  
The higher the number, the more information you will be “stringing together”.
- ▷ When all changes are entered, click **OK** to return to the main Device Profile screen.
- ▷ For these changes to take effect, you **MUST** click on the **Update Device** button.  
This sends the new profile to the Meter.

#### 4.5.4 EN 50160 Flicker

With the Flicker Settings screen, the user can set the test times for the Flicker function.

- ▷ From the Device Profile screen (section 4.2), click on the **+/-** button beside **EN50160 Flicker** or double- click on the **Flicker Settings** line.  
This screen appears

The screenshot shows a dialog box titled "EN50160 Flicker". It contains three settings, each with a pull-down menu and a unit label: "Short term test time (PST)" with a value of 10 and unit "Minutes", "Long term test time (PLT)" with a value of 240 and unit "Minutes", and "Frequency" with a value of 60 and unit "Hz". At the bottom of the dialog are three buttons: "OK", "Cancel", and "Help".

- ▷ From the pull-down menus, select a Short Term test time and a Long Term test time.  
Typical values for PST and PLT are 10 minutes and 120 minutes.
- ▷ From the Frequency pull-down menu, select 50 or 60 Hz.
- ▷ When all changes are entered, click **OK** to return to the main Device Profile screen.
- ▷ For these changes to take effect, you **MUST** click on the **Update Device** button.  
This sends the new profile to the EPM 9800 Meter.



Flicker is discussed in detail in Chapter 16 of the GE Communicator EXT Guide.



### 4.5.5 I Squared T and V Squared T Thresholds

With the I Squared T and V Squared T Thresholds screen, the user can set at what point the Current and Voltage should accumulate.

- ▷ From the Device Profile screen (section 4.2), click on the **+/-** button beside **I Squared T and V Squared T** or double-click on the **I Squared T and V Squared T** line.

This screen appears:


- ▷ Input the desired thresholds.
- ▷ Click **OK** to exit the screen and return to the GE Communicator EXT main screen.

### 4.5.6 High Speed Inputs

This section of the Device Profile enables you to label the eight High Speed Inputs. Using this storage field allows a user to label the inputs so that when the data is later analyzed, the user knows the source of the status change.

- ▷ From the Device Profile screen (see section 4.2), click on the **+/-** button or double-click on the **Digital Inputs** line.
- ▷ Double-click on **High Speed Inputs**.

The following submenu appears:



- Double-click on any of the **Input #** lines.  
The High Speed Digital Input Assignments screen appears.

Device Profile: High Speed Digital Input Assignments					
Input ID	Name	Open Label	Shorted Label	Normal Condition	Input Type
1	HSI Input 1	Open_1	Closed_1	Open	Waveform / PQ Trigger
2	HSI Input 2	Open_2	Closed_2	Open	Waveform / PQ Trigger
3	HSI Input 3	Open_3	Closed_3	Open	Waveform / PQ Trigger
4	HSI Input 4	Open_4	Closed_4	Open	Waveform / PQ Trigger
5	HSI Input 5	Open_5	Closed_5	Open	Waveform / PQ Trigger
6	HSI Input 6	Open_6	Closed_6	Open	Waveform / PQ Trigger
7	HSI Input 7	Open_7	Closed_7	Open	Waveform / PQ Trigger
8	HSI Input 8	Open_8	Closed_8	Open	Waveform / PQ Trigger

OK

Cancel

Help

- Double-click on the Input you would like to label.
- Enter text in each field.
- Click **OK** to return to the main Device Profile screen.
- For these changes to take effect, you **MUST** click on the **Update Device** button.  
This sends the new profile to the EPM 9800 Meter.

## 4.6 Trending Profile Settings and Load Profile Recording

This section of the Device Profile enables you to set the Trending Profiles for historical logs.

- ▷ From the Device Profile screen (see section 4.2), click on the **+/-** button or double-click on the **Trending Profile Settings** line.

This submenu appears:



- ▷ Double-click on one of the Trending topics to access the programming screens.

### Load Profile Recording - Definition

Load Profile Recording is a subset of the Meter's more general Logging and Trending capability. The same screens are used for setup but Load Profile Recording only deals with Accumulated Values; Energy (Wh), Reactive Energy (VARh) and Apparent Power (VAh).

Historically, Load Profile Recording referred to recording of Quadrant 1 Energy (Wh) because electromechanical meters only measured energy and were detented to prevent reverse rotation outside of Quadrant 1.


#### 4.6.1 Trending Log Time Intervals

Trending Log Time Intervals determine the interval at which Historical Logs 1 and 2 will take a snapshot. To set the parameters for the logs, see section 4.6.2.

See Chapter 8 of the GE Communicator EXT Guide for how to view and retrieve logs.

- ▷ From the Device Profile screen (see section 4.2), click on the **+/-** button beside **Trending Log Time Intervals** or doubleclick on the **Trending Log Time Intervals** line.

This submenu appears:



This screen displays the current Device Profile's Trending Log TimeIntervals. The values shown are for example only.

- Double-click on either **Log 1 Interval** or **Log 2 Interval**. The Interval Log Setting screen appears:



- Enter the hours, minutes and seconds for each log. The logs will be time-stamped based on the meter's time, which is set using the Tools menu. See section 4.10.
- When all changes are entered, click **OK** to return to the main Device Profile screen.
- For these changes to take effect, you **MUST** click on the **Update Device** button. This sends the new profile to the meter.
- It is recommended that you **Reset Logs** (see section 4.11) when changing settings that effect the logs.


### 4.6.2 Trending Setup

The Trending Setup controls the channel assignments for Historical Logs 1 and 2. To set the Time Intervals for these Logs, see section 4.6.1. See Chapter 8 of the GE Communicator EXT Guide for how to view logs.

- From the Device Profile screen (see section 4.2), click on the **+/-** button beside **Trending Setup** or double-click on the **Trending Setup** line. The following submenu appears:



- To change the settings for Log 1 double-click on **Log 1**. To change the settings for Log 2 click on **Log 2**. The Snapshot Channel Assignment Log 1 or 2 screen appears:



Make changes to this screen according to the requirements of your application:

- ▷ **Type:** Using pull down menu, select the type of snapshot.
- ▷ **Channel:** Using pull down menu, select a channel for the snapshot.
- ▷ Click on **Add** to include the selections in the Log; click on **Remove** to delete.
- ▷ To Remove multiple items, hold **Control** while clicking items to be removed and click **Remove**.
- ▷ To Remove a range of items, click the first item, hold **Shift**, then click the last item, then click **Remove**.
- ▷ When all changes are entered, click **OK** to return to the main Device Profile screen.
- ▷ Click on the **Update Device** button to effect changes.
- ▷ **Resetting Logs** is recommended (see section 4.9).


Total Bytes Used and Bytes Remaining screens display the memory status for that particular file. The Meter assumes 256 bytes of memory for each file. Total memory is determined at time of purchase.

### 4.6.3 Pad Missing Records for Historical Logs

When the meter is not in normal operation, it will not record any data for Log 1 and Log 2. For example, during firmware updates or loss of power, data will not be saved. Some applications may require data logs to contain those missing records.

To remedy this problem, you can Enable the feature in **View > Options > Log Retrieval**.

- ▷ Click the **Pad Meter Log File** box in front of the feature.
- ▷ Click **OK**.



This feature pads missing records for Log 1 and Log 2. The software causes the Log Converter program to automatically pad the missing records with a value of 0 for each log retrieval process and stores them in the Log DB file.

By default, if the Meter Trending Interval is set for Greater than 1 Hour, the meter will always save a record on the hour in the Trending Logs.

## 4.7 External Devices

This setting of the Device Profile configures the Meter's External Devices, a variety of I/O



- ▷ From the Device Profile screen (see section 4.2), double-click on the **External Devices** line.  
The following screen appears.

Module Number	Type	Assigned Address	Nexus Settings	Module Settings	Nexus Port	Log / Limit ID
1	20mAON4: Analog Out 4 - 20mA 4 ch	132	<a href="#">Edit</a>	<a href="#">Edit</a>	4	AO Module 1
2	No Device Assigned				4	
3	No Device Assigned				4	
4	No Device Assigned				4	
5	No Device Assigned				4	
6	No Device Assigned				4	
7	No Device Assigned				4	
8	No Device Assigned				4	
9	No Device Assigned				4	
10	No Device Assigned				4	
11	No Device Assigned				4	
12	No Device Assigned				4	
13	No Device Assigned				4	
14	No Device Assigned				4	
15	No Device Assigned				4	
16	No Device Assigned				4	

OK Cancel Help

- ▷ Click in the **Type** column and use the pull down menu to select the specific I/O you wish to add
- ▷ Enter a unique address for each.
- ▷ Use the **Edit** buttons to configure each module further.
- ▷ Click **OK** to return to the main Device Profile screen.
- ▷ For these changes to take effect, you **MUST** click on the **Update Device** button.  
This sends the new profile to the EPM 9800 Meter.

## 4.8 Set and Retrieve Meter Time

The EPM 9800 uses its on-board clock for time-stamping any logs it is recording.

### To set the meter's clock:

- ▷ Select **Tools > Set Meter Time**.

The meter's On-board Clock screen appears:




- ▷ To synchronize the meter and your computer, leave the **Use PC Time** box checked.
- ▷ To set the date and time to be independent from the PC, deselect the **Use PC Time** box and enter the time and date settings.
- ▷ Click the **Send** button to update the meter's time settings.

### To retrieve the Meter device's current time and date settings:

- ▷ Select **Tools > Retrieve Meter Time**.

This screen appears. Date and running time display in LEDs.






- ▷ Click **OK** to return to the main GE Communicator EXT screen.



## 4.9 Reset Meter Information

- From the menu bar select **Tools > Reset Meter Information**.  
The following set of screens appears:



- ▷ Click on the tabs to navigate between screens.
- ▷ Click on the box beside the value(s) you would like to reset.
- ▷ Click **OK**.



If you click Reset Logs, a **Warning** will appear asking you if you want to **Save Connected Device Settings**. Click on the settings you would like to save, then proceed with the Update. If you do not save the settings, they will be overwritten.


For each box you select, a window will appear which states that the “Reset is Completed”.

- ▷ Click **OK**.
- The reset is completed.**

You can password protect this feature by enabling the Password feature of the meter. (See Chapter 12 of the GE Communicator EXT Guide for details).

## 4.10 Manual Waveform Capture

- ▷ From the Menu bar, click on **Tools > Manual Waveform Capture**. The Manual Waveform Capture screen (shown here) appears, if the connected device is an EPM 9800.



This screen displays the Waveform Log Statistics of the logs that have possible Waveform Triggers.

- ▷ Click the **Trigger Now** button at the bottom of the screen to create a waveform.  
GE Communicator EXT creates a Waveform in Meter memory. The Records on the screen will increase by 1.
- ▷ To retrieve the Waveform, from the Menu Toolbar, click **Logs > Retrieve Log** from the device
- ▷ Click **OK** to return to the main Device Profile screen.


### 4.11 Test Mode Preset Accumulators

There are two reasons why a user might want to use the Preset Accumulators screens:

- 1. A meter in Test Mode is out of service and is therefore not monitoring accumulations. The New Value can be used to adjust for the values not monitored while in Test Mode.
- 2. When replacing an old meter, that has accumulations, with a new meter that has no accumulations, the New Value can be set with the value of the accumulations of the old meter.

#### Setting Test Mode Preset Accumulators for EPM 9800

- ▷ From the menu bar select **Tools > Test Mode > Preset Accumulators**.  
The set of screens shown here appears.



Accumulator	Current Value	New Value	Preset
Internal Input #1	000003.459 M	000003.459 M	<input type="checkbox"/>
Internal Input #2	000000.000 M	000000.000 M	<input type="checkbox"/>
Internal Input #3	000000.000 M	000000.000 M	<input type="checkbox"/>
Internal Input #4	000000.000 M	000000.000 M	<input type="checkbox"/>
Internal Input #5	000000.000 M	000000.000 M	<input type="checkbox"/>
Internal Input #6	000000.000 M	000000.000 M	<input type="checkbox"/>
Internal Input #7	000000.000 M	000000.000 M	<input type="checkbox"/>
Internal Input #8	000000.000 M	000000.000 M	<input type="checkbox"/>

Each screen has a Current Value, New Value and Preset Box for each accumulator. A new meter will have zeros for Current Values.

- ▷ Click Tabs at the top of the screens to access the individual screens.

Settings can be preset for the following sets of values:

- Primary Energy
- Secondary Energy
- Primary Energy (Quadrants)
- Secondary Energy (Quadrants)
- Internal Input Accumulators
- KYZ Output Accumulators
- I & V Squared T Accumulators
- Cumulative Demand (Secondary)
- Uncompensated Energy and Q Hours

- ▷ Click the Preset Boxes for the values you want to set.
- ▷ Click **Set** or **Cancel**.

## 4.12 CT and PT Compensation

The CT and PT Compensation feature allows users to remove the error caused by the CTs (external to unit) and PTs that are connected to the unit.


### Enable CT and PT Compensation:

The steps:

- ▷ From the Device Profile (Revenue and Energy Settings), click **CT & PT Compensation > State**.
- ▷ Enable **CT & PT Compensation**.



- ▷ To send the new profile to the meter click **OK** and click **Update Device Profile**.
- ▷ Exit Device Profile.
- ▷ Click **Tools > CT & PT Compensation > Calibration Table Status**



- ▷ Click the **First Time CT & PT Comp Selection**.
- ▷ Click **Preload CT & PT Comp with Initial Values**.
- ▷ Click **OK**.

- Click **Tools > CT & PT Compensation > View Calibration Tables.**

Calibration Tables

Factory Table Blk Time: 07/30/2004 09:38:40.22      CTPT Table Blk Time: 07/30/2004 09:38:39.14  
 Factory Table Cal Time: 02/18/2004 14:31:46.79      CTPT Table Cal Time: 05/20/2004 15:50:52.00

EPM Calibration Point	Factory Table				CT & PT Compensation Table			
	Phase A	Phase B	Phase C	Aux N	Phase A	Phase B	Phase C	Aux N
<b>Voltage</b>	40065	39976	40043	-2070	36059	35978	36039	-2070
<b>0.15A</b>	38184	38173	38228	1586466935	38184	38173	38228	1586466935
<b>0.25A</b>	38168	38150	38219	289354719	38168	38150	38219	289354719
<b>0.50A</b>	38165	38143	38201	289354719	38165	38143	38201	289354719
<b>1.00A</b>	38189	38163	38221	289354719	38189	38163	38221	289354719
<b>2.50A</b>	38192	38168	38228	17606926	38192	38168	38228	17606926
<b>5.00A</b>	38198	38173	38231	17606926	38198	38173	38231	17606926
<b>0.50A @60</b>	19	19	18		19	19	18	
<b>1.00A @60</b>	19	19	18		19	19	18	
<b>2.50A @60</b>	17	18	18		17	18	18	
<b>5.00A @60</b>	16	16	16		16	16	16	
<b>10.00A @60</b>	13	13	13		13	13	13	

Refresh    Print    Copy Factory Table to CT & PT Comp Table

OK

- Click **Copy Factory Table to CT & PT Comp Table.**
- Click **OK.**

CT & PT Compensation is now Enabled and ready for corrections.

- Collect data to determine the correction required.

### Compensate CTs & PTs:

- Click **Tools > CT & PT Comp > Compensate CTs & PTs.**
- Follow direction on screens. Click tabs to make additional corrections.

CT & PT Compensation

Voltage Readings		Gain Factors	
	% Error	Existing	New
A		36059	
B		35978	
C		36039	
Aux		-2070	

Write New Gain Factors

Calibration Point: Voltage Cal Point

Step 1: Voltage    Step 2: Power at Unity    Step 3: Power at 60° Phase

Instructions: Apply Voltage to each Phase. Write in error in percent for each phase. Press Write New Gain Factors after entering all % Errors for Voltage. Click Step 2 Tab

OK    Print

- Click **OK.**







1  
011  
101110011100  
01100111110001  
000111010110110  
11110001001101  
010101110010  
011  
1

## GE Communicator EXT

# Chapter 5: Configuring the EPM 6000 Panel Meter

---

### 5.1 Introduction

GE Communicator EXT Software enables you to configure the EPM 6000, 9450/9650 and 9800 GE Panel Meters.

To configure the EPM 9450/9650, see Chapter 3.

To configure the EPM 9800, see Chapter 4.

To configure the EPM 6000, see Chapter 5.



If you cannot make a connection, make sure your communication settings match those shown here.

## 5.2 EPM 6000 Configuration

The EPM 6000 meter can be configured using the meter Face Buttons (Menu, Enter, Down and Right) or the software, GE Communicator EXT, using the IrDA port (Com 1) on the face of the meter or the RS-485 port (Com 2) on the back panel of the meter. (Hardware installation and Face Button Configuration are detailed in the EPM 6000 Installation and Operation Manual.) Once a wired or wireless connection is established and the GE Communicator EXT 3.0 software is installed in your computer, you can begin to communicate between your computer and the meter.

### 5.2.1 Quick Connect

**Quick Connect** is the easiest way to connect GE Communicator EXT to your meter.

- ▷ From the GE Communicator EXT Menu, click **Quick Connect** or click on the **Connect** Icon.  
The Connect screen appears.

Configure the Connect Screen:

- ▷ Click on **Serial Port** or **Network**.  
The Initial Settings for the meter appear on the screen. If you have a Licensed version of GE Communicator EXT, you can change any of the settings.



If you have a demo version, you cannot change the Device Address; it must be "1".

#### Settings:

Device Address: 1 - 249  
 Baud Rate: 9600; 17,600; 34,600; 52,700  
 Port: COM 1 - COM 99 (OS dependent)  
 Protocol: Modbus ASCII or RTU

Flow Control: None or Hardware



#### Settings for EPM 6000 IrDA Port Connection:

Device Address - 1;

Baud Rate - 57600;

Protocol - Modbus ASCII;

Flow Control - Hardware.

- Click the **Connect** button to connect software to your meter.  
If a connection is established, the Device Status screen appears, showing the Currently Connected Devices.

List of Currently Connected Devices													
Device	Device Type	Boot	Run-time	DSP Boot	DSP Run-time	Comm State	DSP State	On Time	Serial #	NVSRAM	Protection	Xilinx DSP	Xilinx COM
121685 EPM 955	601	610	600	610	610	Healthy	Healthy	6/13/2006 12:01:52.54	00121685	4MB	Full Protection - Password Protection Enabled	0	3

Poling Protection Status: 1

OK Help



If there is more than one device, a list will appear on this screen. Click **OK**. The GE Communicator EXT 3.0 Main Screen Appears.

## 5.2.2 Connection Manager

Connection Manager is used if you want to Add or Remove Connecton Locations and/or Devices at Locations.

- From the GE Communicator EXT Menu, click **Connection Manager**.  
The Connection Manager screen appears.

Connection Manager

List of Locations	Connected to Location
0002: Warehouse 0003: GE 0005: Test Location 0006: New Location	Network - IP Address: 3.94.246.209:502

Sort by: Oldest - Newest

Add Remove Edit

Close Connect Disconnect Help

### List of Locations:

On the left side of the Connection Manager screen is a List of Locations. These are locations of one or more meters to which you might want to connect.

### Add a Location:

- ▷ Click on the **Add** button.
- The Connection Manager Location Editor screen appears.

On this screen, you program the communication settings for each New Location:


- ▷ Type a name for the New Location.
- ▷ Click **Serial Port** or **Network**.
- ▷ Enter settings.

### Com Settings:

Com Port: COM 1 - 99  
 Baud Rate: 1200 - 115200  
 Flow Control: None or Hardware  
 Data Bits: 8 (or 7)  
 Parity: None (Even, Odd)

### Add a Device:

- ▷ Click the **Add** Button in the **Devices at Location** box.  
If, at the top of the screen, you clicked Serial Port, a Serial Port Device Connection is added.
- ▷ Click **Network** to add a Network Device Connection.  
Here you can add up to 255 Devices (Serial Port and/or Network connections) at one Location.



All devices must have the same connection parameters: Baud, Parity and Flow Control.



Multiple Devices slow down polling.

### Edit Devices at Location:

- ▷ Scroll down to find all devices.
- ▷ Click on any **Device Address**, **Device Name** or **Description** to edit Device Settings.  
The Connection Manager Location Device Editor screen appears.

- On this screen, program the Device Properties for each device at a Location.  
If the Device has a Serial Port Device Connection, the top example screen appears. If it has a Network Device Connection, the lower example screen appears:

The screenshot shows a software window titled "Connection Manager Location Device Editor". Inside, there's a section titled "Device Properties" with a "Serial" tab selected. The form contains the following fields: "Address" with value "1", "Name" with value "Device 1", "Description" with value "Device 1", "Protocol" with a dropdown menu showing "Modbus TCP", "Device Type" with a dropdown menu showing "EPM 9000 Series", "IP Address" with value "3.90.240.300", and "Network Port" with value "502". At the bottom are "Close" and "Help" buttons.

FIGURE 5-1: Network Device Connection Settings

:

The screenshot shows the same software window, but with the "Network" tab selected. The form fields are: "Address" with value "1", "Name" with value "Device 1", "Description" with value "Device 1", "Protocol" with a dropdown menu showing "Modbus TCP", "Device Type" with a dropdown menu showing "EPM 9000 Series", and "Comm Port" with value "1". "Close" and "Help" buttons are at the bottom.

FIGURE 5-2: Serial Port Device Connection Settings

**Device Properties:**

Address: 1 - 247 (Unique Address)

Name: Easily Recognizable Name

Description: (Type and Number, for example)

Protocol: Modbus RTU or ASCII (Modbus TCP, EI Protocol for other devices)

Device Type: EPM 6000 (Others: EPM 4000, 5000, 7000, 9000 Series Meters and I/O Modules)

Comm Port: 1 or 2 (Serial Port Only)

IP Address: 100.10.10.10 (Example) (Network)

Port Number: 502 (Default) (Network)

- ▷ Click **Close** to save settings and return to the previous screen.

### Edit another Device

- ▷ Repeat steps above.

or

- ▷ Click **Close** to return to the Connection Manager screen.

### Edit a Location:

- ▷ Select a "New Location" listing in the List of Locations Field. Your selection is highlighted.
- ▷ Click the **Edit** button.  
The Location Editor screen appears, displaying the computer's communication settings.
- ▷ Follow the above procedure to Edit Locations and/or Devices.

### Sort Locations:

- ▷ Use the pull-down menu to select a sort method, A to Z, Z to A, Newest to Oldest or Oldest to Newest.
- ▷ Click **Sort By**.

### Remove a Location:

- ▷ Select and click **Remove**.

### Connect to a Location:

- ▷ Click once on the location to which you would like to connect your computer.  
You may only connect to one location at a time.
- ▷ To change to a different location, you **MUST** disconnect from the current location by selecting it and clicking **Disconnect**.

### Click Connect.

When the connection is made, the selected location appears in the Connected To Locations section.

- ▷ Click **Close**.

The Device Status screen appears, confirming the connection. The Computer Status Bar at the bottom of the screen confirms the computer's connection parameters.

### If the Connection Fails

A popup screen will alert you. Check that all cables are secure, that the RS-232 cable is connected to the correct Com Port on the computer and that the computer is set to use the same baud rate and protocol as the GE Meters to which the computer is connected.

## 5.2.3 Disconnect from a GE Meter

To disconnect from a GE Meter or to disconnect from a location, do one of the following:

- ▷ Click on the **Disconnect** Icon.



- ▷ From the menu bar select **Disconnect**.



- ▷ Click on the **Connection Manager** icon, or from the menu bar select **Connection Manager**.
- ▷ Select the location from the List of Connections.
- ▷ Click the **Disconnect** button.

## 5.2.4 Change the Primary Device

One copy of GE Communicator EXT connected to one or multiple GE Devices may only view data or Edit Device Profiles from one device at a time - the Primary Device. (An exception is the Poll Multiple Devices screen; see Chapter 7 for details.)



### To change the Primary Device:

- ▷ Select **Connection**.
- ▷ Change Primary Device/Address.  
The following screen appears.




If you have multiple meters connected to GE Communicator EXT, a window with a pull-down menu appears:

- ▷ Select the device you would like to designate as the **Primary Device**.
- ▷ Click **OK**.

The Device Status screen, reached by clicking on the **Device Status** button or by selecting **Tools > Retrieve Device Status**, will now list the New Primary Device first.


## 5.2.5 Merge Connection Databases

This is a tool for combining old Connection directories with new Connection directories.



From the GE Communicator EXT Toolbar:

- ▷ Click on **Merge Connection Databases**.  
The Merge Connection Databases screen appears.



- ▷ Type in the Source File or browse for the file by clicking **Browse**.
- ▷ Type in the Destination File or browse for the file by clicking **Browse**.
- ▷ Click **Merge** to import the Source File into the Destination File.
- ▷ Click **OK** to exit the screen and return to the Main GE Communicator EXT screen.

### 5.3 Configure the EPM 6000 Device Profile

- ▷ From the GE Communicator EXT Toolbar, click the **Profile** icon.  
A group of screens appears, the EPM 6000 Profile screens:

All screens have buttons across the bottom which do the following


- ▷ To Print a Report, click **Report**.  
A list of all settings on these screens is printed.
- ▷ To Save current Profile settings to a file, click **Save**.
- ▷ To Load Profile settings from a file, click **Load**.
- ▷ Click **Update Device** to send changes to the Device.  
Input Password (if Enabled).
- ▷ Click **OK**.



To Update a Device, you MUST be connected to that device.

### 5.3.1 Configure Settings

The primary screen of the EPM 6000 Device Profile is the Settings screen. Click tabs to move to the other screens.



To change settings:

- ▷ Check or uncheck box to Enable or Disable Password for Reset or Configuration.
- ▷ Click **Change Password** or **Change V-Switch**.
- ▷ Change Device Designation by inputting a new designation on this screen. See the next sections for details.

#### Password Settings

Enable or Disable Password for Reset (Reset Max/Min Energy Settings) or Configuration (Device Profile) by clicking the boxes next to the settings. Enabling the Password protection will prevent unauthorized tampering with devices.

When the user attempts to make an unauthorized change, GE Communicator EXT will ask for a Password using the screen shown here. If the correct Password is not entered, the change will not take place.



- ▷ Change Password by clicking on the **Change** button.  
The Enter New Password screen appears.



- ▷ Type in the new password (0 - 9999).
- ▷ Retype it.
- ▷ Click **Change**.  
The Enter Password screen appears (as shown above).
- ▷ Input the **OLD** Password.
- ▷ Click **OK**.  
The Device will save the New Password and Restart.

### V-Switch Change

The EPM 6000 is equipped with V-Switch® Technology. V-Switch® is a virtual firmware-based switch that allows you to enable meter features through communication. This allows the unit to be upgraded after installation to a higher model without removing the unit from service.

#### Available V-Switches®:

V-Switch 1 (-V1): Volts and Amps Meter - Default

V-Switch 2 (-V2): Volts, Amps, kW, kVAR, PF, kVA, Freq


V-Switch 3 (-V3): Volts, Amps, kW, kVAR, PF, kVA, Freq., kWh, kVAh, kVARh

V-Switch 4 (-V4): Volts, Amps, kW, kVAR, PF, kVA, Freq., kWh, kVAh, kVARh, %THD  
Monitoring and Limit Exceeded Alarms

To change the V-Switch®, follow these simple steps:

- ▷ Install **GE Communicator EXT 3.0** on your PC.
- ▷ Set up the EPM 6000 to communicate with your computer; power up your meter.

- ▷ Log on to **GE Communicator EXT 3.0** software.
- ▷ Click on the **Profile** icon.  
The **SETTINGS** screen appears.
- ▷ Click **CHANGE V-SWITCH**.  
A small screen appears that requests a code.



- ▷ Enter the code which GE provides.  
The V-Switch® will be changed automatically and the meter will restart.


### How to get a V-Switch

V-Switches are based on the particular serial number of the ordered meter. To obtain a higher V-Switch, you need to provide GE with the following information:

1. Serial Number or Numbers of the meters for which you desire an upgrade.
  2. Desired V-Switch Upgrade.
  3. Credit Card or Purchase Order Number.
- Contact your GE representative with the above information. GE will issue you the Upgrade Code.

### 5.3.2 Configure Communications

The Communication Settings on this screen are the settings for the EPM 6000's two ports, the IrDA Port (COM 1) and RS485 Port (COM 2).



The screenshot shows the 'EPM 6000 Profile' window with the 'Communication' tab selected. The window has a blue background and a title bar with a close button. The 'Communication Settings' section is visible, showing two ports: COM1 (IrDA) and COM2 (RS485). For COM1, the 'Response Delay (msec)' is set to 0. For COM2, the 'Address' is 0, 'Protocol' is set to a dropdown menu, 'Baud Rate' is set to a dropdown menu, and 'Response Delay (msec)' is 0. At the bottom, there are buttons for 'Update', 'Cancel', 'Load', 'Save', 'Report', and 'Help'.

The settings that appear are the Initial Settings for communication. Any changes may effect communications between the EPM 6000 and your PC.

Response Delay: 0 to 750 (50msec increments)

Address: 1 to 247

Protocol: Modbus RTU or ASCII

Baud Rate: 9600 to 57600

Response Delay: 0 to 750 (50msec increments)

### 5.3.3 Configure Energy and Display

This screen displays the Power and Energy Format, Demand Averaging, Auto Scrolling and Display Configuration.

**EPM 6000 Profile**

Scaling | **Energy And Display** | Communication | Settings | Limits

**Power and Energy Format**

Power Scale: unit

Energy Digits: 5

Energy Decimal Places: 0

Energy Scale: unit

Example: 12345 **Recalculate**

Power Direction: view as load

**Demand Averaging**

Averaging Method: block

Interval[Minutes]:

Sub Interval: 1

Auto Scroll Display: ☐ Off

**Display Configuration**

☐ Volts L-N ☐ VA/Hz

☐ Volts L-L ☐ Wh

☐ Amps ☐ VARh

☐ W/VAR/PF ☐ VAh

Update Cancel Load Save Report Help

#### Power and Energy Format

Power Scale: Unit, kilo (k), Mega (M), Auto

Energy Digits: 5, 6, 7, 8

Decimal Places: 0 - 6

Energy Scale: Unit, kilo (k), Mega (M)



The Energy Digits, Scale and Decimal Places settings determine how the Energy Values are displayed.

#### Power Direction

View as Load

View as Generator

#### Demand Averaging

Average Method: Block or Rolling

Interval: 5, 15, 30 or 60 Minutes

Subinterval: 1, 2, 3 or 4



### Auto Scroll Display

- Check **On** box for Parameters checked in the Display Configuration section of this screen to be automatically scrolled on the faceplate of the meter.

### Display Configuration

- Check the **Readings** that you want displayed on the faceplate of the meter.

If invalid CT, PT and Interval Settings are entered, a **warning** will appear on the screen.

### 5.3.4 Configure Scaling

This screen displays the CT and PT Ratios and System Wiring.

#### CT Ratios

CT Numerator: 5 (1 - 9999)

CT Denominator: 5 (Preset to 5 or 1 Amp and cannot be changed)

CT Multiplier (Scaling): 1 (1, 10 or 100)

#### PT Ratios

PT Numerator: 600 (1 - 9999)

PT Denominator: 600 (1 - 9999)

PT Multiplier (Scaling): 1 (1, 10 or 100)

## System Wiring

3 Element Wye

Delta with 2 CTs

2.5 Element Wye

If invalid CT, PT and Interval Settings are entered, a **warning** will appear on the screen.

---

## 5.4 Using EPM 6000 Polling and Tools Menus

### 5.4.1 Using EPM 6000 Polling Menu

The Polling Menu for the EPM 6000 is similar to that of the other GE meters, with two exceptions:

1. There are fewer screens for the EPM 6000. Unavailable screens may appear on the menu and be greyed out.
2. EPM 6000 has a unique screen - **Real Time Trending**. Details in Polling - Chapter 7.

The Polling Screens for the EPM 6000 display the following:

**Volts, Current:** Instantaneous, Minimum and Maximum Values for Voltage, Current and Frequency.

**Poll Multiple Devices:** View polling data from multiple connected meters.

**Power and Demand:** Instantaneous, Minimum and Maximum Values for Power and Accumulated Energy

**Real Time Trending:** Displays a graph of instantaneous values. Also provides Logging of instantaneous values in a **.csv** (Comma Separated Value) Excel file.

### 5.4.2 Using EPM 6000 Tools Menu

The Tools/Reset Screens for the EPM 6000 are similar to the other GE meters.

**Reset Meter Information:** Resets stored Max/Min and Energy Accumulations.

---

## 5.5 Real-Time Poll

After connecting to the meter, on the menu bar, select Real-Time Poll button. A menu of screens allows the user to select one of the following polling screens:

- Instantaneous Polling
- Poll Max and Min Readings
- Poll Power Readings
- Poll Harmonics
- Poll Internal Inputs
- Poll Limit Status

The individual screens are readings that result from the settings in the Device Profile which were discussed in the earlier sections of this chapter. The screens are very similar to the EPM 9450/0650 and 9800 screens. Occasionally, the meter screens will have slightly fewer readings.

For details on how to utilize the data on the screens, see sections 6.3, 6.5, 6.6, 6.7, 6.8 and 6.11 of this manual.

---

## 5.6 Tools

After connecting to the meter, on the menu bar, select **Tools**. A menu of the following tools will appear:

- Edit Current Device Profile (covered in earlier sections of this chapter)
- Set Meter Time
- Retrieve Meter Time
- Reset EI Device Information
- Retrieve Device Status
- Low Level Access
- Analog Output Programmer

Each of these Tools will be described in the following sections, with the exception of Edit Current Device Profile, which was described in detail in sections 5-1 to 5-15 of this chapter.

## 5.7 Set Device Time

- ▷ After connecting to the meter, on the menu bar, select **Tools**.
- ▷ Click **Set Device Time**.



The image shows a dialog box titled "Set Device On-Board Clock". It has a blue background and contains input fields for Date and Time. The Date section has three fields: Month (04), Day (17), and Year (2007). The Time section has three fields: Hour (15), Minute (34), and Second (42). Below these fields is a checkbox labeled "Use PC Time" which is checked. At the bottom of the dialog are two buttons: "Send" and "Cancel".

	Month	Day	Year
Date	04	17	2007

	Hour	Minute	Second
Time	15	34	42


☒ Use PC Time

Send Cancel

- ▷ Set the Month, Day, Year, Hour Minute and Second, or click **Use PC Time**.
- ▷ Click **Send** to send the new settings to the meter, or click **Cancel**.


## 5.8 Retrieve Device Time

- ▷ After connecting to the Meter, on the menu bar, select **Tools**.
- ▷ Click **Retrieve Device Time**.  
The following screen will appear.
- ▷ Click **OK** to return to the main screen.  
To adjust Meter Time, see section 5.18.



## 5.9 Reset Device Information

- ▷ After connecting to the meter, on the menu bar, select **Tools**.
- ▷ Click **Reset Device Information**.  
The following screen will appear.



- ▷ Select the parameters that you want to reset.
- ▷ Click **OK**.  
A screen will appear that confirms the reset.
- ▷ Click **OK** to return to the main screen.




## 5.10 Retrieve Device Status

- ▷ After connecting to the meter, on the menu bar, select **Tools**.
- ▷ Click **Retrieve Device Status**.  
The following screen will appear:



## 5.11 Low Level Access

- ▷ After connecting to the meter, on the menu bar, select **Tools > GE Multilin Programmer**.
- ▷ Click **Low Level Access**.



**Low Level Access is not required for normal operation.** Low Level Access is a diagnostic tool for third party software and devices. It is designed to be used ONLY by appropriate level Programming Personnel in conjunction with the Modbus Map.

The latest version of the Modbus Map can be downloaded from the Free Downloads section of our website: [www.GEmultilin.com](http://www.GEmultilin.com).



1  
011  
101110011100  
01100111110001  
000111010110110  
11110001001101  
010101110010  
011  
1

## GE Communicator EXT

# Chapter 6: Total Web Solutions

---

### 6.1 Overview

The 10/100BaseT Ethernet Option (INP100) for GE's EPM 9450, 9650 and 9800 Meters, a fully customizable web server, provides access to real-time data via Internet Explorer.

GE's name for this dynamic system is Total Web Solutions®. This is an open design that enables you to communicate with any device via a variety of open protocols. The system incorporates a highly programmable network card with built-in memory, installed in 10/100BaseT Option meters. Each card can be programmed to perform an extensive array of monitoring functions.



The EPM meter with the INP10 Option does not support Total Web Solutions®.

## 6.2 System Components

The components of the Total Web Solutions© system are detailed below. Each component adds special features to this fully configurable system. For Flow Charts of the components see 6.10 to 6.12.

**WebExplorer©:** This component uses your Web Browser to provide you with direct access to all power data. Using your browser, you can access any data file, and because it looks like a standard HTML web page to an IT department, the data transmits through corporate firewalls. This fully configurable component allows you to customize your own SCADA quality web pages, graphics and configurations via FTP Server and/or FTP Client. The Main Default Page is shown below. This is just an example; the web pages for your data may be changed or created to your own needs and specifications.

The URL address for this page is: <http://www.myEPMmeter.com>

## GE Power Leader Web Solutions

Volts/Amps

Power/Energy

Power Quality

Pulse  
Accumulation

Inputs

Meter

Information

Emails

Diagnostic

Tools

Meter Name 00121689

Date/Time 2007-04-17 16:22:18.450

### Voltage/Frequency

	Instantaneous	Maximum	Minimum
Volts AN	0.00	275.68	0.00
Volts BN	0.00	276.87	0.00
Volts CN	0.00	275.90	0.00
Volts A-B	0.00	479.64	0.00
Volts B-C	0.00	479.65	0.00
Volts C-A	0.00	479.40	0.00
Frequency	0.00	60.03	0.00

### Current

	Instantaneous	Maximum	Minimum
Amps A	0.00	23.49	0.00
Amps B	0.00	19.79	0.00
Amps C	0.00	19.78	0.00
Amps N (calculated)	0.00	0.89	0.00

Last Max Reset 2007-02-01 13:25:37.110

**WebXML©:** A very versatile component for configuring data to your specifications. The data is polled, then stored in an XML file for later access by any client on the network. The data can be viewed via a host of applications including Internet Explorer and Microsoft Excel, PowerPoint and Word.

**WebReacher©:** With this component, you can access meters anywhere in the world. WebReacher© has a built-in Modbus data concentrator that allows you to poll up to 8 devices or 512 unique polling items from any device that uses Modbus RTU and/or Modbus TCP protocols. WebReacher© can retrieve the data and consolidate it into web pages without separate software.

**WebMod©:** The 10/100BaseT design allows the unit to communicate using Modbus TCP. Once the programmable network card is placed inside the meter, Port 2 becomes a gateway. The gateway enables a high-speed interface between the Network LAN and other Modbus-based IED (Intelligent Electronic Device) equipment. Modbus TCP is an industry-proven open protocol that can be easily integrated with other software or hardware.

**WebAlarm®:** Real-Time Email alerts are sent via the Internet to up to 9 recipients simultaneously for any combination of event notifications. You decide what message is sent and to whom. Email format can be Short Format or Long Format. Short Format is for cellphones with text messaging service. Long Format provides detailed alarm conditions for any devices with full email support (computers, PDAs, cellphones).

---

## 6.3 Hardware Connection

The EPM 9450, 9650 and 9800 meters with the 10/100BaseT Ethernet Option (INP100) have all the components of the standard Meters PLUS the capability of connection to a network through an Ethernet LAN or to the Internet via Modbus TCP, HTTP, SMTP, FTP and/or DHCP. Monitors with the 10BaseT Option (INP10) connect via Modbus TCP ONLY.

INP100 can auto detect the cable type and works with either straight or crossover cable. INP10 does not have the straight connection capability.

**Example:** A direct connection between a PC and INP100 can use a straight or a crossover cable. But, for an INP10 connection, you must use a crossover cable.

### EPM 9450/9650: RJ-45 Connection - Meter with 10/100BaseT Option to Multiple PCs

The 10/100BaseT Option conforms to the IEEE 802.3 specification using unshielded twisted pair (UTP) wiring, allowing inexpensive RJ-45 connectors and CAT5 (or better) cabling to be used.

This LAN connection allows multiple PCs to be connected concurrently. The RJ-45 line is inserted into the RJ-45 Port on the face of the EPM 9450/9650 with 10/100BaseT option. The connection using RJ-45 into the EPM 9450/9650 can connect the meter to a network using Modbus TCP protocol over the Ethernet. To connect with other meters using Modbus RTU in either remote or local locations, you MUST use Port 2 (which is labeled Ethernet Gateway) as a Master, and an RS-485 connection. The link using RS-485 is viable for up to 4000 feet (1219 meters).

**RS-232:** Insert RS-232 cable from a PC into Port 1 and set the Selector Switch to RS-232. This connection is necessary in order to set the initial software configuration. For details on EPM 9450/9650 connections and wiring, see the *EPM 9450/9650 User's Manual*.

### EPM 9800: RJ-45 Connection

The 10/100BaseT option conforms to the IEEE 802.3 specification using unshielded twisted pair (UTP) wiring. This allows the use of inexpensive RJ-45 connectors and CAT5 (or better) cabling. An RJ-45 connector is supplied with the meter.

This LAN connection allows multiple PCs to be connected concurrently. The RJ-45 line is inserted into the RJ-45 Port (or Jack) on the Port 3 cable coming from the back of the EPM 9800 with 10/100BaseT option.

The connection using RJ-45 into the EPM 9800 connects the meter to a network using Modbus TCP protocol over the Ethernet. You can access the meter with a SCADA system, MV90 and PCs all at the same time.

**RS-232:** Use the Optical Port on the face of the meter to make the RS-232 connection. The magnetic coupler snaps into place; the other end of the cable connects to your PC. This connection is necessary to set the initial software configuration. For additional details on EPM 9800 connections and wiring, refer to the *EPM 9800 User's Manual*.

## 6.4 Software Connection

### All EPM 9450/9650 and 9800 Meters:

Connect a meter to a computer using Port 1 (9450/9650) or Port 3 (9800) to configure the network parameters and add a network connection. The meter must be configured to speak Modbus TCP. (Modbus TCP is the common protocol used for Modbus communication over a network.)



The Gateway operates as a Modbus RTU Master with programmable Baud Rate up to 115200.

### Direct Connection:

- ▷ Click the **Connect** button on the Tool Bar or select **Connect > Quick Connect**.
- ▷ Click the **Network** radio button.  
The Connect screen will change from the Serial Port version to this example.

The screenshot shows a 'Connect' dialog box with a blue background. At the top, there are two radio buttons: 'Serial Port' and 'Network'. The 'Network' button is selected. Below the radio buttons are four labeled input fields: 'Device Address' with the value '1', 'Host' with the value '3.94.246.209', 'Network Port' with the value '502', and 'Protocol' with a dropdown menu showing 'Modbus TCP'. At the bottom of the dialog are three buttons: 'Connect', 'Cancel', and 'Help'.

Enter settings for Network Connection (see your Network Administrator for correct settings):

- ▷ In the Device Address field, enter **1**.
- ▷ In the Host field, enter an IP Address or a Registered Name (see your Network Administrator).

In the Network Port and Protocol fields, the example settings are fixed.

- ▷ Click **Connect**.  
GE Communicator EXT locates the meter and the Device Status screen appears, confirming the connection.
- ▷ Click **OK**.  
The computer is now connected to the meter.

The Computer Status Bar at the bottom of the screen confirms the computer's connection parameters. Status Bars vary, depending on the connection parameters.



You may use a connected external display to view the baud rate, address and communication protocol of each port. See Chapter 3 for details of how to configure the meter's communication ports.


### Connection Manager:

Connect a meter to a computer using Port 1 (9450/9650) or Port 3 (9800) to configure the network parameters and add a network connection. The meter must be configured to use Modbus TCP. (Modbus TCP is the common protocol used for Modbus communication over a network.)



The Gateway operates as a Modbus RTU Master with programmable Baud Rate up to 115200.


- ▷ Click the **Connection Manager** icon, or select **Connection > Connection Manager**.  
The example screen appears:



- ▷ Select the **New Location** listing in the **Locations** field.  
Your selection will be highlighted.
- ▷ Click the **Edit** button.  
The Location Editor screen appears, displaying the computer's communication settings:
- ▷ Enter a Location Name in the field at the top of the screen, if desired.



- ▷ Click on the **Network** button.
- The screen will change to the following:



The screenshot shows the 'Connection Manager Location Editor' dialog box. At the top, the 'Location Name' is 'Substation #1'. Below this, there are two radio buttons: 'Serial Port' and 'Network'. The 'Network' radio button is selected. Under 'Network', there are two text fields: 'Host' with the value '10.0.0.1' and 'Network Port' with the value '302'. To the right of these fields is a checkbox labeled 'Use Data Switch String(s)' which is checked. Below the checkbox are two empty text boxes labeled 'Connect' and 'Disconnect'. At the bottom of the dialog, there is a section titled 'Devices At Location' which contains four buttons: 'Add Serial', 'Add Net', 'Remove', and 'Edit'. Below these buttons is a table with three columns: 'Device Address', 'Device Name', and 'Description'. The table contains three rows of data: '1 Device 1 Device 1', '2 Device 2 Device 2', and '3 Device 3 Device 3'. At the very bottom of the dialog are 'Close' and 'Help' buttons.

- ▷ Enter a Computer's IP Address in the **Host** field.
  - ▷ In the **Network Port** field, enter 502 (assigned port for Modbus TCP).
  - ▷ To add or remove devices from the network, click **Add** or **Remove**.
  - ▷ If you are adding a device, click **Edit** to change the device Name, Address and/or Description.
- The following screen will appear:



The screenshot shows the 'Connection Manager Location Device Editor' dialog box. At the top, the title is 'Device Properties'. Below the title is a tab labeled 'Serial'. The dialog contains several fields: 'Address' with the value '1', 'Name' with the value 'Device 1', 'Description' with the value 'Device 1', 'Protocol' with a dropdown menu showing 'Modbus RTU', 'Device Type' with a dropdown menu showing 'EPM 9000 Series', 'IP Address' with the value '255.255.255.0', and 'Network Port' with the value '1'. At the bottom of the dialog are 'Close' and 'Help' buttons.

Ethernet Gateway (Port 2) of the Internal Network Option Meter is used to add multiple additional units. Additional meters must be configured to speak Modbus RTU and set to the same Baud Rate (up to 115200) as the Internal Network Option Meter.



A computer “talks” to the Internal Network Option Meter via Modbus TCP. This meter receives data in Modbus TCP “incoming message format” and communicates with other devices via Modbus RTU. They do not have to be Internal Network Option units.


If additional devices are required:

- ▷ In the **Device Address** field enter the address assigned to the additional meter.  
Again, each unit **MUST** have a unique address other than **1**. “**1**” is reserved as the address of the meter connected to the network.
- ▷ In the **Name** field, enter a name for the device, one that is different from any others at that location.
- ▷ In the **Protocol** field, select Modbus TCP.
- ▷ Leave the **Device Type** field set to Meter.
- ▷ Click on the **Close** button when all information is entered.

If you are connecting to multiple meters at this location:

- ▷ Repeat the above process for all meters.  
Each device **MUST** have a unique address.
- ▷ To remove devices, select and click **Remove**.
- ▷ Click on the **Close** button when you have finished adding or removing devices.  
The first Connection Manager screen returns.
- ▷ Click once on the **Location** to which you would like to connect your computer.  
You may only connect to one location at a time.

- ▷ To change to a different location, you must first disconnect from the current location by clicking on the **Disconnect** button or by selecting **Disconnect** from the **Connection Menu**.



- ▷ Click **Connect**.  
The computer connects to the meter via the network.

When GE Communicator EXT has located the meter(s) at that location, the Device Status screen appears, confirming the connection. The Computer Status Bar at the bottom of the screen confirms the computer's connection parameters.



**Troubleshooting the Connection:** If the connection fails, check first to see if both the physical and software connections to the primary Internal Network Option Meter are viable (see below). Once these connections have been checked, check the connections with other devices.

### Suggested checkpoints:

Internal Network Option Meter:

- ▷ Check cables.
- ▷ Check IP Address, Subnet Mask and Default Gateway settings.
- ▷ Check that the Address is **1**.
- ▷ Check that **Modbus TCP** was selected in Device Properties.

Other Devices:

- ▷ Check all the above except the Address.
- ▷ Check that the Address is unique and **not** set to **1**.
- ▷ Check that the Baud Rate settings for the Ethernet Gateway (Port 2) and the Devices are the same.

Try “Pinging” to a known good network device, such as another computer, to verify that your computer is connected properly to the network:

- ▷ Go to the DOS Prompt (or, Console, if you are using Windows® NT).
- ▷ **Ping IP Address.**  
Example: “Ping 10.0.0.1”.

## 6.5 Setting Up the 10/100BaseT Connection

Setting up the 10/100BaseT Option consists of configuring the web connection and the Advanced Network Card Screens so that you can access the data you need from the Web.

Once the initial configuration is set, you will not need software, unless you want to make changes to the configuration. With the Basic Setup, you will be able to access the Default Screens (page 6-1) that display a variety of Real-Time readings. You may wish to customize your screens. (See details in section 6.6.)

In order for the Web to access the data from a meter, the meter must have an IP Address. An IP Address is a number (typically written as four numbers separated by periods, e.g. 107.3.2.54) which uniquely identifies a computer attached to the Internet. An IP Address can be assigned using a DHCP Server or it can be entered manually.

For your information, here is a brief explanation of DHCP:

**DHCP** (Dynamic Host Configuration Protocol) was created by IETF (Internet Engineering Task Force) to enable individual computers on an IP network to extract their configurations from a server (the "DHCP Server"), or servers, that have no exact information about the individual computers until they request the information. The DHCP Server "leases" the IP Address to the DHCP Client for a period of time from 15 minutes to a year. More information can be found in the Internet RFCs (Request for Comments) regarding available servers and technical details.



In DHCP Mode, if a NACK message is received from the DHCP server, INP100 will stop all Ethernet activities immediately and start a new DHCP process.

### 6.5.1 DHCP Setup

Enable the DHCP Mode in the meter:

- ▷ From **Device Profile** in GE Communicator EXT, open the **Communication Ports** screen.
- ▷ Click on **Advanced Settings**.
- ▷ Click **DHCP** tab.
- ▷ Click **Enable DHCP**.
- ▷ Access a working DHCP Server.

DHCP Servers automatically assign an IP Address and Subnet Mask. Some DHCP Servers, such as the one in Windows 2000® allow you to assign a Default Gateway IP (DHCP Option #3), DNS IP (DHCP Option #6) and SMTP Server IP (DHCP Option #69) to the meter. If your DHCP Server does not let you assign parameters other than the IP Address, enter those values manually.


- ▷ Enter a unique computer name (Optional).

This allows the user to access the meter by name, if there is a DNS Server working in conjunction with the DHCP Server. Please see your network administrator and the server's user manuals

for further details. The Default Computer Name is **GE MultilinNET\_XXXXXX** where the X's are the last 3 octets of the MAC Address.

## Manual Set Up

▷ Manually enter an IP Address, if DHCP Mode is **OFF**.



### For reference - IP Addresses reserved for Internal Networks:

Class A -- 10.0.0.0 - 10.255.255.255

Class B -- 172.16.0.0 to 172.31.255.255

Class C -- 192.168.0.0 to 192.168.255.255



See RFC1918 for Internal IP Reference.

### Basic Items:

IP Address

Subnet Mask

Default Gateway

### Nonconfigurable Gateway Port Items:

Data Bits = 8

Stop bits = 1

Parity = none

### Advanced Items:

Gateway Port (RS-485) Baud Rate

Gateway Port Delay

DNS IP (will be needed for WebAlarm email and FTP Client if the Server Address is entered as a name string, not an IP Address).


## 6.5.2 Services & Security

- ▷ Click the **Services** tab.
- ▷ Check the boxes in front of the listed Services to Enable the features desired.  
Unless these Services are Enabled, they will not work.
- ▷ If you do not want to Block Password Protected Access, press **OK > OK** to return to the main screen and press the **Update Device** button.

### Block Password Protected Access

This feature blocks access to an EPM 9650 or 9800 at Modbus Address 1 in INP100/102.

The feature was added to INP100/102 runtime firmware in v0.1.52.



Once it is enabled, the INP100/102 network card will block all network requests when it detects that a user is sending a password to the meter at Modbus Address 1.

As a result, if the meter is password-enabled and the user is trying to gain access by sending a password through the network interface via Modbus TCP or through the modem via Modbus ASCII, the operation will be stopped and the user will not be able to access the password enabled area.



Use of this feature requires an INP100/102 firmware update and a GE Communicator EXT software update.

### Update Procedures:

- ▷ Go to the meter's **/update1.htm** page to update its firmware.  
(Example: 100.0.0.0/update1.htm)
- ▷ When done, go to **/reset\_ethernet.htm** page to reset it.
- ▷ **Uninstall** the old software.


- ▷ **Install** the new software.
- ▷ Connect to a meter via serial port and retrieve its **Device Profile**.
- ▷ Under **Communications > Advanced Settings** (for network card) > **Services & Security**, check the box for **Block password protected access to device with address 1**.
- ▷ Press **OK > OK** to return to the main screen, and press the **Update Device** button.
- ▷ Go to menu bar **Tools > Password > Enable/Disable** to enable password protection for the meter.

In the meter's /diag\_modbus\_tcp\_server.htm web page, you should see:

**Block set password to meter: Enabled**

### 6.5.3 Computer Name / DNS

- ▷ Click the **Computer Name / DNS** tab.




- ▷ Enter the Computer Name.
- ▷ Enter the IP Addresses for Domain Name Servers 1 and 2.
- ▷ Click **OK** to save settings.



### 6.5.4 Auto TFTP Download

- ▶ Click the **Auto TFTP Download** tab.



- ▶ Enable Auto TFTP Download; the port is **69**.
- ▶ Enter the TFTP Server IP Address, Client IP Address, Subnet Mask, Default Gateway and the Download Filename.
- ▶ Click **OK** to Save.

Once that data is saved, it is downloaded automatically until you change it.

### 6.5.5 WebAlarm/Email

This feature sends out email when an alarm condition occurs. The settings are configured in the Advanced Network Card Settings. An additional 8 email addresses can be configured in the poll\_profile.xml file.

- ▶ Access those settings from **Device Profile > Communication Ports > Advanced Settings**.
- ▶ Click the **Services** tab.  
The Services screen appears.
- ▶ Enable/Disable the sending of Email by clicking **SMTP Client**.  
The Initial Setting is **OFF**.

- ▷ Click on the **Alarm/Email** tab.  
The screen appears as it is shown here.

Enter the settings below to configure Alarm/Email service.

#### Alarm/Email Settings:


- SMTP Server IP or Name (Requires DNS Setup).
- Email Server Port Number: 25
- Administrator Email Address/To Address: for user preferred address or any monitoring software receive address such as GE Multilin's Dial-In Server.
- Return/Reply/From Address.
- Subject Text: any

#### 6.5.6 FTP Client

This feature allows the user to substitute his own (user-defined) polling profile, web pages or graphics for the web server. User should set up an FTP Server nearby with a user account and read-only access for this purpose.

- ▷ Access the **Advanced Network Card Settings** (see above).
- ▷ Click the **Services** tab.  
The Services screen appears.
- ▷ Enable/Disable the sending of Email by clicking **FTP Client**.  
The Initial Setting is **OFF**.

- Click on the **FTP Client** tab.  
An example screen is shown here.



- Enter the following settings to load user defined files.  
**FTP Client Settings:**
- FTP Server IP or Name (requires DNS setup).
  - FTP Server Port, Initial Setting is xx.
  - Startup Directory: (where files are located)(subdirectory is not supported). If the file has the same name as the one in the Initial Files within the meter, the new file will replace the Initial one.
  - User Name
  - Password.

### FTP Client Settings Example:

By default, Microsoft's FTP Server will use "C:\inetpub\ftproot\" as the root directory. When a user logs onto the FTP Server, this is the initial directory the user will see.

1. If the files for INP100 are stored in the root directory ("C:\inetpub\ftproot\"), leave the "Startup Remote Directory" text box empty.

Example Files in FTP Server's Root Directory:

- C:\inetpub\ftproot\index.htm
  - C:\inetpub\ftproot\poll\_profile.xml
  - C:\inetpub\ftproot\logo.gif
- When INP100 starts up, it will check to see what files are in the server's directory and will download them all.
2. If the files for INP100 are stored in a subdirectory in the root directory, such as C:\inetpub\ftproot\EPM\_meters\feeder\_12345\, put EPM\_meters/feeder\_12345 in the Startup Remote Directory text box.

**Note the different "/" between directory names.**

When INP100 starts up, it will check for all files in the server's directory (EPM\_meters/feeder\_12345) and download all files found.

If there is another subdirectory inside this directory that is not listed in the server's directory as above, such as "C:\inetpub\ftproot\EPM\_meters\feeder\_12345\info\", INP100 will not locate that subdirectory and no files will be downloaded from that subdirectory to INP100.

That may cause an error during the file downloading process and the system may not enter its normal operation mode until the subdirectory is removed from the server.

3. The user should always check the FTP server to see if it's configured properly. To do this, open the IE browser window, enter the correct address in the URL window.

The standard format is: **ftp://[username]:[password]@[ip\_address]**.

**Example:**

**ftp://john:1a2b3c@192.168.1.1** where **John** is the user name and **1a2b3c** is the password.

### 6.5.7 INP 102 Ethernet/Modem Combination

INP 102 is an extension of INP 100. It has all the features of an INP 100, plus a built-in modem. The communication protocol supported by the modem is Modbus ASCII. The communication protocol supported by the RS-485 Ethernet/Modem gateway port is Modbus RTU.

The INP 102 converts all Modbus ASCII incoming modem requests to Modbus RTU for internal and gateway communication, then it converts all response Modbus RTU messages into Modbus ASCII protocol and send out to the modem. Some of the fixed parameters for the Ethernet/Modem gateway port are: 8 data bits, no parity, 1 stop bit. The Ethernet/Modem gateway port's baud rate and delay time are configurable.

#### The modem has three operational modes:

1. **Modem Command**  
Mode Invisible to users. Modem is idle, waiting for incoming call.
2. **User Command Mode**  
Visible to users. If modem password protection is enabled, the user can enter the password in this mode, so that the modem can grant him access. In addition, the user can query the modem for its boot and runtime firmware version, modem identification information.
3. **Passthrough Mode**  
Normal Operation mode. Modbus requests and responses are passed through the modem.

Table 6–1: INP102 Settings

Setting	Description
Inactivity Timeout Limits (Minutes)	In Passthrough Mode, if the user does not send anything to the modem, the modem will disconnect when this Inactivity Timeout Limit has been reached.
Rings to Answer (Rings)	The modem will answer the call after a certain number of rings.
Identification	User-defined modem ID: up to 32 characters.
Password	User-defined modem password: up to 16 characters.
Enable Password	Option to enable or disable modem password feature.
Violation Limit (Attempts)	If Password was enabled and the user failed to enter a correct password, a Violation (Call Failure) Flag will be set and the Violation Counter will Increment by 1. Once the total number of violations goes over the limit of three, the modem will enter Lockout mode. The modem will not answer calls until the Violation Lockout Time is reached.
Violation Lockout Time (Hours)	Modem will stay in Lockout mode until this Lockout Time is reached.
Call Failure Reset Limit (Hours)	If the Password was enabled and the Total Violations (Call Failures) did not reach the Violation Limit (modem not in Lockout Mode), the modem resets the Violation (Call Failure) Counter when it reaches this reset limit.
Share the Phone Line	Option to Enable or Disable modem's Share the Phone Line feature.

**Example:**

call failure reset limit = 1 hour

violation lockout time = 24 hours

incoming connection failure count = 3

The first connection with a bad password occurred at 10:00am. Another occurred at 10:05, a third at 10:30, a fourth at 10:45 (all with a bad password). That's more than 3 in 1 hour, so the modem will not answer the phone again until 10:45am the next day. If the fourth connection attempt had been received at 11:31 instead of 10:45, the modem would have answered the call because the first 3 had "expired" at 11:30.

Table 6–2: INP102 Modem Commands

Command	Description
[3 seconds pause] :CM [3 seconds pause]	Set the modem to User Command mode
ONLINE<CR>	Set the Modem to Passthrough mode
E<CR>	Command or querying modem's characteristic information. Modem returns "INP-102 Ethernet/Modem"
MODEM?<CR>	Command for querying modem's ID
PASSWORD?<CR>	<p>If the Modem Password was enabled, the modem will send this query to the user once the connection is established, asking for a Password .</p> <p>The user must enter the Correct Password before sending any other user data. The user has 20 seconds to reply with a Password. If there is no response from the user, the modem will resend this command.</p> <p>If the Password was incorrect, the modem will resend this command. The user can have 3 attempts to enter the Correct Password before the modem automatically disconnects.</p>
FBOOT?<CR>	Command for querying modem's boot firmware version
FRUN?<CR>	Command for querying modem's Runtime Firmware version

### More information about the modem operation

1. When the Share the Phone Line option is set, the modem should drop the connection in about 5 seconds, assuming someone picked up the receiver and didn't hang up. If the receiver was hung up quickly, the connection will not drop.
2. When the Share the Phone Line option is not set, the modem should not drop the connection and communication should resume about 10 seconds after the receiver was hung up. The modem can still drop the connection if the noise level is too high, such as with repeated pick-up and hang-up or noise at the receiver. The performance of this mode is not guaranteed. There will be no valid communication if the receiver is picked up for any substantial length of time.
3. No dial out support: User cannot "flash upgrade" the Ethernet/modem's firmware from a modem connection.
4. Modem and Ethernet connections will close if either detects a change in device profile or are forced to reset by the user from a web interface.
5. If the firmware does not detect the modem hardware, the modem task will be stopped.

A modem status/diagnostic web page can be found at /diag\_modem.htm.

### 6.5.8 DNP for LAN/WAN

The original DNP 3.0 was designed for serial point-to-point communication (e.g. RS-232) with limited support for half-duplex serial networks (e.g. RS-485). In order for devices to exchange DNP messages in a local (LAN) or wide area network (WAN), one must either augment the protocol to support a network environment or use an existing network transport mechanism. DNP 3.0 LAN/WAN was specifically defined to transport DNP traffic on the Internet Protocol Suite.

GE's DNP 3.0 LAN/WAN implementation was based on the specifications described in *DNP3 Specification, Volume 7, Networking*, according to the *Version 2.0 Draft E* of March 12, 2004. The official DNP 3.0 specifications can be found at [www.dnp.org](http://www.dnp.org).

**Table 6-3: DNP Parameters**

Name	Settings	Notes
DNP Over TCP	<b>Enabled</b> Disabled	If set to <b>Enabled</b> , network card will receive DNP over TCP requests.
DNP Over TCP Listen on Port	<b>20000</b> User Defined	TCP Listening Port
DNP over UDP	<b>Enabled</b> Disabled	If set to <b>Enabled</b> , network card will receive DNP over UDP requests.
DNP Over UDP Listen on Port	<b>20000</b> User Defined	UDP Listening Port
UDP Respond to	Client Port <b>User Defined</b>	If set to <b>Client Port</b> , UDP response will be sent to the UDP Request Port. Otherwise, UDP Response will be sent to a user-defined port number. Default is fixed at 20000.
UDP Addressing	Unicast Broadcast  <b>Unicast &amp; Broadcast</b>	If set to <b>Unicast &amp; Broadcast</b> , all UDP requests are accepted. If set to Unicast, network card will check to see if the UDP Destination Address matches the meter's IP Address. If set to Broadcast, network card will check to see if the UDP Destination Address is 255.255.255.255. If no match, the UDP connection is refused.
Validate Sources IPs	<b>Validation Disabled</b>  1 IP Address  2 to 4 IP Addresses	If set to Disabled, network card will not perform validation on any incoming IP Addresses.  If set to 1 to 4, network card will perform validations on every IP Address defined by user.

Table 6-3: DNP Parameters

Name	Settings	Notes
Validate Source Ports	<b>No</b> Yes	If set to No, network card will not perform validations on incoming TCP and UDP Ports for a given IP Address.
IP Addresses	User Defined	Up to 4 IP Addresses to validate.
Subnet Mask	User Defined	Masking bits applied to IP Address. When defined properly, user can specify validation on a single (or a range of) IP Address.
TCP Ports, Start and End	User Defined	TCP Port Range to be validated.
UDP Ports, Start and End	User Defined	UDP Port Range to be validated.



Settings in **bold** are default for Standard Mode

GE's DNP 3.0 LAN/WAN feature is available for certain EPM advanced meters with INP-100/102 Network Card. Currently, advanced power meters with INP-100/102 have this feature. If a user chooses to use this feature, the user has to configure the EPM meter's DNP Custom Classes Map in the meter's Device Profile. See Chapter 4 of this manual for configuration screens and details.

### Modes of Operation

**Disabled:** Feature is disabled. No DNP 3.0 LAN/WAN communication will be accepted.

**Standard:** Feature is enabled. Most communication parameters are fixed, except the port number to which UDP packets respond. Security features are not available.

**Manual:** Feature is enabled. All communication parameters are configurable. Security features are available.

A single DNP Over TCP connection and a single DNP Over UDP connection will be available when it is enabled. While DNP Over TCP connections may be closed at the decision of the network card, the main meter might also determine that the current DNP Over TCP connection should be closed.

Since INP-100/102 has several built-in servers, the DNP LAN/WAN TCP and UDP Listen on Ports defined by the user cannot be one of the following:

### Example of setting up validation for IP Addresses

1. Set Validate Source IPs to 1 IP Address.
2. Set Validate Source ports to Yes.
3. Enter IP address, such as 10.0.0.101.
4. Enter mask, such as 255.255.255.128.
5. Enter TCP ports range, such as 20000-20000.



6. Enter UDP ports range, such as 20000-20000.

As a result, a valid DNP 3.0 LAN/WAN request must come from a device with IP address of 10.0.0.1 to 10.0.0.127, with TCP and UDP ports set at 20000.

If a DNP Over TCP connection was established and Validation was also enabled, any new incoming DNP Over UDP connection has the same IP Address as the TCP connection. If they are different, the UDP connection will be closed.

The DNP address in the DNP LAN/WAN request should always be 1. All incoming communication for DNP LAN/WAN will go to the main meter and no DNP communication will go to the INP-100/102's gateway port.

Name	Port Number
Echo	7
FTP Server Data	20
FTP Server Control	21
Web Server	80
Modbus TCP Server	502


## 6.6 Customizing Screens

### 6.6.1 Configuring WebExplorer©

All polled data is stored in an XML file: poll\_data.xml. Each polled item is located in its DEVICE\_x section as it is programmed in the **poll\_profile.xml** file. The standard data format for each device is:

up to 64, each with its D\_UID, D\_LABEL and D\_VALUE.

This XML file can be viewed directly in your browser. To display it on a customized web page, you must set up your browser to run JavaScript. (Configuring XML is detailed in section 6.6.2.)



Auto Refresh Rate is set in the SetTimeout ()Function (see Java Script example below).

#### Example of the data file:

```
<?xml version="1.0" encoding="UTF-8"?>
<!--Embedded network server polled data-->
<GE_Multilin_DATA>
<GE_Multilin_SYSTEM>
</GE_Multilin_SYSTEM>
<DEVICE_1>
    <DEV_NAME>Meter Demo 1</DEV_NAME>
    DEV_TYPE>Meter 1250</DEV_TYPE>
    <item D_UID="1_1" D_LABEL="Inst Van"
D_VALUE="+122.46"><item>
</DEVICE_1>
<DEVICE_2>
    <DEV_NAME>N/A</DEV_NAME>
```

```

DEV_TYPE></DEV_TYPE>
<item D_UID="2_1" D_LABEL="Inst Watt" D_VALUE="+0.08 k"></
item>
</DEVICE_2>
</GE_Multilin_DATA>

```

### Displaying a value in an HTML file: (Use JavaScript in the web browser)

Define a unique name for a value to be displayed, such as data\_name. Insert [CODE] in the HTML file where it will be displayed.

Create JavaScript code inside the HTML file (Auto Screen Refresh is set at 5000ms in the Set Timeout () Function; see Example below) :

#### Example:

```

<Script language=Javascript>
<!--var disp_value;
var timerID;
var tmp_name;
var xmlDoc=new ActiveXObject("MSXML.DomDocument");
xmlDoc.async=true;
xmlDoc.onreadystatechange=do_get_data;
function do_get_xml()
{
    xmlDoc.load("poll_data.xml");
}
function do_get_data()
{
    if (xmlDoc.readyState == 4)
    {
        if (xmlDoc.documentElement == null)
        {
            timerID = setTimeout("do_get_xml();",5000);
        }
        else
        {
            disp_value =
            xmlDoc.documentElement.selectSingleNode
            ("//item[@D_UID='1_1']").
            getAttribute("D_VALUE");
            data_name.innerHTML = disp_value;
            timerID = setTimeout("do_get_xml();",5000);
        }
    }
}

```

```
//--></SCRIPT>
```



Inside the <body> of the HTML file, add on the following:

```
Load="do_get_xml () "
```

### Server Side Include Functions

These functions will send data directly to the browser as part of a requested document.

#### Example of using Server Side Include Functions:

1. In HTML file, add to the first line of that file

```
<!-- ** THIS FILE DOES CONTAIN REALTIME DATA ** -->
```

Without that line, any server side Include functions will not be processed by the web server.

2. Inside the HTML file where you want the info displayed, add

```
<!--#exec cgi="/[server_side_include_function_name]"-->
```

where [server\_side\_function\_name] can be one of the function names.

3. To display stored email #1's date/time, add the following to your HTML file at the location where you want the data displayed:

```
<!--#exec cgi="/ssi_show_email_date_time 1"-->
```

**Table 6-4: General Functions**

Server Side Include Function Name	Parameter	Description
get_ip.fn		Show local IP address

**Table 6-5: Diagnostic Functions**

Server Side Include Function Name	Parameter	Description
ssi_diag_cpu		Show CPU
info ssi_diag_ethernet_hardware		Show ethernet hardware
info ssi_diag_firmware		Show firmware
info ssi_diag_ftp_server		Show FTP Server
info ssi_diag_imported_files		Show FTP client/imported files status
ssi_diag_memory		Show memory
info ssi_diag_modbus_com		Show all Modbus communication info
ssi_diag_modbus_tcp_server		Show Modbus TCP Server info

Table 6–5: Diagnostic Functions

Server Side Include Function Name	Parameter	Description
ssi_diag_modem		Show internal modem (INP102) status
ssi_diag_system		Show system info, such as start time
ssi_diag_web_server		Show Web server info
stats.fn		Show ethernet communication status

Table 6–6: Stored E-mail Functions

Server Side Include Function Name	Parameter	Description
ssi_show_email_date_time	1 to 10	Show stored email's date/time
ssi_show_email_subject	1 to 10	Show stored email's subject text
ssi_show_email_from	1 to 10	Show stored email's from text
ssi_show_email_to	1 to 10	Show stored email's to text
ssi_show_email_cc	1 to 10	Show stored email's cc text
ssi_show_email_device_name	1 to 10	Show stored email's device name text
ssi_show_email_contact_person	1 to 10	Show stored email's contact person name
ssi_show_email_contact_phone	1 to 10	Show stored email's contact phone number
ssi_show_email_alarm_ids	1 to 10	Show stored email's alarm IDs
ssi_show_email_alarm_names	1 to 10	Show stored email's alarm names
ssi_show_email_alarm_details	1 to 10	Show stored email's alarm details
ssi_show_email_send_status	1 to 10	Show stored email's send status
NOTE: 1 = Newest, 10 = Oldest STORED EMAIL FUNCTIONS		

Table 6–7: Special Functions for MODBUS DEVICE 1

Server Side Include Function Name	Parameter	Description
ssi_show_pt		Show PT ratio

Table 6-7: Special Functions for MODBUS DEVICE 1

Server Side Include Function Name	Parameter	Description
ssi_show_ct		Show CT ratio
ssi_show_system		Show hookup info
ssi_show_dev_type		Show device type/model
ssi_show_dev_name		Show device name
ssi_show_boot		Show boot firmware version
ssi_show_run_time		Show runtime firmware version
ssi_show_dsp_boot		Show DSP firmware boot version
ssi_show_dsp_runtime		Show DSP runtime firmware version
ssi_show_sn		Show device serial number
ssi_show_com_state		Show COM firmware runtime state
ssi_show_dsp_state		Show DSP firmware runtime state
ssi_show_pw_state		Show password protection state
ssi_show_mac		Show ethernet MAC address
ssi_show_ip		Show IP address
ssi_show_mask		Show subnet mask
ssi_show_gateway		Show default gateway IP address
ssi_show_dnp_lan_wan		Show DNP LAN/WAN status

### 6.6.2 Configuring WebXML©

The term XML stands for EXtensible Markup Language. XML is a markup language similar to HTML which is used to describe data.

HTML displays the data. XML does not replace HTML; it compliments HTML.

An XML document is information wrapped in XML tags. A piece of software has to be written to send, receive or display the document.

#### The “Rules” of XML

1. The first line of the document, the XML declaration, defines the XML version and the characters used in the document.
2. All XML elements MUST have a closing tag. It is illegal to omit the closing tag.
3. XML tags are case sensitive.
4. All XML elements must be properly nested.
5. All XML documents must have a root tag (first tag in an XML document).

6. Attribute values must always be quoted. It is illegal to omit quotation marks around attribute values.
7. Comment syntax is similar to HTML. <!--This is a comment-->

### Example of Root Tag and Elements:

The first tag in an XML document is the root tag. All XML documents must contain a single tag pair to define the root element. All other elements must be nested within the root element.

All elements can have subelements ("children"). Subelements must be correctly nested within their parent elements as shown below:

```
<root>

    <child>
        <subchild>....</subchild>
    </child>

</root>
```

### Example of Attributes:

```
<data id="1" value="123"></data>
```

### Poll\_profile.xml:

File configured to poll parameters of each device

**Root tags:** <GE\_Multilin\_POLL\_DATA> and </GE\_Multilin\_POLL\_DATA>

**System elements:** <GE\_Multilin\_SYSTEM> and </GE\_Multilin\_SYSTEM>

Contains system parameters and email addresses

General attribute:

```
<item DATA_POLL_DELAY="400"
    ALARM_POLL_DELAY="1000"
    SYSTEM_COMM_TIMEOUT="1000"
    ALARM_CONTACT_PHONE=" "
    ALARM_CONTACT_PERSON="Administrator"
></item>
```

**Table 6–8: System Attributes**

Attribute	Description	Settings
DATA_POLL_DELAY	Poll delay between each Modbus poll, in milliseconds	Min=500 Max=65536 Default=500
SYSTEM_COMM_TIMEOUT	System communication timeout, in milliseconds	Min=500 Max=32000 Default=500
ALARM_POLL_DELAY	Poll delay between each Modbus poll for each device's alarm polling, in milliseconds	Min= 1000 Max=65535 Default=1000

Table 6–8: System Attributes

Attribute	Description	Settings
ALARM_CONTACT_PHONE	Alarm contact phone number	Max size=10 digits
ALARM_CONTACT_PERSON	Alarm contact person name	Max size=64 characters

### Email Attributes

```

<item EMAIL_1="" FORMAT_1="long"
    EMAIL_2="" FORMAT_2="long"
    EMAIL_3="" FORMAT_3="long"
    EMAIL_4="" FORMAT_4="short"
    EMAIL_5="" FORMAT_5="short"
    EMAIL_6="" FORMAT_6="short"
    EMAIL_7="" FORMAT_7="short"
    EMAIL_8="" FORMAT_8="short"
></item>

```

### Device Elements <DEVICE\_X> and </DEVICE\_X>

where X is from 1 to 16.

Contain parameters for each device.

### General Attributes

```

<item DEV_TYPE="Meter 1250"
    DEV_PROTOCOL="Modbus RTU"
    DEV_NAME="Meter Demo 1"
    DEV_ADDRESS="1"
    DEV_IP=""
    DEV_MAX_PACKET_LEN="127"
    DEV_POLL_ALARM="yes"
    DEV_ALARM_OPTIONS="1+2+3+4+5+9"
    DEV_ALARM_DELAY="2000"
    DEV_COMM_TIMEOUT="750"
    DEV_PARENT="1"
></item>

```

### Polling Data Elements <DEV\_DATA> and </DEV\_DATA>

Polling data attributes, up to 64 in each <DEV\_DATA> element:

```

<item D_UID="1_1"
    D_LABEL="Inst Van"
    D_ADDR="180"
    D_LENGTH="2"
    D_TYPE="7"

```



```

D_USE_SPECIAL="3"
D_VALUMODE="Primary"
></item>

```

Table 6–9: E-mail Attributes

EMAIL_X	Email address, X is from 1 to 8	Max size = 64 characters
FORMAT_Y	Email format, Y is from 1 to 8	Strings 'long' or 'short'

Table 6–10: System Elements

Device	Element Description	Settings
DEV_TYPE	Supported device name	Generic Modbus EPM 1250 (EPM 9450) EPM 1252 (EPM 9650) EPM 1260 EPM 1262 EPM 1270 EPM 1272 (EPM 9800) [~DEVICE_TYPE_LABEL] = Auto detect device's type (Only supported in EPM devices)
DEV_PROTOCOL	Protocol name	Modbus RTU Modbus TCP
DEV_NAME	User assigned device name	Max = 32 characters [~DEVICE_LABEL] = Use the name stored inside the device (Only supported in EPM devices)
DEV_ADDRESS	Device address	Modbus protocol = 1 to 247
DEV_IP	IP address for Modbus TCP devices	xxx.xxx.xxx.xxx
DEV_MAX_PACKET_LEN	Max modbus registers for a device's response buffer	EPM = 127 EPM & DMMS = 50
DEV_POLL_ALARM	Enable or disable device alarm poll function	Yes = Enable No = Disable

Table 6–10: System Elements

Device	Element Description	Settings
DEV_ALARM_OPTIONS	Alarm poll options	1 = Limits changed 2 = Inputs changed 3 = Waveform captured 4 = PQ (CBEMA) event captured 5 = Control output changed 9 = Communication failure
DEV_ALARM_DELAY	Delay time for reporting alarm condition (in milliseconds) for limit and input type alarms	Min = 0 Max = 300000 Default = 0
DEV_COMM_TIMEOUT	Device communication timeout (in milliseconds)	Min = 500 Max = 32000 Default = 500
DEV_DATA_FORMAT	Data format	0 to 0.000000
DEV_PARENT	Parent device ID (see NOTE)	Value from 1 to 16
DEV_MODBUS_REG_BASE	Device's modbus register base is either	0 based integer value or 1 based integer value (default)
DEV_TCP_PORT	Remote Modbus TCP device's port number	Default setting = 502

Table 6–11: Data Element Attributes

Attribute	Description	Settings
D_UID	User assigned device polling data unique ID	Max = 16 characters
D_LABEL	User assigned data label	Max = 32 characters
D_ADDR	Modbus register address	0 or 1 based integer value
D_LENGTH	Number of Modbus registers	
D_TYPE	Data type	For EPM9450/9650, 9800 devices, use Fx Communication Data Formats For Generic Modbus Device Type, see NOTE below for values
D_USE_SPECIAL	Special functions	See NOTE*

Table 6–11: Data Element Attributes

Attribute	Description	Settings
D_VALUEMODE	Value mode	Raw Primary Secondary Value (for Generic Modbus Device Type) Interpreted. See NOTE**
D_CHANNEL	Channel ID for I/O type values	(EPM only)
D_SHOW_KM	Format value with k or M	Auto = auto show k or M k = fixed to k M = fixed to M
D_NA_VAL	If a numerical value is set here and a real polled value matched with this number, a '***' string will be stored in the xml data file.	Numerical Value for '***' (EPM only)
D_FUNCTION_CODE	Modbus protocol function code	1, 2, 3 (default), 4
D_BYTE_ORDER	Data byte order for Generic Modbus device. (Settings if source is 0x12345678)	0 MSR, MSB 0x1234, 0x5678: MS reg first, MS byte first (default) 1 MSR, LSB 0x3412, 0x7856, MS reg first, LS byte first 2 LSR, MSB 0x5678, 0x1234, LS reg first, MS byte first 3 LSR, LSB 0x7856, 0x3412, LS reg first, LS byte first
D_SPECIAL	Generic multiplier value for Generic Modbus device; applied when D_USE_SPECIAL is set to 6	1 = Default
D_TAG_SPECIAL	Cross linked multiplier ID for Generic Modbus device	Setting is any unique D_UID's setting within polling profile
D_MASKING_TYPE	Data masking type for Generic Modbus device	0 = do nothing (default) 1 = NOT 2 = OR 3 = AND 4 = NOR 5 = NAND 6 = XOR 7 = XNOR

Table 6-11: Data Element Attributes

Attribute	Description	Settings
D_MASKING_VALUE	Data masking value for Generic Modbus device; setting is hex ASCII string for up to 8 bytes of data	0x0 = default Example of a 3 byte value: 0xAB12CD
D_CFG_FILE	Configuration file name for Generic Modbus device	Case sensitive file name up to 128 characters; the file must be available at system start up using FTP download
D_VALUE	Value processed by Total Web Solutions and stored in poll_data.xml file	
D_REF	Reference info or value for polled item; stored in poll_data.xml file	Data source is the configuration file



Parent device ID (DEV\_PARENT), for polling expansion beyond the 64 items per device limitation. If set, it will use the parent device's communication settings.



Values for Generic Modbus D\_TYPE:

- 1 = ASCII string
- 2 = 1 byte, signed high byte of the Modbus Register
- 3 = 1 byte, signed low byte of the Modbus Register
- 4 = 1 byte, unsigned high byte of the Modbus Register
- 5 = 1 byte, unsigned low byte of the Modbus Register
- 6 = 2 bytes, signed integer
- 7 = 2 bytes, unsigned integer
- 8 = 4 bytes, signed long integer
- 9 = 4 bytes, unsigned long integer
- 10 = 8 bytes, signed long long integer
- 11 = 8 bytes, unsigned long long integer
- 12 = 4 bytes, IEEE float
- 13 = 1 digit, 8 bits representation
- 14 = 1 digit, 4 bits representation (aka Packed BCD)
- 15 = 1 byte, signed
- 16 = 1 byte, unsigned
- 17 = 8 bytes, IEEE float



**\* Parameters for D\_USE\_SPECIAL:**

- 0 = do not multiply any number
- 1 = multiply by CT ratio (mainly used for current values)
- 2 = multiply by CT Aux ratio
- 3 = multiply by PT ratio (mainly used for voltage values)
- 4 = multiply by PT Aux ratio
- 5 = multiply by CT and PT ratio (mainly used for power, energy values)
- 6 = multiply by the value in D\_SPECIAL (generic modbus device only)



**\*\*** If D\_VALUEMODE is set to Interpreted, when used with Meter Input Values, the result will be a user-defined name in the Meter's Device Profile instead of a value of 0 or 1.

### Poll\_data.xml

Root tag: <GE\_Multilin\_DATA> and </GE\_Multilin?DATA>

One (1) system element: <GE\_Multilin\_SYSTEM> and </GE\_Multilin\_SYSTEM>

Eight (8) device elements: <DEVICE\_X> and </DEVICE\_X> where X is from 1 to 8.

In each of the 8 device elements: Device info elements: card copies data from poll\_profile.xml

<DEV\_NAME> and </DEV\_NAME>

<DEV\_TYPE> and </DEV\_TYPE>

Up to 64 polling data attributes: card copies data from poll\_profile.xml

```
<item D_UID="1_1"
      D_LABEL="Inst Van"
      D_VALUE="+126.06" (Data value) .
></item>
```

### Configuration File (for Generic Modbus Device)

The purpose of the configuration file is to allow the user to set what real value or information could be available in the poll\_data.xml file. Each configuration file allows the user to set up 8 interpreted values or strings. The configuration file's format is XML.

**Below is an example xml file with three values:**

```
<?xml version="1.0" encoding="UTF-8" ?>
<GE_Multilin_CONFIGURATION>
  <item CFG_COMPARE_TYPE="Value" CFG_VALUE="0" CFG_REF="Disabled" />
  <item CFG_COMPARE_TYPE="Value" CFG_VALUE="128" CFG_REF="Enabled" />
  <item CFG_COMPARE_TYPE="String" CFG_VALUE="107 EPM 1250"
    CFG_REF="EPM 1250 Meter" />
</GE_Multilin_CONFIGURATION>
```

The root tags are <GE\_Multilin\_CONFIGURATION> and </GE\_Multilin\_CONFIGURATION> with up to 8 items between the root tags.

CFG\_COMPARE\_TYPE settings are "Value" for numeric comparison or "String" for text comparison.

CFG\_VALUE can be a numeric value or text string (up to 256 characters) to be used for comparison.

CFG\_REF is any interpreted value or text string when the comparison returned a match (up to 256 characters for a text string).

D\_REF is the corresponding value in the poll\_data.xml file.

### Order of Data Processing for Generic Modbus Device

The steps in data processing are as follows:

- ▷ Set byte order
- ▷ Apply bit masking
- ▷ Apply multiplying factor
- ▷ Apply interpreted values from generic file(s)

#### 6.6.3 Configuring WebReacher©

Through the configuration of poll\_profile.xml, you can poll up to 8 individual devices or up to 512 unique items via Modbus RTU protocol or Modbus TCP protocol.

Devices supported: Any device that supports Modbus RTU or Modbus TCP protocol (with at least one available socket).

Devices supported for Advanced Features: EPM 9450/9650 and EPM 9800. (Use Generic Modbus device settings for EPM 4000, 5000, 6000, 7000 meters.)

System set-up: Set DATA\_POLL\_DELAY in milliseconds; the system will pause between each Modbus poll. Set SYSTEM\_COMM\_TIMEOUT in milliseconds.

**Example:**

```
<GE_Multilin_POLL_DATA>
  <GE_Multilin_SYSTEM>
    <item DATA_POLL_DELAY="400"SYSTEM_COMM_TIMEOUT="500"></Item>
  </GE_Multilin_SYSTEM>
</GE_Multilin_POLL_DATA>
```

Device Set-up: within the boundary of <DEVICE\_X> and </DEVICE\_X>

- ▷ Assign a device type, DEV\_TYPE.
- ▷ Assign a protocol, DEV\_PROTOCOL
- ▷ Assign user defined device name, DEV\_NAME (should be unique in a system).
- ▷ Assign Modbus device address, DEV\_ADDRESS.
- ▷ If protocol is Modbus TCP, assign the remote device's IP address and the TCP port number, DEV\_IP and DEV\_TCP\_PORT.
- ▷ Set max Modbus packet length in number of registers, DEV\_MAX\_PACKET\_LEN.

- ▷ Set device's communication timeout in milliseconds, DEV\_COMM\_TIMEOUT.  
The timeout value should be longer for devices that speak Modbus TCP than for devices that speak Modbus RTU, depending on network traffic.
- ▷ Set device's data display format, DEV\_DATA\_FORMAT, from 0 to 0.000000.
- ▷ You can expand the polling item limitation of 64 items per device by setting a device as a child device of a parent device.

For example, in <DEVICE\_X> section, if you set it to be the parent device, DEV\_PARENT must be X or 0. Then for <DEVICE\_Y>section, if you set the device to be a child device of X, set DEV\_PARENT to X. Other parameters can be omitted.

**Example:**

```
<GE_Multilin_POLL_DATA>
  <DEVICE_1>
    <item DEV_TYPE="EPM 1250"
      DEV_PROTOCOL="ModbusRTU"
      DEV_NAME="EPM Demo 1"
      DEV_ADDRESS="1"
      DEV_IP=""
      DEV_TCP_PORT=""
      DEV_MAX_PACKET_LEN="127"
      DEV_COMM_TIMEOUT="750"
      DEV_DATA_FORMAT="0.00"
      DEV_PARENT="1" >
    </item>
  </DEVICE_1>
</GE_Multilin_POLL_DATA>
```

## Polling Item Set-up

In each DEVICE\_X, DEV\_DATA section, you can have up to 64 items. Any extra items will be ignored.

- ▷ Set a unique ID, D\_UID, so any program can easily access this item.
- ▷ Set a data label, D\_LABEL (optional).
- ▷ Set Modbus register in decimal, 1 based, D\_ADDR.
- ▷ Set how many Modbus registers, D\_LENGTH. Note: Each register is 2 bytes long.
- ▷ Set data type, D\_TYPE. (See Modbus Protocol Mapping Manual.)
- ▷ Set special operations, such as multiplying PT or CT ratio, D\_USE\_SPECIAL.
- ▷ Set value mode, D\_VALUEMODE as primary, secondary or raw value.
- ▷ Set display units, D\_SHOW\_KM (optional).

▷ Set a N/A value, D\_NA\_VAL (optional).

**Example:**

```
<GE_Multilin_POLL_DATA>
  <DEVICE_1>
    <DEV_DATA>
      <item D_UID="1_1"
        D_LABEL="Inst Van"
        D_ADDR="180"
        D_LENGTH="2"
        D_TYPE="7"
        D_USE_SPECIAL="3"
        D_VALUEMODE="Primary"
      ></item>
      [...up to 64 items...]
    </DEV_DATA>
  </DEVICE_1>
</GE_Multilin_POLL_DATA>
```

#### 6.6.4 Configuring WebMod©

WebMOD© allows the network to interface with Modbus-based EIDs. WebMOD© supports 12 Modbus TCP sockets (12 simultaneous connections). The Modbus Port Number is 502. The Modbus Port Number is set on the Location Editor screen and Devices are added to the Network on this screen.



If you have a firewall in your system, you must ask your network administrator to grant communication access on TCP/IP Port 502.

#### Modbus TCP Format:

[6-byte Header] [Modbus RTU message without checksum]

Header detail: [2 Bytes - Sequences/Transactions ID] [2 Bytes - 0s] [2 Bytes - Length, Number of Bytes following]

**Example:**

Request:

01 03 00 00 00 06 01 03 00 00 00 02

Transaction #259, 6 Bytes long, Modbus RTU Request for Address 01, Function Code 03 (read holding registers), Start at Register 0 for 2 registers.

Response:

01 03 00 00 00 07 01 03 04 xx xx xx xx

Transaction #259, 7 Bytes long, Modbus RTU Response for Address 01, Function Code 03, 4 Bytes long data.



This will not support multiple Modbus requests and responses in a single Modbus TCP packet. For INP10 and INP100 Options, all requests with Modbus Address 01 will transmit to the meter itself. All other requests with Modbus Addresses other than 01 will transmit to the RS-485 Gateway Port.

### 6.6.5 Configuring WebAlarm©

The user must Enable this feature.

- ▷ From the Device Profile, click **Communication Ports**
- ▷ Click the **Advanced Settings** button.  
The following tabbed screens will appear:
- ▷ Click the **Services** tab.
- ▷ On that screen, click the **SMTP Client** box.

- ▷ Click the **Alarm/Email** tab.

The screen (shown here) allows you to configure one Email Address, which will be stored in the meter for single user or administrative use. Eight additional addresses can be programmed in the poll\_profile.xml file (see WebXML). The alarm format for the Administrative Address is always Long Format to insure that the alarm detail will be transmitted.

- ▷ Enter the following values on this screen to configure the **Administrative Address**:
  - Email Server IP Address/Name:
  - IP Address, Name, 10.0.0.250, or mail@abccorp.com.
  - Email Server Port: Port 25 is the Default.
  - Email Monitor Email Address/To Address: the Primary Email Address to be notified of an event.
  - Return/Reply Address/From Address: Administrative Email Address.

- Email Subject Text: Typical Message might be "Limits Exceeded".

If your email server (SMTP server) requires authentication before sending out the email, you must enable the checkbox and supply the correct user name and password in the configuration screen or the device will not be able to send out emails. This feature is implemented according to *ESMTP Specification* and supports 64-bit encryption for the user name and password.

▷ Click **OK** or **Cancel**.

### Configure more Email Recipients:

Edit the poll\_profile.xml file saved in FTP Server (see FTP Server):

▷ From EMAIL\_1 to EMAIL\_8, enter the email address within the double quotes

▷ From FORMAT\_1 to FORMAT\_8, enter the format name as either "short" or "long" within the double quotes.

A section of a poll\_profile.xml file is shown below without values entered.

```
<GE_Multilin_POLL_DATA>
    <GE_Multilin_SYSTEM>
        <item EMAIL_1="" FORMAT_1=""
            EMAIL_2="" FORMAT_2=""
            EMAIL_3="" FORMAT_3=""
            EMAIL_4="" FORMAT_4=""
            EMAIL_5="" FORMAT_5=""
            EMAIL_6="" FORMAT_6=""
            EMAIL_7="" FORMAT_7=""
            EMAIL_8="" FORMAT_8="" >
        </item>
    </GE_Multilin_SYSTEM>
</GE_Multilin_POLL_DATA>
```

### Short Format

For all handheld mobile devices with text messaging service capable of receiving up to 160 characters. Character number includes sender address, subject and body plus additional separator characters. This format is defined by GE Multilin and the user cannot modify it.

**Example** of the Short Format:

```
[64 characters of sender's email address]##[32 characters of Meter ID]
#Alarm[10digit operator's phone number]
IDs1+2+3+4+5+6+7+8+9+10+11+12+13+14+15+16
```

### Long Format

For all handheld mobile devices and PC users who can receive regular email. This includes detailed alarm information.

**Example of Long Format:**

Device Name: Meter Demo 1  
 Contact Person: Administrator  
 Contact Phone: 1234567890  
 Alarm IDs: 1+2+3+4  
 Alarm Names:  
 - (1) Limits changed  
 - (2) Inputs changed  
 - (3) Waveform captured  
 - (4) PQ (CBEMA) event captured

Alarm Details:

Limits:

- (4) 1s IA, Below Limit 2, Combination=OR, value = +0.38
- (5) 1s IB, Below Limit 2, Combination=OR, value = +0.38
- (6) 1s IC, Below Limit 2, Combination=OR, value = +0.38

Inputs:

- (1) HSI Input 1 BK101 Off
- (3) HSI Input 3 Closed
- (4) HSI Input 4 Closed

### Configure Alarm Polling Options:

- ▷ Enter values within the double quotes.
- ▷ To enable the polling for a device, set DEV\_POLL\_ALARM to **Yes**; to disable it, set **No**.

Alarm polling options: 1 to 9 (See table below).

The default is to send alarm emails for all options, 1 to 9.

You can configure the polling profile to have any combination of options:

- ▷ Edit the poll\_profile.xml.
- ▷ Set up the alarm polling options by concatenating the options IDs, such as: "1+2+3+4+5+9".
- ▷ Set the alarm delay for limits in Milliseconds (a value of 1000 = 1 second).  
 If a limit condition occurs for 1 second or more, an alarm email will be sent.

```
<GE_Multilin_POLL_DATA>
  <DEVICE_x>
    <item DEV_POLL_ALARM=""
      DEV_ALARM_OPTIONS=""
      DEV_ALARM_DELAY="" >
    </item>
  </DEVICE_x>
</GE_Multilin_POLL_DATA>
```



Most of the Alarm Triggering Conditions for EPM devices rely on the device's configuration in the Device Profile. Make sure that the settings are correct for Limits, Inputs, Waveforms, etc.

**Table 6–12: Alarm Polling Options**

Option ID	Option Name	Description
1	Limits exceeded	Any limit condition exceeded for the 32 EPM limit channels
2	Inputs abnormal condition	Any internal digital input abnormal condition
3	Waveform captured	When EPM captures a waveform
4	PQ (CBEMA) event captured	When EPM captures a PQ event
5	Control Output changed	When any relay modules connected to meter changes state
9	Communication Failure	Network card has difficulty talking to EPM Meter

### Configure Alarm Polling for more individual devices.

Edit the poll\_profile.xml file for each device's section. Configure the parameters.

```
<GE_Multilin_POLL_DATA>
<DEVICE_x>
<item DEV_POLL_ALARM=" "
DEV_ALARM_OPTIONS=" "
></item>
</DEVICE_x>
</GE_Multilin_POLL_DATA>
```

### Common Problem

If you entered a name for the SMTP Server instead of an IP Address, make sure your DNS Server is working and you have either set a DSP IP inside the meter or your DNS can supply a DNS IP. Otherwise, if it cannot resolve the name to an IP translation; no email will be sent.

### Stored Emails

User can access the stored\_emails.htm page from any internet browser. The last 10 emails sent will be stored in the RAM on a FIFO basis (First In, First Out) and will be displayed in descending order. The page will be cleared after a complete system restart.

---

## 6.7 FTP Server

A built-in FTP Server is available for INP100. It has a 3-user limit; three users can connect to the FTP Server simultaneously. The FTP Server logon User Name and Password are stored in the INP100 card, not in the meter's programmable settings. The Initial FTP Server User Name and Password are: GE Multilinnet and inp100. The FTP Server's quota is 4Meg RAM.

To change the Initial FTP User Name and Password, switch to INP100's boot mode and change the Initial Settings. (See section 6.9.)

To copy a file into the FTP Server, simply copy the file and paste it into the Server. If there is a file with the same file name in the Server, you must delete the existing file first, then copy and paste the new file.

If the memory quota is filled before a new file is completely copied into the FTP Server, that file will be deleted and an error will be sent to the FTP Client.

Since poll\_profile.xml and poll\_data.xml file sizes can be dynamic, it's preferable to have some reserved space in the FTP Server for those files.

**Example:** After a test run, if poll\_data.xml is approximately 1kB, you should reserve at least 4kB for those files. The ratio is about 1 to 4.

## 6.8 Update Network Card Firmware from a Browser (in Runtime Mode ONLY)

Network card firmware can be easily updated via the Web. Follow these steps:

- ▷ Start your browser.
- ▷ If you know the meter's IP Address, type it in the browser's URL Address Bar.  
The Main WebExplorer screen appears.

**GE Power Leader Web Solutions**

Meter Name: 00121689  
Date/Time: 2007-04-17 16:15:09.560

**Voltage/Frequency**

	Instantaneous	Maximum	Minimum
Volts AN	0.00	275.68	0.00
Volts BN	0.00	276.97	0.00
Volts CN	0.00	275.90	0.00
Volts A-B	0.00	479.64	0.00
Volts B-C	0.00	479.65	0.00
Volts C-A	0.00	479.40	0.00
Frequency	0.00	60.03	0.00

**Current**

	Instantaneous	Maximum	Minimum
Amps A	0.00	23.49	0.00
Amps B	0.00	19.79	0.00
Amps C	0.00	19.78	0.00
Amps N (calculated)	0.00	0.89	0.00

Last Max Reset: 2007-02-01 13:25:37.110

- ▷ Click **Tools**.
- ▷ Click on **Firmware Upgrade**, or add **/update1.htm** to the end of the URL.  
The Enter Network Password screen will appear and ask for a User Name and Password.
- ▷ Type User Name and Password into Windows.

**Enter Network Password**

Please type your user name and password.

Site: 3.94.246.209  
Realm: Administrator

User Name:   
Password:

☐ Save this password in your password list

OK Cancel

Initial User Name = eignet


Initial Password = inp100



See section 6.9 to change User Name and Password.

- ▷ Click **OK**.

The Update Run-Time Firmware screen appears:



- ▷ Click the **Browse** button to select the correct runtime firmware file.
- ▷ Click on the **Update Run-Time Firmware** button to continue.

The whole process can take several minutes. Make sure that during the process you do not close the Update Run-Time Firmware screen (or update1.htm browser window). During the update process, the INP100 Update Run-Time Firmware Status screen appears. It displays the current status of the update.

- ▷ If the update is successful, restart the connected meter.

Restart one of two ways:

- ▷ Go to **reset\_ethernet.htm**. (Click on **Restart**.)
- ▷ Power down/up the connected meter.

## 6.9 Update Network Card Firmware from GE Communicator EXT

Using this screen is the ONLY way to change the Boot Firmware and Username and Password. Changes are easy with this screen. Usage is the same for all meters. Connections are different.



While you are on this screen, the Network Card is in BOOT MODE.



Changes made here DO NOT modify the meter's Device Profile.

- ▷ Using an RS-232/RS-485 converter, connect your computer to the EPM 9800 Port 1.  
Port 1 is RS- 485, so an RS-232/RS-485 Converter is required to create an RS-232 serial connection.
- ▷ For EPM 9450/9650, move the switch beneath Port 1 to select RS-232; no converter is required.  
Make sure that the meter is connected to your network and is operating properly.



This screen is not supported by meters with the INP10 Option.

- ▷ Close the **Device Status** window.
- ▷ Select from the menu bar **Tools/Network Card Settings**.  
The Network Card Run Time Update screen appears (see below).
- ▷ Make sure there is a check mark in the checkbox at the top of the window for **Communicate through Meter**. If there is no check, click on the box.
- ▷ Click **Connect** at the top left of the window. (Progress is shown in a sub-window at the bottom of the screen.)  
When connected the "Boot Version" window lists data about the Network board.



A blinking red bar at the bottom of the window (and a pinging sound) will remind the user that the meter is now in Boot Mode and the meter is not available to other users via the Internet.



**Network Card RunTime Update**

**Connect** ☒ **Communicate through Nexus**

**Boot Version**  
 Copyright 2002 Electro Industries/GaugeTech (EIG) - All Rights Reserved.  
 INP-100 ColdFire MCF5272 (EIG) 10/100 Base-T Network Option  
 Runtime Firmware: v0.1 (Build 20) Checksum = 0x753, Length = 0xCE902  
 Boot Firmware : v1.0 (Build 39) Checksum = 0x114A, Length = 0x20418  
 Flash Memory Size: 2MB  
 SDRAM Size : 32MB

**Flash File Update Settings**

Server: 0.0.0.0  
 Client: 0.0.0.0  
 Gateway: 0.0.0.0  
 Net Mask: 255.255.255.0  
 Runtime File:  
 Boot File:

Retrieve Settings Write Settings  
 Update Run time Update Boot

**Run Time File Update Settings (Fixed)**

Base: 16  
 Baud Rate: 115200  
 File type: S-Record  
 Mac Address: 00.01.58.FF.F5.F5

**Firmware Update Via the Web Username and Password**

	Current	New
Username		
Password		

Change Password

Read command completed

OK Help

- ▷ Click on **Retrieve Settings** to retrieve the network settings used to download Flash Files for updating the network option board via TFTP. (The Initial Settings appear in the settings windows.)
- ▷ In the text boxes provided, enter the name of the Runtime Update File and/or Boot Update File.  
Check with your Network Administrator and make any changes necessary to the network settings.



These changes facilitate file transfers while in Boot Mode; there is **no permanent change**. Click on **Write Settings** to send the updated settings to the Meter. A screen will ask, "Are you sure you want to Update the Flash File Settings?" Click **Yes** to update. The sub-window will display "Write Completed".

- ▷ Start up a TFTP server on your computer.
- ▷ Set the default file path for the TFTP server to the location of the Runtime/Boot Flash file location (TFTP server software is available from GE.)  
See Appendix D for more information on TFTP.).
- ▷ To update Runtime/Boot, click on **Update Runtime** or **Update Boot**.
- ▷ Click **Yes** to verify that you would like to update the Runtime/Boot firmware.  
After the update is completed, the message **Update Completed** will appear in the sub-window.
- ▷ To Change the Username and Password, type in the Current Username and Password, then the New Username and Password.


The Initial Username and Password are GE Multilinnet and inp100. You will not be able to change the Username and Password unless you know the Current Username and Password. (A screen will ask, "Are you sure you want to change the Username and Password?") If you click Change Password, a note in the sub-window will confirm the Password changes.

- ▷ To close the Network Card Runtime Update window, click **OK**.  
GE Communicator EXT will update the meter. After approximately one minute the network will resume its normal functions.




It is VERY IMPORTANT to store the passwords in a safe place and to change them frequently.


## 6.10 WebXML Flow Chart



## 6.11 WebExplorer Flow Chart



## 6.12 WebAlarm Flow Chart







1  
011  
101110011100  
01100111110001  
000111010110110  
11110001001101  
010101110010  
011  
1

## GE Communicator EXT

# Chapter 7: Real-Time Polling

---


### 7.1 Overview

The Real-Time Polling features of GE Communicator EXT are used to continuously view instantaneous and stored values within one or several EPM Series 6000, 7000 and 9000 Meters. GE Communicator EXT provides tabular views of Metered Values, Circuit Measurements, Interval Data, Power Quality Values, Pulse Data and Input/Output Status and Accumulations.

The Real-Time Polling features are divided into three groups, accessed by clicking the **Real-Time Polling** menu:

1. Real-Time Readings
2. Revenue, Energy and Demand Readings
3. Power Quality and Alarms.

All screens are not available on all models. (EPM 6000 meters have a unique screen.)



GE Communicator EXT receives data from one connected device at a time—by default, the Primary Device. To view polling data from multiple devices, either select Poll Multiple Devices (section 7.2.4) or change the Primary Device (select Connection, Change Primary Device; see section 2.7).



Clicking the **Polling** button on the Tool Bar is the same as selecting **Instantaneous Polling** from the Menu Bar. Clicking the **Phasors** button on the Tool Bar is the same as selecting **Phasors** from the Menu Bar.




## 7.2 Real Time Readings

### 7.2.1 Instantaneous Polling

To view instantaneous polling data for the primary device, either

- ▷ Select **Instantaneous Polling** from the Real-Time Polling menu,
- OR
- ▷ Click the **Polling** button on the Tool Bar.

The Instantaneous Polling screen appears.



The graphic representation on the right side of the screen displays the options listed in the pull-down menu beneath it (Volts A, B, C; Current A, B, C). Select either spectrum or waveform view by clicking on the Spectrum/Waveform button.

- ▷ Click the radio button in the lower right corner to select either **1 Second** or **0.1 Second** measurements for all data.
- ▷ Click **Print** to send a copy of the screen to a printer.
- ▷ Click **OK** to return to the main GE Communicator EXT screen.

### 7.2.2 Poll Max and Min Readings

To view the Maximum and Minimum readings for the currently connected device,

- ▷ Select **Poll Max and Min Readings** from the Real-Time Polling menu.

The Max and Min Readings with Time Stamps screen appears.



The Max/Min is the Max/Min of the Thermal Average in the profile.

Channel	Positive Maximum		Positive Minimum		Negative Maximum		Negative Minimum	
	Value	Time	Value	Time	Value	Time	Value	Time
Volts AN	13.028	3/30/2006 15:00:00.00	0.000	4/10/2006 16:06:07.05				
Volts BN	13.038	3/30/2006 15:00:00.00	0.000	4/10/2006 16:06:07.05				
Volts CN	13.038	3/30/2006 15:00:00.00	0.000	4/10/2006 16:06:07.05				
Volts ALK	0.008	3/30/2006 14:59:42.05	0.000	3/30/2006 14:59:42.05				
IA	0.99	3/30/2006 10:27:53.06	0.00	3/30/2006 14:59:42.05				
IB	0.99	3/30/2006 10:41:49.04	0.00	3/30/2006 14:59:42.05				
IC	0.99	3/30/2006 10:32:18.06	0.00	3/30/2006 14:59:42.05				
IIm	0.00	3/30/2006 14:59:42.05	0.00	3/30/2006 14:59:42.05				
INc	0.99	3/30/2006 14:09:51.06	0.00	3/30/2006 14:59:42.05				
Volts AB	0.008	3/30/2006 14:59:42.05	0.000	3/30/2006 14:59:42.05				
Volts BC	0.008	3/30/2006 14:59:42.05	0.000	3/30/2006 14:59:42.05				
Volts CA	0.008	3/30/2006 14:59:42.05	0.000	3/30/2006 14:59:42.05				
VA A	0.00	3/30/2006 14:59:42.05	0.00	3/30/2006 14:59:42.05				
VA B	0.00	3/30/2006 14:59:42.05	0.00	3/30/2006 14:59:42.05				
VA C	0.00	3/30/2006 14:59:42.05	0.00	3/30/2006 14:59:42.05				
VA Total	0.00	3/30/2006 14:59:42.05	0.00	3/30/2006 14:59:42.05				
VAR A	0.00	3/30/2006 14:59:42.05	0.00	3/30/2006 14:59:42.05	*****	0/0/0 00:00:00.00	*****	0/0/0 00:00:00.00
VAR B	0.00	3/30/2006 14:59:42.05	0.00	3/30/2006 14:59:42.05	*****	0/0/0 00:00:00.00	*****	0/0/0 00:00:00.00
VAR C	0.00	3/30/2006 14:59:42.05	0.00	3/30/2006 14:59:42.05	*****	0/0/0 00:00:00.00	*****	0/0/0 00:00:00.00
VAR Total	0.00	3/30/2006 14:59:42.05	0.00	3/30/2006 14:59:42.05	*****	0/0/0 00:00:00.00	*****	0/0/0 00:00:00.00
Watt A	0.00	3/30/2006 14:59:42.05	0.00	3/30/2006 14:59:42.05	*****	0/0/0 00:00:00.00	*****	0/0/0 00:00:00.00
Watt B	0.00	3/30/2006 14:59:42.05	0.00	3/30/2006 14:59:42.05	*****	0/0/0 00:00:00.00	*****	0/0/0 00:00:00.00
Watt C	0.00	3/30/2006 14:59:42.05	0.00	3/30/2006 14:59:42.05	*****	0/0/0 00:00:00.00	*****	0/0/0 00:00:00.00
Watt Total	0.00	3/30/2006 14:59:42.05	0.00	3/30/2006 14:59:42.05	*****	0/0/0 00:00:00.00	*****	0/0/0 00:00:00.00
Frequency	60.011	3/30/2006 15:01:00.04	0.000	4/10/2006 16:06:07.05				
Pwr Factor A								
Pwr Factor B								
Pwr Factor C								
Imbalance V	100.00	4/10/2006 16:06:07.05	99.99	3/30/2006 14:59:42.05				
Imbalance I	90.26	3/30/2006 14:59:42.05	0.00	3/30/2006 14:59:42.05				
THD Volts AN/AB	5.46	3/30/2006 15:02:20.03	0.00	4/10/2006 16:06:07.05				
THD Volts BN/BC	5.46	3/30/2006 15:02:20.03	0.00	4/10/2006 16:06:07.05				
THD Volts CN/CA	5.46	3/30/2006 15:02:20.03	0.00	4/10/2006 16:06:07.05				
THD I A	10.15	3/30/2006 09:37:00.04	0.00	3/30/2006 14:59:42.05				
THD I B	9.76	3/30/2006 09:37:00.04	0.00	3/30/2006 14:59:42.05				
THD I C	9.77	3/30/2006 09:37:00.04	0.00	3/30/2006 14:59:42.05				
KFactor I A	44.52	3/30/2006 09:37:00.04	0.00	3/30/2006 14:59:42.05				
KFactor I B	38.96	3/30/2006 09:37:00.04	0.00	3/30/2006 14:59:42.05				
KFactor I C	37.58	3/30/2006 09:37:00.04	0.00	3/30/2006 14:59:42.05				
Ph Angle Volts AN								
Ph Angle Volts BN								
Ph Angle Volts CN								
Q1 Pwr Factor A	0.000 LAG	0/0/0 00:00:00.00	0.000 LAG	3/30/2006 14:59:42.05				
Q1 Pwr Factor B	0.000 LAG	0/0/0 00:00:00.00	0.000 LAG	3/30/2006 14:59:42.05				
Q1 Pwr Factor C	0.000 LAG	0/0/0 00:00:00.00	0.000 LAG	3/30/2006 14:59:42.05				
Q1 Pwr Factor Total	0.000 LAG	0/0/0 00:00:00.00	1.000	0/0/0 00:00:00.00				
Q2 Pwr Factor A	0.003 LEAD	0/0/0 00:00:00.00	1.000	0/0/0 00:00:00.00				

▷ Scroll left/right and up/down to access all data.



To adjust the column widths, position the cursor on a line between columns at the top of the screen. When the cursor changes to a left/right arrow, hold down the left mouse button and drag the column border left or right. Release the button when the column is at the desired width.

- ▷ Click **Pause** to temporarily stop the screen update and enable the **Copy** button.
- ▷ Click **Resume** to continue the real-time update.
- ▷ Click **Print** to send the data to a printer.
- ▷ To Copy the data into another program, click **Pause** to enable the Copy button; then click **Copy**.
- ▷ Paste into your new document.
- ▷ Click **OK** to return to the main GE Communicator EXT screen.

To reset the Max/Min and Demand Readings, see Chapters 3, 4, 5.

### 7.2.3 Poll Reading Grid

To view all available polling data of the currently connected device,

- ▷ Select **Poll Reading Grid** from the Real-Time Polling menu.  
The following screen appears.

Polling Grid								
Polling 00121689								
Channel	0.1 second	1 second	Average	+Maximum	+Minimum	-Maximum	-Minimum	1 Cycle
Volts AN	7.60k	7.59k	7.19k	13.02k	0.00k			7609.93
Volts BN	7.59k	7.59k	7.18k	13.03k	0.00k			0.00
Volts CN	7.60k	7.60k	7.19k	13.02k	0.00k			7578.02
Volts AUX	0.00k	0.00k	0.00k	0.00k	0.00k			0.00
I A	0.00	0.00	0.00	0.99	0.00			0.13
I B	0.00	0.00	0.00	0.99	0.00			0.13
I C	0.00	0.00	0.00	0.99	0.00			0.13
I Nm	0.00	0.00	0.00	0.00	0.00			0.13
I Nc	N/A	0.00	0.00	0.89	0.00			0.00
Volts AB	13.15k	13.15k	12.44k	12.44k	0.00k			0.00
Volts BC	13.15k	13.15k	12.45k	12.44k	0.00k			0.00
Volts CA	13.16k	13.16k	12.46k	12.45k	0.00k			0.00
VA A	0.00	0.00	0.00	0.00	0.00			
VA B	0.00	0.00	0.00	0.00	0.00			
VA C	0.00	0.00	0.00	0.00	0.00			
VA Total	0.00	0.00	0.00	0.00	0.00			
VAR A	0.00	0.00	0.00	0.00	0.00	*****	*****	
VAR B	0.00	0.00	0.00	0.00	0.00	*****	*****	
VAR C	0.00	0.00	0.00	0.00	0.00	*****	*****	
VAR Total	0.00	0.00	0.00	0.00	0.00	*****	*****	
Watt A	0.00	0.00	0.00	0.00	0.00	*****	*****	
Watt B	0.00	0.00	0.00	0.00	0.00	*****	*****	
Watt C	0.00	0.00	0.00	0.00	0.00	*****	*****	
Watt Total	0.00	0.00	0.00	0.00	0.00	*****	*****	
Frequency	60.022	60.013	56.794	60.011	0.000			
Pwr Factor A	1.000	0.000 LAG	0.053 LAG					
Pwr Factor B	1.000	0.000 LAG	0.053 LAG					
Pwr Factor C	1.000	0.000 LAG	0.053 LAG					
Pwr Factor Total	1.000	1.000	1.000					
Imbalance V	v-Aux -179.50	0.00	5.34	100.00	5.34			
Imbalance I	N/A	0.00	0.00	90.20	0.00			
THD Volts AN/AB		0.00		5.46	0.00			
THD Volts BN/BC		0.00		5.46	0.00			
THD Volts CN/CA		0.00		5.46	0.00			
THD I A		0.00		10.15	0.00			
THD I B		0.00		9.76	0.00			
THD I C		0.00		9.37	0.00			
KFactor I A		0.00		44.57	0.00			
KFactor I B		0.00		38.86	0.00			
KFactor I C		0.00		37.58	0.00			
Ph Angle Volts AN		0.00						
Ph Angle Volts BN		119.94						
Ph Angle Volts CN		120.49						
Coincident Channel								
	P Max Watt	N Max Watt	P Min Watt	N Min Watt				
Thermal Average VAR	0.00	0.00	0.00	0.00				
Block Window Average VAR	0.00	0.00	0.00	0.00				
Rolling Window Average VAR	0.00	0.00	0.00	0.00				
<div> <div>OK</div> <div>Print</div> <div>Pause</div> <div>Copy</div> </div>								

Scroll left/right and up/down to access all data. The first two columns are Instantaneous values, Column 3 is the Thermal Average, Columns 4 to 7 are the Thermal Max and Mins and Column 8 is a Single Cycle value captured during the last screen update.



To adjust the column widths, position the cursor on a line between columns at the top of the screen. When the cursor changes to a left/right arrow, hold down the left mouse button and drag the column border left or right. Release the button when the column is at the desired width.


- ▷ Click **Pause** to temporarily stop the screen update and enable the Copy button.
- ▷ Click **Resume** to continue the real-time update.

- ▷ Click **Print** to send the data to a printer.
- ▷ To Copy the data into another program, click **Pause** to enable the Copy button; then click **Copy**.
- ▷ Paste into your new document.
- ▷ Click **OK** to return to the main GE Communicator EXT screen.

#### 7.2.4 Poll Multiple Devices

To view polled data from multiple devices connected to your computer,

- ▷ Select **Poll Multiple Devices** from the Real-Time Polling menu. The Poll Multiple Devices screen appears.



- ▷ Click on the tabs to access the following readings (see previous page for details on measurements):
  - **0.1 Seconds:** Volts AN, BN, CN, Aux, IA, B, C, Nm, Volts AB, BC, CA, VAA, B, C, Total, VAR A, B, C, Total, Watt A, B, C, Total, Freq, Power Factor A, B, C, Total, VAN Aux, Update Time.
  - **1 Second:** Volts AN, BN, CN, Aux, IA, B, C, Nm, Nc, Volts AB, BC, CA, VAA, B, C, Total, VAR A, B, C, Total, Watt A, B, C, Total, Freq, Power Factor A, B, C, Total, Imb V, I, Update Time.
  - **Average:** Volts AN, BN, CN, Aux, IA, B, C, Nm, Nc, Volts AB, BC, CA, VAA, B, C, Total, VAR A, B, C, Total, Watt A, B, C, Total, Freq, Power Factor A, B, C, Total, Imb V, I, Update Time.
  - **Maximum, Minimum:** Volts AN, BN, CN, Aux, IA, B, C, Nm, Nc, Volts AB, BC, CA, VAA, B, C, Total, P VAR A, B, C, Total, N VAR A, B, C, Total, PWatt A, B, C, Total, N Watt A, B, C, Total, Update Time.
  - **Hour Readings:** Quad (1+4) Watthour, Quad 1 VAhour, Quad 1 VARhour, Quad 4 VAhour, Quad 4 VARhour, Quad (2+3) Watthour, Quad 2 VAhour, Quad 2 VARhour, Quad 3 VAhour, Quad 3 VARhour.
  - **Device Time and Accumulations:** Date and Time, Internal Temperature.


- **Accumulations:** I SquaredTA, TB, TC, V Squared TA, TB, TC.
- ▷ Use the scroll bar at the bottom of the screen to access all the values.
- ▷ Click **OK** to return to the main GE Communicator EXT screen.

### 7.2.5 Poll External Analog Inputs

To view the polling screens for the External Analog Inputs,

- ▷ Select **Poll External Analog Inputs** from the Real-Time Polling menu.

The following screen appears:



Information on the screen includes:

- Input number
- Name assigned to the input
- Raw Value (Actual Value the input is measuring)
- Primary Value (Scaled Value from the Device Profile).

See Chapter 11 for setup instructions.

The Copy button at the right of the screen will allow you to copy the information from up to 32 Inputs and paste that data into a document.

- ▷ Click **OK** to return to the main screen.

### 7.3 Revenue, Energy and Demand Readings

#### 7.3.1 Power

To view Power readings for the currently connected meter,

- ▶ Select **Power** from the **Real-Time Poll > Revenue, Energy and Demand Readings** menu.  
The set of Power screens appears.
- ▶ Click on the tabs at the top of each screen to access other readings.  
Examples of the additional screens follow.

#### Total

Multiphase Total and Individual Phase Readings for Watts, VARS, VA and PF.



#### Instantaneous per Phase

One second Per Phase Values and Multiphase Totals



## Thermal per Phase

Per Phase and Multiphase Totals

	Total	A	B	C
Watts	0.00	0.00	0.00	0.00
VARS	0.00	0.00	0.00	0.00
VA	0.00	0.00	0.00	0.00
PF	1.000	0.003 LAG	0.003 LAG	0.003 LAG

## Uncompensated

Metered Values without Line and Loss Compensation and Multipliers. Includes Interval and Rolling Demand.

	Total	A	B	C
Watts	0.00	0.00	0.00	0.00
VARS	0.00	0.00	0.00	0.00
VA	0.00	0.00	0.00	0.00

- ▷ Click **Print** to send a copy of the screen to a printer.
- ▷ Click **OK** to return to the main GE Communicator EXT screen.

### 7.3.2 Demand

To view Demand data for the currently connected device,

- ▷ Select **Demand** from the **Real-Time Poll>Revenue, Energy and Demand Readings** menu.  
The set of Demand screens appears.
- ▷ Click on the tabs at the top of each screen to access other readings.  
Examples of the additional screens follow.



Peak

Peak Demand Readings for Watts, VARS, VA and PF. (Peak or Maximum Demand is the largest Average Value for the selected demand interval.)

Demands

Peak

Thermal

Block

Rolling

	Thermal	Block	Rolling
+Watts	0.00	0.00	0.00
-Watts	0.00	0.00	0.00
+Watts Coincident VARS	0.00	0.00	0.00
-Watts Coincident VARS	0.00	0.00	0.00
+VARS	0.00	0.00	0.00
-VARS	0.00	0.00	0.00

Polling 00121689

OK

Print

Thermal Demand

Thermal or Exponential Demand is used to emulate the operation of electromechanical Thermal Demand meters. This measurement responds like lagged thermal heating effects in electrical equipment.

Demands

Peak

Thermal

Block

Rolling

Watts

VARS

VA

Average

0.00

Time Stamp

+Maximum	0.00	2/20/2006 14:59:42.00
-Maximum	0.00	0/0/0 00:00:00
+Minimum	0.00	2/20/2006 14:59:42.00
-Minimum	0.00	0/0/0 00:00:00

Polling 00121689


OK

Print




Thermal Average VARS

The exponential average VARS. Exponential averages are used because they discount older values and respond more like the thermal effects.




Thermal Average VA




Block Window Average (or Average Demand)

Max and Min Watts, VARS and VA readings with Time Stamp. Click on tabs to access readings.



**Rolling Window Average (or Average Rolling Demand)**

Max and Min Watts, VARS and VA readings with Time Stamp. Click on Watts, VARS, and VA tabs to access readings.




### 7.3.3 Energy

To view Energy data for the currently connected device,

- Select **Energy** from the **Real-Time Poll > Revenue, Energy and Demand Readings** menu.

The set of Energy screens appears:



- Click on the tabs to move from screen to screen.

The EPM 9450/9650 Series Meters are true four-quadrant power meters. In the Quadrant Energy (Primary) section of this screen (shown above), readings are displayed for the VARS and VA in each quadrant.

Quadrant	Power Factor	Watts	VARS
1	Lag	+	+
2	Lead	-	+
3	Lag	-	-
4	Lead	+	-




Power Factor Lag and Lead is programmable in the Limits section of the Device Profile (3.5.1, 4.5.1)

Additional screens are shown below.

Cumulative Demand:

Readings in Secondary and Primary.




I & V Squared T:

Positive Readings for Phases A, B and C.




Q Hours:

Plus and Minus Readings in Secondary and Primary.




Uncompensated Energy:

Plus and Minus Watt, VAR and VA Readings in Secondary and Primary.



Energy (Secondary):

Plus and Minus Watt, VAR and VA Readings.



- ▷ Click **Print** to send the data to a printer.
- ▷ Click **OK** to return to the main GE Communicator EXT screen.

7.3.4 Energy, Pulse and Accumulations in the Interval

To view the Energy, Pulse & Accumulations in the Interval of the currently connected device,

- ▷ Select **Energy, Pulse & Accumulations in the Interval** from the Real-Time Poll>Revenue, Energy and Demand Readings menu. The following set of screens appears:



These screens are Read Only. They display the readings from the Interval set on several screens.


### Demand Integration Intervals (Chapters 3, 4)

Primary Current & Voltage Thresholds


Interval in minutes (15 = Initial setting)




### Internal KYZ Outputs (Chapters 3, 4)



I & V Squared T



Pulse Accumulations (Chapters 3, 4)





**Uncompensated Energy:**

Readings that are NOT adjusted by Transformer Loss Compensation.

Energy, Pulses and Accumulations in the Interval

Hour Counters	KYZ Pulse Output	Pulse Accumulations
I & V Squared T	Uncompensated Energy	Q Hours

	Primary	Secondary
+Wh	00000.00 k	00000
-Wh	00000.00 k	00000
+VARh	00000.00 k	00000
-VARh	00000.00 k	00000
VAh	00000.00 k	00000

Poling 00121688      OK      07/26/2006 16:00:00.02  
Interval: 15 min

**Q Hours:**

Q is the quantity obtained by lagging the applied voltage to a wattmeter by 60 degrees.

Energy, Pulses and Accumulations in the Interval

Hour Counters	KYZ Pulse Output	Pulse Accumulations
I & V Squared T	Uncompensated Energy	Q Hours

	Primary	Secondary
+Qh	00000.00 k	00000
-Qh	00000.00 k	00000

Poling 00121688      OK      07/27/2006 10:00:00.00  
Interval: 15 min

- ▷ To change any of the settings that effect the readings, click **OK**. You will return to the main GE Communicator EXT screen.
- ▷ Click **Edit Profile**.
- ▷ Double click on the appropriate screen to access settings and make adjustments.
- ▷ Click **Update Profile** to send the new settings to the meter.

### 7.3.5 Internal KYZ Output Accumulations

To view the Internal KYZ Output Accumulations of the currently connected device,

- ▷ Select **Internal KYZ Output Accumulations** from the **Real-Time Poll > Revenue, Energy and Demand Readings** menu. The following screen appears:.



This screen is read-only. It displays the readings from the KYZ Output Relays. Internal KYZ Outputs are configured in sections 3.4.3 and 4.4.3.

- ▷ To change any of the settings that effect the readings, click **OK**. You will return to the main GE Communicator EXT screen.
- ▷ Click **Edit Profile**.
- ▷ Double-click on the appropriate screen to access settings and make adjustments.
- ▷ Click **OK** to exit this screen and return to the main GE Communicator EXT screen.

### 7.3.6 Total Average Power Factor

To view Total Average Power Factor from the device connected to your computer,

- ▷ Select **Total Average Power Factor** from the **Real-Time Poll > Revenue, Energy and Demand Readings** menu.
- The following screen appears.

**Total Average Power Factor**

Time Stamp  
 Quadrant 1+4 1.0000 03/22/2006 10:20:19  
 Quadrant 2+3 1.0000

Equation used to compute the Total Average Power Factor

$$\frac{\left( \frac{\text{Quadrant 1+4 Power Factor}}{\text{Quadrant 2+3 Power Factor}} \right) + \left( \frac{\text{Quadrant 2+3 Power Factor}}{\text{Quadrant 1+4 Power Factor}} \right)}{2} = \text{PF}_{TA}$$

Maximum Time Stamp Minimum Time Stamp  
 Quadrant 1+4 1.0000 03/22/2006 17:39:42 1.0000 00/00/0000 00:00:00  
 Quadrant 2+3 1.0000 03/22/2006 17:39:42 1.0000 00/00/0000 00:00:00

Time of Last Total Average Power Factor Reset 00/00/0000 00:00:00

■ Polling 00121689

OK

This is a read-only screen. Readings are based on Power Factor settings from the Device Profile of the connected device.

- ▷ To make changes on this screen, click **OK** and return to the main GE Communicator EXT screen.
- ▷ In the **Device Profile**, make changes to Maximum and Minimum Power settings.
- ▷ Click **OK** to return to the main GE Communicator EXT screen.

### 7.3.7 Time of Use Registers

To view Time-of-Use Readings from the device connected to your computer,

- ▷ Select **Time of Use** from the **Real-Time Poll > Revenue, Energy and Demand Readings** menu.

The following screen appears:

This is a read-only screen. Readings are based on Time-of-Use settings from the Device Profile of the connected device.

- ▷ Use windows at the top of the screen to view a choice of Groups and Registers.
- ▷ Type in start and end times.
- ▷ To make changes on this screen, click **OK** and return to the main GE Communicator EXT screen.
- ▷ In the **Device Profile**, make changes to time-of-use settings.
- ▷ To Copy the data into another program, click **Copy**.
- ▷ **Paste** into your new document.
- ▷ Click **Export** to send the data to another device.
- ▷ Click **Print** to send a copy of the screen to a printer.
- ▷ Click **OK** to return to the main GE Communicator EXT screen.

### 7.3.8 Poll Pulse Accumulations

To view the Pulse Accumulations readings for the currently connected device,

- ▷ Select **Poll Pulse Accumulations** from the **Real-Time Poll > Revenue, Energy and Demand Readings** menu.
- The Pulse Accumulations screen appears:

Pulse Accumulations					
Source	Totals	Average	Maximum	Time Stamp	Acc To
Pulse Counter 1	00000.014	0	40	3/20/2006 14:53:59.11	None
Pulse Counter 2	00000.014	0	52	3/20/2006 14:53:59.11	None
Pulse Counter 3	00000.014	0	40	3/20/2006 14:53:59.11	None
Pulse Counter 4	00000.014	0	52	3/20/2006 14:53:59.11	None
Pulse Counter 5	00000.014	0	40	3/20/2006 14:53:59.11	None
Pulse Counter 6	00000.014	0	52	3/20/2006 14:53:59.12	None
Pulse Counter 7	00000.014	0	40	3/20/2006 14:53:59.12	None
Pulse Counter 8	00000.014	0	52	3/20/2006 14:53:59.12	None
Watt Hour					
00121189	00000.004				None
Aggregator					
Aggregator	Totals	Average	+Maximum	Time Stamp	
Aggregator 1	00000.004	0	0	0/0/0 00:00:00.00	• Max
Aggregator 2	00000.004	0	0	0/0/0 00:00:00.00	• Max
Aggregator 3	00000.004	0	0	0/0/0 00:00:00.00	
Aggregator 4	00000.004	0	0	0/0/0 00:00:00.00	
Polling 00121189					
<div>OK</div> <div>Print</div> <div>Export</div>					

This screen displays the scaled Pulse Accumulations from the meter's eight internal digital inputs. It also displays the Fixed Window Average and Max Demand for the eight Pulse Accumulations. At the bottom of the screen, you will also find four Totalizers, which are combinations of the eight internal inputs and the meter's watt-hour counter.

This screen is the result of configuring the Pulse Accumulations settings in the Device Profile. See Chapters 3 and 4 for details on settings and to edit settings. The meter can be programmed to accumulate and aggregate poles from any pulse-generating device.

- ▷ Click **OK** to return to the main GE Communicator EXT screen.
- ▷ Click **Print** to print this screen.
- ▷ Click **Export** to save a text file of the Input Readings. Your computer will ask you to name the file and choose a "save in" location.
- ▷ Click **Save** or **Cancel** to return to the main GE Communicator EXT screen.

## 7.4 Power Quality and Alarms


### 7.4.1 Phasors

The Phasors screen displays the phase relationships of the currently connected device.

The EPM 9800 screen displays the Form and Configuration at the top of the screen.




- ▶ Select **Phasors** from the **Real-Time Poll > Power Quality and Alarms** menu, or click the Phasors button on the tool bar.
- The Phasors screen:



If you have an auxiliary voltage reading (i.e. generator and bus where the  $V_{Aux}$  is the generator), Aux box and the  $V_{Aux}$  phaser will be displayed. The  $V_{Aux}$  phaser is referenced to  $V_A$  phase.

- ▷ From the buttons at the bottom of the screen, click on **Options**. A pop-up window, Phasor Diagram Options, appears:



- ▷ Check **Display Voltage Phase-to-Phase Readings When In Wye Configuration**, if you want to include that reading in the graph.
- ▷ In the Display Angles Increasing and Phasor Rotation boxes, select either **Clockwise** or **Counter Clockwise**.
- ▷ From the pull-down menu at the bottom of the screen, select Vectors, Triangles or Vectors and Triangles to change the graphic representation of the data.
- ▷ Click **OK** to save your selections and return to the main Phasors screen.

Use the Buttons at the bottom of the screen to complete the following tasks:


- ▷ Click **Copy** to save a copy of the screen to the clipboard.
- ▷ Click **Print** to send a copy of the graph to a printer.
- ▷ Click **OK** to return to the main GE Communicator EXT screen.

### 7.4.2 Poll Harmonics

To view harmonics data for the currently connected device,

- ▷ Select **Poll Harmonics** from the **Real-Time Poll>Power Quality and Alarms** menu.

The Harmonics screen appears:



- ▷ To change the presentation format, click on the **Values**, **Spectrum** or **Waveform** buttons.

The screen above is in **Values** mode.

- ▷ To change the channel, use the pull-down menu, located beneath the Spectrum radio button. Select from Volts A, B, C or Current (I) A, B, C.

Use the scroll bar at the right side of the screen to access all the values. The EPM 9450 and 9650 poll harmonics to the 127th order.


- ▷ Click **Print** to send the data to a printer.
- ▷ Click **Copy** to send the contents of the screen to the clipboard.
- ▷ Click **OK** to return to the main GE Communicator EXT screen.



### 7.4.3 Flicker

To view Flicker data for the currently connected device,

- ▷ Select **Flicker** from the **Real-Time Polling** menu.  
The Flicker screen appears:



- ▷ To view Short Term or Long Term Flicker data, click on the tabs at the top of the screen.  
The Short Term or Long Term screen will appear:



- ▷ Use the Flicker Monitoring buttons to Start or Stop Flicker Monitoring or to Reset the meter's Flicker Monitoring.
- ▷ Click **Print** to send the data to a printer.
- ▷ Click **OK** to return to the main GE Communicator EXT screen.

### 7.4.4 Alarm Status

To view Alarm Status data for the currently connected device,

- ▷ Select **Alarm Status** from the **Real-Time Poll>Power Quality and Alarms** menu.

The Limit Status screen appears:

Limit Status										
Limit ID	Item	Value	Status		Limit 1		Limit 2		Combination	
			Limit 1	Limit 2	Setting	Setpoint	Setting	Setpoint	Type	Status
1	0.1 Second Volts AN	7593.59	In	Out	Above	15.84k	Below	10.56k	OR	Out
2	0.1 Second Volts BN	7586.96	In	Out	Above	15.84k	Below	10.56k	OR	Out
3	0.1 Second Volts CN	7595.80	In	Out	Above	15.84k	Below	10.56k	OR	Out
4	0.1 Second I A	0.00	In	Out	Above	10.00	Below	4.90	OR	Out
5	0.1 Second I B	0.00	In	Out	Above	10.00	Below	4.90	OR	Out
6	0.1 Second I C	0.00	In	Out	Above	10.00	Below	4.90	OR	Out
7			In	In						In
8			In	In						In
9			In	In						In
10			In	In						In
11			In	In						In
12			In	In						In
13			In	In						In
14			In	In						In
15			In	In						In
16			In	In						In
17			In	In						In
18			In	In						In
19			In	In						In
20			In	In						In
21			In	In						In
22			In	In						In
23			In	In						In
24			In	In						In
25			In	In						In
26			In	In						In
27			In	In						In
28			In	In						In
29			In	In						In
30			In	In						In
31			In	In						In
32			In	In						In

This screen displays the Status of the Limits set in the Programming Limits section of the Device Profile (sections 3.10 and 4.10). Up to 32 Limits can be set.

- ▷ To change any of the settings, click **OK**, which will return you to the main GE Communicator EXT screen.
- ▷ Click **Edit Profile**.
- ▷ Double click on **Limits** and any of the settings to access the programming screen.
- ▷ Click **Print** to send the data to a printer.
- ▷ Click **OK** to return to the main GE Communicator EXT screen.




To adjust the column widths, position the cursor on a line between columns at the top of the screen. When the cursor changes to a left/right arrow, hold down the left mouse button and drag the column border left or right. Release the button when the column is at the desired width.

### 7.4.5 Poll Device Control Status

To view the status of the currently connected device,

- ▷ Select **Poll Device Status** from the **Real-Time Poll > Power Quality and Alarms** menu.

The Device Status screen appears:



This screen displays the Status of the Settings set in the **Programming Relay** section of the Device Profile (sections 3.11 and 4.11). Up to 8 assignments can be set per **relay**. If there are no relays installed, a note "Relay Module Not Installed" will appear on the screen.

- ▷ To print this screen, click on the **Print** button.


This is a read-only screen.

- ▷ To change any of the settings, click **OK**, which will return you to the main GE Communicator EXT screen.
- ▷ Click Edit Profile.
- ▷ Double click on **Relay** to access the programming screen.
- ▷ To select a different **relay**, click on the pull-down menu in the upper right corner of the screen.
- ▷ Click on your selection.

7.4.6 Poll Internal Inputs

To view Internal Input data for the currently connected device,

- ▷ Select **Poll Internal Inputs** from the **Real-Time Poll > Power Quality and Alarms** menu.  
The Internal Inputs screen appears.



- ▷ To change this screen in any way Click **OK** to return to the GE Communicator EXT screen.
- ▷ Click on **Edit Profile**.


See sections 3.5.6 and 4.5.6 for details.

### 7.4.7 Poll External Digital Inputs

To view the polling screens for the External Digital Inputs,

- ▷ Select **Poll External Digital Inputs** from the **Real-Time Poll>Power Quality and Alarms** menu.

The following screen appears:



Information appearing on the screen will include:

- Input number
- Name given to the device
- State and Transitions.

With the buttons on the right side of the screen, you can use the pull-down menu to Reset Counters or Copy the data from up to 32 inputs and paste it into a document.

- ▷ Click **OK** to return to the main screen.

The Copy button at the right of the screen will allow you to copy the information from up to 32 Inputs and paste that data into a document.

## 7.5 Poll Real Time Trends


The **EPM 6000** meter has a unique screen, Real Time Trends.

To view the **Real Time Trends** polling screen,

- ▷ Select **Real Time Trends** from the **Real Time Poll** menu (shown here).



The following screen appears:



- ▷ To view parameters on this screen, in the **Parameters** section of the screen, select a set of values by clicking on the boxes next to the values.
- ▷ Click **Start**.  
This will start the graph.
- ▷ Enter a value greater than **0** in the **AutoStore** box to create a **.csv** (Comma Separated Value Excel file) that contains a log of the current values of the Store Interval.  
The number entered is the Store Interval in seconds. Stores all values, not just those selected.
- ▷ Click on the **Store** button at the bottom of the screen to grab the most current values and add them to the file.

The Poll Interval can be set. Set to 0 for as fast as possible.

The Min and Max Y Values that the graph displays (the Y Range) can be set. Auto Scale determines the best range of values automatically.

▷ Click **Cancel** to return to the main screen.







1  
011  
101110011100  
01100111110001  
000111010110110  
11110001001101  
010101110010  
011  
1

# GE Communicator EXT

## Chapter 8: Viewing Logs

---

### 8.1 Overview

The EPM 9450/9650 and EPM 9800 Meters record the following logs (EPM 7000 logs as noted):

#### Historical Trends Logs 1 and 2 (EPM 7000 - Historical Log)

These logs are two separate collections of time-stamped records (or “snapshots”) used to track any parameter over time. Each record or snapshot can contain multiple data items, which are recorded at specific intervals and stamped with the time of recording. The following programmable criteria determine when the Meter will take a snapshot:

- The user-specified time interval
- A parameter’s exceeding of a limit or a return to within limits
- The capture of a waveform
- An I/O event (a change in a relay or input)

#### Limits Log

The Limits Log retrieves independent out-of-limit information, creating a sequence of events for any occurrence.

#### Event-Triggered Waveform Log (EPM 7000 Series)

The Event-Triggered Waveform log records a waveform when a user-programmable value goes out of limit and when the value returns to normal. All information is time-stamped to the nearest 1 msec. A new feature for interharmonic analysis observes further frequencies.

### Power Quality (CBEMA) Log

This log records magnitude and duration of voltage and current surges and sags for every power quality (PQ) event. The associated waveform is also recorded.

### Status Change (Input) Log

(Included in EPM 7000 Series Event I/O Log)

This log displays the input change status for a selected meter file and time range.

### Control Output (Relay) Log

(Included in EPM 7000 Series Event I/O Log)

This log displays the relay change status for a selected meter file and time range.

### AiReports

AiReports 2.0 is an optional power quality analysis software package used in conjunction with meter Logs. It provides a comprehensive report on the status of the equipment being monitored; it uses artificial intelligence to diagnose PQ events and provide the possible cause of the event.

### System Events Log

The log records system events for security and anti-tampering.

### The following is the general sequence for working with all logs:

1. Program parameters specific to each log in the meter's Device Profile (section 8.2). Logs run automatically.
2. Retrieve the logs manually from the meter (section 8.3); or retrieve logs automatically using the Script & Scheduler Program. See Chapter 15 for further details.
3. View and analyze log data with GE Communicator EXT's Log Viewer (sections 8.5–8.18).
4. Diagnose PQ Events from meter logs, create comprehensive report, transmit, modify, print or export file with optional AiReports software (section 8.15).

### Free Space Calculation Feature

The Log Converter automatically checks your computer and calculates the amount of free space on your hard drive. This calculation is performed to insure enough hard drive space for the Log Converter to operate. Below are the parameters for the calculations and the actual calculation performed by the meter.

**Table 8–1: Free Space Calculation Parameters**

ITEM	DESCRIPTION	MINIMUM VALUE
THDS	Total Hard Disk Space	
THDFS	Total Hard Disk Free Space	

**Table 8–1: Free Space Calculation Parameters**

MIN%THDS	Minimum % of Free Space of Total Space (Min%ofFreeSpace)	1 (After 3/19/2002)
MinSetFS	Minimum Free Space (MinFreeSpace)	50 MB
CalMinFS	Calculated Minimum Free Space	



NOTE

Min%ofFreeSpace and MinFreeSpace Values are set in the LogConverter.ini file.

**CALCULATION:**

$$\text{Min\%THDS} \times \text{THDS} = \text{CalMinFS}$$

If CalMinFS < MinSetFS then CalMinFS = MinSetFS

If CalMinFS <= THDFS then OK

If CalMinFS > THDFS then Need More Space on your HD

## 8.2 Programming and Running Logs

Program the following parameters specific to each type of log in the meter's Device Profile. See Chapter 3 (9450/9650), Chapter 4 (9800) or Chapter 5 (7000) for details.



Any time you update the Device Profile, a pop-up screen will announce that the logs are not being reset and asks if you would like to reset them. Resetting the logs is recommended if you make changes to CT & PT Ratios, Limits or Limit Full Scales.

- Limit and Waveform Full Scales
- Limits
- Trending Setup
- Trending Log Time Intervals
- Power Quality and Waveform Thresholds
- Labels — YOU MUST LABEL THE METER

You do not need to start the logs; the meter is always recording.

To confirm the parameters and track the progress of the logs,

- ▷ **Select Statistics** from the Logs menu (or click on the **Log Status** icon on the Tool Bar).

The Log Statistics screen appears.

Log Statistics							
Logging Statistics							
Log	Records	Memory Used	Newest Record Time	Oldest Record Time	Record Size	Max Records	Memory
Historical Log 1	26624	100%	07/24/2006 14:19:00.00	07/03/2006 23:38:00.00	64	26624	1664K
Historical Log 2	6400	100%	07/24/2006 14:19:00.00	07/20/2006 03:36:00.00	64	6400	400K
Limit Triggers	0	0%			32	1024	32K
Limit Snapshots	0	0%			32	1024	64K
Digital Input	0	0%			16	512	16K
Digital Input Snapshots	0	0%			64	512	32K
Digital Output	0	0%			64	256	16K
Digital Output Snapshots	0	0%			32	256	32K
Flicker	0	0%			32	5120	160K
Waveform Triggers	8	8%	07/24/2006 09:36:39.63	06/29/2006 08:49:05.08	256	95	32K
System Events	1024	100%	07/24/2006 10:52:55.97	07/19/5757 31:19:59.43	16	1024	16K
Waveform Samples	8	8%	07/24/2006 09:36:39.63	06/29/2006 08:49:05.08	16384	95	1536K
PQ(CBEMA)	8	2%	07/24/2006 09:36:39.63	06/29/2006 08:49:05.08	128	512	64K

Polling 00121689

OK

Help

## 8.3 Retrieving Logs

To retrieve logs from the meter and convert them for viewing and analysis:

- ▷ Click on the **Retrieve Logs** button, or select **Logs > Retrieve Log(s)** from Device.

The following screen appears.

Log Type	Status	Retrieve
Historical Log 1	Available	Yes
Historical Log 2	Available	No
Limits	Available	Yes
Digital Inputs	Available	No
Digital Outputs	Available	Yes
Flicker	Available	No
Waveform / PQ	Available	No


- ▷ Double-click on the logs you would like to retrieve from the meter. The “No” in the Retrieve column will become a “Yes.”
- ▷ Double-click again to change the “Yes” back to a “No.” GE Communicator EXT will only retrieve those logs with a “Yes” in the Retrieve column.



Note on the Meter Designation field:

- If you have entered a label for the meter in the Labels section of the Device Profile (Chapters 3, 4,5), the label will appear here. GE Communicator EXT will apply this name to the file containing the logs you choose to retrieve, placing the file in the Retrieved Logs folder.
- If the EPM Meter does not have a meter designation or label, this field will appear blank and GE Communicator EXT will ask you to name the log file and supply a destination. See Chapter 3 (9450/9650), chapter 4 (9800) or chapter 5 (7000) for how to give the meter a label.

- ▷ Click **Start**.  
GE Communicator EXT begins to retrieve the log.  
The following screen appears:



After GE Communicator EXT has retrieved the log it converts the data. The Log Converter application runs automatically.

GE Communicator EXT then runs Log Viewer: See sections 8.4–8.18 for information on using Log Viewer.



Retrieve logs as often as you want. Each time you retrieve a log file, GE Communicator EXT appends only the newest records and captures to the existing database. These “partial downloads” are listed in Log Viewer’s Database Status screen (see section 8.13). Snapshots, or partial downloads, must be a time frame within the database dates. Otherwise, there is no data from which to retrieve the snapshot.

## 8.4 Viewing Logs with GE Communicator EXT's Log Viewer

GE Communicator EXT's Log Viewer displays retrieved logs in a variety of formats.

To access Log Viewer, either:

- ▷ Retrieve logs from a connected meter, as in section 8.3.


OR

- ▷ Click the **Open Log** button.

GE Communicator EXT will ask you to select a previously stored log file (.DB). GE Communicator EXT defaults to the Retrieved Logs directory.

OR

- ▷ Run **Log Viewer** from the Windows® Start menu.  
Log Viewer's main screen appears:



- ▷ Choose the log data file(s) you would like to view:


If you have retrieved a log from GE Communicator EXT, that file is selected for Meter 1, as in the example above ("Meter 1");

OR

- ▷ Click on either meter button (1 or 2) that displays a meter name.  
Log Viewer will ask you to select a log database file:



- ▷ You may choose a different log file for Meter 1 and for Meter 2. You may only load one log file per meter.
  - ▷ The log file assigned to each meter is listed in the pull-down menu above the button.
  - ▷ Select **No Meter** from the pull-down menu to close a log file.
  - ▷ Select what log data points you would like to view by clicking on the **Data Points** button in the **Select Data** section.
- The following screen appears:



The Data Points available will vary with the type of log and the parameters set for it.

- ▷ From the **Available Data Points** column, click on the data points you want to include when viewing the log file.
- ▷ To select multiple points, hold down the **Ctrl** key while clicking.
- ▷ To select a complete sequence of points, hold down the **Shift** key while clicking.




- ▷ Click on the **Add** button to move the Data Points to the Selected Data Points column.
- ▷ Click on the **Restore** button to return the selection to its previous setting.
- ▷ When you have made your selection, click **OK** to return to Log Viewer's main screen.

The pull-down menu above the Data Points button lists the points you have selected.


You can select what portion of the log(s) you wish to view by specifying a time range.

Log Viewer bases its time/date format on your computer's Regional Settings (Windows® Control Panel).

- ▷ Click on the **Time Range** button in the **Select Time** section.  
The following screen appears:



- ▷ To select a specific time range, click the **Between** radio button and enter a date and time in each field.
- ▷ Double-click either date/time field to bring up the following calendar.



- ▷ Click the selected day and use the slide at the bottom of the screen to select a time.
- ▷ Click **OK**.
- ▷ To select a range of hours, days, months or years only, click the appropriate radio button and the counter menu beside it.
- ▷ To return to the main screen, click **OK**.  
The time range you selected is displayed above the button.

After you have loaded the log file(s), selected data points and chosen a time range, you may begin viewing the data. The following sections detail the different viewing formats for each type of log.

## 8.5 Viewing Historical Trends and Snapshots

- ▷ From Log Viewer's main screen, click on the **Historical Trends** button or **View Data > Snapshots**.

Log Viewer will display Snapshot Information for the selected log file(s) based on the time range and data points specified in the Select Data and Time Range windows of the main screen (section 8.4).

Date/Time	Record Type	00121689-0.1s Vab	00121689-0.1s VAP	00121689-Inst Vab	00121689-Inst VAP
7/24/2006 2:44:00.000 PM	Log 2				
7/24/2006 2:43:00.000 PM	Log 2				
7/24/2006 2:42:00.000 PM	Log 2				
7/24/2006 2:41:00.000 PM	Log 2				
7/24/2006 2:40:00.000 PM	Log 2				
7/24/2006 2:39:00.000 PM	Log 2				
7/24/2006 2:38:00.000 PM	Log 2				
7/24/2006 2:37:00.000 PM	Log 1	0.00	0.00	0.00	0.1
7/24/2006 2:36:00.000 PM	Log 1	0.00	0.00	0.00	0.1
7/24/2006 2:35:00.000 PM	Log 1	0.00	0.00	0.00	0.1
7/24/2006 2:34:00.000 PM	Log 1	0.00	0.00	0.00	0.1
7/24/2006 2:33:00.000 PM	Log 1	0.00	0.00	0.00	0.1
7/24/2006 2:32:00.000 PM	Log 2				

The name of the log file ("Feeder 1" in this example) and the type of data point are listed in the top row.


The viewer can move columns, so that the most important data is most accessible.

- ▷ Right-click on the column title and drag it to the desired location on the table. Repeat as desired to customize the table.
- ▷ To save the data to your clipboard, right-click with the cursor positioned anywhere in table.
- ▷ To sort the data by record type in either ascending or descending order, click on the **Sort** button and use the pull-down menu to make your selection.

See the following section 8.8 for details about viewing Snapshot Graphs.

## 8.6 Sort

At the bottom of all the display pages for the selected log file(s), including the Historical Trends display page, you'll find a **Sort** button. The Sort button allows you to customize the Log Viewer data to your needs by using the pull-down menus to set the criteria for the sort.



- ▷ Select from the variety of Record Types, determined by the type of log being viewed.  
For example, the Historical Trends Log includes the following choices in the Record Type menu: All Snapshots, Group by Type, Log 1, Log 2, Limits, Input, Relay, Flicker
- ▷ Click on the **Sort Item** pull-down menu to select Date/Time or Readings for the currently selected meter.
- ▷ Click on the **Sort Order** pull-down menu to select Ascending or Descending Order
- ▷ Click **OK**.  
In a few moments, the customized data will load on to your screen.

## 8.7 Viewing Trending and Demand Graphs (XY and Circular)


To display Trending or Demand data as either an XY or Circular graph,

NOTE: Holding down the Ctrl key allows you to add or remove multiple items.

- Click on the **Graph** button in the main Log Viewer (Historical) Trend or Demand screen.



The following screen appears:



The Available Items column lists the data points that have been selected for the log file.


- To add a new data point, return to Log Viewer's main screen and click on the **Data Points** button (see section 8.4).


- ▷ From the Available Items column, click on the parameters you want to graph.  
You can select up to six parameters.
- ▷ If you want to remove a parameter from the Graph Items list, highlight it and click the Remove button.
- ▷ Click the **Add** button.  
The items will appear in the Graph Items column.
- ▷ To select multiple points, hold down the **Ctrl** key while clicking.
- ▷ To select a sequence of points, hold down the **Shift** key while clicking.



Only a total of six pens may be used at one time. If there are two log files open, you will be allowed to select only three data points from the left column.

- ▷ To view the graph, press either the **Advanced**, **Circular** or **XY Graph** button:





The following pertain to either type of graph:

To change the starting point of the graph:

- ▷ Choose a new date/time segment from the Starting Date/Time to view pull-down menu.

To change the amount of time represented on the graph:

- ▷ Enter a value in the Number of Days to View field
- ▷ Press **Enter** or click on the **Redraw** button.

To change the scale of the graph:

- ▷ Enter a value in the Minimum Value and Maximum Value fields
- ▷ Press **Enter** or the **Redraw** button.

To view one sample at a time:

- ▷ Click in the **Move by Sample** box.
- ▷ Click on the **Forward** or **Reverse** buttons each time you would like to view the next (or previous) sample.

To view a continuous, sample-by-sample rendering of the graph:

- ▷ Click the **Move by Sample** box and the **Auto Show** box.
- ▷ Select a speed by sliding the **Auto Show Speed** bar left or right.
- ▷ Click on the **Forward** or **Reverse** button to determine the direction of the Auto Show.
- ▷ To stop Auto Show, deselect the **Auto Show** box.

To print the graph on a color printer:

- ▷ Check the **Color Printout** box
- ▷ Click **Print**.

To print the graph on a black-and-white printer:

- ▷ Click the **Use Symbols** box
- ▷ Click **Print**.

To copy the graph data to the computer's clipboard:


- ▷ Select **Copy** from the File menu.
- ▷ Paste the data into a spread sheet, such as Excel.

To export the graph's data:

- ▷ Select **Export Data** from the File menu.

To change the graph's color assignments:

- ▷ Select **Select Colors** from the Options menu.
- The following screen appears:



The small squares under the Color heading represent the color currently assigned to each component of the graph.


To make adjustments to an item's color:

- ▷ Click the radio button beside it
- ▷ Create a new color by moving the red, green and blue sliders.
- ▷ Create black by moving all sliders down, white by moving all sliders up.  
The large square on the right shows the color you have created.
- ▷ Click **OK** to return to the graph.  
Log Viewer will redraw using the new color scheme.
- ▷ Click the **Restore** button to return all color schemes to default values.

To create a label for the graph:



- Select **User Labels** from the Options menu.  
The following screen appears:



- Enter a label in each line and click **OK**.  
The two-line label will appear on the right side of the graph.
- Click **Restore** to enter the previous label.


To view a summary of data for any point on the graph:

- Position the cursor on the graph and hold down the mouse button.

## 8.8 Viewing the Limits Log

- ▷ From Log Viewer's main screen click on the **Out of Limit** button or **View Data > Limits**.


Log Viewer displays limit information for the selected log file(s) based on the time range specified in the Select Time Range section of its main screen (see section 8.4).



- ▷ Click the **Show Snapshots** box on the left side of the screen to display the limits snapshot information.
- ▷ To copy the data to the computer's clipboard, right-click with the cursor positioned anywhere in the table.
- ▷ To sort the data by record type in either ascending or descending order, click on the **Sort** button and use the pull-down menus to make your selection.

## 8.9 Viewing the Waveform Log


- ▷ From Log Viewer's main screen (section 8.4), click on the **Waveform** button or **View Data > Waveform**.  
Log Viewer will display waveform information for the selected log file(s) based on the time range specified in the Select Time Range section of its main screen. (EPM Series 7000 Waveform Time Precision is 1 second.)



- ▷ To save the data to your clipboard, right-click anywhere in the table.
- ▷ To view the Waveform Settings, click on a waveform record then click the **Show Waveform Settings** box on the left side of the screen.
- ▷ To *adjust* the column widths, position the cursor between columns at the top of the screen. When the cursor changes to a left/right arrow, hold down the left mouse button and drag the column border left or right. Release the button when the column is at the desired width.
- ▷ To *sort* the data by record type in either ascending or descending order, click on the **Sort** button. Use the pull-down menus to make your selection.
- ▷ To view the waveform graphs, see the following section.

8.10 Viewing Waveform Graphs

- To view any waveform in the main Waveform Log screen (section 8.9), click on the desired record and then click the **Graph** button (or double-click on the desired record).



- To change the Waveform Display Settings, click the **Options** button in the upper left corner of the screen. The Waveform Options screen will appear:

Waveform Display Settings

Startup Display Mode	Classic
Overlay Mode	Overlay (Group)
Plot Mode	Line
Point Size	Small
Foreground Color	
Background Color	
Filter Freq (Hz)	60

Subsets	Item Names	Overlay Select	Item Colors	Item Line Types	Item Point Types
1	Va	<input checked="" type="checkbox"/>		Thin Solid	Plus
2	Vb	<input checked="" type="checkbox"/>		Thin Solid	Cross
3	Vc	<input checked="" type="checkbox"/>		Thin Solid	Circle
4	Ia	<input checked="" type="checkbox"/>		Thin Solid	Solid Circle
5	Ib	<input checked="" type="checkbox"/>		Thin Solid	Square
6	Ic	<input checked="" type="checkbox"/>		Thin Solid	Solid Square
7	I <sub>n</sub>	<input checked="" type="checkbox"/>		Thin Solid	Diamond
8	Input 1	<input checked="" type="checkbox"/>		Thin Solid	Solid Diamond
9	Input 2	<input checked="" type="checkbox"/>		Thin Solid	Upward Triangle
10	Input 3	<input checked="" type="checkbox"/>		Thin Solid	Solid Upward Triangle
11	Input 4	<input checked="" type="checkbox"/>		Thin Solid	Downward Triangle
12	Input 5	<input checked="" type="checkbox"/>		Thin Solid	Solid Downward Triangle
13	Input 6	<input checked="" type="checkbox"/>		Thin Solid	Dash
14	Input 7	<input checked="" type="checkbox"/>		Thin Solid	Pixel
15	Input 8	<input checked="" type="checkbox"/>		Thin Solid	Plus

OK Cancel Help

**Configurable options include:**

1. **Start Up Mode:** Classic, Overlay or Overlay (group)
2. **Overlay Mode:** Overlay or Group
3. **Plotting Method:** Line, Point or Line and Point (Line and Point is slower than the other two options.)
4. **Colors:** Background, Foreground, Subsets (User can reverse the colors.)
5. **Point Sizes for Each Subset:** Small, Medium, Large or Micro
6. **Line Types for Each Subset:** Pull-down menu offers Dashed, Dot, Dash Dot, Dash Dot Dot, Medium Solid, Thick Solid, Medium Thin Solid, Medium Thick Solid, Extra Thick Solid.
7. **Item Point Types for Each Subset:** Pull-down menu offers Plus, Cross, Solid Circle, Square, Solid Square, Diamond, Solid Diamond, Upward Triangle, Solid Upward Triangle, Downward Triangle, Solid Downward Triangle, Dash or Pixel.

To include the  $I_{aux}$  in the graph:

- ▷ Click the  **$I_{aux}$  On** button.
- ▷ Click the  **$I_{aux}$  Off** button to remove.
- ▷ Double click on the  **$I_{aux}$  graph** for a closer view.

To include the High Speed Inputs in the graph:

- ▷ Click the **Inputs On** button.
- ▷ Double click on the **Inputs** graph for a closer view.  
Each input is listed on the Y axis followed by a 1 or 0—a 1 denotes that the input is open; a 0 denotes that the input is closed.
- ▷ Click **Inputs Off** to remove.

To Print the graph:

- ▷ Click the **Print Graph** button.

To Export an image from the screen:

- ▷ Click the **Export Picture** button.

To Export the data only:

- ▷ Click the **Export Data** button.

To view the previous or next waveform record:

- ▷ Click the **Previous** or **Next** buttons.

To Zoom In on a portion of the graph:

- ▷ Click and drag to form a box. Double click.

To Zoom Out:

- ▷ Click the **Zoom Out** button.



- ▷ Use radio buttons to select the **Entire Capture** or a **Selected Window**.

Selected Window is enabled if a user sets mark 1 and mark 2 for a given channel. The waveform for that channel between those marks will be graphed in the overlaid advanced graph.

To add to the Selected Waveform Items list, from the **Current Waveform Items** indexed on the left of the screen:

- ▷ Click on an item.
- ▷ Click on **Add**.

To remove an item from Selected Waveform Items:

- ▷ Click on the item.
- ▷ Click **Remove**.

To view the Original Waveform Property of a Selected Waveform Item:


- ▷ Click on one of the list items.  
The **Waveform Property** for that item will appear.

To return to the main Waveform Graph:

- ▷ Click the **Back** button.

To create an Advanced Waveform Graph:


- ▷ Click the **Graph** button.  
This screen appears:



To edit the Advanced Waveform Graph:

- ▷ Click on **Edit Graph**.

The first of a series of screens appears. These screens help the user customize Advanced Waveform Graphs.



This screen's special features include:

1. **Main Title:** user can edit the Main Title of the graph..
2. **User Annotation:** user can add a line of text inside the graph in the form of a Sub Title. This feature applies to graph with single Y axis, non-overlaid.
3. **Viewing Style:** Color, Monochrome or Monochrome and Symbols.
4. **Font Size:** Large, Medium or Small
5. **Numeric Precision:** digits behind the decimal (from 0-3).
6. **Grid Lines:** All (Both), Y, X, None, Grid in Front of Data.

To Apply changes:

- ▷ Click **Apply**.

To return to the Original screen:

- ▷ Click **Original**. (This will erase any changes.)

To Export:


- ▷ Click **Export** (see details below).

To Maximize the screen:

- ▷ Click **Maximize**.  
The graph will fill your screen.




To add style and dimension to graphs, use the **Plot** screen and follow these steps:



- ▷ Choose one or more axes.
- ▷ From the 3D buttons, choose **Shadow**, **3D** or **Off**.
- ▷ Choose to **Mark Data Points** or not.
- ▷ Choose a style from **Plot Style**.
- ▷ Choose a **Comparison Plot Style**.

To Add Subsets to the Graph:


- ▷ Use the **Subsets** screen:



- ▷ From the **Subsets** screen, choose **Subsets to Graph**.
- ▷ Choose number of **Scrolling Subsets** to be graphed.


To Set the Configuration of the Y Axis and the X Axis:

► Use the **Axis** screen:



- Set Linear or Log Axis.
- Set Auto, Min, Max or Min/Max.
- Set Numeric Min and Max for each axis.

In the **Font** screen, to set the Fonts for the Graph::




► Select from the list of different font styles in Bold, Italic or Underline for:

Main Title

Sub-Title

Subset / Point / Axis Labels

In the **Color** screen, to choose colors from **Graph Attributes**:



▷ Select from the available colors for:

Desk Foreground and Background (area surrounding graph).

Shadow Color


Graph Foreground (lines and points)

Graph Background

Table Foreground and Background

To select color **Point Type** and **Line Type** from a wide selection:


▷ Use the **Style** screen.



To combine multiple waveforms into one graph:

- ▷ Click the items on the left side of the **Advanced Waveform** screen for each waveform you wish to include.
- ▷ Click the **Add** button to add the selected items to the Selected Waveform Items list on the right side of the screen.

- ▷ Click the **Graph** button at the bottom of the screen.  
The following example screen shows the  $V_{bn}$  and  $I_c$  channels:



To move *Hash Marks* on the screen:

- ▷ Move the mouse.  
Duration is calculated from mark 2 to mark 1 in milliseconds.

To *zoom in* on a portion of the graph:

- ▷ Draw a box around the desired area by dragging the mouse and holding down the left button.
- ▷ Release the mouse button to activate the zoom.
- ▷ Click the **Zoom Out** button to decrease the resolution.

To include the  $I_{aux}$  in the graph:

- ▷ Press the  $I_{aux}$  On button.
- ▷ Click  $I_{aux}$  Off to remove it.

To include the *High Speed Inputs* in the graph:

- ▷ Click **Inputs On**.
- ▷ Double click on the Inputs graph for a closer view.  
Each input is listed on the Y axis followed by a 1 or 0. A 1 denotes that the input is open; a 0 denotes that the input is closed.
- ▷ Click **Inputs Off** to remove the graph.

To *print* the graph:

- ▷ Click the **Print Graph** button.

To *export* an image from the screen:

- ▷ Click the **Export Picture** button.

To *export* the data only:

- ▷ Click the **Export Data** button.


To view details of one of the Waveform graphs:

- ▷ Double-click on the desired graph.

To view details for this waveform:

- ▷ Click on the **Waveform Details On** button.

The following screen appears:



To *return* to the previous graph:

- ▷ Click **Back** or click **Waveform Details Off**.

To *zoom in* on a portion of the graph:

- ▷ Draw a box around the desired area by dragging the mouse and holding down the left button.
- ▷ Release the mouse button to active the zoom.

To *zoom out* on a portion of the graph:

- ▷ Click the **Zoom Out** button to decrease the resolution.


### 8.10.1 Interharmonic Analysis

A new feature has been added to the Log Viewer program for Interharmonic Analysis. It is only available for advanced meters on Voltage ( $V_A$ ,  $V_B$ ,  $V_C$ ) and Current channels ( $I_A$ ,  $I_B$ ,  $I_C$ ,  $I_{AUX}$ ).

IEC-1000-2-1 [1] defines Interharmonics as follows: "Between the harmonics of the power frequency voltage and current, further frequencies can be observed which are not an integer multiple of the fundamental. They can appear as discrete frequencies or as a wide-band spectrum."

To perform the analysis, there must be a waveform record with a 200ms duration. For a 50Hz system, the waveform is 10 cycles; for a 60Hz system, the waveform is 12 cycles. By default, the starting point for Interharmonic Analysis of a Waveform is its first point. But, a user can set a starting point (place the mark) anywhere in the waveform, assuming that there will be enough sample points available after the starting point. If there are not enough points in this waveform capture, the software will check the next waveform record(s) stored in the database. If it is contiguous, additional points up to 200ms will be retrieved for analysis. For a waveform with sampling rate equal to or less than 64, the software will only check the next (1) contiguous record. For a waveform with a sampling rate equal to or greater than 128, the software will check the next two contiguous records. Resetting the mark will set the starting point back to the waveform's first point.

- ▷ From the detailed view of the graph from the main Waveform screen, click the **Interharmonic Analysis** button. The following screen will appear.





To view a graph:

- ▷ Select a **Starting Point**, if it is other than the first point of the waveform (default).

- ▷ Select System Frequency (50Hz or 60Hz) before performing the analysis by clicking **Options** (at the top of the screen) and clicking **50Hz** or **60Hz**.  
(The last frequency set will be the default until it is changed.)

Two more graphs will be displayed:



## Measurement

IEC 61000-4-7 ([ref] First Edition) establishes a well disciplined measurement method for harmonics which utilizes 10 (50Hz systems) or 12 cycle (60Hz systems) sample windows upon which to perform the Fourier transform. The result is a spectrum with 5Hz resolution for both 50Hz and 60Hz systems. The standard further defines ways of combining individual 5 Hz bins to produce various groupings and components for referenced limits and guidelines.

The IEC Measurement Method defines interharmonic groups. These indices are the RMS values of the interharmonic components between adjacent harmonic components. The frequency bins directly adjacent to the harmonic bins are omitted. This relationship is defined by the following equation:

$$x_{IH}^2 = \sum_{i=2}^8 x_{10n+i}^2 \quad (50\text{Hz Systems}) \quad (\text{EQ 8.1})$$


$$x_{IH}^2 = \sum_{i=2}^{10} x_{12n+i}^2 \quad (60\text{Hz Systems}) \quad (\text{EQ 8.2})$$



## 8.11 Viewing the Power Quality Log

- ▶ From Log Viewer's main screen, click on the **Power Quality** button or **View Data > Power Quality**.

Log Viewer will display power quality information for the selected log file(s) based on the time range specified in the Select Time Range section of its main screen (see section 8.4).



To save the data to your clipboard:

- ▶ Right-click with the cursor positioned anywhere in table.

To view waveform information associated with a record or a range of records:

- ▶ Click on the record(s).
- ▶ Click the **Show Waveform Settings** box on the left side of the screen.

To view the PQ/Waveform Settings:

- ▶ Click on the record(s).
- ▶ Click the **PQ/Waveform Settings** box.

To view a waveform:

- ▶ Double-click on the waveform record.  
See section 8.10 for details on viewing waveforms.


To adjust the column widths:


- ▶ Position the cursor between columns at the top of the screen.
- ▶ When the cursor changes to a left/right arrow, hold down the left mouse button and drag the column border left or right.
- ▶ Release the button when the column is at the desired width.

## 8.12 Viewing the Power Quality Graph

To view a graph of any PQ record:

- ▷ Click on the desired record
- ▷ Click the **Graph** button.  
The following screen appears.
- ▷ Use the pull-down menu on the lower right of the screen to access a 3D graph and a Histogram of the record.





Use Scroll Bars on the side and bottom of the screens to adjust the view.

## 8.13 Database Status

The Database Status screen provides statistical information about the selected log(s).

- ▷ Click on the **Database** button or **View Data > Database Status**.  
The following screen appears:

	Device #1	Device #2
Device Type	Nexus	
Device Name	00121689	
Device ID	00121689	
File Name	net/Communicator_ext/retrieved Log(00121689 C30)	
File file size	17,244,160 Bytes	
Number of downloads	18	
First download	7/24/2006 2:33:21 PM	
Last download	7/27/2006 12:17:49 PM	
Number of data points	30	
Database file version	0.6	
Database file description	05/04/2004 Added EN50160 Features	
Crash Log	First Date	Last Date
Snapshots	7/24/2006	7/27/2006
Limits	N/A	N/A
Status Change (inputs)	N/A	N/A


A partial download consists of the newest records and captures appended to the existing records in the log database. The snapshot must be a timeframe within the database dates, otherwise, there is no data from which to retrieve the snapshot.

To copy the data to the computer's clipboard:

- ▷ Right-click with the cursor positioned anywhere in the table.
- ▷ To return to Log Viewer's main screen, click **Back**.

## 8.14 AiReports

AiReports 2.0 is an optional power quality analysis software package used in conjunction with GE Communicator EXT Logs. It provides a comprehensive report on the status of the equipment being monitored and it uses artificial intelligence to diagnose PQ events and provide the possible cause of the event. The screen below is an example of one of the screens.



AiReports 2.0 must be installed on your computer for the view button to be enabled, otherwise, the button will be disabled.

### To view the AiReport

- From the GE Multilin Log Viewer, select a **Meter Database File** for **Meter 1** and set a **Time Range**.
- Click on the **AiReports** button and the report will be generated.

Once the detailed report is generated, you can transmit it to a colleague, modify the report with your favorite word processing software, print it and/or export the file using PDF format.

### Reasons for Incomplete Analysis

AiReports for GE Communicator EXT analyzes the voltage waveform records in the meter database file. If the file does not contain any voltage waveform records, AiReports will not run.

AiReports will not perform a valid analysis on a waveform record if it was converted by the Log Converter program with a version of v1.0.11 (June 26, 2000) or older.

---

## 8.15 PQDIF Converter

The latest release of AiReports includes a new useful feature, PQDIF Converter. Power Quality Data Interchange Format (PQDIF) is a tagged, compressible binary file format which offers a platform-neutral, flexible means of exchanging power quality data between instruments and data management and analysis software. PQDIF is currently under adoption by EPRI as the standard file format for power quality data and under consideration by IEEE as its standard file format.

### Using the PQDIF Export Feature with Log Viewer

**System Requirements:** Installation of AiReports with NEXAIPWR.DII file version 2.1.0.8 or higher. PQDIF Viewer Program optional.

**Meters Supported:** EPM 9450, 9650 and 9800.

**Operation:**

- ▷ Use the **Meter 1** button, select a DB file with waveform data.
- ▷ Select a **Time Range**.
- ▷ Press the **PQDIF Format** button.
- ▷ Select a PQDIF file name (\*.PQD) to which you will export data.
- ▷ Click **OK**.  
PQDIF exports the waveform data and converts it to PQDIF format.

## 8.16 COMTRADE Converter

The latest release of AiReports includes a new useful feature: COMTRADE Converter. Common Format for Transient Data Exchange (COMTRADE) is a standard that defines a format for the files containing transient waveform and event data collected from power systems or power system models. The format is intended to provide an easily interpretable form for use in exchanging data. As such, it does not make use of the economies available from data encoding and compression that proprietary formats depend upon for competitive advantage.

The standard is for files stored on physical media, such as digital hard drives and diskettes. It is not a standard for transferring data files over communication networks. This standard defines a common format for the data files and an exchange medium needed for the interchange of various types of fault, test and simulation data.

The COMTRADE Converter carefully adheres to COMTRADE specification IEC 60255-24 (2001).

### File types and operations

COMTRADE converter will generate the following types of file:

filename.cfg  
filename.dat  
filename.inf  
filename.d##  
filename\_\*.cfg  
filename\_\*.dat  
filename\_\*.inf  
filename\_\*.d##

The term **filename** represents the user specified file name.

The symbol **##** represents a value from '00' through '99'.

The symbol **\*** is the number of 1 or above for each additional waveform record.

File type **cfg** is for Configuration.

File type **dat** is for Data.

File type **inf** is for Information.

The software requires user to enter a unique filename each time the COMTRADE converter runs. Upon COMTRADE Converter startup, it will scan all files with the filename provided by the user at a location associated with COMTRADE (file types listed above). If it finds any file that already exists, the software will issue a message and no conversion will take place.



The software will not overwrite an existing file; it will only convert to a new filename.

## Using the COMTRADE Converter Feature with Log Viewer

**System Requirements:** Installation of AiReports with NEXAIPWR.DII file version 2.1.2.8 or higher. COMTRADE Viewer Program is optional.

**Meters Supported:** EPM 9450, 9650 and 9800.

### Log Viewer Operation:


- ▷ Use the **Meter 1** button, select a DB file with meter waveform data.
- ▷ Select a **Time Range**.
- ▷ Press the **COMTRADE format** button.
- ▷ Enter a unique file name (file extension is not needed) to which you will export data.
- ▷ Click **OK**.

COMTRADE Converter exports the waveform data and converts it to COMTRADE format files.



## 8.17 Status Change Log (Inputs)

The Status Change Log (Input Log) displays the input change status for a selected meter file and time range.



### To view the Status Change Log

- ▷ From the Log Viewer, select a **Meter Database File** and set a **Time Range**.
- ▷ Click the **Status Change Log** button or **View Data > Status Change (Inputs)**.  
The above screen will appear.

Usually, if a record being displayed in the grid box has a start date/time and an end date/time, the state being displayed is and out-of-normal state.

If a record does not show the start time/date or the end date/time, this means that at the time of the log conversion by the Log Converter it could not find the start or end record. This situation can be caused by log rollover and/or other interruptions. Without a start or end record, this will not be a complete record and no duration will be calculated.




Module Index 0 refers to HSI Internal Meter Inputs.

## 8.18 Control Output Log (Relays)

The Control Output Log (Relay Log) displays the relay change status for a selected meter file and time range.

### To view the Control Output Log

- ▷ From the Log Viewer, select a **Meter Database File** and set a **Time Range**.
- ▷ Click on the **Control Output Log** button or **View Data > Control Output (Relays)**.  
This screen appears.



There are three stages in the relay process:

- Stage 1 = Trigger
- Stage 2 = Command
- Stage 3 = Acknowledgement

**Stage 1:** The change relay state process starts.

**Stage 2:** A meter responds to the change relay request and sends out the change relay command to the relay device.

**Stage 3:** The meter gets a response back from the relay device.

A complete record should have all three stages' date/time stamp. The Start State is the relay state at the time of the Trigger. The End State is the relay state at Stage 3 or the Acknowledgement Stage.


### Reasons for Incomplete Records

- At the time of the log conversion process, if the Log Converter cannot find the Stage 1 record (which can be caused by log roll over), the Trigger date/time and the Start State will not be displayed.
- At the time of log conversion, if the Log Converter cannot find the Stage 1 record, the Inputs, Gates and the Relay Start State will not be displayed.

- If the Log Converter program cannot find the Stage 2 record, the Command date/time will not be displayed.
- If the Log Converter cannot find the Stage 3 record, the Acknowledgement date/time and End State will not be displayed and the appropriate duration will not be calculated.
- If any one stage is missing, the appropriate duration will not be calculated.

### To view the GE Graph

- ▷ Click on an event
  - ▷ Click on the **Graph** button.
- The following screen will appear:



### Key Functions for the GE Graph

- Page Up = Previous Relay Record
- Page Down = Next Relay Record
- Home = Current Relay Start State
- End = Current Relay End State





1  
011  
101110011100  
01100111110001  
000111010110110  
11110001001101  
010101110010  
011  
1

# GE Communicator EXT

## Chapter 9: Time-of-Use

---

### 9.1 General Procedure

See the meter's Installation and Operation Manuals for a detailed discussion of the GE Communicator EXT Time-of-Use (TOU) function.

The following is a general outline for programming TOU. Each step is described in detail in subsequent sections.

- ▷ From the Tool Bar, select **Time-of-Use > Calendar Settings**:
- ▷ Create a TOU calendar profile using the following elements:
  - Usage registers (eg "Peak," "Off Peak," "Shoulder Peak") for each fifteen-minute block of the day;
  - Demand Integration Averaging for Block (Fixed) or Rolling (Sliding) Window
  - Programmable start dates for four seasons per year
  - Programmable bill dates for each month of the year
  - TOU schedules—eg, "Weekday," "Weekend," "Holiday"—for each day of the year.
- ▷ Send the TOU calendar profile to the connected meter.  
TOU accumulations will begin.
- ▷ View, print or export the TOU accumulations.
- ▷ Reset the TOU accumulations at any time by selecting **Reset Meter Information** from the Tools Menu (see Chapter 3 for EPM 9450/ 9650 (Chapter 4 for EPM 9800) for details).

Resetting clears all accumulations of the current month or season, causes the accumulations to use the present date as the start-date, and accumulates to the next new end-date, which is taken from the new calendar.

To use **Daylight Savings Time**, you must enable it in the meter's Device Profile (see Chapter 3 (EPM 9450/9650) or 4 (EPM 9800)), and enter the associated dates. Or you can use Auto DST, which sets Daylight Savings Time automatically for the United States only.

If GPS Time (IRIG-B) is connected, you must set the appropriate time zone. Date and time settings (except year) are overridden by GPS Time.




An IRIG-B signal-generating device connected to the GPS satellite system will synchronize meters located at different geographic locations. See the meter's Installation and Operation Manuals for installation instructions.

## 9.2 Creating a TOU Calendar Profile

The TOU calendar profile sets the parameters for TOU data accumulation. You may store up to twenty calendars in the meter and an unlimited amount on your computer. To create a new calendar, follow the steps below. To edit an existing calendar, see section 10.3.

- ▷ From the Time-of-Use menu, select **Calendar Settings**.  
The following screen appears:



- ▷ From the pull-down menu, choose the year for which you would like to create a TOU usage structure.
- ▷ Click on **New Calendar**.  
The following screen appears:


Edit Calendar [New]	
CURRENT YEAR	2006
LABELS	TOU Registers
DEMAND	Averaging
MONTHLY SELF READ	Monthly Bill Date
ADJUSTABLE SELF READ	Period Selection
REGISTER ACCUMULATION	Method
DAILY SETUP	TOU Schedules
	Calendar Assignments
STORE	Update Nexus
	Save to File
<div> Cancel Help </div>	

- ▷ Click on **TOU Registers**.  
The following screen appears:

A dialog box titled "Assign Register Labels" with a blue background. It contains a section labeled "Register Label" with eight numbered input fields (#1 through #8). The first field (#1) contains the text "On-Peak" and the second field (#2) contains "Off-Peak". The remaining fields (#3 through #8) are empty. At the bottom of the dialog are three buttons: "OK", "Cancel", and "Help".

A register is a type of rate structure, for example "Peak", "Off-Peak" or "Shoulder Peak." You will assign one register to each fifteen-minute interval of the day when you set up the TOU schedule (see below).

- ▷ Enter a name for each different register (up to eight).
- ▷ Click **OK** to return to the main Edit Calendar screen.
- ▷ Click **Averaging**.  
The following screen appears:

A dialog box titled "Set Demand Window" with a blue background. It contains a section labeled "Demand Windows" with two radio button options: "Block Window" (which is selected) and "Rolling Window". At the bottom of the dialog are three buttons: "OK", "Cancel", and "Help".

- ▷ Select the type of Demand Averaging to be applied to the TOU accumulations.  
For a discussion on Demand, see the meter's Installation and Operation Manuals.
- ▷ Click **OK** to return to the main Edit Calendar screen.



- ▷ Click on **Monthly Bill Date**.  
The following screen appears:



The dialog box titled "Monthly TOU Report Dates" has a blue background. At the top, "Current Year" is set to "2006". Below this, there are two columns of months from January to December. Each month has a pull-down menu showing a specific day and day of the week. For example, January is "Tue, 3" and September is "Mon, 4". At the bottom are three buttons: "OK", "Cancel", and "Help".

Month	Day	Day of Week
January	Tue, 3	
February	Fri, 3	
March	Mon, 6	
April	Mon, 3	
May	Fri, 5	
June	Fri, 2	
July	Mon, 3	
August	Fri, 4	
September	Mon, 4	
October	Mon, 2	
November	Fri, 3	
December	Mon, 4	

To program a specific Bill Date for each month, use the pull-down menus. If you do not select a specific billing date for a given month, accumulations will continue until the next monthly billing date is reached or December 31, if there is no next year spanning calendar.

- ▷ When you have entered all Monthly Bill Dates, click **OK** to return to the main Edit Calendar screen.
- ▷ Click **Period Selection**.  
The following screen appears:



The dialog box titled "Adjustable Self Period Selection" has a blue background. It features a "Freeze Period" pull-down menu set to "Seasonal". Below this is a "Hour of Day to Freeze" pull-down menu set to "03:00:00". At the bottom, there are four "Season # Start" fields, all labeled "Not Set". At the very bottom are "OK" and "Cancel" buttons.

- ▷ Use the pull-down menus to program a Freeze Period and Hour of Day to Freeze.

- ▷ Double-click one of the **Season Start** windows.  
The Season Start screen appears:



The 'Season Start' dialog box has a blue title bar and background. It contains the following fields and controls:


- TOU Year:** A text box containing '2006'.
- Start Date:** A label above four date input fields.
- Season #1:** A text box containing '1/01/06'.
- Season #2:** A text box containing '4/01/06'.
- Season #3:** A text box containing '7/01/06'.
- Season #4:** A text box containing '10/01/06'.
- Buttons:** 'OK', 'Cancel', and 'Help' at the bottom.

- ▷ Assign a **Start Date** for up to four seasons per year. Enter a date in each window or double-click to retrieve a calendar from which you can choose a Month and a Day.  
All Start Dates also act as the End Date of the prior season or month. A season ends at midnight of the day before the start of the next season.
- ▷ Click **OK** to return to the Adjustable Self Period Selection screen.



The date format you use here should be the same the date format set for your computer. To change or view your computer's date settings, click on the Windows® Start Menu and select Settings, Control Panel, Regional Settings. Click on the Date tab.

- ▷ When all selections are made, click **OK** to return to the main Edit Calendar screen.
- ▷ Click **Method** in the Register Accumulation section of the window.  
The following screen appears:



The 'Current Monthly and Active Registers Accumulation method' dialog box has a blue title bar and background. It contains the following controls:

- Radio buttons:**
  - ☒ Accumulations in Registers start at zero when new period starts
  - ☐ Accumulations in Registers continue where Prior Month and Frozen Registers left off
- Buttons:** 'OK' and 'Cancel' at the bottom.

- ▷ Click the radio button for the type of Accumulations you require and click **OK**.

- ▷ Click **TOU Schedules**.

The following screen appears:

Label	Schedule_1	Schedule_2	Schedule_3	Schedule_4	Schedule_5
00:00:00 - 00:14:59	Off-Peak	Off-Peak	Off-Peak		
00:15:00 - 00:29:59	Off-Peak	Off-Peak	Off-Peak		
00:30:00 - 00:44:59	Off-Peak	Off-Peak	Off-Peak		
00:45:00 - 00:59:59	Off-Peak	Off-Peak	Off-Peak		
01:00:00 - 01:14:59	Off-Peak	Off-Peak	Off-Peak		
01:15:00 - 01:29:59	Off-Peak	Off-Peak	Off-Peak		
01:30:00 - 01:44:59	Off-Peak	Off-Peak	Off-Peak		
01:45:00 - 01:59:59	Off-Peak	Off-Peak	Off-Peak		
02:00:00 - 02:14:59	Off-Peak	Off-Peak	Off-Peak		
02:15:00 - 02:29:59	Off-Peak	Off-Peak	Off-Peak		
02:30:00 - 02:44:59	Off-Peak	Off-Peak	Off-Peak		
02:45:00 - 02:59:59	Off-Peak	Off-Peak	Off-Peak		
03:00:00 - 03:14:59	Off-Peak	Off-Peak	Off-Peak		
03:15:00 - 03:29:59	Off-Peak	Off-Peak	Off-Peak		
03:30:00 - 03:44:59	Off-Peak	Off-Peak	Off-Peak		
03:45:00 - 03:59:59	Off-Peak	Off-Peak	Off-Peak		
04:00:00 - 04:14:59	Off-Peak	Off-Peak	Off-Peak		
04:15:00 - 04:29:59	Off-Peak	Off-Peak	Off-Peak		

- The first column lists each fifteen-minute block of a 24-hour day.
  - The Individual Registers defined in Step 5 will be applied to each fifteen-minute block.
  - A schedule is the type of accumulation structure you will apply to individual days. You may program up to 16 different schedules.
- ▷ Double-click on one of the **Schedule Headings** — for example: "Schedule\_1".

The following screen appears:

- ▷ Enter a Name for the schedule, such as "Weekday," "Weekend" or "Holiday".
- ▷ Click **OK**.

- Double-click on one of the fifteen-minute blocks in the schedule. The following screen appears:




- From the pull-down menu, select the **Register Name** you would like to apply to this fifteen-minute block.
- Click **OK**.
- Repeat the above procedure until all fifteen-minute blocks in the schedule(s) are assigned registers.
- When all schedules are formatted, click **OK** to return to the main Edit Calendar screen.
- Click on **Calendar Assignments**. The following screen appears:




The schedules created in steps 16–21 are shown beneath the calendar. Each schedule is color-coded.

- Assign a particular Schedule to each day by clicking on the day.  
The following screen appears:



- From the pull-down menu, select the **Schedule** you would like to apply to this day.
- Click **OK** to return to the calendar.
- To apply a Schedule to a Range of Dates or to selected days of the week, select and click **Multi Date**.  
The following screen appears:



With the Multi Date button, you can quickly program a whole year (For Example, 2005) by selecting, for instance, all the weekdays (Mon - Fri) and in the Date Range type 01/03/05 to 12/30/05. Do the same for the weekend days. Fill in holidays and vacations for each month.

- Enter a Date Range; select the type of Schedule and, if desired, choose a Day of the Week.
- Click **OK**.
- Use the color-coded key below the calendar to review which Schedules have been applied to the month.
- Click **Next Month** and repeat the process for the year.
- When the calendar settings are complete, click **OK** to return to the main Edit Calendar screen.

You may now:


- Click **Save to File** to send the calendar to the computer for future use.  
See section 10.3 for how to edit a previously saved calendar.

- Click on **Save to File** to store the file in your computer.  
Your computer screen will ask you the File Name, Save In and Save as Type information. Enter data.
- Click **Save** or **Cancel**.
- Click **Update EPM** to send the calendar to the meter.  
The following screen appears:



Before updating the meter, GE Communicator EXT checks that the data entered is valid. It will warn you if any data is not correct. If one of the Status Screens fails, GE Communicator EXT not let you update the device. A pop-up screen will tell you that it is an Invalid Calendar. Click **OK**. You will return to the Edit Calendar screen to create another calendar.

- Click **Continue**.  
The following screen appears:



- Select the slot you would like to use.

▷ Click **Send**.




Communicator will send the calendar to the meter. The above pop-up window will tell you that the calendar was received. Click **OK**. The meter will use the calendar for the designated year, based on the date settings of your computer.




Do not enter more than one calendar for the same year (ie, do not store two calendars for 2005). If this occurs, the meter will use the first calendar entered.

## 9.3 Update a TOU Calendar Profile

- ▷ From the Time-of-Use menu, select **Calendar Settings**.  
The following screen appears:



- ▷ Click **Edit Calendar**.  
The following screen appears:




- ▷ To edit a calendar saved on the computer's hard drive, click **Load From File**.  
Communicator EXT will ask you to locate the calendar. After the calendar has loaded, see section 10.2 for details on programming the calendar.



- ▷ To edit one of the calendars stored in the meter, click **Load From Meter**.


The following screen appears:



- ▷ Select the calendar year you would like to edit and click **Retrieve**. After the calendar year has been retrieved, see section 10.2 for details on editing.

## 9.4 Viewing TOU Accumulated Data

- ▷ From the Real Time Poll menu select **Revenue, Energy and Demand Readings > Time of Use Registers**.



The following screen appears: (If Passwords are Enabled, you must enter a Password to view this screen.)

**Time of Use Readings**

Status: **Active**    Group: **Current Month**    Start Time: **03/30/2006 00:00:00**    End Time: **12/31/2006 23:59:59**    Register: **Register Totals**

---

**Register Accumulations**

Register	Value	Register	Value
VARh	00000.00 k	Q1	00000.00 k
VAh	00000.00 k	Q2	00000.00 k
Rec Wh	00000.00 k	Q3	00000.00 k
VAh	00000.00 k	Q4	00000.00 k
-VARh	00000.00 k		

---

**Register Peak Demand**    Block Window

Register	Value	Time
Delivered Watt	0.00	03/30/2006 14:59:43.14
Received Watt	0.00	03/30/2006 14:59:43.14
Delivered VAR	0.00	03/30/2006 14:59:43.14
Received VAR	0.00	03/30/2006 14:59:43.14
Delivered Watt Coincident VAR	0.00	
Received Watt Coincident VAR	0.00	

---

**Register Cumulative Demand**

Register	Value	Continuous
Delivered Watt	0000000000	0000000000
Received Watt	0000000000	0000000000

Polling 00121689, SN: 00121689

OK    Copy    Export    Print    Help

- ▷ From the **Group** pull-down menu, select the month or season accumulations you would like to view.
- ▷ From the **Register** pull-down menu, select the individual register accumulation (or the total of all registers) you would like to view for the selected month or season.

The EPM Advanced Meters are true four-quadrant power meters. They display the VARs and VA for each quadrant, as illustrated below:

Quadrant	Power Factor	Watts	VARs
1	Lag	+	+
2	Lead	-	+
3	Lag	-	-
4	Lead	+	-

- ▷ **Print or Export** the data by clicking the appropriate button at the bottom of the screen.

**Send Password:** If Passwords are Enabled, the Send Password button will be visible on the screen. You must enter a Password initially to view the screen. Then, when the Password has expired, you must click "Send Password" to continue polling. This feature was initiated because some users found that continuous polling filled up the system event log too fast.

- ▷ Click **OK** to close this window and return to the main GE Communicator EXT screen.






1  
011  
101110011100  
01100111110001  
000111010110110  
11110001001101  
010101110010  
011  
1

## GE Communicator EXT

### Chapter 10: External I/O Modules

#### 10.1 Overview

I/Os must use the EPM Meter's Port 4. EPM9450/9650 can also use Port 3. Set the port to 57600 Baud, Master.



Use these Edit buttons to configure the connected I/Os.

The External Devices section of the EPM Meter's Device Profile (Chapter 3 - 9450/9650, Chapter 4 - 9800) tells the Meter which I/O Modules are connected to it at which addresses. This profile must reflect what is physically attached to the unit. Revise the EPM Meter's Device Profile each time an I/O is added, removed or configured.

Type	Assigned Address	EPM Settings	Module Settings	EPM Port	Log / Limit ID
ImAON4: Analog Out 4 - 20mA 4 ch	132	Edit	Edit	4 AO Module 1	
ImAON4: Analog Out 4 - 20mA 4 ch	133	Edit	Edit	4 AO Module 2	
AI1: Analog In 0 - 1mA 8 ch	136	Edit	Edit	4 AI Module 1	
Device Assigned				4	
Device Assigned				4	
Device Assigned				4	
Device Assigned				4	
Device Assigned				4	
Device Assigned				4	
Device Assigned				4	
Device Assigned				4	
Device Assigned				4	
Device Assigned				4	
Device Assigned				4	
Device Assigned				4	
Device Assigned				4	

Change Address / Baud Rate [Through Nexus]

Device Port: Port 4

	Current Settings	New Settings
Module Address	1	1
Module Baud Rate	57600	57600

Make Change Cancel

The EPM Meter recognizes I/O modules by the unique address assigned to each one. Use the Change I/O Module Address/Baud Rate function to assign a unique address to each I/O before connecting the group to the EPM Meter.

## 10.2 Outline of the Procedure for Installing I/O Modules

The steps below are detailed in subsequent sections of this chapter.

- ▷ Review I/O hardware details in the meter's Installation and Operation Manuals.
- ▷ Before connecting any I/Os to the EPM Meter, make sure each one has its own unique address.  
All I/Os are shipped with a pre-set address and a baud rate of 57600. See section 11.5 for a list of factory-set addresses and baud rates. To assign or change I/O addresses, see section 11.6.
- ▷ Write down the name and unique address of each I/O you will be using. (You will need to know the addresses for the EPM Meter's Device Profile.)
- ▷ Connect the I/O or group of I/Os to the EPM9450/9650 Meter's Port 3 or 4 or EPM 9800 Meter's Port 4.
  - You must use the correct port. Be sure ports are set to operate at the same baud rate as the I/O modules.
  - The ports must also be configured as Masters. See Chapters 3 (EPM 9450/9650) and 4 (EPM 9800) for how to configure the communication ports.
- ▷ Retrieve the EPM Meter's Device Profile.
  - In the External Devices section, enter the name of each I/O and its unique address.
  - Use the Edit buttons to configure the I/Os.
  - Each I/O connected to the unit must be included in the Device Profile.
  - Update the Device Profile to record the changes. See section 11.7.



Updating the Device Profile will reset all logs.

This chapter also covers the following I/O utilities:

- **Meter I/O Device Status** (section 11.13): lists all registered I/Os currently in use.
- **Query I/O Module** (section 11.14): locates an I/O's address and baud rate.
- **Locator Utility** (section 11.15–16): locates an I/O's address and baud rate without using the reset button.
- **Stand Alone Programmer** (section 11.17): allows you to configure all I/O parameters directly from a computer, not through a EPM Meter.

---

## 10.3 Using Multiple I/O Modules

Each type of I/O module is shipped with a factory-set address (see section 11.5). If you plan to use more than one I/O module of the same type (such as three KYZ modules), you must change the address of each module individually before connecting the group to the EPM Meter. See section 11.6 for how to change a module's address and baud rate.

Each I/O module in a group must have its own unique address. Each module must be set to operate at the same baud rate as the EPM 9450/9650 Meter's Port 3 or Port 4 (Port 4 ONLY for EPM 9800) (57600 is recommended).

If you do not know an I/O module's address or baud rate, use the Query I/O function detailed in section 11.14. This function works only on Port 4.

To connect multiple I/Os together, attach the male RS-485 port of one module to the female RS-485 port of another. Secure by tightening built-in fasteners. Attach mounting brackets to the outside modules. Use the steps below (section 11.4) to determine if you must use a separate power source (for example, GE Multilin PSIO) to supply added power to the group.

To connect a group of I/Os to the EPM Meter, connect an RS-485 cable to the group's available female RS-485 port. Connect the other end of the cable to the EPM 9450/9650 Meter's Port 3 or 4 (Port 4 ONLY for EPM 9800).

You may combine different types of I/O modules together in a group.

After all modules have been assigned a unique address and connected to the EPM Meter, you must enter them in the EPM Meter's Device Profile. See section 11.7.

---

## 10.4 Steps to Determine Power Needed

- Available power for All Ports of the EPM 9450/9650 is 12 VA. EPM 9800 does NOT support I/O Modules; a power supply is required.
- Refer to the table in the next section (Section 11.5) to determine the VA Ratings for I/O modules and displays.
- Add together the VA Ratings for I/Os and Displays in use.
- Compare Available Power to Power Needed. See the Meters' Installation and Operation Manuals for details.



## 10.5 I/O Modules' Factory Settings and VA Ratings

All I/Os are shipped pre-programmed with a baud rate of 57600 and addresses. The table below details the factory-set address for each module and the VA Ratings for I/O modules and displays. Refer to the previous section (section 11.4) for the steps to determine if you must use an additional power source with the EPM 9450/9650. EPM 9800 does NOT support I/O Modules; a power supply, such as the PSIO, is required. See section 11.5.1.


To temporarily reset an I/O module to address 247 and 57600 baud (program defaults), press and hold the reset button for 3 seconds. The module will remain in reset mode for 30 seconds.

I/O MODULES FACTORY SETTINGS AND VA RATINGS			
MODEL NUMBER	MODULE	ADDRESS	VA RATING
1mAON4	0-1mA, 4 Analog Outputs	128	2.7 VA
1mAON8	0-1mA, 8 Analog Outputs	128	3.2 VA
20mAON4	4-20mA, 4 Analog Outputs	132	5.0 VA
20mAON8	4-20mA, 8 Analog Outputs	132	8.5 VA
8AI1	0-1mA, 8 Analog Inputs	136	2.3 VA
8AI2	0-20mA, 8 Analog Inputs	140	2.3 VA
8AI3	0-5 VDC, 8 Analog Inputs	144	2.3 VA
8AI4	0-10 VDC, 8 Analog Inputs	148	2.3 VA
4RO1	4 Latching Relay Outputs	156	2.7 VA
4PO1	4 KYZ Pulse Outputs	160	2.7 VA
8DI1	8 Status Inputs (Wet/Dry)	164	1.0 VA
DISPLAYS VA RATINGS			
P40N	LED Display		8 VA
P60N	Touch Screen Display		5 VA


### 10.5.1 Additional Power Source for I/O Modules

Available power for All Ports of the EPM 9450/9650 is 12 VA. The EPM 9800 Power Supply will NOT SUPPLY POWER TO THE I/O MODULES. You must use a power source, such as the PSIO (12V), for additional I/Os connected to the EPM 9450/9650 and for ANY I/Os connected to the EPM 9800. RS-485 communication is viable for up to 4000 feet (1219 meters).


Below are the dimensions and the labels for the PSIO.



PSIO Power Source (Male RS-485 Side Port)



PSIO Power Source with I/O Modules



Labels for PSIO Power Source

### Connection Steps

- ▷ Connect the A(+) and B(-) terminals on the meter to the A(+) and B(-) terminals of the male RS-485 port.
- ▷ Connect the shield to the shield (S) terminal.  
The (S) terminal on the meter is used to reference the meter's port to the same potential as the source. It is not an earth ground connection.  
You must also connect the shield to earth-ground at one point.
- ▷ Put termination resistors at each end, connected to the A(+) and B(-) lines. RT is ~120 Ohms.

## 10.6 Assigning Addresses and Baud Rates to an I/O Module



The utility described below requires the I/O to be connected to the EPM 9450/9650 Meter at Port 3 or 4 (EPM 9800 at Port 4 ONLY). To configure an I/O module by connecting it directly to your computer, use the Stand Alone Programmer utility, section 11.17.

You must know the current address and baud rate of the I/O you want to change. See section 11.5 for a list of factory-settings, if the I/O is new, or use the Query I/O function (section 11.14) (Port 4 ONLY), if the address and/or baud rate has been changed or is no longer known. When you have determined the current address and baud rate, proceed with the steps listed below.

- ▷ Make sure the EPM Meter's Port 3 or 4 is configured to communicate with the I/O module at the same baud rate (57600 recommended).
- ▷ Set the Port to Master mode. See Chapter 3 (EPM 9450/ 9650) or Chapter 4 (EPM 9800) for details on configuring the EPM Meter's communication ports.
- ▷ Connect the I/O to the EPM 9450/9650 Meter's Port 3 or 4 or EPM 9800 Port 4.



You may connect a group of I/Os to the EPM Meter to make address/baud rate changes only if each I/O already has a unique address. If the I/Os have the same address—such as three new KYZ modules—you must connect and change their addresses individually. See section 11.3 for details on using multiple I/O modules.

- ▷ From the I/O Devices menu select Change I/O Module Address/Baud Rate.  
The following screen appears:

- ▷ From the pull down menus, enter the module's current address and baud rate.
- ▷ Enter the address and baud rate you would like to assign.
- ▷ Enter an address from 1 to 247, being sure that the address is not already assigned to any other I/O you will be using.
- ▷ Click **Make Change**.  
A confirmation screen appears after the module has been updated.
- ▷ Repeat the procedure for all I/Os in the group.
- ▷ Write down the module's new address and baud rate.

- ▷ Proceed to section 11.7 to enter the I/O in the EPM Meter's Device Profile and configure all other I/O parameters.

## 10.7 Entering I/O Modules in the EPM Meter's Device Profile

The EPM Meter uses a Master/Slave polling architecture when communicating with the I/O modules; therefore you must enter all I/Os in the EPM Meter's Device Profile. This procedure tells the unit what types of modules are connected to it, what parameters you have set for them and at what address they may be found.

- ▷ Write down the name and unique address of each I/O you plan to use.  
Be sure all baud rates match that of the EPM 9450/9650 Meter's Port 3 or 4 (EPM 9800's Port 4) (57600 is recommended).  
Be sure all addresses are unique. See section 11.6 for how to assign addresses and baud rates.
- ▷ Connect the I/O module(s) to the EPM 9450/9650 Meter's Port 3 or 4 (EPM 9800's Port 4); see the Meter's Installation and Operation Manuals for hardware/installation details.  
Be sure Port 3 or 4 is operating at 57600 baud and is in Master mode (see Chapter 3 (EPM 9450/9650), Chapter 4 (EPM 9800)).
- ▷ Click on the **Edit Profile** button (or select Edit Current Device Profile from the Tools Menu) to retrieve the EPM Meter's Device Profile. (See Chapter 3 (EPM 9450/9650), Chapter 4 (EPM 9800)).
- ▷ When GE Communicator EXT has retrieved the Device Profile from the EPM Meter, double click on **External Devices**.  
The following screen appears.

Device Profile: I/O Modules

Module Number	Type	Assigned Address	EPM Settings	Module Settings	EPM Port	Log / Limit ID
1	20mAON4: Analog Out 4 - 20mA 4 ch	132	Edit	Edit	4	AO Module 1
2	20mAON4: Analog Out 4 - 20mA 4 ch	132	Edit	Edit	4	AO Module 2
3	8AI1: Analog In 0 - 1mA 8 ch	136	Edit	Edit	4	AI Module 1
4	No Device Assigned				4	
5	No Device Assigned				4	
6	No Device Assigned				4	
7	No Device Assigned				4	
8	No Device Assigned				4	
9	No Device Assigned				4	
10	No Device Assigned				4	
11	No Device Assigned				4	
12	No Device Assigned				4	
13	No Device Assigned				4	
14	No Device Assigned				4	
15	No Device Assigned				4	
16	No Device Assigned				4	

OK Cancel Help


- ▷ Click in the **Type** column and use the pull-down menu to select the specific I/O you wish to enter.  
You may enter up to 16 modules.
- ▷ Enter each module's unique address.  
If you have not assigned a unique address to each module, see section 11.6. Each module's address must be unique, otherwise communication will not function properly.

You may now configure the modules using the **Edit** buttons. See the following sections (11.8–11.12) for details on how to configure each type of module.

- ▷ Check the **Table of Contents** for the type of module you want to configure and read the corresponding section.
- ▷ After you have configured all modules, click **OK**.



Log / Limit ID is an internal identification based on the order in which the modules are entered into the profile.



The EPM Meter will begin to look for the modules at the addresses listed. If all are present, the main Device Profile screen will appear. If an incorrect address is given, a screen appears and the changes are rejected. Determine the correct address of any missing I/O using the Query I/O function (section 11.14) (Port 4 Only) or the Locator Utility (section 11.15 - 11.16) and enter the correct information in the External Devices section of the meter's Device Profile.

You MUST now Update the EPM Meter's Device Profile to enter the Modules.

- ▷ Click on **Update Device**.  
This sends the new Device Profile, with the I/O information, to the EPM Meter.
- ▷ Click **Report** to print out a copy of the I/O information.
- ▷ Click **Save** to save these parameters to your computer.
- ▷ Click **Load** to enter a previously saved set of parameters.

## 10.8 Configuring the Analog Output Module

- ▷ Be sure each module has a unique address and is connected to the EPM 9450/9650 Meter's port 3 or 4 or the EPM 9800 Meter's Port 4 at the same baud rate as the port (57600 recommended); see section 11.6.
- ▷ Retrieve the **External I/O Modules** section of the Device Profile from the EPM Meter (see Chapter 3 (9450/9650) or Chapter 4 (EPM 9800) for more detail on the Device Profile and section 11.7).
- ▷ After you have entered the type of Analog Output Module in the Type column and its address in the assigned address column, click on the **Edit** button in the EPM Meter Settings column.  
The following screen appears:

Device Profile: Analog Output

Output	Assigned Item (Click Item to Change)
1	Phase Angles Phase A-N Voltage
2	Not Assigned
3	Not Assigned
4	Not Assigned
5	Not Assigned
6	Not Assigned
7	Not Assigned
8	Not Assigned

Channel Update

For Pulse Accumulators and Aggregator Block Window Average (8 Byte data) only, please choose 4 of the 8 bytes you want to map to the Analog outputs

Bytes 7, 6, 5, 4

OK Cancel Help

- ▷ From the pull-down menus, select the type of reading and the channel to which it will be applied.
- ▷ The module reads a 4-byte value per channel. So, you must select 4 of the 8 bytes to be read by the module.  
Use the pull-down menu to choose 4 of the 8 bytes.
- ▷ Click **OK** when all channels are set.  
The Device Profile: I/O Modules screen appears.



- ▷ Click on the **Edit** button in the Scale Settings.  
GE Communicator EXT retrieves the settings from the I/O module.  
The following screen appears:

Analog Output 4 to 20 mA External Module Programmer

Module Type: Analog Output Module 8 Channel

Version: 0017, Build 112

Address: 132

Baud Rate: 57600

Transmit Delay: 0.0 ms

Scale Settings should be entered in secondary for Volts, Current and Power. All other readings should be entered in primary

Channel #	Scale High Value(20mA)	Scale Low Value(4mA)
1:1 Second Volts AN	120.000	0.000
2:1 Second Volts BN	120.000	0.000
3:1 Second Volts CN	120.000	0.000
4:1 Second IA	5.000	0.000
5:1 Second IB	5.000	0.000
6:1 Second IC	5.000	0.000
7:1 Second Watt Total	1800.000	-1800.000
8:1 Second VA Total	1800.000	-1800.000

Update Cancel Print Save Load Help

For each channel, enter the scale setting according to the needs of your application. The scale High Value refers to the high end of the module; the scale Low Value refers to the low end of the module. For example, if you have a 4–20mA module, the scale High Value determines what 20mA equals. The scale Low Value determines what 4mA equals. (See note below on How to Set Scale Values.)

To change the I/O's Transmit Delay, you must use the Stand Alone Programmer, section 11.17.

- ▷ To enter the scale settings, click on the **Module Settings** button.  
GE Communicator EXT will send the new scale settings to the module and then reset it.
- ▷ Be sure to send the updated Device Profile to the EPM Meter after you have finished configuring all I/Os.
- ▷ Click on the **Update Device** button.



**How to Set Scale Values:** Enter values for volts, current and power in secondary. All other values should be set in primary.

## 10.9 Configuring the Analog Input Module

The Analog Input Module can measure any type of reading, once it is converted to an electrical signal (within limits of the I/O Module). Below is an example of a reading and its conversion to a value:

CONVERSION TO VALUE		
READING	SIGNAL	VALUE
100 <sup>0</sup>	1.0 mA	100%
50 <sup>0</sup>	0.5 mA	50%
0 <sup>0</sup>	0.0 mA	0%
50 <sup>0</sup>	-0.5 mA	-50%
110 <sup>0</sup>	-1.0 mA	-100%

Following are the steps to configure the Analog Input Module:


- ▷ Be sure each module has a unique address and is connected to the meter's Port 3 or 4 at the same baud rate as the port (57600 recommended) (see section 11.6).
- ▷ Retrieve the **External I/O Modules** section of the Device Profile from the meter (section 11.7).
- ▷ After you have entered the type of Analog Input Module in the Type column and its address in the Assigned Address column, click on the meter's **Settings Edit** button.

The following screen appears:

Input	Channel Label	High Value (20mA)	Low Value (4mA)
1	Temp Sensor 1, C	100.0000	-10000000.0000
2	Temp Sensor 2, K	300.0000	-300.0000
3		120.0000	0.0000
4		5.0000	0.0000
5		5.0000	0.0000
6		5.0000	0.0000
7		1800.0000	-1800.0000
8		1800.0000	-1800.0000

OK Cancel Help

- ▷ Enter label and scaling factor for each input.  
The Value columns will appear in either milliamps or Volts, depending on the type of input chosen in the Device Profile.
- ▷ Click **OK** when done.
- ▷ Click on the **Module Settings** button.  
The following screen will appear, reflecting the settings for Address, Baud Rate and Transmission Delay.



## 10.10 Configuring the KYZ Output Module

Be sure each module has a unique address and is connected to the EPM Meter's Port 3 or 4 at the same baud rate as the port (57600 recommended); see section 11.6.

- ▷ Retrieve the External I/O Modules section of the Device Profile from the EPM Meter (see Chapter 3).
- ▷ After you have entered the KYZ module in the Type column and its address in the Assigned Address column, click on the Edit button in the EPM Meter Settings column.

The following screen appears:

The dialog box titled "Device Profile: KYZ Module" contains two columns: "Relay" and "Accumulation". There are four rows corresponding to relays 1 through 4. Relay 1 is set to "Quad 1 Watthour", Relay 2 to "Quad 2 Watthour", Relay 3 to "Quad 3 VAhour", and Relay 4 to "Disabled". At the bottom are "OK" and "Cancel" buttons.

Relay	Accumulation
1	Quad 1 Watthour
2	Quad 2 Watthour
3	Quad 3 VAhour
4	Disabled

- ▷ Assign an accumulation to each relay based on the needs of your application.
- ▷ Click **OK** to return to the main I/O Device Profile screen.
- ▷ Click on the **Edit** button in the Scale Settings.  
GE Communicator EXT retrieves the settings from the I/O module.  
The following screen appears:

The "KYZ External Module Programmer" screen displays configuration fields for a KYZ module. Below these fields is a table with four columns: "KYZ Output", "Watt/Pulse", "Roll Over", and "Min Pulse Width (ms)". The table lists four output configurations, all with a roll-over value of 9999999999999999 and a minimum pulse width of 250 ms.

KYZ Output	Watt/Pulse	Roll Over	Min Pulse Width (ms)
1:Quad (1 + 4) Watthour	72000	9999999999999999	250
2:Quad 4 VAhour	72000	9999999999999999	250
3:Quad 4 VAhour	72000	9999999999999999	250
4:Quad 4 VAhour	72000	9999999999999999	250

- ▷ For each output, enter the Watt per Pulse and the Minimum Pulse Width in milliseconds.
- ▷ Leave the Roll Over at the default value of sixteen 9s.  
This value matches the Roll Over of the EPM Meter. It is important that the Roll Over of the module match the Roll Over of the device

to which it is connected. Change the Roll Over only if you are using the module with a device other than an EPM Meter or if you are using the module as a stand-alone unit.

To change the I/O's Transmit Delay you must use the Stand Alone Programmer, section 11.17.

- ▷ When you have entered the scale settings, click **Update**. GE Communicator EXT will send the new scale settings to the module and then reset it.
- ▷ Be sure to send the updated Device Profile to the EPM Meter after you have finished configuring all I/Os.
- ▷ Click on the **Update Device** button.

### 10.11 Configuring the Digital Output Module

Be sure each module has a unique address and is connected to the meter’s Port 3 or 4 at the same baud rate as the port (57600 recommended); see section 11.6.

- ▷ Retrieve the **External Devices** section of the Device Profile from the meter (see Chapter 3).
  - ▷ After you have entered the Digital Output module in the Type column and its address in the Assigned Address column, click on the **Edit** button in the EPM Meter Settings column.
- The following screen appears:

Relay	Label	Common Shorted to N.C.	Common Shorted to N.O.	Lock to Manual Control
1	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
2	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
3	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
4	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>

OK Cancel Help

- ▷ Enter label and Common Shorted to N.C. or N.O. for each output. Click **Lock to Manual Control**, if desired.
  - ▷ Click **OK** when done.
  - ▷ Click on the **Module Settings** button.
- The following screen will appear, reflecting the settings for Address, Baud Rate and Transmission Delay.

Digital Output External Module Programmer

Module Type:

Version:

Address:

Baud Rate:

Transmit Delay:


Update Cancel Print Save Load Help

## 10.12 Configuring the Relay Outputs

Be sure each module has a unique address, is entered in the EPM Meter's Device Profile and connected to Port 3 or 4 at the same baud rate. See section 11.7.

- ▷ From the I/O Devices menu select **Relay Control**.

The following screen appears:



Each module has four relays that can be configured using this screen.

- ▷ To change the state of one or more relays, click the box next to the relay(s) you want to change.
- ▷ Use the pull down menu next to "Select New State" to assign a **Lock Common to N.C.**, **Lock Common to N.O.** or an **Unlock** state to the relay(s).
- ▷ Click on the **Apply** button to send the new setting to one or more relays of one or more modules.
- ▷ Click **OK** when you have finished configuring all Relay Outputs.

## 10.13 Using the Digital Input Module

Be sure each module has a unique address and is connected to the meter's Port 3 or 4 at the same baud rate as the port (57600 recommended); see section 11.6.

- ▷ Retrieve the **External Devices** section of the Device Profile from the meter (see Chapter 3).
- ▷ After you have entered the Digital Input module in the Type column and its address in the Assigned Address column, click on the **Edit** button in the EPM Meter Settings column.

The following screen appears:

Input	Channel Label	Open Label	Closed Label	Normal State
1	Ext Dig In 1	Open 1	Closed 1	Open
2	Ext Dig In 2	Open 2	Closed 2	Open
3	Ext Dig In 3	Open 3	Closed 3	Open
4	Ext Dig In 4	Open 4	Closed 4	Open
5	Ext Dig In 5	Open 5	Closed 5	Open
6	Ext Dig In 6	Open 6	Closed 6	Open
7	Ext Dig In 7	Open 7	Closed 7	Open
8	Ext Dig In 8	Open 8	Closed 8	Open

OK Cancel Help

- ▷ Enter **Channel Label**, **Open Label**, **Closed Label** and **Normal State** for each input.
- ▷ Click **OK** when done.
- ▷ Click on the **Module Settings** button.  
The following screen will appear, reflecting the settings for Address, Baud Rate and Transmission Delay.



If you are using a Digital Input module with a EPM Meter, you only need to enter the module in the EPM Meter's Device Profile (section 11.7) and configure the screen above; you do not need to configure the module further unless you want to change the roll over. The module's Roll Over should always match the Roll Over of the device to which the module is connected. The Digital Input's default Roll Over parameters are set for use with a EPM Meter; therefore they do not need to be changed



**Digital Input External Module Programmer**

Module Type:

Version:

Address:

Baud Rate:

Transmit Delay:

Digital Input	Roll Over
1: ~~~~~	99999999
2: ~~~~~	99999999
3: ~~~~~	99999999
4: ~~~~~	99999999
5: ~~~~~	99999999
6: ~~~~~	99999999
7: ~~~~~	99999999
8: ~~~~~	99999999

Update Cancel Print Save Load Help

To change the I/O's Transmit Delay, you must use the Stand Alone Programmer, section 11.17.

- Assign a Roll Over to each relay based on the needs of your application.  
If the module is connected to a EPM Meter, you do not need to change the Roll Over from the default.
- Click **Update** to send the new Roll Over settings to the module.


Be sure to send the updated Device Profile to the EPM Meter after you have finished configuring all I/Os.

- Click on the **Update Device** button.


## 10.14 I/O Device Status

This utility allows you to view a list of all the modules that have been entered (“registered”) in the EPM Meter’s Device Profile (see section 11.7).

- ▶ From the I/O Devices menu, select **I/O Device Status**.  
GE Communicator EXT searches for all entered I/O modules.  
The following screen appears (the listings shown are for example only):



- ▶ To view the current programmable settings of a particular module, select it and click **Query**.  
For example, a query of the KYZ module at address 247 yields the following:



- ▶ To change the I/O’s Transmit Delay, you must use the Stand Alone Programmer, section 11.17.
- ▶ Query screens are read-only. To change any parameters you must edit the EPM Meter’s Device Profile (see section 11.7).
- ▶ Click **Refresh** to initiate a new search and listing of connected I/Os.

## 10.15 Query I/O—Locating an Unknown Address and Baud Rate



This utility requires you to press the I/O module's reset button. If you are off-site, or cannot access the reset button, use the Locator Utility described in section 11.15–16.

I/Os may be connected to either the EPM Meter's Port 3 or 4. However, ONLY Port 4 is programmed to query. Be sure the port is configured to operate at 57600 and is set to Master mode; see Chapter 3 for how to configure the EPM Meter's communication ports.

- ▷ Select **I/O Devices > Query I/O Module**.

The following screen appears:



- ▷ Click **Continue**.

The following screen appears:



- ▷ Use a fine point to depress the I/O module's reset button. Hold it in for at least three seconds.

This resets the I/O module to address 247 at 57600 baud for thirty seconds, allowing GE Communicator EXT to retrieve the stored address and baud rate.

- ▷ Click **OK**.

The EPM Meter will begin looking for the device at the temporary address of 247. When the I/O's programmable information is located, the following screen appears:



- ▷ Write down the address and baud rate.


## 10.16 Locator Utility—Through Meter Method

Use this utility if you do not have access to an I/O module's reset button; otherwise use the Query I/O function. The Through Meter Locator Utility searches each address in succession only at the baud rate at which the computer and the EPM Meter are connected.



The Locator Utility—Stand Alone Locator method (section 11.16) allows you to search for an I/O's address and baud rate without a EPM Meter by connecting the I/O directly to the computer.

- ▷ Connect the module to the EPM Meter at Port 4.
- ▷ Establish a connection between the computer and the EPM Meter. The baud rate at which the computer and the EPM Meter are connected is the baud rate that Locator will use to search for the I/O's address.
- ▷ From the I/O Devices menu, select **Locator Utility > Through EPM**. The following screen appears:



- ▷ Set the Address range for the search. GE Communicator EXT will begin at the start address, searching every address up to and including the End Address. Set the Address range as small as possible to limit the time of the search.
- ▷ Click the **Start** button to begin the search.

Device Locator lists any device it finds:

The screenshot shows a software window titled "Through Device Locator". It has a blue background. At the top, there are two input fields: "Start Address" with the value "1" and "End Address" with the value "247". Below these is a "Device Port" dropdown menu set to "Port 4". A status message reads "Searching for a device at Address 168". Below this is a table with two columns: "Device Type" and "Address". The table lists four items: "8AI 0 to 1mA" at address 136, "8AI 0 to 20mA" at address 140, "8AI 0 to 10V" at address 148, and "Digital Input Module" at address 164. At the bottom of the window are four buttons: "Start", "Stop", "Exit", and "Help".

Device Type	Address
8AI 0 to 1mA	136
8AI 0 to 20mA	140
8AI 0 to 10V	148
Digital Input Module	164

- ▷ Device Locator will continue to search for devices until it reaches the end of the specified criteria or until you click **Stop**.
- ▷ Click **OK** to return to the main GE Communicator EXT screen.


## 10.17 Locator Utility—Stand Alone Method

The Stand Alone Locator utility searches for any I/O device connected directly to your computer (it is not for use with remote connections). The search criteria is a programmable range of baud rates and addresses. When a device is found, Locator displays its name, baud rate and address.

To make a Stand Alone connection you will need the following:

- RS-232 Cable
- Unicom 2500 (or similar RS-232/RS-485 converter)
- An RS-485 cable with power wires separated from communication wires; see diagram below.
- A 15–20V DC at 50–200 mA power source for the I/O module, such as model PSIO; you may also use any port on a EPM 9450/9650 Meter as a power source.


▷ Wire the Unicom, I/O module and computer as shown:



▷ Use an RS-232 cable to connect the RS232/485 Converter and your computer:

- Set the Converter to operate at 57600 baud.
- Set the Converter to DCE and HD.

- ▷ Click on the **GE Communicator EXT Connect** icon on the tool bar, or select **Connect > Quick Connect**.  
The following screen appears:

A screenshot of a Windows-style dialog box titled "Connect". It has a blue background. At the top, there are two radio buttons: "Serial Port" and "Network". The "Network" radio button is selected. Below this, there are four labeled text input fields: "Device Address" with the value "1", "Host" with the value "3.94.246.209", "Network Port" with the value "502", and "Protocol" with a dropdown menu showing "Modbus TCP". At the bottom of the dialog, there are three buttons: "Connect", "Cancel", and "Help".


Field	Value
Serial Port / Network	Network
Device Address	1
Host	3.94.246.209
Network Port	502
Protocol	Modbus TCP

This screen displays your computer's communications settings.

- ▷ Leave the Device Address field at **1**.
- ▷ In the Baud Rate field enter 57600 (or the baud rate to which the RS-232/RS-485 converter is set).
- ▷ In the Serial Port field enter the computer's communication port into which the RS-232 cable is inserted.
- ▷ Leave the Protocol field set at Modbus RTU.
- ▷ Click **Connect**.  
GE Communicator EXT will be unable to locate the device; after a few seconds a No Device Found At This Location dialogue box will appear.
- ▷ Click **OK**.



- ▷ From the I/O Devices menu select **Locator Utility > Stand Alone**.  
The following screen appears:




Device Type	Address	Baud Rate
-------------	---------	-----------

- ▷ Set the Address and baud rate ranges for the search.  
GE Communicator EXT will begin at the start address and baud rate, searching every address up to and including the End Address; then it will begin the same address search at the next baud rate in the range.



If you include ALL BAUD RATES, the Device Locator will take about 12 hours to complete the search. If you know the baud rate of the device (EPM Meters are normally 115200, I/O's are 57600), just look in that baud rate. The search will take minutes instead of hours.

- ▷ Click **Start**.  
The Device Locator begins searching for devices within the specified baud rate and address range.



The Device Locator will continue to search for devices until it reaches the end of the specified criteria or until you click Stop.

- ▷ Write down the address and baud rate.
- ▷ Click Exit to return to the main GE Communicator EXT screen.

## 10.18 Stand Alone Programmer

The Stand Alone programmer allows you to configure all parameters of an I/O module or group of I/O modules by connecting the I/O(s) directly to the computer.




If you plan to connect the module(s) to a EPM Meter in the future, you must still enter them in the External Devices section of the EPM Meter's Device Profile. See section 11.7.

To use the Stand Alone Programmer, you will need the following:


- RS-232 Cable
- RS-232/RS-485 Converter
- An RS-485 cable with power wires separated from communication wires; see diagram below.
- A 15–20V DC at 50–200 mA power source for the I/O module, such as PSIO; you may also use any port on a EPM 9450/9650 Meter as a power source.

▷ Wire the RS232/485 Converter, I/O module(s) and computer as shown:



- ▷ Use an RS-232 cable to connect the Unicom 2500 and your computer:
- ▷ Set the Converter to operate at 57600.
- ▷ Set the Converter to DCE and HD.

- ▷ Click on the **GE Communicator EXT Connect** icon on the tool bar, or select **Connect > Quick Connect**.  
The following screen appears.




The **Connect** dialog box has a blue background. At the top, there are two radio buttons: **Serial Port** and **Network**. The **Network** button is selected. Below the radio buttons are four input fields: **Device Address** with the value **1**, **Host** with the value **3.94.246.209**, **Network Port** with the value **502**, and **Protocol** with a dropdown menu showing **Modbus TCP**. At the bottom, there are three buttons: **Connect**, **Cancel**, and **Help**.

This screen displays your computer's communications settings.

- ▷ In the **Device Address** field, enter the current address of one of the I/O modules in the group.  
If you do not know the address, use the Stand Alone Locator utility (section 11.16).
- ▷ In the **Baud Rate** field, enter a baud rate that matches the baud rate of the I/O(s)—57600 recommended.  
If you do not know the baud rate, use the Stand Alone Locator utility (section 11.16).
- ▷ In the **Serial Port** field, enter the computer's communication port into which the RS-232 cable is inserted.
- ▷ Leave the **Protocol** field set to **Modbus RTU**.
- ▷ Click **Connect**.  
GE Communicator EXT searches for a module at the specified baud rate and address.

When it has located the I/O(s), the following screen appears (see **NOTE** below):



The screen shows a table titled "List of Currently Connected Devices". The table has columns for Device, Device Type, Boot, Run-time, DSP Boot, DSP Run-time, Comm State, DSP State, On Time, Serial #, NVRAM, Protection, Xilinx DSP, and Xilinx. The first row shows a device with ID 121689, type EPM 9650, and various status fields. Below the table, there is a status bar that says "Polling Device Info 1". At the bottom, there are **OK** and **Help** buttons.

Device	Device Type	Boot	Run-time	DSP Boot	DSP Run-time	Comm State	DSP State	On Time	Serial #	NVRAM	Protection	Xilinx DSP	Xilinx
121689	EPM 9650	601	618	600	628	Healthy	Healthy	7/25/2006 10:04:34.15	00121689	4 MB	Full Access - Password Protection Disabled	0	3




GE Communicator EXT will find a group of I/Os, if they have been added together on the Connection Manager screen.

- ▷ Click **OK** to close the status screen.

- ▷ From the I/O Devices menu, select **Stand Alone Programmer**.  
GE Communicator EXT retrieves the current settings from the specified I/O and displays them in the Module Programmer screen.

The contents of this screen will vary, depending on the type of module in use. The example below shows the Digital Output Module Programmer screen. See sections 11.8–11.12 for details on the specific programming functions of each module.



- ▷ Make changes to this screen according to the needs of your application.
- ▷ When you have finished configuring the address, baud rate and other programmable settings, click **Send** to send the new settings to the I/O module.
- ▷ If you have connected a group of I/O modules to the computer, click **Retrieve**.
  - At the prompt, enter the address of the next module you wish to program.
  - Click **OK**.  
GE Communicator EXT will retrieve the programmable settings of that device.
- ▷ When you have finished with all programming, click **Exit**.  
Be sure to enter any I/Os in the External Devices section of the meter's Device Profile when you connect them. See section 11.7.





1  
011  
101110011100  
01100111110001  
000111010110110  
11110001001101  
010101110010  
011  
1

# GE Communicator EXT

## Chapter 11: Passwords

### 11.1 Overview



**The use of the Password feature is recommended ONLY if there are security issues and ONLY if you have a secure place in which to save the password.** If you have forgotten your meter password, you cannot call the factory for help. There is no “back door”. If you lose or forget your password, you must send the unit back to the factory to have the Flash RAM that stores the password replaced.

If you are not using this meter for primary revenue metering or for protective functions, you do not need to put a password protection scheme in the unit. If you do, make sure you archive the meter location and associated passwords carefully!

GE Communicator EXT’s password feature protects the following from unauthorized use:

- Changes to an GE Meter’s Device Profile
- Setting Meter Time
- Resetting Meter Information (Max/Min/Demand, Hour Counters, Logs and Time-of-Use)
- Test Mode Entry from software
- Flash Upgrades
- Flicker Start and Stop
- Pulse Test
- CT and PT Compensation
- Relay Control and I/O Utilities
- Time-of-Use Accumulations and changes to the Time-of-Use calendar settings

Password protection has two levels:

- Level 1 accesses Time-of-Use Accumulations Only. These are billing functions.
- Level 2 accesses all password-protected functions (listed above). The Level 2 Password also allows a user to enable or disable the password function.


When the password feature is enabled, GE Communicator EXT will ask for the appropriate password each time a user attempts to perform a protected operation.

The password feature is on a two-minute timer: after exiting from a password-protected area, the user has two minutes to access another protected area without re-entering the password. If more than two-minutes elapse, GE Communicator EXT will ask for the appropriate password. Use the Log On/Off feature (section 12.4) to renew password protection immediately.



## 11.2 Enabling Passwords

- ▷ From the Tools Menu select **Passwords > Enable/Disable**:


A dialog box titled "Enable Password Feature" with a blue background. It contains the text "To Enable Passwords Please Fill In The Following Fields (10 Characters Max For Each)". There are four input fields: "Level 1 Password", "Retype", "Level 2 Password", and "Retype". At the bottom are "OK" and "Cancel" buttons.

Passwords may contain up to 10 characters and may include the digits 0–9 and/or the letters A–Z. Passwords are not case-sensitive.

- ▷ Enter a password for Level 1 and then retype it.  
The Level 1 password blocks a user access to the Poll Time-of-Use Registers screen only without a password.



If you enter and retype only a Level 1 Password or Level 2 Password and click **OK**, the following screen will appear:



You must enter passwords in both fields for the system to accept any password.

- ▷ Enter a password for Level 2 and then retype it.  
The Level 2 password blocks the user's access to all password-protected functions listed in section 12.1 without a password. Only the Level 2 password can disable the password feature. 3.

- ▷ Click **OK**.

A screen appears:



- ▷ Click **Yes**.

The Password Status screen appears:



- ▷ Click **OK**.



The password function is now enabled. The computer status bar at the bottom of the screen will read PW: Enabled. See section 12.4 for how to disable passwords.

## 11.3 Password Status

To confirm if the password protection feature is enabled or disabled, do either of the following:

- ▷ From the Tools menu, select **Passwords > Status**.  
One of two screens will appear -- either the screen stating Password Protection Enabled or the screen stating Password Protection Disabled.
- ▷ Click **OK**.
- ▷ Check the computer status bar at the bottom of the screen.  
If passwords are enabled, it will read "**PW: Enabled**". If passwords are disabled, it will read "**PW: Disabled**." (Access the computer status bar from the View menu).


Connected	Network	TCP/IP	Addr: 1 @ 3.94.246.209	00121689	Modbus TCP	PW: Enabled, SS: Disabled
-----------	---------	--------	------------------------	----------	------------	---------------------------

## 11.4 Disabling Passwords

To disable the password function, you must use the Level 2 password.

- ▷ From the Tools menu select **Passwords > Enable/Disable Passwords**.

The following screen appears:



- ▷ Enter the Level 2 password and click **OK**.



The password function is now disabled. The status bar at the bottom of your screen will now read: **PW: Disabled**.


## 11.5 Logging On and Off

When passwords are enabled, you may Log On using either password level to gain access to protected areas. The two-minute timer described in section 12.1 will still run. Log Off to end your password session and renew password protection immediately (rather than wait for the two-minute timer to expire).

- ▷ Select **Tools > Passwords > Enable/Disable Passwords** (to enable passwords).
- ▷ Select **Tools > Passwords > Log On**.



- ▷ Enter a Level 1 or Level 2 password.
- ▷ Click **OK**.
- ▷ To Log Off, select **Tools > Passwords > Log Off**.  
The status screen returns to remind you that password protection is still enabled.



- ▷ Click **OK**.

## 11.6 Changing Passwords

If you are going to use Passwords, it is a good idea to change them from time to time.

- ▷ From the Tools menu select **Passwords > Change**.

A blue dialog box titled "Change Password" with the instruction "To Change a Password Fill In The Following Fields". It contains three text input fields: "Current Password", "New Password", and "Retype New Password". At the bottom are "OK" and "Cancel" buttons.

- ▷ Enter the password you would like to change in the **Current Password** field.  
You may enter either the Level 1 or the Level 2 password.
- ▷ Type the new password in the **New Password** field, then retype it below.
- ▷ Click **OK**.  
The following screen will appear:

A light gray dialog box titled "Change Password" with the question "Are you sure you want to change the Level 2 Password?". It has "Yes" and "No" buttons.

- ▷ Click **Yes**.



If you forget to type in a new password before you click OK in the Change Meter Password screen, the following screen will appear. The password has to have at least one character and not more than ten.

A light gray dialog box titled "Communicator Ext" with the message "The New Password is too small". It has an "OK" button.

- ▷ Click **OK**.
- ▷ Type in new password then retype it.
- ▷ Click **OK**.
- ▷ Click **Yes**.

You now have a new password.



1  
011  
101110011100  
01100111110001  
000111010110110  
11110001001101  
010101110010  
011  
1

## GE Communicator EXT

# Chapter 12: Flash Upgrading

---

### 12.1 Overview

The **Flash** command allows you to upgrade the following firmware components:

- **GE Communication Processor ("GE Comm").**  
This processing chip performs all tasks related to communication and storing data.
- **GE Digital Signal Processor ("GE DSP").**  
This processing chip performs all tasks related to data calculation.
- **LED Display.**  
This processing chip is installed in the GE External LED Display.
- **Internal Modem Card.**  
This optional card is installed in the meter and enables the meter to act as meter and modem in one device. This card must be upgraded in addition to upgrading the GE Comm and DSP. (Refer to section 13.5.)
- **Internal Network Option.**  
This meter option allows a meter to communicate with multiple PC's concurrently. This card must be upgraded in addition to upgrading the GE Comm and DSP. (Refer to section 13.6.)



The new GE Unit button upgrades the GE Comm and GE DSP firmware files at the same time and provides the checksum automatically (see section 13.2). Again, the optional Internal Modem Card or Internal Network Card must be upgraded separately.

There are 3 ways to learn what firmware versions are currently installed in your GE Meter:

- ▷ Click on the **Device Status** icon (or select **Retrieve Device Status** from the Tools Menu).  
The "Run-time" field shows the current EPM Comm firmware version number; the "DSP Run-time" field shows the current EPM DSP firmware version number.

- ▷ Click on the **Edit Profile** icon to retrieve the current Device Profile from the connected GE Meter.
  - Click on **Report**. The GE Comm and GE DSP firmware are listed in the Runtime column.
- ▷ If you have an External Display connected to the meter, see the **Meter Installation and Operation Manual** for details on using it to access firmware version numbers.



- To flash upgrade, you must have the most recent upgrade file from the factory.
- Flash upgrading erases the existing firmware and replaces it with the new version.
- Flash Upgrading should only be done with the proper firmware. Otherwise, data may be lost! Back up your stored data prior to installing new flash programming into your unit.



## 12.2 Flash Upgrading the EPM Unit


- ▷ Contact GE to receive the most recent firmware upgrade.  
Be sure your version of GE Communicator EXT is compatible with the firmware upgrade you want to perform.  
You can download the latest software version through the internet site at: [www.GEmultilin.com](http://www.GEmultilin.com). Click on the **Free Downloads** button.
- ▷ Copy the new firmware upgrade files to a directory on your computer.  
The GE Comm firmware upgrade is divided into two files. The DSP upgrade is a single file.  
The GE Unit button will upgrade all three files (GE Comm and GE DSP) at the same time. Generally, when you perform an update, update all firmware at the same time.
- ▷ Be sure to read the text file accompanying the firmware files for important information such as the Checksum Code.  
Write down the Checksum Code.  
If you are flashing "GE Comm Only" or "GE DSP Only", you will need it later in the Flash upgrade process.  
Flash upgrading will fail if an incorrect Checksum Code is entered.  
If you are flashing using "GE Unit", the checksum will be entered automatically.



The Checksum Code consists only of the digits 0–9 and the letters A–F. The checksum will never contain the letters O or I, which are often confused for zeros and ones.

Connect to the GE Meter:

- ▷ From the Tools Menu, select **Flash Me**.  
The following screen appears: (If you have not upgraded your software, you will not have a EPM Unit button).  
To Flash Upgrade GE Comm Only or GE DSP Only, see section 13.3.




- ▷ Choose the type of upgrade you want to perform: **GE Unit**, **GE Comm** or **GE DSP**.  
See section 13.3 to Flash Upgrade GE Comm Only or GE DSP Only.  
See section 13.4 to Flash Upgrade the GE External Display, section 13.5 to Flash Upgrade the Internal Modem Card and section 13.6 to Flash Upgrade the Internal Network Option.
- ▷ Click **Next**.  
The screen below appears:



If your meter has the Internal Network Option, that option will appear instead of Internal Modem (see example above). Your meter cannot have both of those options.




- ▷ Click the **Browse** button beside File 1.




- ▷ Locate the firmware file on your computer.  
You will need only one file (\*.ini file) for the GE Unit upgrade. File names and formats may vary from the example screen above. Be sure to read the text file accompanying the firmware files.
- ▷ Select the file.

- ▷ Click **Open**.



- ▷ When the files have been entered, click **Next**.  
The following screen appears:



- ▷ If you are already connected to the GE Meter you want to upgrade, disregard this screen, click **Next** and skip to **Click Start to begin the upgrade** below.
- ▷ If you are not connected to the GE Meter and/or you have a series of GE Meters to upgrade, this screen avoids the reloading of files.
- ▷ In the Address field, enter the Address of the GE Meter to which your computer is connected that you want to 11Flash upgrade.
- ▷ In the Baud Rate field, enter the baud rate of the GE Meter port to which your computer is connected that you want to Flash upgrade.
- ▷ In the Serial Port field enter the computer's comm port you are using.
- ▷ Click **Next**.




If you want to Flash upgrade using a modem, connect with a modem connection first; then, enter the Flash sequence mode.



- ▷ Click **Start** to begin the upgrade.  
A final warning screen appears.
- ▷ Click **Yes**.

Flash upgrading begins. The following screen displays the progress of the upgrade:



When the Flash upgrade is complete, the Cancel button changes to **OK**.

- ▷ Click **OK**.



To upgrade additional GE Meters, click **Previous** and return to the Communications Parameters screen. Repeat the steps as needed, entering a unique address for each unit.

## 12.3 Flash Upgrading the GE Comm and GE DSP Firmware

- ▷ Contact GE to receive the most recent GE firmware upgrade. Be sure your version of GE Communicator EXT software is compatible with the firmware upgrade you want to perform. You can download the latest software version through the internet site at: [www.GEmultilin.com](http://www.GEmultilin.com). Click on the **Free Downloads** button.
- ▷ Copy the new firmware upgrade files to a directory on your computer. The GE Comm upgrade is divided into two files. The DSP upgrade is a single file. The GE Unit upgrade will upgrade all three files (GE Comm files and GE DSP file) at the same time. Generally, when you perform an update, update all firmware at the same time.
- ▷ Be sure to read text file accompanying the firmware files for important information such as the checksum code. Write down the Checksum Code. If you are flashing “GE Comm Only” or “GE DSP Only”, you will need it later in the Flash upgrade process. Flash upgrading will fail if an incorrect checksum code is entered.



The checksum code consists only of the digits 0–9 and the letters A–F. The checksum will never contain the letters O or I, which are often confused for zeros and ones.

Connect to the GE Meter.

- ▷ From the Tools Menu, select **Flash Me**. The following screen appears: (If you have not upgraded your software, you will not have a GE Unit button).




- ▷ Choose the type of upgrade you want to perform: GE Comm or GE DSP. See section 13.2 for how to Flash upgrade the GE Unit. See section


13.4 to Flash Upgrade the GE External Display, section 13.5 to Flash Upgrade the Internal Modem Card and section 8.6 to Flash Upgrade the Internal Network Option.

- ▷ Click **Next**.

The following screen appears:



- ▷ Click the **Browse** button beside File 1.




- ▷ Locate the firmware files on your computer.  
File names and formats may vary from the example screen above; be sure to read the text file accompanying the firmware files.
- ▷ Select the file and click **Open**.

If you are upgrading GE Comm firmware, repeat the process for File 2.

GE DSP firmware requires only one file.

Two files are entered for a GE Comm upgrade.

- ▶ When the files have been entered, click **Next**.  
The following screen appears:



The image shows a Windows-style dialog box titled "Flash Me" with a subtitle "Communications Parameters". It has a blue background. Inside, there are three input fields: "Address" with the value "1", "Baud Rate" with the value "9600", and "Serial Port" with the value "COM1". Each field has a small dropdown arrow on the right. At the bottom, there are three buttons: "Previous", "Next", and "Cancel".

- ▶ If you are already connected to the GE Meter you want to upgrade, disregard this screen, click **Next** and skip to **Click Start to begin the upgrade** below.


If you are not connected to the GE Meter and/or you have a series of GE Meters to upgrade, this screen avoids the reloading of files.

- ▶ In the Address field, enter the Address of the GE Meter to which your computer is connected that you want to flash upgrade.
- ▶ In the Baud Rate field, enter the baud rate of the GE Meter port to which your computer is connected that you want to flash upgrade.
- ▶ In the Serial Port field enter the computer's comm port you are using.
- ▶ Click **Next**.




The image shows a Windows-style dialog box titled "Flash Me" with a subtitle "Flashing Status". It has a blue background. Inside, there is a text area with the message "Warning you are about to begin the Flash Process. Press Start to Continue". Below this, there is a label "Sequence Number" followed by an empty input field. At the bottom, there are three buttons: "Previous", "Start", and "Cancel".

- ▷ Click **Start** to begin the upgrade.  
A final warning screen appears.
- ▷ Click **Yes**.  
This screen appears:



- ▷ Enter the checksum code from the text file accompanying the firmware files.  
If you do not enter the correct checksum code, the flash upgrade will fail.
- ▷ Click **OK**.  
Flash upgrading begins.  
The following screen displays the progress of the upgrade:



When the Flash upgrade is complete, the Cancel button changes to **OK**.

- ▷ Click **OK**.



To upgrade additional GE Meters, click Previous and return to Communications Parameters screen. Repeat the steps as needed, entering a unique address for each unit.



## 12.4 Flash Upgrading the GE External Display

Flash upgrading the GE Display takes approximately 15 minutes.

- ▷ Contact GE to receive the most recent GE External Display firmware upgrade.  
Be sure your version of GE Communicator EXT software is compatible with the firmware upgrade you want to perform.
- ▷ Copy the new firmware upgrade file to a directory on your computer.  
Be sure to read the accompanying text file for important information, such as the checksum code.  
Write down the Checksum Code; you will need it later in the Flash upgrade process. Flash upgrading will fail, if an incorrect checksum code is entered.



The checksum code consists only of the digits 0–9 and the letters A–F. The checksum will never contain the letters O or I, which are often confused for zeros and ones.

- ▷ Make sure the External Display is connected to a GE Meter port operating at 9600 baud. See Chapter 3 for details on configuring the GE Meter's communication ports.


Connect to the GE Meter.

- ▷ From the Tools Menu, select **Flash Me**.  
The following screen appears:




- ▷ Click the **LED Display** radio button.

- Click **Next**.  
The following screen appears:




The GE External Display firmware upgrade requires only one File.

- Click the **Browse** button beside File 1.




- Locate the GE External Display file on your computer.

- ▷ Select the file and click **Open**.  
File names and formats may vary from the example screen above;  
be sure to read the text file accompanying the firmware files.  
The following screen appears:



- ▷ Click **Next**.  
The following screen appears:



- ▷ If you are already connected to the GE Meter, disregard this screen, click **Next** and skip to **Click Start to begin the upgrade process** below.


If you are not connected to the GE Meter:

- ▷ In the Address field, enter the Address of the GE Meter to which your computer is connected and that you want to flash upgrade.

- ▷ In the Baud Rate field, enter the baud rate of the GE Meter port to which your computer is connected and that you want to flash upgrade.
- ▷ In the Serial Port field enter the computer's comm port you are using.
- ▷ Click **Next**.




- ▷ Click **Start** to begin the upgrade process. A final warning screen appears.
- ▷ Click **Yes**. The following screen appears:




- ▷ From the pull-down menus, select **Through Meter** and the port to which the External Display is connected.

- ▷ Click **OK**.

In a moment the following screen appears:



- ▷ Enter the checksum code from the text file accompanying the firmware upgrade file.  
If you do not enter the correct checksum code, the flash upgrade will fail.
- ▷ Click **OK**.  
Flash upgrading begins.  
The following screen displays the progress of the upgrade:



When the Flash upgrade is complete, the Cancel button changes to **OK**.

- ▷ Click **OK**.



To upgrade additional GE External Displays, click Previous and return to Communications Parameters screen. Repeat the steps as needed, entering a unique address for each unit.

## 12.5 Flash Upgrading the Internal Modem Card

- ▷ Contact GE to receive the most recent Internal Modem Option Flash firmware upgrade.  
This Flash Upgrade effects ONLY the Internal Modem Card within the meter.  
This Flash Upgrade DOES NOT UPGRADE THE GE UNIT. To upgrade the GE device, refer to sections 13.2, 13.3 and 13.4 of this manual.  
You can download the latest software version through our internet site at: **www.GEmultilin.com**. Click on the **Free Downloads** button.
- ▷ Copy the new firmware upgrade file to a directory on your computer.  
The Internal Modem firmware upgrade is a single file.
- ▷ Be sure to read the text file accompanying the firmware files for important information such as the Checksum Code.  
Write down the Checksum Code. You will need to verify it later in the Flash Upgrade process.



The Checksum Code consists only of the digits 0–9 and the letters A–F. The checksum will never contain the letters O or I, which are often confused for zeros and ones.

Connect to the GE Meter.

- ▷ From the Tools Menu, select **Flash Me**.

If the Password Feature is Enabled, the following Password screen appears:


Enter Password

Password


OK Cancel

The Password is the number **2**.

- ▷ Enter **2** and click **OK**.  
The Internal Modem Flash Programmer screen appears. Enter Command Mode is highlighted.



- ▷ Click on **Enter Command Mode**.  
In the Status windows, the words "Entering Command Mode" and "Sending Escape Sequence" will appear.  
Then, "In Command Mode" appears on the screen.




- ▷ Click on **Program Flash**.  
The following screen appears:






In this example, the hex file is in a file on the desktop. The hex file may be stored anywhere in your system, on disk or CD. This screen browses your system to find the file.

- ▷ Locate the firmware file on your computer.  
You will need only one file (\*.hex file) for the Internal Modem Upgrade. File names and formats may vary from the example screen above.  
Be sure to read the text accompanying the firmware files.
- ▷ Select the file name and click **Open**.



The program automatically uploads the data. Lines 1 and 2 of the Status window display the progress of the upgrade. When the Flash Upgrade is complete, the Status window will say "Flash has been Programmed" and the Checksum verification window appears:



- ▷ Click **Yes**.  
If you click **No**, the Flash will fail.
- ▷ Click **Exit** to exit the program and return to the Main screen.



## 12.6 Flash Upgrading the Internal Network Option

Flash upgrading the Internal Network (Ethernet) Option takes approximately 30 minutes.

- ▷ Contact GE to receive the most recent Internal Network (Ethernet) Option firmware upgrade.  
This Flash Upgrade effects **ONLY** the Internal Network Option within the meter. This Flash Upgrade **DOES NOT UPGRADE THE GE UNIT**. To upgrade the GE device, refer to sections 13.2, 13.3 and 13.4 of this manual.  
You can download the latest software version through our internet site at: **www.GEmultilin.com**. Click on the Free Downloads button.
- ▷ Copy the new firmware upgrade file to a directory on your computer.  
The Internal Network firmware upgrade consists of two files - an .ini and a .hex file.

Connect to the GE Meter.

- ▷ From the Tools Menu, select **Flash Me**.  
This screen appears:




- ▷ Click **Internal Network** and the **Next** button.  
If the Password Feature is Enabled, the following Password screen appears:



- ▷ Enter your Level 2 Password.

- ▷ Click **OK**.  
The Internal Network Flash Programmer screen appears.  
Enter Command Mode is highlighted.




- ▷ Click on **Enter Command Mode**.  
After a moment "In Command Mode" appears on the screen.
- ▷ Click on **Program Flash**.  
The following screen appears:




In this example, the \*.ini file is in a file on the desktop. The \*.ini file may be stored in your system, on disk or on CD. Use the "Look In:" window at the top of the screen to browse your system.

Locate the firmware file on your computer. You will need two files (\*.ini and .hex files) for the Internal Network Upgrade. Both files must be in the same directory. File names and formats may vary from the example screen above. Be sure to read the text accompanying the firmware files.


- ▷ Select the file name and click **Open**.  
A screen will appear.



- ▷ Click **Yes**.  
The program automatically uploads the data. Lines 2 and 3 of the Status window and the Status Bar below them display the progress of the upgrade. It will automatically retrieve the Checksum from the device. Again, flash uploading takes about 30 minutes.



When the Flash Upgrade is complete, the Status window will say "The Flash has been Programmed" as below.



- ▷ Click **Exit** to exit the program and return to the Main screen.





1  
011  
101110011100  
01100111110001  
000111010110110  
11110001001101  
010101110010  
011  
1

## GE Communicator EXT

# Chapter 13: Energy Billing Module

---

### 13.1 Overview

#### 13.1.1 Managing Your Load Profile

Your monthly electric bill is composed of your total energy usage (kWh) plus your maximum demand (kW) during the billing period. Maximum demand, (a.k.a. peak demand), can represent 30% to 60% of your total energy cost. Managing your load profile is the key to reducing your costs; reducing your peak demand, even without changing your total usage, lowers your costs.

The optimal load profile would be flat, with minimum demand at constant usage. But, a flat load profile is not possible in industrial and commercial environments because of the variation and number of loads in the system. However, there are steps you can take to control those variations and ultimately reduce costs. The steps are listed below:

- Collect historical and real time energy data.
- Use graphical tools to calculate and analyze the data.
- Control loads and shift the timing of demands.
- Calculate savings and results.

The Energy Billing Module detailed in this chapter gives you a tool to use with the EPM 9450, 9650 and 9800 meters to collect data and analyze it. With a few clicks, you can collect historical and real time power usage data so that you can make changes necessary to reduce costs.




FIGURE 13–1: Example Screen for the Energy Billing Module

The Energy Billing Module Graph Screen, as shown in the example screen above, displays a Demand Graph, a Graph Profile by Day and a Graph of kWh Usage by Day for the Date Range selected.

## 13.2 Basic Energy Management

To understand how to manage your power usage, you must understand billing determinants and the terminology of energy management. Below are Basic Energy Terms followed by an Energy Management Example.

### 13.2.1 Basic Energy Terms

<b>Kilowatt hour (kWh)</b>	Measurement for energy equal to the amount of work done by 1,000 watts for one hour.
<b>Kilovolt-ampere-reactive hour (kVARh)</b>	Measurement similar to kWh that reflects current drawn by a customer that produces no useful work, but takes up space on the electrical distribution system.
<b>Megawatt-hour (MWh)</b>	1,000 kWh.
<b>Energy (Active and Reactive)</b>	The total consumption that is measured in Kilowatt hours (kWh) and Kilovolt-ampere-reactive hours (kVARh).
<b>Interval Type</b>	An interval is composed of N subintervals ( $1 \leq N \leq 10$ ). The data collected in the previous N subintervals is used in the demand calculation.
<b>Demand</b>	Rate at which electric energy is delivered to a system, usually expressed in kW or MW. There are two methods for calculating demand: (1) Block window and (2) Rolling (or sliding) window.
<b>Load Factor</b>	An indicator of the quality of the load profile (0 to 1) for a certain period in the electrical system.
<b>Block Demand</b>	Demand calculations performed over a fixed period (interval) of time. When that time period lapses, the next interval starts where the previous interval ended.
<b>Rolling (Sliding) Demand Window</b>	Demand calculations performed over a fixed period (interval) of time that is made up of (n) subintervals ( $n \geq 2$ ). When one subinterval elapses, the demand value is computed by adding the most recently completed subinterval data to the demand interval and subtracting the oldest subinterval data from the demand interval.

<b>Thermal Demand</b>	Emulation of a Thermal Demand Meter that provides an exponentially time-lagged demand where, given a constant load, the indication reads 90% of the actual demand in 15 minutes.
<b>Power Factor</b>	An indicator of the quality of the power (-1 to +1) at a certain point in the electrical system.
<b>Time of Day or Time of Use</b>	Rates vary at different times of the day (on-peak and off-peak) for Energy and Demand.
<b>Off-Peak</b>	Designated periods of low system demand (usually non-business hours) when electricity is generally less expensive.
<b>On-Peak</b>	Designated periods of high system demand when electricity is generally more expensive.
<b>Shoulder</b>	Designated periods between off-peak and on-peak.
<b>Real Time Pricing</b>	The instantaneous pricing of electricity based on the cost of the electricity available for use at the time the electricity is demanded by the customer. Rates are downloaded over the phone or Internet. This is a customized plan.
<b>Aggregation</b>	The combined total energy use of customers/ units/ cost centers for billing purposes.

### Energy Management Example:

A light manufacturer operates on two shifts. The typical electricity cost is about \$150,000 per year. Before the installation of any energy management equipment and software, the facility was paying, in a typical summer month, \$12,000 for electricity.

56,000 kWh (Off-Peak) - \$2,400

120,000 kWh (On-Peak) - \$5,500

480 kW (Peak Demand) - \$4,100

**Total Bill - \$12,000**






FIGURE 13-2: Energy Management Example - Before

With the Energy Billing Module, plant management is able to optimize the loads. Essential loads are monitored and turned on or off in sequence. Simple steps are taken without jeopardizing the integrity of the manufacturing process. Savings in energy costs = 4% (see calculations above and below).

56,000 kWh (Off-Peak) - \$2,400

120,000 kWh (On-Peak) - \$5,500

480 kW (Peak Demand) - \$3,600

**Total Bill \$11,500**




FIGURE 13-3: Energy Management Example - After

Further savings can be realized by doing the following:

- Shift non-essential loads to off-peak hours.
- Flatten the demand curve wherever possible.
- Identify equipment and process problems.
- Negotiate with your utility based on peak demand.
- Source the best utility for your needs.

---

## 13.3 Cost Allocation

In addition to the cost savings steps listed above, further steps can be taken using Cost Allocation. By submetering, one of your primary fixed costs, electricity, becomes a variable cost that can be accurately allocated.

### 13.3.1 Cost Allocation Steps

- Determine cost centers.
- Use submeters to monitor usage at each cost center.
- Assign accountability and offer incentives for departments within a facility to reduce their own energy usage.
- Determine equipment and system efficiency within cost centers.
- Make sure Tenant Billing accurately reflects usage.

### 13.3.2 Cost Allocation System

- One computer at primary facility.
- A number of low cost, high quality meters to monitor usage at each cost center. • A simple network connecting the meters to the computer.
- Energy Billing Module.

## 13.4 System Configuration

The basic Energy Billing Module System consists of the following components:

### Hardware

- A dedicated Energy Billing Module PC or Laptop
- A Unicom RS-232/485 Converter
- At least one Energy Billing Module meter

### Software

- GE Communicator EXT Software (meter programming and communication)
- Energy Billing Module with MS-Excel Macros



MS Excel ('97 or later) must be installed in the computer

### 13.4.1 Setup Requirements for EPM 9450, 9650 and 9800

1. GE Communicator EXT Software
2. GE Log Converter Software
3. GE\_Multilin\_EBM.EBM-DB (template database file)
4. EPM 9450, 9650 or 9800 Meter Log 2, logging interval greater than 0 seconds, less than and equal to 900 seconds and will have an integer number of records during a 15 minute period.  
**Example:** If Log 2 interval is set at x and 900 modulo with interval x is at 0, then setting is OK.
5. EPM Meter Log 2, Log Block Window Avg Watt (Modbus Register 0A35-0A36).
6. EPM Meter Block Window Avg interval set at 15 minutes.
7. GE's EBM Excel worksheet.

### 13.4.2 Setup Requirements for EPM Series 7000 Meters

1. GE Communicator Software
2. GE Log Converter Software
3. GE\_Multilin\_EBM.EBM-DB (template database file)
4. Meter Historical Logging Interval greater than or equal to 60 seconds, less than and equal to 900 seconds and with an integer number of records during a 15 minute period.  
**Example:** If Log Interval is set at x, if 900 modulo with interval x is at 0, then the setting is OK.
5. Meter Historical Log, Log Avg Watt.

6. Meter Avg Window Interval set at 900 seconds (15 minutes).
7. GE's EBM Excel worksheet.
8. Must set Time Sync for Historical Logging.
9. Firmware must support Time-stamped Record.

## 13.5 Operation Overview

### 13.5.1 Creating a Demand Database

- ▷ Click **View > Options > Energy Billing Module** and the screen below appears.
- ▷ Click **Enable Energy Billing Module**. (If the Enable Box is not checked, no data will be processed by EBM.)  
If the option is set, Log Converter will store the Avg Watt values from the log into the new Demand Database.

The new database will carry the same file name as the regular meter database, except the file extension is EBM-DB. If the file does not exist, Log Converter will make a duplicate copy of the template database and rename it [Device\_Name].EBM-DB. There should be no more than 96 records per day in the database. GE's EBM Excel worksheet can be used to load and view the Demand Database.


#### System Requirements:

MS Excel '97, 2000 with SP3 or 2002 installed.



The EBM Excel Spreadsheet File Location is **C:\Program Files\GE Applications\Communicator\_Ext\Add-Ins\GE\_Multilin\_EBM.xls** (shown below: **View > Options** - click on **Energy Billing Module**).

- ▷ Click **Select** for a different location.



### 13.5.2 Using the Excel Spreadsheet

1. On startup, the user must select a valid EBM database file or click the **Load Database** button to select a file.
2. Under **File > Properties > Summary**, the EBM Excel Spreadsheet information will be displayed, including version number and release date.

---

## 13.6 Hardware and Software Installation and Setup

### Hardware Installation:

The typical Hardware Installation for the Energy Billing Module System is an RS-485 loop. However, the network that connects the hardware can be simple or complicated. See Setup Requirements in Section 14.4.

### Software Installation:

The software required for the system, GE Communicator EXT, enables the user to program the meter and to communicate to the computer. GE Communicator EXT software is installed in the meter at the factory. The Energy Billing Module is also installed at the factory. The user may only be required to update the software at some time in the future, when new features are added to the software. The initial installation is done for you.



MS Excel '97, 2000 with SP3 or 2002 Software must be installed on your computer for the Energy Billing Module to work.

---

## 13.7 Using the Energy Billing Module

The Energy Billing Module software is an MS-Excel based graphical user interface for viewing, tracking, comparing and analyzing real time electrical energy data. It is a productivity tool that provides the energy information you need so you can monitor and control your loads to reduce overall energy cost.

The Energy Billing Module is a Visual Basic macro that runs inside MS Excel. The module contains three worksheets:

- **Demand Graphs**  
Graphical presentations of demand and energy usage information.
- **Demand Statistics**  
Statistical data and analysis on demand and energy.
- **Bill Verification**  
Calculate and verify your electrical utility cost based on a utility rate structure.

### Start-up

First, make sure that your meter is connected to the PC.

To start the Energy Billing Module, simply go to the bottom left corner of your Windows main screen and click through the following:

- ▷ **Start > Programs > GE Applications > Log Viewer**  
The Log Viewer screen appears.
- ▷ Click **\$Bill** button MS Excel will start automatically.  
A message box will appear to ask if you want to enable the macros.
- ▷ Click on **Enable Macros**.  
Your screen will display the Demand Graphs screen.

## 13.8 Demand Graphs

First, make sure that the CAM Logger is running at the bottom of your screen.

Available Energy Data will be shown above the Demand Graph, indicating the start and end dates of the data. If you just installed the system, "No Data Available" will appear in this section.

### Select Date Range

To view the graphs, enter your start and end dates in the Start Date and End Date fields. Ranges are limited to days only.

For example, if you want to view data from January 1, 2005 3:00pm to February 23, 2005 6:00am, enter "1/1/2005" in the Start Date field and "2/24,2005" in End Date field.



Make sure the dates are with the range of the Available Energy Data start and end dates. Otherwise, the graphs will not be correct.

### Select Parameters

A list of Energy Billing Module meters will be displayed in the pull-down menu in this section. Select a meter from which you want to retrieve data.

### Refresh Graph

- ▷ Click on **Refresh Graph** to start retrieving graphs for the dates and parameters selected.




DO NOT click anywhere on the spreadsheet while the system is in Calculation Mode!



## Demand Graph

This graph shows the Demand History. Demand data is collected every 15 minutes from the Energy Billing Module meter.



### Profile by Day Graph (upper right)

This graph shows the Daily Peak Demand for the period you selected.

### kWh Usage by Day Graph (lower right)

This graph shows the Aggregated Daily Usage (kWh) for the period you selected. Generic load information is displayed at the bottom of the screen.

## 13.9 Demand Statistics

The Demand Statistics screen displays statistical energy data for the time period you selected.

- Click the **Demand Statistics** tab in the Demand Graph screen. The Demand Statistics screen appears.

Energy Billing Module GE Multilin				
Energy data available from 5/14/2002 to 6/12/2002				
Select Date Range		Select parameters		
Start Date:	6/13/00	Watt, kWh, etc.		
End Date:	6/13/00	Refresh Data		
Peak Time Range				
On-Peak		Mid-Peak		Off-Peak
From	To	From	To	From
06:00	12:00	N/A	N/A	00:00
12:00	17:00	N/A	N/A	17:00
On-Peak		Mid-Peak	Off-Peak	Entire Duration
Peak		0.00	0.00	0.00
Average		0.00	0.00	0.00
Minimum		0.00	0.00	0.00
Load Factor		0.00	0.00	0.00
Total Usage (kWh)		0.00	0.00	0.00
Peak		0.00	0.00	0.00
Average		0.00	0.00	0.00
Minimum		0.00	0.00	0.00
Load Factor		0.00	0.00	0.00
Daily Usage (kWh)		0.00	0.00	0.00
5% Peak Interval		0	0	0
10% Peak Interval		0	0	0
20% Peak Interval		0	0	0
30% Peak Interval		0	0	0
Total Interval		0	0	0

### Select Parameters

- Enter a Start Date, End Date and Select a meter. Peak Time Range is your Utility Time Structure setup.

**Example:** Your utility has the following setup:

On-Peak: 7:00am - 6:00pm.

Off-Peak: 6:00pm - 7:00am.

To retrieve statistics for that setup:

Select the following:

- Select **On-Peak** from 7:00 to 18:00 in Range 1 and N/A's in Range 2.
- Since no Mid-Peak is given, select **Mid-Peak** from 6:00 to 6:00 in Range 1 and 18:00 to 18:00 in Range 2.
- Select **Off-Peak** from 18:00 to 0:00 in Range 1 and from 0:00 to 7:00 in Range 2.
- Click on **Refresh Data** to get statistical results. Data will appear for each time period and for each day.



DO NOT click anywhere on the spreadsheet while the system is in Calculation Mode!

## 13.10 Bill Verification

The Bill Verification screen calculates and displays cost analysis results for a billing period you selected.

- Click the **Bill Verification** tab in the Demand Graph screen. The Bill Verification screen appears.

# Energy Billing Module

## GE Multilin

Energy data available from 5/14/2002 to 6/12/2002

Select Date Range

Start Date: 05/13/2002

End Date: 06/13/2002

Select parameters

In Out\_VMD\_1

Calculate

Distribution

Transmission

Generation

Misc

On-Peak	Mid-Peak	Off-Peak	Sum
\$6.00	\$8.00	\$0.00	\$6.00
\$6.00	\$8.00	\$0.00	\$6.00
\$6.00	\$8.00	\$0.00	\$6.00
\$6.00	\$8.00	\$0.00	\$6.00

Peak Time Range						TOTAL	
On-Peak		Mid-Peak		Off-Peak			
From	To	From	To	From	To		
AM	08:00 - 12:00	N/A	N/A	06:00 - 08:00			
PM	12:00 - 17:00	N/A	N/A	17:00 - 24:00			

Please enter your rate information on the white area.

On-Peak Charge				Mid-Peak Charge				Off-Peak Charge			
Actual KW	Total KWH			Actual KW	Total KWH			Actual KW	Total KWH		
2.00	120.00			6.00	6.00			2.00	15.00		
Demand	Usage(kW)	Rate(\$/kW)	Amount(\$)	Usage(kW)	Rate(\$/kW)	Amount(\$)		Usage(kW)	Rate(\$/kW)	Amount(\$)	
	First		0			0				0	
	Remaining	2.8582356	0			0			2.839678955	0	
Energy	Usage(kWh)	Rate(\$/kWh)	Amount(\$)	Usage(kWh)	Rate(\$/kWh)	Amount(\$)		Usage(kWh)	Rate(\$/kWh)	Amount(\$)	
	First		0			0				0	
	Remaining	320.7998981	0			0			87.99547191	0	
Demand	Usage(kW)	Rate(\$/kW)	Amount(\$)	Usage(kW)	Rate(\$/kW)	Amount(\$)		Usage(kW)	Rate(\$/kW)	Amount(\$)	
	First		0			0				0	
	Remaining	2.8582356	0			0			2.839678955	0	
Energy	Usage(kWh)	Rate(\$/kWh)	Amount(\$)	Usage(kWh)	Rate(\$/kWh)	Amount(\$)		Usage(kWh)	Rate(\$/kWh)	Amount(\$)	
	First		0			0				0	
	Remaining	320.7998981	0			0			87.99547191	0	
Demand	Usage(kW)	Rate(\$/kW)	Amount(\$)	Usage(kW)	Rate(\$/kW)	Amount(\$)		Usage(kW)	Rate(\$/kW)	Amount(\$)	
	First		0			0				0	
	Remaining	2.8582356	0			0			2.839678955	0	
Energy	Usage(kWh)	Rate(\$/kWh)	Amount(\$)	Usage(kWh)	Rate(\$/kWh)	Amount(\$)		Usage(kWh)	Rate(\$/kWh)	Amount(\$)	
	First		0			0				0	
	Remaining	320.7998981	0			0			87.99547191	0	
Demand	Usage(kW)	Rate(\$/kW)	Amount(\$)	Usage(kW)	Rate(\$/kW)	Amount(\$)		Usage(kW)	Rate(\$/kW)	Amount(\$)	
	First		0			0				0	
	Remaining	2.8582356	0			0			2.839678955	0	
Energy	Usage(kWh)	Rate(\$/kWh)	Amount(\$)	Usage(kWh)	Rate(\$/kWh)	Amount(\$)		Usage(kWh)	Rate(\$/kWh)	Amount(\$)	
	First		0			0				0	
	Remaining	320.7998981	0			0			87.99547191	0	
Demand	Usage(kW)	Rate(\$/kW)	Amount(\$)	Usage(kW)	Rate(\$/kW)	Amount(\$)		Usage(kW)	Rate(\$/kW)	Amount(\$)	
	First		0			0				0	
	Remaining	2.8582356	0			0			2.839678955	0	
Energy	Usage(kWh)	Rate(\$/kWh)	Amount(\$)	Usage(kWh)	Rate(\$/kWh)	Amount(\$)		Usage(kWh)	Rate(\$/kWh)	Amount(\$)	
	First		0			0				0	
	Remaining	320.7998981	0			0			87.99547191	0	

Misc 1

Misc 2

## Select Parameters

- ▷ In the Select Data Range field, enter a Start Date and an End Date.
- ▷ In the Select Parameters field, select a meter from which to calculate data.
- ▷ In the Peak Time Range fields, enter the peak time structure (or make changes).
- ▷ In the Rate Structure Table, enter your rate structure in the white spaces in the table. Leave a space empty if it does not apply.

## Rate Structure Table

This generic rate structure table is set up based on utility rates for small and medium industrial and commercial facilities. This model has charges for Distribution, Generation, Transmission and some miscellaneous items. It also allows 1 to 2 tiers in rate structure.

### Example of tiered rate structures:

A company used 5,000 kWh with a 400 kW peak demand during a billing period.

#### Single Tier Rate Structure:

Utility charges a flat usage rate of 4 cents per kWh and a flat demand rate of 2 cents per kW.

#### Double Tier Rate Structure:

Utility charges a usage rate of 4 cents per kWh for the 1st 2000 kWh and a lower usage rate of 3 cents per kWh for the remaining 3000 kWh. Demand rate is 2 cents per kW for the 1st 300kW and 1 cent per kW for the remaining 100kW.

▷ **Double check the data entered in the table and click on Calculate.**



DO NOT click anywhere on the spreadsheet while the system is in Calculation Mode!

## 13.11 Notes


### 13.11.1 Excel 2002

The Excel Spreadsheet used in the EBM is designed for use with Excel '97. When using this module with Excel 2002, the first time a file is opened it takes several minutes for the file to be converted into the updated format. Save the file immediately after the load is completed. After the initial conversion, the file will open more quickly.

When using Excel 2000 with SP3 or 2002, check that a level of security is in place.

- ▷ **Select Tools > Macro.**
- ▷ **Click on Security.**

The following screen appears:



- ▷ **Click Medium.**
- ▷ **Click OK.**


### 13.11.2 Trouble Shooting

If you are experiencing a problem executing this module, you may be missing the DAO component. To add the DAO component to your system, do the following:

- ▷ **Click Tools > Macro > Visual Basic Editor.**  
The Visual Basic Editor screen appears.

On the VB Editor Screen:

- ▷ Click **Tools > References > VBA Project**.  
The following screen appears.



- ▷ Select the **Microsoft DAO 3.6 Object Library** (as highlighted).  
If 3.6 is not available, select the next highest below 3.6.
- ▷ Make sure only one DAO Library is selected.
- ▷ Click **File > Save** before closing the Macros.
- ▷ Save the Excel spreadsheet before closing.



If the user tries to open the EBM file saved in Excel 2002 using Excel '97, a conflict could occur. DO NOT ATTEMPT THIS!

The File Format is not Backwards Compatible!



1  
011  
101110011100  
01100111110001  
000111010110110  
11110001001101  
010101110010  
011  
1

## GE Communicator EXT


### Chapter 14: Script & Scheduler Program

#### - Automated Data Retrieving and Processing -

##### 14.1 Overview

GE Script & Scheduler software program serves as a stand-alone module for the GE Communicator EXT software package. The GE Script & Scheduler program is Automated Data Retrieving and Processing software which automatically retrieves data from GE Power Meters.

With this easy-to-use application, you can set up multiple scripts and schedules that command an GE device to automatically execute scheduled scripts, retrieve stored data files from installed devices and manage batch log conversions. The data retrieved and converted by the Scheduler, as well as other retrieved data, is in Access format and can be viewed in the device Log Viewer.



This is the main screen for the Scheduler. This one screen gives you an overview of the program by displaying the current active scripts and the current status and it provides the links to all the programming features in the sections at the bottom of the screen.

There are two supporting programs: GE Communicator EXT software program and Log Converter program. After GE Communicator EXT finishes retrieving a log or finishes a script, the Log Converter program automatically translates the binary logged data into a database file (Access format).

### 14.1.1 Features

At the top of the screen, the **Run/Stop** button turns the Scheduler On and Off. To add scripts to the Scheduler or edit existing scripts, the Scheduler must be turned OFF. You can perform only one of the following tasks at a time; set up scripts, set up scheduler or run scheduler.

**Active Scripts** window displays the scripts that are currently running on the Scheduler. Using the buttons at the bottom of the screen, those scripts can be edited or deleted and new scripts can be added.

**Current Status** displays the Script & Scheduler operations.

### 14.1.2 Using the GE Scheduler

- ▷ Access the GE Script & Scheduler program from **Drive C:\ Program Files \ GE Applications \ GE Communicator \ Script & Scheduler**.
- ▷ Click on it.  
The main screen (above) will appear.

There are four sections at the bottom of the screen: Script, Scheduler, Status and the Help/ Exit section. The components in these sections enable the user to set up all the elements of the Script & Scheduler program and view the resulting logs. Step by step directions are given in the following sections and Help buttons are on each screen.



To work on the Scheduler, the Scheduler must be stopped, by pressing the Run/Stop button at the top right of the Scheduler window.

- **Set Up Script:**  
Create a new script, open an existing script or delete a script (sections 14.3 - 14.5); Set up Script Devices and Script Commands with buttons on the Set Up Script screen.
- **Set Up Script Devices:**  
Add, edit or delete script devices (sections 14.6 - 14.8)
- **Set Up Script Commands:**  
Add, edit or delete script commands (sections 14.9 - 14.12);
- **Set Up Scheduler:**  
Once a script is created, you must add it to the Scheduler. Add a script to the Scheduler, edit a script or delete a script from the Scheduler (sections 14.13 - 14.15);
- **Status:**  
View the Scheduler Log and clear Current status (section 14.16);



- **Exit:**

Exit from the program (section 14.17). Help Files appear on each page.

Appendix A lists the Component Files of the GE Script & Scheduler program with each file's location in your system.

## 14.2 Operational Overview

The user creates the scripts with the software, adding devices and commands, and sets up the Scheduler. Once this is accomplished, the Scheduler runs automatically, executing the script with the oldest scheduled run time first.

When the script is run by the Scheduler, small windows appear on your PC to advise you that the script is running and data switch strings (if needed) and commands are being sent. A new scheduled run time is calculated. If the Frequency Type is "Once", this script will be removed from the Scheduler immediately. Any failures to connect or complete commands will be noted in the Scheduler log (see Process Log below). A multiple page Script Report will be generated when a user selects a script from the list box and clicks the Report button.

After GE Communicator EXT finishes the script, the Scheduler starts the Log Converter Manager to convert the binary logs to Microsoft Access format. The Scheduler automatically launches the Log Converter program which converts the log files one at a time to a database file after a download has succeeded.

After the Log Converter Manager finishes its conversion, the Scheduler can resume its process and run the next script with the oldest run time. If there are no files to convert, the screen will appear as above.



**Log Converter:** The log converter's purpose is to convert the binary data accumulated from the GE device into the ODBC compliant (Access) database for later retrieval. This is done automatically within the software.



**Devices:** The GE Script & Scheduler can be used with many GE devices, including EPM9450/9650, EPM9800 and Series 7000 meters. The Scheduler Log can be viewed by clicking View Log on the main Scheduler screen. The script logs produced by the Scheduler can be found in **Drive:\ Program Files\ GE \ Communicator\ Retrieve\ Logs**. The files produced by the Log Converter program can be accessed in **Drive:\ Program Files\ GE \ Communicator EXT** in a default subdirectory.

GE Script and Scheduler has a new Process Log, which is in HTML format and carries the .HTML extension. The Process Log consists of three top level files that work together to signal an error and provide links to detailed script logs and detailed log converter logs. Following are the files that make up the Process Log:

**EPMSchedulerLog - Main.Html:** Software generated top layer file with frame set linked to EPMSchedulerLog - Detail.Html and EPMSchedulerRun-TimeLog.Html.

**EPMSchedulerLog - Detail.Html:** Software generated blank frame file.

**EPMSchedulerRun - TimeLog.Html:** Software generated schedule process log with hypertext link to detailed script logs and detailed Log Converter logs.

If any type of error occurs during the execution of a scheduled script, **EPMSchedulerRun-Time Log.Html** will have an entry in red with the appropriate hypertext link to its detailed logs. The Reset Alarm button will also create a visual alarm (red background color) and a continuous beep (until the user clears it), if an error occurs. To clear the contents of a current EPMSchedulerRun-TimeLog.Html file, the user deletes that file from its location.



It is strongly recommended that the user back up that file before deleting it.

### **For a list of all the component files...**

of the GE Script & Scheduler Program and their default locations, see Appendix A.

### **Default locations can be changed...**

but, you must also change the associated programs so they know where to find the files.

### **To change default locations:**

GE Communicator EXT: **View > Options**

### **Scheduler Auto Run and Hide on Windows Start-up:**

The Scheduler runs automatically whenever Windows starts up, if desired. The program will hide the main screen and add an icon to the system tray (lower right hand corner of your screen) and will run unattended. To open the main screen, click on the icon in the system tray. The following are the procedures to set up Auto Run and/or Hide:

- ▷ **Create a shortcut for this program and place it in the Windows Startup folder.**
- ▷ **Add the following to the command line: `/auto /hide`.**  
After the Windows operating system has restarted, this program will automatically start.

## 14.3 Scripts

This application will enable you to set up as many as 300 independent scripts. Each script tells the software to make a connection to a particular GE device and retrieve data from that device. By making selections from the windows on the script screens, you can easily create scripts that automatically retrieve the data you need. This screen is a window to the other script screens.



Each single script can be used to retrieve data from multiple GE meters. You need to assign one script for each telephone number.

The pull-down menu lists all the scripts that have been created and are currently in use with the number the Scheduler assigns to it. If you currently have no scripts, a screen will appear that shows "New Script 1" in the window. "#" is not a valid character for a script name.



- ▷ Stop the Scheduler by clicking the **Run/Stop** button at the top right side of the Scheduler window.
- ▷ Press the **Scripts** button on the Scheduler window.
- ▷ To create a new script, click **New**.  
The Set Up Script screen will appear (see section 14.5).  
After the new script is created, Scheduler will add it to the pull-down menu.
- ▷ To edit an existing script, use the pull-down menu to select a script.
  - Click on the script name.
  - Click **Open**.  
The Set Up Script screen will appear (see section 14.5).
  - Make desired changes.
- ▷ To delete an existing script, use the pull-down menu to select a script.
  - Click on the script name.
  - Click **Delete**.  
A window will appear which asks, "Are you sure you want to delete this script?"
  - Click **Yes** or **No**.
- ▷ To exit either screen and return to the main screen, click **Close**.
- ▷ To generate a multiple page Script Report, select a script from the pull-down menu.

- ▷ Click the **Report** button.  
An example of a Script Report appears in the next section.

## 14.4 Script Report




The Script Report provides a detail of a particular script. For scripts that have many devices and/or many commands, the report may be quite lengthy.

### 14.4.1 Features

- **Print:** To print all or part of the report, type the page numbers and click on **Print**.
- **Save:** To save the report to a particular file, click on **Save**.
- **Cancel:** To exit the report and return to the main screen, click **Cancel**.
- **Scroll Bar:** To move from page to page in the report, click the **Back** or **Forward** Arrows.
- **Zoom:** Use the pull-down menu to select from a variety of magnifications (from Thumbnail to 400%). The screen capture above shows a Zoom of 100%.

## 14.5 Set Up a Script

- ▷ In the Script Name window, type in a name for the script.  
Each script must have a unique name. If the script is not named, a default name is assigned by the software. Most users assign the name of the substation where the device is located as the name. (# is not a valid character for a script.)
- ▷ To select a Connection Type, use the pull-down menu to select either **Remote - Dial Up** or **Direct - Single COM Port**.  
The Script Connection Properties are disabled until you enter this selection. If the Connection Type is not set, GE Communicator EXT program will treat it as an empty script.
- ▷ From the pull-down menu, select the Number of Retries (the number of times the software will try to connect) from 0 to 5.  
In some situations, connecting lines are shared by other programs or telephones. The retries enable the software to try to connect more than once (over a period of a few seconds). If the retries fail, the log will automatically note the date, time and script name for which the connection was not completed. The script will fail.



Connection Type: Direct - Single COM Port

- ▷ Using the pull-down menus, enter the following selections:
  - **Comm Port** - Select from Com 1 to Com 99. (See note below).
  - **Baud Rate** - Select 1200, 2400, 4800, 9600, 19200, 38400, 57600 or 115200.
  - **Flow Control** - Select None or Hardware.
  - **Data Bits** - Select 7 or 8.
  - **Parity** - Select None, Even or Odd.

Connection Type: Remote - Dial Up

Two additional screens will appear.

▷ Enter the following selections:

- **Phone Number** - Type in Phone Number.
- **Setup String** - Type in Data Strings, if needed.

New Connection Type: Ethernet.

To add, edit or delete devices:

▷ Click **Devices** button.

To add, edit or delete commands:

▷ Click **Commands** button.

To exit the screen and return to the main screen:

▷ Click **Close**.




**Choosing a port:** The script opens and closes a PC communication port, creates a log and creates a database for the script. When you run the Scheduler, if the port your script is using is already open (i.e. being used by a different program), the script's command will fail.



## 14.6 Devices

This screen lists the current devices for a particular script. Columns shown include: the device's number or identification, the device's unique address, the device type and the device's unique name.



- You can enter up to 256 devices for each script. The Add, Edit and Delete buttons on this screen facilitate the adding of new devices and the editing and deleting of current devices.
- You must set up an address, protocol, device type and a unique name for each device. Optional settings for each device are passwords for an EPM9450, 9650 or 9800 device. When GE Communicator EXT retrieves a log from a device and it does not have a predefined name, it will use the device name assigned here as the file name for the retrieved log file. If you already named your device, you do not have to assign it a name in this section. We recommend that you keep both names the same.
- To add a device
  - ▷ Click **Add**.  
The Edit Script Device screen will appear.
- To edit a device
  - ▷ Select a device from the list by clicking on it.
  - ▷ Click **Edit**.  
The Edit Script Device screen will appear.
- To delete a device
  - ▷ Select a device from the list by clicking on it.
  - ▷ Click **Delete**.  
A window will appear that asks, "Are you sure you want to delete this device?"
  - ▷ Click **Yes or No**.
- If you Click Edit or Delete before you select a device, a window will appear that says, "Please select a device."
  - ▷ Click **OK**.

- ▷ Select a device and follow the above steps.
- ▷ Click **Close** to return to the Set Up Script screen.

## 14.7 Adding a Script Device

This screen facilitates the adding of new devices to a particular script. You can enter up to 256 devices for each script. For editing of devices, see section 14.8.

You must set up an address, protocol, device type and a unique name for each device. Optional settings for each device are passwords for an EPM 9450, 9650 or 9800. When GE Communicator EXT retrieves a log from a device and it does not have a predefined name, it will use the device name assigned here as the file name for the retrieved log. If you have a name already designated in the device, the device name shown here will not be used.

Note: The EPM7000 Series meters will use the name shown here.

- ▷ Add an EPM 9450, 9650 or 9800
- ▷ Type in a unique **Device Name**.
- ▷ Under Device Information, type in a unique **Address**.
- ▷ To select a protocol, use the pull-down menu. Select **Modbus RTU**, **Modbus ASCII** or **Modbus TCP EI Protocol**.
- ▷ To select a Type (of device), use the pull-down menu.
- ▷ Click your selection.
- ▷ Add Level 1 Password and/or Level 2 Password, if desired. (Not required.)



The device you choose will determine what data is required for this screen. When you add a device, passwords are not required. Also, Data Switch Strings will probably not be necessary. Data Switch Strings tell GE Communicator EXT how to connect to and disconnect when a data switch is present. It already knows how to connect to a single device.

You must set up an address, protocol, device type and a unique name for each device. Optional settings for each device are passwords for an EPM 9450, 9650 or 9800. When GE Communicator EXT retrieves a log from a device and it does not have a predefined name, it will use the device name assigned here as the file name for the retrieved log.


#### Add Multiple Devices

- ▷ Type in a unique **Device Name**.
- ▷ Under Device Information, type in a unique **Address**.
- ▷ To select a protocol, use the pull-down menu.  
Select **Modbus RTU** or **Modbus ASCII**.
- ▷ To select a Type (of device), use the pull-down menu.
- ▷ Click your selection.
- ▷ Add Level 1 Password and/or Level 2 Password, if desired. (Not required.)
- ▷ Click **OK** or **Cancel** to return to the Devices for Scripts screen.

## 14.8 Editing a Script Device



- ▷ Select a device that you would like to edit, by clicking on it. The Edit Script Device screen will appear.
- If you click **Edit** before you select a device, a window will appear that reminds you to "Please select a device."




- ▷ Using the windows available, select or deselect the item(s) you would like to change.
- ▷ Edit the items.
- ▷ Click **OK**.

## 14.9 Script Commands

This screen lists all the current commands for a particular script. You can enter up to 1000 commands for each script and each command is assigned to a selected device for that script. Each device is listed by Index Number, Type, Name and Address and the Command Description follows the device information.

You cannot set up multiple retrieve commands for a single device. But, you can have up to 256 devices for each script.



The sequence of the commands listed on the screen must be valid. To move a command record to a different sequence,

- ▷ Click on the command.
- ▷ Click the **Up** or **Down** buttons to move it.  
The new sequence will be saved to the database when the window is closed.




If the sequence is not correct, you may clear the device's log before retrieving it.

- ▷ To add a command, click **Add**.  
The Edit Script Command screen will appear.
- ▷ To edit a command, select a command by clicking on it.
- ▷ Click **Edit**.  
The Edit Script Command screen will appear.
- ▷ To delete a command, select a command by clicking on it.
- ▷ Click **Delete**.  
A window will appear which asks, "Are you sure you want to delete this command?"
- ▷ Click **Yes** or **No**.
- ▷ To exit the screen, click **Close**.

## 14.10 Add a Script Command

This screen enables you to add or edit a script command. This section will discuss adding a script, Section 14.11 will discuss editing a script command.



### 14.10.1 Add a script command

- ▷ Use the pull-down menu to select a **Device**.  
The device you choose in this window will determine the choices available for the other screens:
- ▷ Use the pull-down menu to select the **Number of Retries** (from 0 to 5).  
This is the number of times the software will attempt to connect.
- ▷ Use the pull-down menu to select a **Primary Command**.
- ▷ Type in or click to select the **Secondary Command(s)**.  
When you add a Device, the Primary Command will be "Retrieve" and the Secondary Commands will be a selection of logs.
- ▷ Click **OK**.

### 14.10.2 Add an EPM 7000 Series Device script command


If you have an EPM 7000 Series Device connected to the GE Script & Scheduler, the above screen will appear slightly different. The process is the same as for an EPM 9450, 9650 and 9800.

## 14.11 Edit a Script Command

- ▷ Select a command that you would like to edit, by clicking on it.  
If you click the **Edit** button before you select a command to edit, a window will appear to remind you to select a command.
- ▷ Click **OK**.
- ▷ Select a command.
- ▷ Click **Edit**.  
The command you choose will determine the screen that appears.

### 14.11.1 Edit an Advanced script command

If you selected an EPM 9450, 9650 or 9800 script command to edit, the following window will appear:



When you edit an advanced device, the Primary Command will be **Retrieve** and the Secondary Commands will be a selection of logs.

- ▷ Using the windows available, select or deselect the item(s) you would like to change.
- ▷ Make the change(s).
- ▷ Click **OK**.



### 14.11.2 Editing a Data Switch or System Device command

If you select a Data Switch or System Device Command to edit, the following screen will appear:


Secondary Commands	
Name	String
1 System data switch string	

If you edit a Data Switch or System Device Command, the Primary Command will be "Send Switch String" and the Secondary Commands will request a System Data Switch String. A tool-tip screen will display special characters to be used in the Data Switch Strings: "&" = line feed, "|" = carriage return. Select or deselect to make changes. Click **OK**.


### 14.11.3 Editing a EPM+ Device command

If you have an EPM7000 Series meter connected to the GE Script & Scheduler, the above screen will appear slightly different. The editing process is the same as for an EPM 9450, 9650 or 9800 device.

## 14.12 Delete a Script Command



- ▷ Select a command you would like to delete by clicking on it.
- ▷ Click the **Delete** button.  
A window will appear.




- ▷ Click **Yes** or **No**.
- ▷ Click **Close** to return to the main script screen.  
A nother warning window will appear.
- ▷ Click **Yes** or **No** to return to the Set Up Script screen.
- ▷ Click **Close** to return to the main Scheduler screen.


## 14.13 Add Scripts to the Scheduler

Once you have created the scripts, they have to be added to the Scheduler. From there, the Scheduler sends the scripts to GE Communicator EXT to be executed. It is at this stage that you set the time and interval for the automatic data retrieval.

- ▷ First, Stop the Scheduler.



- ▷ On the main Scheduler screen, click **Add Script** in the Scheduler section of the screen.  
The following screen will appear:




- ▷ To add a script to the Scheduler, select an **Available Script** from the pull-down menu.  
By changing the Frequency, you can create additional versions of the script and add the updated version(s) to the Scheduler.

- ▷ In the Schedule section of the screen, use the pull-down menu to select the desired **Frequency**.  
Select from: Yearly, Once, Interval, Daily, Weekly, Monthly by Date, Monthly by Day or Last Day of the Month.


Based on the desired frequency, the screen will change to offer the following selections: Month, Date, Day and/or Time (if appropriate).

For example:



- ▷ Use the pull-down menus to make selections.
- ▷ Type in desired time.
- ▷ Click **OK** to add to the Scheduler. Or, click **Cancel**.  
If you click OK, the new scripts will immediately be added to the Scheduler and you will return to the main Scheduler screen.
- ▷ Repeat steps to add additional scripts to the Scheduler.


## 14.14 Edit Scheduler Scripts



To edit a script currently running on the Scheduler,


- Stop the Scheduler.
- Select a script from the **Active Scripts** window.
- Click **Edit Script**.  
 One of the Add/Edit Script to Scheduler screens will appear; the one that is appropriate for the Frequency of the selected script. (Refer to section 14.13 to see a sampling of Add/Edit Script to Scheduler screens.)

Below is a screen for the selected script in the illustration above:




- ▷ To change the frequency, click the pull-down menu for **Frequency** and make a selection.  
If you change the frequency, the screen will change to offer the appropriate selections (Refer to section 14.13 to see a sampling of Add/Edit Script to Scheduler screens).
- ▷ Using the available pull-down menus, make selection(s).
- ▷ Type in the time, if you want it to change.
- ▷ Click **OK** to add to the Scheduler. Or, click **Cancel**.

## 14.15 Delete Scheduler Scripts




To delete a script that is currently running on the Scheduler,

- ▷ Stop the Scheduler.
- ▷ Select a script from the **Active Scripts** window by clicking on it.
- ▷ Click **Delete Script**.  
A warning window will appear:




- ▷ Click **Yes**.  
The script will be deleted immediately from the Active Scripts window and you will return to the main Scheduler screen.

14.16 Status



The Current Status window on the Scheduler screen displays entries in the EPM Scheduler Log. It shows the date, time in minutes and seconds and the status or action performed. The EPM Scheduler Log records all the activities for the GE Script & Scheduler program.

- To view the entire Scheduler Log, click the **View Log** button. The **Scheduler Run-Time Status Log** screen will appear:
- Scroll down to find a particular date, time or action.
- To clear the Current Status window, click the **Clear Status** button. The screen will be cleared as follows:








Individual logs for each script can be found by the name of the script in Drive **C:\ Program Files \ GE Applications \ Communicator EXT \ Script Logs**.

## 14.17 Exit

The best way to Exit the GE Script & Scheduler software program is to click the Exit button on the main Scheduler screen.

- ▷ First, you must **Stop** the Scheduler.
- ▷ If you are on a screen other than the main Scheduler screen, click the **Close** button until you return to the main Scheduler screen.
- ▷ Click **Close**.
- ▷ Click **Exit**.  
A window will appear.



- ▷ Click **Yes** to Exit. Click **No** to remain on the screen.



You can also Minimize the program, if you want the Scheduler to continue to run but not appear on your PC, by clicking the **Minimize** button in the upper right hand corner of the screen. The icon will appear at the bottom of your screen. To restore the Scheduler to view on your screen, click the icon at the bottom of your screen.



1  
011  
101110011100  
01100111110001  
000111010110110  
11110001001101  
010101110010  
011  
1

## GE Communicator EXT

### Chapter 15: Flicker

---

#### 15.1 Overview

Flicker is the sensation that is experienced by the human visual system when it is subjected to changes occurring in the illumination intensity of light sources. The primary effects of flicker are headaches, irritability and sometimes epilepsy.

**IEC 61000-4-15** and former **IEC 868** describe the methods used to determine flicker severity. This phenomenon is strictly related to the sensitivity and the reaction of individuals. It can only be studied on a statistical basis by setting up suitable experiments among people.

## 15.2 Theory of Operation

Flicker can be caused by voltage variations which are caused by variable loads, such as arc furnaces, laser printers and microwave ovens. In order to model the eye brain change, which is a complex physiological process, the signal from the power network has to be processed while conforming with Figure 16.1 below.

- **Block 1** consists of scaling circuitry and an automatic gain control function that normalizes input voltages to Blocks 2, 3 and 4. For the specified 50 Hz operation, the voltage standard is 230 V RMS.
- **Block 2** recovers the voltage fluctuation by squaring the input voltage scaled to the reference level. This simulates the behavior of a lamp.
- **Block 3** is composed of a cascade of two filters and a measuring range selector. In this implementation, a log classifier covers the full scale in use so the gain selection is automatic and not shown here. The first filter eliminates the DC component and the double mains frequency components of the demodulated output.

The configuration consists of a .05 Hz Low High Pass filter and a 6 Pole Butterworth Low Pass filter located at 35 Hz. The second filter is a weighting filter that simulates the response of the human visual system to sinusoidal voltage fluctuations of a coiled filament, gas-filled lamp (60 W - 230 V). The filter implementation of this function is as specified in IEC 61000-4-15.

- **Block 4** is composed of a squaring multiplier and a Low Pass filter. The Human Flicker Sensation via lamp, eye and brain is simulated by the combined non-linear response of Blocks 2, 3 and 4.
- **Block 5** performs an online statistical cumulative probability analysis of the flicker level. Block 5 allows direct calculation of the evaluation parameters Pst and Plt.

Flicker Evaluation occurs in the following forms: Instantaneous, Short Term or Long Term. Each form is detailed below:

### 15.2.1 Instantaneous Flicker Evaluation

An output of 1.00 from Block 4 corresponds to the Reference Human Flicker Perceptibility Threshold for 50% of the population. This value is measured in Perceptibility Units (PU) and is labeled Pinst. This is a real time value and it is continuously updated.

### 15.2.2 Short-Term Flicker Evaluation

An output of 1.00 from Block 5 (corresponding to the Pst value) corresponds to the conventional threshold of irritability per IEC 1000-3-3. In order to evaluate flicker severity, two parameters have been defined: one for the short term called Pst (defined in this section) and one for the long term called Plt (defined in the next section).

The standard measurement time for Pst is 10 minutes. Pst is derived from the time at level statistics obtained from the level classifier in Block 5 of the flicker meter. The following formula is used:

$$P_{st} = (\sqrt{0.0314P_{0.1} + 0.0525P_{1s} + 0.0657P_{3s} + 0.28P_{10s} + 0.08P_{50s}}) \quad (\text{EQ 15.1})$$

Where the percentiles  $P(0.1)$ ,  $P(1)$ ,  $P(3)$ ,  $P(10)$ ,  $P(50)$  are the flicker levels exceeded for 0.1, 1, 2, 20 and 50% of the time during the observation period. The suffix S in the formula indicates that the smoothed value should be used. The smoothed values are obtained using the following formulas:

$$P(1s) = (P(.7) + P(1) + P(1.5))/3 \quad (\text{EQ 15.2})$$

$$P(3s) = (P(2.2) + P(3) + P(4))/3 \quad (\text{EQ 15.3})$$

$$P(10s) = (P(6) + P(8) + P(10) + P(13) + P(17))/5 \quad (\text{EQ 15.4})$$

$$P(50s) = (P(30) + P(50) + P(80))/3 \quad (\text{EQ 15.5})$$

The .3-second memory time constant in the flicker meter ensures that  $P(0.1)$  cannot change abruptly and no smoothing is needed for this percentile.

### 15.2.3 Long-Term Flicker Evaluation

The 10-minute period on which the short-term flicker severity is based is suitable for short duty cycle disturbances. For flicker sources with long and variable duty cycles (e.g. arc furnaces) it is necessary to provide criteria for long-term assessment. For this purpose, the long-term  $P_{lt}$  is derived from the short-term values over an appropriate period. By definition, this is 12 short-term values of 10 minutes each over a period of 2 hours. The following formula is used:

$$P_{lt} = \sqrt[3]{\frac{\sum_{i=1}^N P_{sti}^3}{N}} \quad (\text{EQ 15.6})$$

Where  $P_{sti}$  ( $i = 1, 2, 3, \dots$ ) are consecutive readings of the short-term severity  $P_{st}$ .

### Summary

Flicker = Changes in the illumination of light sources due to cyclical voltage variations.

$P_{inst}$  = Instantaneous flicker values in Perceptibility Units (PU).


$P_{st}$  = Value based on 10-minute analysis.

$P_{lt}$  = Value based on 12  $P_{st}$  values.

### Measurement Procedure

1. Original Signal with amplitude variations.
2. Square demodulator.
3. Weighted filter.
4. Low pass filter 1st order.
5. Statistical computing.

## Data available



$P_{st}$ ,  $P_{st} \text{ Max}$ ,  $P_{st} \text{ Min}$  values for long term recording

$P_{lt}$ ,  $P_{lt} \text{ Max}$ ,  $P_{lt} \text{ Min}$  values for long term recording


Figure 16.1: Simulation of Eye Brain Response

## 15.3 Setup

Initially the user must set up several parameters to properly configure Flicker.

- ▷ Using GE Communicator EXT, from the Icon Menu select **Profile**.
- ▷ From the Device Profile screen, open **+/- Power Quality and Alarm Settings**, then select **EN 50160 Flicker**.

The following screen will appear:



- ▷ Select a  $P_{st}$  time range from 1 to 10 minutes.  
The standard measurement period is nominally 10 minutes.
- ▷ Select a  $P_{lt}$  time range from 1 to 240 minutes.  
The standard measurement is nominally 12  $P_{st}$  periods (120 minutes).  $P_{lt}$  time must always be equal to or greater than and a multiple of  $P_{st}$  time. This is reflected in the selections available to the user.
- ▷ Select the frequency of operation.  
50 Hz is the approved frequency according to Flicker standards. A 60 Hz implementation is available and can be selected. This implementation is the proposed 60 Hz standard that is still in the approval process.  
Remember the voltage is normalized. For 50 Hz, the normalized voltage is 230 V and for 60 Hz, the normalized voltage is 120 V.
- ▷ Press **OK** when you are finished.
- ▷ Press **Help** for more information on this topic.

## 15.4 Software - User Interface

### Main screen

- ▷ From the GE Communicator EXT Icon Menu select **Real Time Poll > Power Quality and Alarms > Flicker**.

The following screen appears:



This section describes the Main Screen functions. The available values (Instantaneous, Short Term, Long Term) will be described below.

### Time

- **Start/Reset** is the time when Flicker was started or reset. A Reset of Flicker causes the Max/Min values to be cleared and restarts the Flicker  $P_{st}$  and  $P_{lt}$  timers. A Start of Flicker is also equivalent to a Reset in that the  $P_{st}$  and  $P_{lt}$  are restarted and the Max/Min Values are cleared.
- **Stop** corresponds to the time when Flicker is turned off.
- **Current** is the current clock time.
- **Next  $P_{st}$**  is the countdown time to when the next  $P_{st}$  value is available.
- **Next  $P_{lt}$**  is the countdown time to when the next  $P_{lt}$  value is available.

### Status

- Indicates the current status. Active = On. Stopped = Off.

### Frequency

- **Base** is the current operating frequency selected by the user (50 or 60 Hz).
- **Current** is the real time frequency measurement of the applied voltage.



- **Base Voltage** is the normalized voltage for the selected frequency (230 V for 50 Hz or 120 V for 60 Hz).

### Flicker Monitoring

- ▷ Click on **Stop** to cause Flicker to stop being processed and freeze all the current values.  
Stop Time is recorded and clears the current Max/Min Values
- ▷ Click on **Start** to start Flicker processing.  
Start Time is recorded.
- ▷ Click on **Reset** to cause the Max/Min values to be cleared and restart the Flicker  $P_{st}$  and  $P_{lt}$  timers.
- ▷ Click **OK** to exit the Flicker screen.
- ▷ Click **Help** for more information on this topic.

### Instantaneous Readings

- ▷ Refer to the Instantaneous section of the Main screen above.
- ▷ If you are on the Short or Long Term screens, click on the **Instantaneous** tab to display the Instantaneous screen.  
The PU values,  $P_{inst}$  for Voltage Inputs  $V_a$ ,  $V_b$  and  $V_c$  are displayed here and are continuously updated. The corresponding Current Voltage values for each channel are displayed for reference.

### Short Term Readings

- ▷ Click on the **Short Term** tab to access the screen containing three groups of  $P_{st}$  readings.

#### $P_{st}$ Readings Displayed

- Current  $P_{st}$  values for  $V_a$ ,  $V_b$  and  $V_c$  and the time of computation.
- Current  $P_{st}$  Max values for  $V_a$ ,  $V_b$  and  $V_c$  since the last reset and the time of the last reset.

- Current  $P_{st}$  Min values for  $V_a$ ,  $V_b$  and  $V_c$  since the last reset and the time of the last reset.
- The following screen is displayed:



Long Term Readings

- ▶ Click on the **Long Term** tab to access the  $P_{lt}$  readings.
- The screen below displays three groups of  $P_{lt}$  values.

$P_{lt}$  Readings Displayed

- Current  $P_{lt}$  values for  $V_a$ ,  $V_b$  and  $V_c$  and the time of computation.
- Current  $P_{lt}$  Max values for  $V_a$ ,  $V_b$  and  $V_c$  since the last reset and the time of the last reset.

- Current  $P_{It}$  Min values for  $V_a$ ,  $V_b$  and  $V_c$  since the last reset and the time of the last reset.

EN 50160 Flicker

Time

Start/Reset00/00/0000 00:00:00

Stop00/00/0000 00:00:00

Current08/04/2006 15:19:37

Next PST0 min, 0 sec

Next PLT0 min, 0 sec

Status

Stopped

Frequency

Base60 Hz

Current50.987 Hz

Base Voltage

120 Volt

Flicker Monitoring

Start

Stop

Reset

Instantaneous

Short Term

Long Term

PLT

Time

Volts A

0.000

00/00/0000 00:00:00.00

Volts B

0.000

00/00/0000 00:00:00.00

Volts C

0.000

00/00/0000 00:00:00.00

Max Volts A

0.000

00/00/0000 00:00:00.00

Max Volts B

0.000

00/00/0000 00:00:00.00

Max Volts C

0.000

00/00/0000 00:00:00.00

Min Volts A

0.000

00/00/0000 00:00:00.00

Min Volts B

0.000

00/00/0000 00:00:00.00

Min Volts C

0.000

00/00/0000 00:00:00.00

Polling Flicker Readings:

OK

Help

Print

---

## 15.5 Logging

The EPM 9450, 9650 and 9800 meters are capable of logging Flicker values in an independent log. When Flicker is on, entries are made into the log in accordance with the times that associated values occur.  $P_{st}$ ,  $P_{st\ Max}$ ,  $P_{st\ Min}$ ,  $P_{lt}$ ,  $P_{lt\ Max}$ ,  $P_{lt\ Min}$ , Start/Reset and Stop times are all recorded. All values can be downloaded to the Log Viewer where they are available for graphing or export to another program, such as Excel.

All Flicker values are predefined and cannot be changed.

---

## 15.6 Polling

The  $P_{inst}$ ,  $P_{st}$ ,  $P_{st\ Max}$ ,  $P_{st\ Min}$ ,  $P_{lt}$ ,  $P_{lt\ Max}$ ,  $P_{lt\ Min}$  values are all capable of being polled through the Communications Port. Refer to the appropriate Modbus and DNP Mappings for register assignments and data definitions.

---

## 15.7 Log Viewer

- ▷ From the GE Communicator EXT Log Viewer screen, using the menus at the top of the Log Viewer screen, select a meter, time ranges and values to access.
- ▷ **Select Flicker.**

The values and the associated time stamps (when the values occurred) are displayed in a grid box. Use the buttons at the bottom of the screen to create a graph or export the data to another program. Max and Min values are only displayed; they cannot be graphed. But, Max and Min values are available for export.

Graphed values include  $P_{st}$  and  $P_{lt}$   $V_a$ ,  $V_b$  and  $V_c$ .

Displayed values include  $P_{st}$  and  $P_{lt}$  Max and Min for  $V_a$ ,  $V_b$  and  $V_c$ .

---

## 15.8 Performance Notes

$P_{st}$  and  $P_{lt}$  average time are synchronized to the clock (e.g. for a 10 minute average, the times will occur at 0, 10, 20, etc.). The actual time of the first average can be less than the selected period to allow for initial clock synchronization.

If the wrong frequency is chosen (e.g. 50Hz selection for a system operating at 60Hz), Flicker will still operate but the values computed will not be valid. Select carefully.

User settings are stored. If Flicker is on and power is removed from the meter, Flicker will still be on when power returns. This can cause data gaps in the logged data.

The Max and Min values are stored and are not lost if the unit is powered down.

Flicker meets the requirements of **IEC 61000-4-15** and former **IEC 868**. Refer to those specifications for more details, if needed.

Operation is at 230V for 50Hz and 120V for 60Hz as per specification. If the input voltage is different, the system will normalize it to 230V or 120V for computational purposes.







1  
011  
101110011100  
01100111110001  
000111010110110  
11110001001101  
010101110010  
011  
1

## GE Communicator EXT

# Chapter 16: Customizing DNP V3.0 Configuration Using GE Communicator

An advanced EPM meter (EPM 9650 and 9800) can measure more than 3000 DNP Static Points. But not all points can be polled at a time. In order for the meter to have the appropriate data, the user should customize the DNP Point Map. This can be done easily using GE Communicator EXT software. Up to 250 points of Event Data can be created in the meter. Refer to DNP V3.00 Level 2 Protocol Assignments for EPM 9650 and 9800, Rev. 1.8, for more details.

---

### 16.1 Connecting to GE Communicator EXT

- ▷ Open GE Communicator EXT software by double-clicking on the icon.
- ▷ Connect to the meter.
- ▷ Click on **Quick Connect**, checking the settings and clicking **Connect**

OR


- ▷ Click on **Connection Manager**, select a location and click **Connect**.

See Chapter 2 of this manual for complete connection instructions.

When a connection is made, a Status Bar will appear showing a Healthy status.

- ▷ Click **OK**.
- ▷ Click the **Edit Profile** icon.  
A pop-up window will tell you that data is being retrieved. The Device Profile screen appears. If the meter (EPM 9650 and 9800) supports DNP V3.00 Level 2, DNP Level 2 will appear in the profile.
- ▷ Click on **+/- General Settings** to open the menu.
- ▷ Click on **+/- DNP Custom Classes Map** to open the menu.

- Click on **DNP Level 2**.  
A set of programming screens appears, the DNP Custom Mapping screens. Each screen has a tab at the top.
- Click on any tab to move from screen to screen.



## 16.2 Binary Input

### Object 1

A meter can use up to 64 Binary Input Points. Values available for Binary Input use can be found in the DNP Object Mapping. Only Class 0 is used when polling Binary Input (Object 1) Data. Class 1, 2 or 3 is used when polling Binary Input Change (Object 2) Data.

### Line, Point, Description

- ▷ Double-click on the box under **Description** to Add, Delete or Modify DNP Points to the screen above.  
A pull-down window will appear.
- ▷ Choose a **Type** (of reading) and a **Channel**.
- ▷ Click **OK**.

The corresponding numbers for the selected reading and channel will appear in the Line and Point columns.

Line and Point Numbers for a Binary Input value can also be found in the DNP Object Mapping (Ch. 7 of the *DNP V3.00 Level 2 Protocol Assignments for EPM 9650 and 9800 Rev.1.8*).

### Example

*1 Cycle High Speed Input Delta and Current State* has Line Number 16 and Point Number 0 in the DNP Object Mapping.

- ▷ Write those numbers into the Object 1 – Binary Input window of the GE Communicator EXT.
- ▷ When the Line and Point Numbers are written, the software fills in the description on the screen.
- ▷ Repeat for each desired Binary Input Point.
- ▷ **Update the device.**

The meter will scan those points every second.

### Object 2

Any DNP Static Point can be configured to create a DNP Event Points. Class Assignments on the Object 2 screen are used to configure Binary Input Change Event Points. In order to create Event Data, Object 2 Points must be assigned to Class 1, 2 or 3. Each point can have a different Class Assignment.

The Clear All button clears all assigned items on all the tabs.

The Clear button clears only the items on the current tab view.

## 16.3 Analog Input (Object 30)

A meter can use up to 64 Analog Input points. Values available for Analog Input use can be found in the EPM DNP Object Mapping. Only Class 0 is used when polling Analog Input (Object 30) Data. Class 1, 2 or 3 is used when polling Analog Change Event (Object 32) Data.

DNP Points	Map		Description	Deadband (%)	Class Assignments
	Line	Point			
0					Object 32
1					
2					
3					
4					
5					
6					
7					
8					

Enter GE Line and Point assignments from the DNP Table or double click the Description Field for a list of Selections.  
 Enter a dead band % to be used in causing an associated Object 32 value. (See Manual for Description of base values used by the dead band %)  
 For Object 32 assign a class.

OK Cancel Help Clear Clear All

### Line, Point, Description

- ▷ Double-click on the box under **Description**.  
A pull-down window will appear.
- ▷ Choose a **Type** (of reading) and a **Channel**.
- ▷ Click **OK**.

The corresponding numbers for the selected reading and channel will appear in the Line and Point columns.

Line and Point Numbers can also be found in the DNP Object Mapping (Chapter 7 of the *DNP V3.00 Level 2 Protocol Assignments for EPM 9650 and 9800 Rev. 1.8*).

### Example

One Second Phase A-N Voltage is Line Number 34 and Point Number 0 in the DNP Object Mapping.

- ▷ Write these numbers into the Object 30 – Analog Input window of GE Communicator EXT.

When the Line and Point Numbers are written, the software will fill in the description.

- ▷ Repeat for each desired Analog Input Point.
- ▷ Click **OK** to return to the main GE Communicator EXT screen.
- ▷ Click **Update Device** to update the meter.

The meter scans those points every second (except for Tenth Second Readings). Tenth Second Readings (Line 18 to 32) are scanned as soon as the meter detects a change (as often as every 50 milliseconds).

### Deadband (%) (Object 32)

Any DNP Static Point can be configured to create DNP Event Points. Deadband and Class Assignments on the Object 32 screen are used to configure Analog Change Event Points. In order to create Event Data, Object 32 Points must be assigned to Class 1, 2 or 3. Each point can have a different Class assignment.

Deadband (%) defines the boundary value for that point. For example, suppose One Second Phase to Neutral Volts AN is programmed and the Voltage Full Scale is 120.00V for the meter. Entering 10% for Deadband will define the boundary value of 12V (10% of 120V). Every second, new Static Data is scanned for One Second Phase to Neutral Volts AN. If the new data is different from the previous standard value by the boundary value, an Analog Change Event will be created.

#### Example

If the previous standard value is 110 and new data is lower than 98V or higher than 122V, a new Analog Change Event Point will be created. The new value then becomes the previous standard value for future scans.

Analog Input Points have various Full Scales values due to different data types (Volts, Amps, Watts, etc.). These Full Scale values are used for Exception Polling in DNP. Some Full Scale values are programmable by users and others have fixed numbers. See the chart of Full Scale Values below.

The **Clear All** button clears all assigned items on all the tabs.

The **Clear** button clears only the items on the current tab view.

**Full Scale** values are 4-byte integer numbers. The units are as follows:

Analog Input	Full Scale	Unit
I A, B, C, Nc	Programmable	1/65536 Amps
I Nm	Programmable	1/65536 Amps
V AN, BN, CN	Programmable	1/65536 Volts
V AB, BC, CA	Programmable	1/65536 Volts
V Aux	Programmable	1/65536 Volts
Power Phase	Programmable	1/65536 Watts
Power Total	Programmable	1/65536 Watts
Frequency	Programmable	1/65536 Hz
Power Factor	4000	0.001 PF
Angles	18000	0.001 PF
Percent	10000	0.01 %
K-Factor	500	0.01
TOU Ratio	N/A	N/A
Temperature	10000	0.01

Flicker	65536	0.0001
In Interval	1000	1000
Day of Week	6	1
Sequence	1	1
Status	100	1
Avg Select	100	1
Delay	100	1
Log Index	100	1
Countdown	100	1

**Example**

In order to find out if there is new log data, use a Log Index Number. One of the Log Index Numbers (Last Index) will increase when a new log is created. In Object 30, Program Last Log Record Index: Waveform Log (Line 499, Point 7). Input Deadband 1.00% and assign a Class. The exception data will be created when the Index Number increases by one.

## 16.4 Binary Counter (Object 20)

A meter can use up to 8 Binary Counter Points. Values available for Binary Counter use can be found in the DNP Object Mapping. Only Class 0 is used when polling Binary Counter (Object 20) Data and Frozen Counter (Object 21) Data. Class 1, 2 or 3 is used when polling Counter Event (Object 22) Data and Frozen Counter Event (Object 23) Data.

DNP Points	Map		Description	Scaling	Object 22		Object 23
	Line	Point			Delta	Class	Class
0							
1							
2							
3							
4							
5							
6							
7							

Enter GE Line and Point assignments from the DNP Table or double click the Description Field for a list of Selections. Enter a Digit Scaling Number(0 to 15) for the point where Number is represented by x in the 10<sup>x</sup> power scaling equation.

Each Object 20 assigned has an associated Object 22 and 23. For Object 22, enter a delta value to trigger the DNP event and assign a class. For Object 23 assign a class.

OK Cancel Help Clear Clear All

### Line, Point, Description

- ▷ Double-click on the box under **Description** to Add, Delete or Modify DNP Points.  
A pull-down window appears.
- ▷ Choose a **Type** (of reading) and a **Channel** and click **OK**.

The corresponding numbers for the selected data and channel will appear in the Line and Point columns.

Line and Point Numbers can also be found in the DNP Object Mapping (Ch. 7 of *DNP V3.00 Level 2 Protocol Assignments for EPM 9650 and 9800 Rev. 1.8*).

### Example

VA hour has Line Number 133 and Point Number 0 in the DNP Object Mapping.

- ▷ Write those numbers into the Object 20- Binary Counter window of GE Communicator EXT.

When the Line and Point Numbers are written, the software fills in the description on the screen.

- ▷ Repeat for each desired Binary Counter Point.
- ▷ Update the device.

The meter scans those points every second.

## Scaling

A meter can measure its Binary Counter value using up to a 16-digit number (0 to 9,999,999,999,999,999). DNP Binary Counter Points use up to 32 bits. That means that the range is 0 to 4,294,967,295 (0x0FFFFFFF). This maximum number is only a 10-digit number. In order to deal with a 16-digit number, Scaling is necessary.

Scaling is used to select a unit in powers of 10: 1 = x10, 2 = x100 and so on. The Scaling value can be 0 to 15.

### Example

If the value inside the meter is 3,000,000 and a Scaling value of 2 (x100) is used, the Binary Counter value will be reported as 30000. The actual value is  $30000 \times 100 = 3,000,000$ .

## Delta (Object 22)

Any DNP Static Point can be configured to create DNP Event Points. Delta and Class Assignments on the Object 22 screen are used to configure Counter Change Event Points. In order to create Event Data, Object 22 must be assigned to Class 1, 2 or 3. Each point can have a different Class Assignment.

The Delta value defines the boundary value for that point.

### Example

Suppose VA hour is programmed and the Delta is 5. That represents 5 increments from the returned 32-bit Binary Counter value. Every second, new Static Data is scanned for VA hour. If new data is different from the previous standard value by the Delta value, the Counter Change Event Data will be created. That means, if the previous standard polled value is 50000 VA hour and if the VA hour reading increases to 50005, it will create a Counter Change Event Point for VA hour and 50005 VA hour will become the previous standard value for the next Static Data.

The Scaling setting for a point also applies to the Delta value. If Delta is 5 and Scaling is 2, this indicates a 500-count change in the internal representation.

## Object 23

Frozen Analog Event (Object 23) will be created if Object 23 is assigned to Class 1, 2 or 3.

### Line, Point, Description

- ▷ Double-click on the box under **Description**.  
A window will appear.
- ▷ Choose a **type** of data and a **channel**.
- ▷ Click **OK**.  
The corresponding numbers for the selected data and channel will appear in the Line and Point columns.

Line and Point Numbers for a Binary Input value can also be found in the DNP Object Mapping (Chapter 7 of this manual).



**Example**

1 Cycle High Speed Input Delta and Current State has Line Number 16 and Point Number 0 in the DNP Object Mapping. Write those numbers into the Object 1 – Binary Input window of the GE Communicator EXT. When the Line and Point Numbers are written, the software fills in the description on the screen. Repeat for each desired Binary Input Point. Update the device.

The meter will scan those points every second.

**Object 2**

Any DNP Static Point can be configured to create a DNP Event Points. Class Assignments on the Object 2 screen are used to configure Binary Input Change Event Points. In order to create Event Data, Object 2 Points must be assigned to Class 1, 2 or 3. Each point can have a different Class Assignment.


The **Clear All** button clears all assigned items on all the tabs.

The **Clear** button clears only the items on the current tab view.

## 16.5 Binary Output (Object 10)

Class 0 is used when polling Binary Output (Object 10) Data.

External Relay Output Modules can be attached to the meter. Up to 4 Relay Output Modules can be attached and each Relay Module has 4 Relay Outputs.



To control a Relay by DNP, check its box. If unchecked, the relay will not be controlled by DNP. The Master in DNP protocol can control 16 relays. In order to do that, each relay box should be checked and the meter should be updated with this profile.

- ▷ Check the box for the **Reset Enable** you want to control through DNP.

### Example 1

The Master can control Relay 1 by sending this message (Meter Address 1, Master Address 10):

```
05 64
```

```
18 C4 01 00 0A 00 6C 1A
```

```
C0
```

```
C0 05
```

```
06
```

```
01 17 01
```

```
00 03 01 01 00 00 00 00 3B EF 00 00 00 FF FF
```

### Example 2

The Master can control Relay 2 by sending this message:

```
05 64
```

```

18 C4 01 00
0A 00 6C 1A
C0

C1 05
0C
01 17 01
01 03 01 01 00 00 00 00 00 E2 5F 00 00 00 FF FF

```

The Master not only controls relays but also can do various resets. Each box should be checked in order for the Master to do the reset.

### Example 3

The Master can do a Log Reset by sending this message:

```

05 04

18 C4 01 00 0A 00 6C 1A
C0
C2 05
0C
01 17 01
10 03 01 01 00 00 00 00 00 C5 1B 00 00 00 FF FF

```

### Example 4

The Master can do an Energy Reset by sending this message:

```

05 04

18 C4 01 00 0A 00 6C 1A
C0

C3 05
0C
01 17 01
13 03 01 01 00 00 00 00 00 E7 5B 00 00 00 FF FF

```



All above examples are done with Function 5 (Direct Operate Relay) using Qualifier **0x17**.

Relay Status and Reset Status can be polled using Object 10.

For Controlling Relays and performing Resets, Object 12 is used.

The Point Numbers for Relays and Resets are as follows:

Points	Assignment
0	Relay 1
1	Relay 2
2	Relay 3
3	Relay 4
4	Relay 5
5	Relay 6
6	Relay 7
7	Relay 8
8	Relay 9
9	Relay 10
10	Relay 11
11	Relay 12
12	Relay 13
13	Relay 14
14	Relay 15
15	Relay 16
16	Log Reset
17	Maximum Reset
18	Minimum Reset
19	Energy Reset
20	Reset Time of Use Current Season and Current Month
21	Manual Waveform Capture
22	Reset Internal Input Accumulations and Aggregations
23	Reset Unit to Boot Mode – Default Communication Settings


The **Clear All** button clears all assigned items on all the tabs.

The **Clear** button clears only the items on the current tab view.

## 16.6 Global Values

Each Object can be polled by Variation 0. In this window, you can assign a default variation to be returned for each Object.

- ▷ Click on the **Object** on the left side of the screen.
- ▷ Click on a **Variation** on the right side of the screen.



- ▷ Click OK to save the new settings.


The **Clear All** button clears all assigned items on all the tabs.

The **Clear** button clears only the items on the current tab view.

## 16.7 DNP Settings

In this window, you can enable DNP Time Synchronization. The Time Interval is the amount of time the device waits before requesting Time Synchronization from the Master (using IINI-4). The Time Interval is configurable from 1 minute to 1 day in 1-minute intervals. The initial factory setting is 1 day.

- ▷ Select a **Class 0 Poll Counter Object** using the lower pull-down menu.



- ▷ Click **OK** to save the new settings.

The **Clear All** button clears all assigned items on all the tabs.

The **Clear** button clears only the items on the current tab view.



1  
011  
101110011100  
01100111110001  
000111010110110  
11110001001101  
010101110010  
011  
1

## GE Communicator EXT

# Appendix A: GE Script & Scheduler Component Files

---

### A.1 GE Script & Scheduler Component Files

The GE Script & Scheduler software program is a stand-alone module for the GE Communicator EXT software package. There are two supporting programs; the GE Communicator EXT program and the Log Converter program. Below is a list of the component files that complete this software program with a brief description of each and their location in your system.

1. **EPM Script & Scheduler.Exe**  
EPM' script and scheduler software program.  
Location: Drive C:\Program Files\GE Applications\Communicator\_Ext
2. **CommExt.exe GE**  
Communicator EXT software program.  
Location: Drive C:\Program Files\GE Applications\Communicator\_Ext
3. **LogConverter.exe**  
GE's log converter program. After GE Communicator EXT finishes retrieving a log or finishes executing a script, the Log Converter program translates the binary log into a database file (Access format).  
Location: Drive C:\Program Files\GE Applications\Log Viewer
4. **EPM Scheduler.Log**  
EPM Script & Scheduler program generated log file (Text format). It records all activities of the EPM Script & Scheduler program.  
Location: Drive C:\Program Files\GE Applications\Communicator\_Ext
5. **[script name].Html (New format) [script name].Log (Old format)**  
Communicator EXT generated log file (Text format). It records all activities when GE Communicator EXT runs a script. Each log file is for a specific script only. Future activities for the same script will be appended to the same log file.  
Location: Drive C:\Program Files\GE Applications\Communicator\_Ext\Script Logs


6. **[Log\_yyyy\_mm].Html (New format) [Log\_yyyy\_mm].Txt (Old format)**  
Log Converter generated log. It records the activity of the Log Converter program. The yyyy and mm in the file name are for the year and month when the Log Converter runs.  
Location: Drive C:\Program Files\GE Applications\LogViewer\Converter Activity Logs
7. **EPM\_Script\_Schedule.Template**  
Template database file for GE Script & Scheduler program and GE Communicator EXT program in Access 97 format.  
Location: Drive C:\Program Files\GE Applications\Communicator\_Ext
8. **EPM\_Script\_Schedule.DB**  
Run time database file for GE Script & Scheduler program and GE Communicator EXT program. Generated by GE Script & Scheduler program, it holds the scripts and scheduler information.  
Location: Drive C:\Program Files\GE Applications\Communicator\_Ext\Scripts
9. **EPMScriptDLFiles.Template**  
Template database file for GE Communicator EXT and GE Script & Scheduler program in Access 97 format.  
Location: Drive C:\Program Files\GE Applications\Communicator\_Ext
10. **EPMScriptDLFiles.DB**  
Run time database for GE Communicator EXT and GE Script & Scheduler program.  
Generated by GE Communicator EXT program, it holds the retrieved log files' locations and the addresses for the converted logs. If all processes are done, the GE Script & Scheduler program will delete this file.  
Location: Drive C:\Program Files\GE Applications\Communicator\_Ext\Scripts
11. **EPMSchedulerLog - Main.Html**  
Software generated top layer file with frame set linked to EPM Scheduler Log - Detail.Html and EPM Scheduler Run-Time Log.Html.
12. **EPMSchedulerLog - Detail.Html**  
Software generated blank frame file.
13. **EPMSchedulerRun-TimeLog.Html**  
Software generated schedule process log with hypertext link to detailed script logs and detailed Log Converter logs.





It is generally less expensive to install metering equipment on the low voltage side of a transformer and in some conditions other limitations may also impose the requirement of low-side metering even though the actual ownership change occurs on the high-voltage side.

The need for loss compensated metering may also exist when the ownership changes several miles along a transmission line where it is simply impractical to install metering equipment. Ownership may change at the midway point of a transmission line where there are no substation facilities. In this case, power metering must again be compensated. This condition is shown in Figure B.2.



**FIGURE B-2: Joint Ownership Line Metering Requiring Loss Compensation M Point of Ownership Change**

A single meter cannot measure the losses in a transformer or transmission line directly. It can however, include computational corrections to calculate the losses and add or subtract those losses to the power flow measured at the meter location. This is the method used for loss compensation in the EPM meter.

The computational corrections used for transformer and transmission line loss compensation are similar. Generically, no-load losses and full-load losses are evaluated and a correction factor for each loss level is calculated. However, the calculation of the correction factors that must be programmed into the meter differ for the two different applications. For this reason, the two methodologies will be treated separately in this chapter.

In the EPM 9450, 9650 and 9800 meters, Loss Compensation is a technique that computationally accounts for active and reactive power losses. The meter calculations are based on the formulas below. These equations describe the amount of active (Watts) and reactive (VARs) power lost due to both iron and copper effects (reflected to the secondary of the instrument transformers).

$$\text{Total Secondary Watt Loss} = (((\text{Measured Voltage}/\text{Cal point Voltage})^2 \times \% \text{LWFE}) + ((\text{Measured Current}/\text{Cal Point Current})^2 \times \% \text{LWCU})) \times \text{Full-scale Secondary VA}$$

$$\text{Total Secondary VAR Loss} = (((\text{Measured Voltage}/\text{Cal point Voltage})^4 \times \% \text{LVFE}) + ((\text{Measured Current}/\text{Cal Point Current})^2 \times \% \text{LVCU})) \times \text{Full-scale Secondary VA}$$

- The Values for %LWFE, %LWCU, %LVFE, %LVCU are derived from the transformer and meter information, as demonstrated in following sections.
- The calculated loss compensation values are added to or subtracted from the measured Watts and VARs.
- The selection of adding or subtracting losses is made through the meter profile when programming the meter.

- The meter uses the combination of the add/subtract setting and the directional definition of power flow (also in the profile) to determine how to handle the losses.
- Losses will be "added to" or "subtracted from" (depending on whether add or subtract is selected) the Received Power flow.

### Example

If losses are set to "Add to" and received power equals 2000 kW and losses are equal to 20kW then the total metered value with loss compensation would be 2020 kW; for these same settings if the meter measured 2000 kW of delivered power the total metered value with loss compensation would be 1980 kW.

Since transformer loss compensation is the more common loss compensation method, the meter has been designed for this application. Line loss compensation is calculated in the meter using the same terms but the percent values are calculated by a different methodology as described in a subsequent section below.

### B.1.1 Transformer/Line Loss Compensation

- Performs calculations on each phase of the meter for every measurement taken. Unbalanced loads are accurately handled.
- Calculates numerically, eliminating the environmental affects that cause inaccuracies in electromechanical compensators.
- Performs Bidirectional Loss Compensation.
- Requires no additional wiring; the compensation occurs internally.
- Imposes no additional electrical burden when performing Loss Compensation.

Loss Compensation is applied to 1 second per phase Watt/VAR readings and, because of that, affects all subsequent readings based on 1 second per phase Watt/VAR readings.

This method results in loss compensation be applied to the following quantities:

- Total Power.
- Demands, per phase and Total (Thermal, Block (Fixed) Window, Rolling (Sliding) Window and Predictive Window).
- Maximum and Minimum Demands.
- Energy Accumulations.
- KYZ Output of Energy Accumulations.



Loss Compensation is disabled when the meter is placed in Test Mode.

## B.2 Transformer / Line Loss Compensation

The meter provides compensation for active and reactive power quantities by performing the numerical calculations using factors derived in two ways; using the TLC Calculator button on the Transformer Loss screen of the Meter's Device Profile or using the worksheet found in section B.2.1, (Calculating Transformer Loss Compensation Percentages Work Sheet). Enter the derived values in the Device Profile screen of the GE Communicator EXT software.

The GE Communicator EXT software allows you to enable Transformer Loss Compensation for Losses due to Copper and Iron, individually or simultaneously. Losses can either be added to, or subtracted from, measured readings.

Loss compensation values must be calculated based on the meter installation. As a result transformer loss values must be normalized to the meter by converting the base voltage and current and taking into account the number of elements used in the metering installation.

For three element meters, the installation must be normalized to the phase-to-neutral voltage and the phase current; in two element meters the installation must be normalized to the phase-to-phase voltage and the phase current. This process is described in the following sections.

### B.2.1 Loss Compensation in Three Element Installations

Loss Compensation is based on the loss and impedance values provided on the Transformer Manufacturer's Test Report. A typical test report will include at least the following information:

- Manufacturer
- Unit Serial Number
- Transformer MVA Rating (Self-Cooled)
- Test Voltage
- No Load Loss Watts
- Load Loss Watts (or Full Load Loss Watts)
- % Exciting Current @ 100% voltage
- % Impedance

The transformer MVA rating is generally the lowest MVA rating (the self-cooled or OA rating) of the transformer winding. The test voltage is generally the nominal voltage of the secondary or low voltage winding. For three phase transformers these values will typically be the three-phase rating and the phase-to-phase voltage. All of the test measurements are based on these two numbers. Part of the process of calculating the loss compensation percentages is converting the transformer loss values based on the transformer ratings to the base used by the meter.

Correct calculation of loss compensation also requires knowledge of the meter installation. In order to calculate the loss compensation settings you will need the following information regarding the meter and the installation:

- Number of meter elements

- Potential Transformer Ratio (PTR)
- Current Transformer Ratio (CTR)
- Meter Base Voltage
- Meter Base Current

This section is limited to application of EPM 9450, 9650 and 9800 meters to three-element metering installations. As a result, we know that:

- Number of metering elements = 3
- Meter Base Voltage = 120 Volts
- Meter Base Current = 5 amps

The loss compensation values can be calculated in two ways:

- ▷ Click the **TLC Calculator** button on the Transformer Loss screen of the EPM Device Profile.  
The TLC Calculator button activates an Excel Spreadsheet, ONLY if you have MS Excel installed on your computer. A copy of the Excel Spreadsheet with Example Numbers is included at the end of this Appendix.
- ▷ Enter the required data into the Excel Spreadsheet.  
The Excel program will calculate the values needed for the Transformer Loss screen of the Device Profile.
- ▷ Enter the values into the Device Profile.
- Use the worksheet found in section B.2.1.1, "Three Element Loss Compensation Worksheet" to calculate the values by hand. Notes under each section will assist you.
  - ▷ Enter values based on the transformer manufacturer's test report.  
The worksheet is progressive and notes under each section will guide you to the next section.
  - ▷ Enter the values into the Device Profile.



See Chapters 3 and 4 - Transformer Loss sections - for more details.

## B.2.2 Three Element Loss Compensation Worksheet

(Use MS Excel Worksheet discussed in sections 3.8 and 4.8 if you have Excel installed on your PC.)

Company		Station Name	
Date		Trf Bank Number	
Trf Manuf		Trf Serial Number	
Calculation By			

**Transformer Data** (from Transformer Manufacturer's Test Sheet)

Winding	Voltage	MVA	Connection
HV-High			Delta-Y
XV-Low			Delta-Y
YV-Tertiary			Delta-Y

Value	Watts Loss		
	3-Phase	1-Phase	1-Phase kW
No-Load Loss			
Load Loss			

- ▷ Enter 3-Phase or 1-Phase values.  
If 3-Phase values are entered, calculate 1-Phase values by dividing 3-Phase values by three. Convert 1-Phase Loss Watts to 1-Phase kW by dividing 1-Phase Loss Watts by 1000.

Value	3-Phase MVA	1-Phase MVA	1-Phase kVA
Self-Cooled Rating			

- ▷ Enter 3-Phase or 1-Phase values.  
If 3-Phase values are entered, calculate 1-Phase values by dividing 3-Phase values by three. Convert 1-Phase Self-Cooled MVA to 1-Phase kVA by multiplying by 1000.

% Exciting Current	
% Impedance	

Value	Phase-to_Phase	Phase-to-Neutral
Test Voltage (volts)		
Full-Load Current (amps)		

Test Voltage is generally Phase-to-Phase for three-phase transformers. Calculate Phase-to-Neutral Voltage by dividing Phase-to-Phase Voltage by  $\sqrt{3}$ . Calculate Full Load Current by dividing the (1-Phase kW Self-Cooled Rating) by the (Phase-to-Neutral Voltage) and multiplying by 1000.

**Meter/Installation Data**

Instrument Transformers	Numerator	Denominator	Multiplier
Potential Transformer			
Current Transformer			
Power Multiplier [(PT Multiplier) X (CT Multiplier)]			

- ▷ Enter the Numerator and Denominator for each instrument transformer.  
For example, a PT with a ratio of 7200/120 has a numerator or 7200, a denominator or 120 and a multiplier of 60 ( $7200/120 = 60/1$ ).

Meter Secondary Voltage (volts)	
Meter Secondary Current (amps)	

**Base Conversion Factors**

Quantity	Transformer	Multiplier	Trf IT Sec	Meter Base	Meter/Trf
Voltage					
Current					

- ▷ For **Transformer Voltage** - enter the Phase-to-Neutral value of Test Voltage previously calculated.
- ▷ For **Transformer Current** - enter the Full-Load Current previously calculated.
- ▷ For **Multipliers** - enter the PT and CT multipliers previously calculated.

**TrfIT Secondary** is the Base Value of Voltage and Current at the Instrument Transformer Secondary of the Power Transformer. These numbers are obtained by dividing the Transformer Voltage and Current by their respective Multipliers.

The **Meter/Trf values** for Voltage and Current are obtained by dividing the Meter Base values by the TrfIT Secondary values.

### Load Loss at Transformer

No-Load Loss Watts (kW) = 1-Phase kW No-Load Loss = \_\_\_\_\_

No-Load Loss VA (kVA) = (%Exciting Current) \* (1-Phase kVA Self-Cooled Rating) / 100

= (\_\_\_\_\_) \* (\_\_\_\_\_) / 100

= \_\_\_\_\_ kVA

No-Load Loss VAR (kVAR) =  $\text{SQRT}((\text{No-Load Loss kVA})^2 - (\text{No-Load Loss kW})^2)$

=  $\text{SQRT}((\text{_____})^2 - (\text{_____})^2)$

=  $\text{SQRT}((\text{_____}) - (\text{_____}))$

=  $\text{SQRT}(\text{_____})$

= \_\_\_\_\_

Full-Load Loss Watts (kW) = 1-Phase Kw Load Loss = \_\_\_\_\_

Full-Load Loss VA (kVA) = (%Impedance) \* (1-Phase kVA Self-Cooled Rating) / 100

= (\_\_\_\_\_) \* (\_\_\_\_\_) / 100

= \_\_\_\_\_ kVA

Full-Load Loss VAR (kVAR) =  $\text{SQRT}((\text{Full-Load Loss kVA})^2 - (\text{Full-Load Loss kW})^2)$

=  $\text{SQRT}((\text{_____})^2 - (\text{_____})^2)$

=  $\text{SQRT}((\text{_____}) - (\text{_____}))$

=  $\text{SQRT}(\text{_____})$

= \_\_\_\_\_

Quantity	Value at Trf Base	M/T Factor	M/T Factor Value	Exp	M/T Factor w/Exp	Value at Meter Base
No-Load Loss (kW)		V		<sup>^2</sup>		
No-Load Loss (kVAR)		V		<sup>^4</sup>		
Load Loss (kW)		I		<sup>^2</sup>		
Load Loss (kVAR)		I		<sup>^2</sup>		

### Normalize Losses to Meter Base

- ▷ Enter Value at Transformer Base for each quantity from calculations above.
- ▷ Enter Meter/Trf Factor value from Base Conversion Factor calculations above.



- ▷ Calculate M/T Factor with Exponent by raising the M/T Factor to the power indicated in the "Exp" (or Exponent) column.
- ▷ Calculate the **Value at Meter Base** by multiplying the (M/T Factor w/ Exp) times the (Value at Trf Base).

### Loss Watts Percentage Values

$$\begin{aligned} \text{Meter Base kVA} &= 600 * (\text{PT Multiplier}) * (\text{CT Multiplier}) / 1000 \\ &= 600 * ( \quad ) * ( \quad ) / 1000 \\ &= \quad \end{aligned}$$

### Calculate Load Loss Values

Quantity	Value at Meter Base	Meter Base (kVA)	% Loss at Meter Base	Quantity
No-Load Loss (kW)				% Loss Watts FE
No-Load Loss (kVAR)				% Loss VARs FE
Load Loss (kW)				% Loss Watts CU
Load Loss (kVAR)				% Loss VARs CU

- ▷ Enter **Value at Meter Base** from Normalize Losses section.
- ▷ Enter **Meter Base kVA** from previous calculation.
- ▷ Calculate **% Loss at Meter Base** by dividing **Value at Meter Base** by **Meter Base kVA** and multiplying by **100**.
- ▷ Enter calculated % Loss Watts values into EPM meter using Communicator EXT software.

### B.2.3 MS Excel Spreadsheet with Example Numbers

If you have MS Excel installed in your computer, use the TLC Calculator button on the Transformer Loss screen of the Device Profile. A copy of the MS Excel Spreadsheet with Example Numbers on the following pages will assist you.

**Transformer Loss Compensation Calculation**

Three Element Meter with 3 Wye-connected PT's and 3 CT's

Company:		Substation:	
Name:		Stn Trf Bank No.:	
Date:			
Trf Manf:			
Trf S/N:			

Loss Factors for GE Communicator Software		Loss Factors	
		Calc	Used
% No-Load Loss Watts	%LWFE	#DIV/0!	#DIV/0!
% No-Load Loss VARs	%LVFE	#DIV/0!	#DIV/0!
% Full-Load Loss Watts	%LWCU	#DIV/0!	#DIV/0!
% Full-Load Loss VARs	%LVCU	#DIV/0!	#DIV/0!

Winding	Voltage	Connection	MVA Ratings
HV - High			
XV - Low			
YV - Tert.			

**Transformer Test Data**

Value	Watts Loss		Calculated	Calc kVA
	3 Phase	1 Phase		
No Load Loss Watts			0.00	0.00
Full Load Loss Watts			0.00	0.00
% Exciting Current				
% Impedance				

	3 Phase	1 Phase	Calculated
Self-Cooled kVA Rating			0

	Phase-to-Phase	Phase-to-Grd
Test Voltage		0
Full Load Current	#DIV/0!	

**Meter / Installation Data**

Instrument Transformers	Numerator	Denominator	Multiplier
Potential Trf			0
Current Trf			0
Power Multiplier	0		

Meter Secondary Voltage	120	120 volts for EPM 9650
Meter Secondary Current	5	5 amps for EPM 9650

1. This spreadsheet is provided as a guide only. It is not intended to be used as a substitute for a professional engineer's design.

**Transformer Loss Compensation Calculation - Example**

Three Element Meter with 3 Wye-connected PT's and 3 CT's

Company:	ABC Power Company	Substation:	Big Station
Name:	Joe Engineer	Stn Trf Bank No.:	131
Date:	2/14/2002		
Trf Manf:	ABB		
Trf S/N:	AT4391-01		

Loss Factors for GE Communicator Software		Loss Factors	
		Calc	Used
% No-Load Loss Watts	%LWFE	0.04314	0.043
% No-Load Loss VARs	%LVFE	0.06765	0.068
% Full-Load Loss Watts	%LWCU	0.87524	0.875
% Full-Load Loss VARs	%LVCU	20.76262	20.763

Winding	Voltage	Connection	MVA Ratings
HV - High	138000	delta	16.8/22.4/28.0
XV - Low	13090	wye	
YV - Tert.			

**Transformer Test Data**

Value	Watts Loss		Calculated	Calc kVA
	3 Phase	1 Phase		
No Load Loss Watts	15400		5133.33	5.13
Full Load Loss Watts	69200		23066.67	23.07
% Exciting Current	0.183			
% Impedance	9.78			

	3 Phase	1 Phase	Calculated
Self-Cooled kVA Rating	16800		5600

	Phase-to-Phase	Phase-to-Grd
Test Voltage	13090	7558
Full Load Current	741	

**Meter / Installation Data**

Instrument Transformers	Numerator	Denominator	Multiplier
Potential Trf	7200	120	60
Current Trf	1500	5	300
Power Multiplier	18000		

Meter Secondary Voltage	120	120 volts for EPM 9650
Meter Secondary Current	5	5 amps for EPM 9650

DUPLICATE OF CHAPTER B

11/10/02

**Line Loss Compensation Calculation**

Three Element Meter with 3 Wye-connected PT's and 3 CT's

Company:		Substation:	
Name:		Stn Trf Bank No.:	
Date:			

Metering Point Information	

Loss Factors for GE Communicator Software		Loss Factors	
		Calc	Used
% Full-Load Loss Watts	%LWCU	#DIV/0!	#DIV/0!
% Full-Load Loss VARs	%LVCU	#DIV/0!	#DIV/0!

**Transmission Line Impedance Data**

Quantity	PU Value	% Value	Used
R			0
X			0
MVA Base			0
Nominal Voltage			

**Meter / Installation Data**

Instrument Transformers	Numerator	Denominator	Multiplier
Potential Trf			0
Current Trf			0
Power Multiplier	0		

Meter Secondary Voltage	120	120 volts for EPM 9650
Meter Secondary Current	5	5 amps for EPM 9650

Value	3 Ph Loss	1 Ph Watt	1 Ph kW
Full Load Loss Watts	-	0.00	0.00
Full Load Loss VARs	-	0.00	0.00
Watts Loss at CT Full Load	#DIV/0!		

	Phase-to-Phase	Phase-to-Grd
Test Voltage	0	0
Full Load Current	#DIV/0!	

**Line Loss Compensation Calculation - Example**

Three Element Meter with 3 Wye-connected PT's and 3 CT's

Company:	ABC Power Company	Substation:	Big Station
Name:	Joe Engineer	Stn Trf Bank No.:	Small Station 138
Date:	2/14/2002		

Metering Point Information	Meter point is 45 miles down line from Big Station.
----------------------------	---

Loss Factors		Loss Factors	
for GE Communicator Software		Calc	Used
% Full-Load Loss Watts	%LWCU	0.00362	0.004
% Full-Load Loss VARs	%LVCU	0.01872	0.019

**Transmission Line Impedance Data**

Quantity	PU Value	% Value	Used
R	0.0304		0.0304
X	0.1573		0.1573
MVA Base	100		100
Nominal Voltage		138000	

**Meter / Installation Data**

Instrument Transformers	Numerator	Denominator	Multiplier
Potential Trf	138000	115	1200
Current Trf	900	5	180
Power Multiplier	216000		

Meter Secondary Voltage	120	120 volts for EPM 9650
Meter Secondary Current	5	5 amps for EPM 9650

Value	3 Ph Loss	1 Ph Watt	1 Ph kW
Full Load Loss Watts	3,040	1013.33	1.01
Full Load Loss VARs	15,730	5243.33	5.24
Watts Loss at CT Full Load	14,068		

	Phase-to-Phase	Phase-to-Grd
Test Voltage	138000	79674
Full Load Current	418	





1  
011  
101110011100  
01100111110001  
000111010110110  
11110001001101  
010101110010  
011  
1

## GE Communicator EXT

# Appendix C: GE Communicator EXT Command Line Arguments V 1.11

---

### C.1 Script Command Line Methods

Tells GE Communicator EXT to perform a task corresponding to the Script ID Number. /

#### **snnnn Script ID Number**

**Example :**

CommExt /s1234 (/s Script ID Number)

#### **uc: Start Log Converter**

0Do not start log converter

1 Start log converter

If left out of command line, Start Log Converter assumed.

**Example :**

CommExt with Script 1234 will Start Log Converter if Log Retrieval is in the script.

CommExt /s1234 uc:1

---

## C.2 Application Command Line Methods

Tells GE Communicator EXT to make a connection and display a particular application screen.

### **/c (additional arguments with a space between each argument)**

#### **Example 1:**

Meter with address 2 on network with IP address 10.0.0.1 using Modbus TCP Start on device status screen.

CommExt /c cm:1 ad:2 pr:3 ip:10.0.0.1 np:502

#### **Example 2:**

Meter with address 2 at remote location with Phone Number 555-545-5110 using Modbus ASCII Start on device status screen.

CommExt /c cm:0 ad:2 pr:1 cp:3 BR:3 um:1 pn:555-545-5110

### **cm: Connect Mode**

- 0 Serial Port
- 1 Network

If left out of command line, Serial Port assumed.

### **ad: Address**

- 1 - 247

If left out of command line, Address 1 assumed.

### **nm: Network Mode**

- 0 One IP Address for n Devices

If left out of command line, 0 assumed.

### **pr: Protocol**

- 0 Modbus RTU
- 1 Modbus ASCII
- 2 DNP 3.0 (Not Supported)
- 3 Modbus TCP
- 4 EI Protocol

If left out of command line, Modbus RTU assumed.

### **ip: IP Address or Host Name**

xxx.xxx.xxx.xxx or 1 - 16 Alphanumeric characters with no spaces.

If left out, error assumed.



**np: Network Port**

502    Open Modbus (Modbus TCP)

If left out, Port 502 assumed.

**cp: Com Port**

1 - 98

If left out, Com Port 1 assumed.

**br: Baud Rate**

0    1200

1    2400

2    4800

3    9600

4    19200

5    38400

6    57600

7    115200

If left out, Baud Rate is 9600.

**um: Use Modem**

0    No

1    Yes

If left out, No modem selected.

**pn: Phone Number**

Use No spaces. To be defined.

**ms: Modem Setup String**

To be defined.

**dc: Data Switch Connect String**

To be defined.

**dd: Data Switch Disconnect String**

To be defined.

**ss: Start Screen**

0    Device Status

1    Phasors Diagram (EPM9450, 9650 & 9800 Only)

2    Instantaneous Polling

- 3 Poll All (EPM9450, 9650 & 9800 Only)
- 4 Poll Max/Min
- 5 Poll Power Readings
- 6 Poll Harmonics
- 7 Poll Internal Inputs
- 8 Poll Multiple Devices (EPM9450, 9650 & 9800 Only)
- 9 Poll Pulse Accumulations (EPM9450, 9650 & 9800 Only)
- 10 Poll Limit Status
- 11 Poll Time of Use Readings (EPM9450, 9650 & 9800 Only)
- 12 Poll Meter External Digital Inputs (EPM9450, 9650 & 9800 Only)
- 13 Poll Meter External Analog Inputs (EPM9450, 9650 & 9800 Only)
- 14 Poll Meter ElectroLogic Status (EPM9450, 9650 & 9800 Only)
- 15 Poll Relay Control
- 16 Poll Readings with DDE Service (EPM9450, 9650 & 9800 Only) (Tech Mode ONLY)
- 17 Poll Log Statistics (Added 08-06-2003)
- 18 Log Retrieval Screen (Added 08-06-2003)
- 19 Poll Power and Demand (EPM9450, 9650 & 9800 Only) (Added 01-22-2004)
- 20 Poll Energy (EPM9450, 9650 & 9800 Only) (Added 01-22-2004)

If left out, Start screen is Device Status.

### **dn: Device Name**

Must use period as place holder for a space.

### **In: Location Name**

Must use period as place holder for a space.

### **vm: View Mode**

- 0 Normal
  - 1 Hide Main Window and Exit Program upon closing of Start Screen.  
GE Communicator EXT acts as a plug-in for integrating with third party software.
- If left out, Normal is the View Mode.

### **am: Answer Modem**

- 0 No
  - 1 Open Port.  
Wait for Modem to ring and attempt to answer Modem if ringing.
- If left out, software does not answer Modem.

**dr: Dial Out Receive Call**

- 0 No
- 1 After Software successfully answers the call, it looks for a reason of call code (based on the code Perform Automated functions).  
Upon completion of all functions, GE Communicator EXT places the Remote Modem into command mode, sends an acknowledgment, hangs up, closes the communications port and exits the program.

**mp: Modem Password**

Must use period as place holder for a space.

**dt: User Defined DDE Topic Name for Start Screen 16**

Topic Name must contain no spaces.

If left out, Meter Designation is used as Topic.

**lr: Retrieve Log Number**

- 1 Historical Log 1
- 2 Historical Log 2
- 3 Both 1 and 2

See Table Below for Other Combinations:

Log to Retrieve	Bits														
	15	14	13	12	10	9	8	7	6	5	4	3	2	1	0
Historical Log 1															X
Historical Log 2														X	
Limit Log													X		
PQ/Waveform Log												X			
Digital Input Log											X				
Digital Output Log										X					
Reserved (Max/Min Log)									X						
Flicker								X							
System of Events Log							X								
Reset Log (Disabled)						X									

**Example:** To retrieve Historical Log 1 and Limit Log

101b = 5d = 5



1  
011  
101110011100  
01100111110001  
000111010110110  
11110001001101  
010101110010  
011  
1

## GE Communicator EXT

# Appendix D: TFTP Server Program Setup

### D.1 TFTP Server Program Setup

A free shareware TFTP (Trivial File Transfer Protocol) server program known as **tftpd32** is provided to customers to be used to update firmware for the INP-100 Ethernet card. The program files are located on the software installation CD.



tftpd32 must be running to update the firmware.

#### Setup requirements

1. Windows Operating System
2. A working Ethernet card with a valid IP Address
3. Winzip software (only if Windows OS does not open the zip file automatically)


#### Setup procedures

1. In your PC's hard disk, create a folder with a name.  
**Example:** C:\Program Files\TFTPD32.
2. Locate the Zipped tftpd32 program files on the CD. Then, use the Winzip program to extract all compressed files into the folder you have created in Step 1.
3. In your PC's hard drive, create a folder with a name to be used as the root directory for TFTP Server.  
**Example:** C:\Program Files\TFTPD32\TFTP\_files.
4. To start running the program, double click on tftpd32.exe.

#### Configuring tftpd32

- ▷ Start the **TFTPD32** program (Step 4 above).  
The following screen appears:

- ▷ Click the **Settings** button.  
The Tftpd32: Settings screen appears.



The screen shown here displays GE's recommended settings.



All firmware files for INP100 should be placed inside the **C:\Program Files\TFTPD32\TFTP\_files** folder before updating firmware.



It is not recommended to check the **Activate Tftpd32 on this interface** box. Once that box is checked and your computer's IP is changed, the TFTPD32 program may not work properly. To fix the problem, you may have to disable this feature inside the Windows Registry.



1  
011  
101110011100  
01100111110001  
000111010110110  
11110001001101  
010101110010  
011  
1

## GE Communicator EXT

# Appendix E: DNP Custom Class Map Readings

---

### E.1 Available DNP Class Map Readings for EPM9450Q:

1 Second Readings  
Thermal Readings  
Accumulations  
Maximum Readings  
Minimum Readings  
Block Window Average  
Rolling Window Average  
THD and K-Factor  
Phase Angles and Voltage Sequence  
0.1 Second Readings  
Harmonic Magnitudes  
Harmonic Phases  
External Analog Inputs  
Time of Use  
Binary States  
Action Block  
Time Stamps  
Energy and Pulses in the Interval  
Flicker  
Miscellaneous







1  
011  
101110011100  
01100111110001  
000111010110110  
11110001001101  
010101110010  
011  
1

## GE Communicator EXT

## Appendix F: Application Notes

Application Notes are designed to help you with various applications of GE Communicator EXT software. GE Communicator EXT has expansive capabilities that can make your Monitoring and Power Control tasks much easier, once the software is set up to do what you need it to do.

---

### F.1 Total Web Solutions MEGA PAGE

#### Displaying Data from Multiple INP100/102 Units on One Web Page

With Total Web Solutions' WebExplorer and WebReacher features, it's possible to design a single web page that displays data from multiple EPM 9450, 9650 and 9800 meters that have INP100/102 Network Options. To achieve this goal, the user should have a basic understanding of Total Web Solutions. Refer to Chapter 6 of this manual for setup and utilization. In addition, the user should modify the Java Script Code on the web pages in use and also make a change to the Internet Explorer browser settings, as detailed below.

## F.2 Modify JavaScript


Using the default files supplied by INP100/102 Network Options as templates, the user should modify the JavaScript code for all web pages using the sample below. The sample portion of JavaScript code is for demonstration purposes only. You must insert your own code where needed.

```
<script language=Javascript>
// insert your own code here
// Define multiple XML DOM Documents objects
var xmlDoc_Meter_1 = new ActiveXObject("MSXML.DomDocument");
var xmlDoc_Meter_2 = new ActiveXObject("MSXML.DomDocument");
var xmlDoc_Meter_1.async = true;
var xmlDoc_Meter_1.onreadystatechange = do_get_data_Meter_1;
var xmlDoc_Meter_2.async = true;
var xmlDoc_Meter_2.onreadystatechange = do_get_data_Meter_2;
//function name 'start process' should be placed in web page's <body>
tag
// such as '<body onLoad="start_process()">'
function start_process()
{
    do_get_xml_Meter_1();
    do_get_xml_Meter_1();
}
// Load each poll_data.xml file from different locations into an XML DOM
Document objects
function do_get_xml_Meter_1()
{
    xmlDoc_Meter_1.load("http://192.168.1.2/poll_data.xml");
}
function do_get_xml_Meter+2()
{
    xmlDoc_Meter_1.load("http://192.168.7.8/poll_data.xml");
}
// functions to read, parse and display data from each XML file
function do_get_data_Meter_1()
{
    // insert your own code here
}
function do_get_data_Meter_2()
{
    // insert your own code here
}
// insert your own code here
</script>
```

### F.3 Change Browser Settings



Changes to the Internet Explorer (IE, Version 6) Browser Settings:

- ▷ Go to Internet Explorer's Internet Options window.



- ▷ Click **Security tab > Internet Icon > Custom Level**  
A security Settings window appears.
- ▷ In the Security Settings window, scroll down to the Miscellaneous section. Set **Enable** for **Access data source across domains** and Set **Enable** for **Navigate sub-frames from across different domains**.
- ▷ Click **OK** to close the Security Settings screen.

- Click **OK** again to close the Internet Options screen.





1  
011  
101110011100  
01100111110001  
000111010110110  
11110001001101  
010101110010  
011  
1

## GE Communicator EXT

# Appendix G: Ethernet Network Error Codes

---

### G.1 Network Error Codes

#### G.1.1 Network Error Codes Reported by Software that uses Ethernet (including GE Communicator EXT)

**These codes are provided for your information.**

- Case 10004: GetWSAErrorString = "Interrupted system call."
- Case 10009: GetWSAErrorString = "Bad file number."
- Case 10013: GetWSAErrorString = "Permission Denied."
- Case 10014: GetWSAErrorString = "Bad Address."
- Case 10022: GetWSAErrorString = "Invalid Argument."
- Case 10024: GetWSAErrorString = "Too many open files."
- Case 10035: GetWSAErrorString = "Operation would block."
- Case 10036: GetWSAErrorString = "Operation now in progress."
- Case 10037: GetWSAErrorString = "Operation already in progress."
- Case 10038: GetWSAErrorString = "Socket operation on nonsocket."
- Case 10039: GetWSAErrorString = "Destination address required."
- Case 10040: GetWSAErrorString = "Message too long."
- Case 10041: GetWSAErrorString = "Protocol wrong type for socket."
- Case 10042: GetWSAErrorString = "Protocol not available."
- Case 10043: GetWSAErrorString = "Protocol not supported."
- Case 10044: GetWSAErrorString = "Socket type not supported."
- Case 10045: GetWSAErrorString = "Operation not supported on socket."

Case 10046: GetWSAErrorString = "Protocol family not supported."

Case 10047: GetWSAErrorString = "Address family not supported by protocol family."

Case 10048: GetWSAErrorString = "Address already in use."

Case 10049: GetWSAErrorString = "Can't assign requested address."

Case 10050: GetWSAErrorString = "Network is down."

Case 10051: GetWSAErrorString = "Network is unreachable."

Case 10052: GetWSAErrorString = "Network dropped connection."

Case 10053: GetWSAErrorString = "Software caused connection abort."

Case 10054: GetWSAErrorString = "Connection reset by peer."

Case 10055: GetWSAErrorString = "No buffer space available."

Case 10056: GetWSAErrorString = "Socket is already connected."

Case 10057: GetWSAErrorString = "Socket is not connected."

Case 10058: GetWSAErrorString = "Can't send after socket shutdown."

Case 10059: GetWSAErrorString = "Too many references: can't splice."

Case 10060: GetWSAErrorString = "Connection timed out."

Case 10061: GetWSAErrorString = "Connection refused."

Case 10062: GetWSAErrorString = "Too many levels of symbolic links."

Case 10063: GetWSAErrorString = "File name too long."

Case 10064: GetWSAErrorString = "Host is down."

Case 10065: GetWSAErrorString = "No route to host."

Case 10066: GetWSAErrorString = "Directory not empty."

Case 10067: GetWSAErrorString = "Too many processes."

Case 10068: GetWSAErrorString = "Too many users."

Case 10069: GetWSAErrorString = "Disk quota exceeded."

Case 10070: GetWSAErrorString = "Stale NFS file handle."

Case 10071: GetWSAErrorString = "Too many levels of remote in path."

Case 10091: GetWSAErrorString = "Network subsystem is unusable."

Case 10092: GetWSAErrorString = "Winsock DLL cannot support this application."

Case 10093: GetWSAErrorString = "Winsock not initialized."

Case 10101: GetWSAErrorString = "Disconnect."

Case 11001: GetWSAErrorString = "Host not found."

Case 11002: GetWSAErrorString = "Nonauthoritative host not found."

Case 11003: GetWSAErrorString = "Nonrecoverable error."

Case 11004: GetWSAErrorString = "Valid name, no data record of requested type."



1  
011  
101110011100  
01100111110001  
000111010110110  
11110001001101  
010101110010  
011  
1

## GE Communicator EXT

### Glossary

<b>0.1 Second Values:</b>	These values are the RMS values of the indicated quantity as calculated after approximately 50 milliseconds (3 cycles) of sampling.
<b>1 Second Values:</b>	These values are the RMS values of the indicated quantity as calculated after one second (60 cycles) of sampling.
<b>Alarm:</b>	An event or condition in a meter that can cause a trigger or call-back to occur.
<b>Annunciator:</b>	A short label that identifies particular quantities or values displayed, for example kWh.
<b>Average (Current):</b>	When applied to current values (amps) the average is a calculated value that corresponds to the thermal average over a specified time interval. The interval is specified by the user in the meter profile. The interval is typically 15 minutes. So, Average Amps is the thermal average of amps over the previous 15-minute interval. The thermal average rises to 90% of the actual value in each time interval. For example, if a constant 100amp load is applied, the thermal average will indicate 90 amps after one time interval, 99 amps after two time intervals and 99.9 amps after three time intervals.
<b>Average (Input Pulse Accumulations):</b>	When applied to Input Pulse Accumulations, the "Average" refers to the block (fixed) window average value of the input pulses.

<b>Average (Power):</b>	When applied to power values (watts, VARs, VA), the average is a calculated value that corresponds to the thermal average over a specified time interval. The interval is specified by the user in the meter profile. The interval is typically 15 minutes. So, the Average Watts is the thermal average of watts over the previous 15-minute interval. The thermal average rises to 90% of the actual value in each time interval. For example, if a constant 100kW load is applied, the thermal average will indicate 90kW after one time interval, 99kW after two time intervals and 99.9kW after three time intervals.
<b>Bit:</b>	A unit of computer information equivalent to the result of a choice between two alternatives (Yes/No, On/Off, for example). Or, the physical representation of a bit by an electrical pulse whose presence or absence indicates data.
<b>Binary:</b>	Relating to a system of numbers having 2 as its base (digits 0 and 1).
<b>Block Window Avg (Power):</b>	The Block (Fixed) Window Average is the average power calculated over a (Power) user-set time interval, typically 15 minutes. This calculated average corresponds to the demand calculations performed by most electric utilities in monitoring user power demand. (See Rolling Window Average.)
<b>Byte:</b>	A group of 8 binary digits processed as a unit by a computer (or device) and used especially to represent an alphanumeric character.
<b>CBEMA Curve:</b>	A voltage quality curve established originally by the Computer Business Equipment Manufacturers Association. The CBEMA Curve defines voltage disturbances that could cause malfunction or damage in microprocessor devices. The curve is characterized by voltage magnitude and the duration which the voltage is outside of tolerance. (See ITIC Curve.)
<b>Channel:</b>	The storage of a single value in each interval in a load profile.
<b>Cold Load Pickup:</b>	This value is the delay from the time control power is restored to the time when the user wants to resume demand accumulation.



<b>CRC Field:</b>	Cyclic Redundancy Check Field (Modbus communication) is an error checksum calculation that enables a Slave device to determine if a request packet from a Master device has been corrupted during transmission. If the calculated value does not match the value in the request packet, the Slave ignores the request.
<b>CT (Current) Ratio:</b>	A Current Transformer Ratio is used to scale the value of the current from a secondary value up to the primary side of an instrument transformer.
<b>Cumulative Demand:</b>	The sum of the previous billing period maximum demand readings at the time of billing period reset. The maximum demand for the most recent billing period is added to the previously accumulated total of the maximum demands.
<b>Demand:</b>	The average value of power or a similar quantity over a specified period of time.
<b>Demand Interval:</b>	A specified time over which demand is calculated.
<b>Display:</b>	User-configurable visual indication of data in a meter.
<b>DNP 3.0:</b>	A robust, non-proprietary protocol based on existing open standards. DNP 3.0 is used to operate between various systems in electric and other utility industries and SCADA networks. EPM 9450 supports Level 1; EPM 9650 & 9800 support Level 2.
<b>EEPROM:</b>	Nonvolatile memory. Electrically Erasable Programmable Read Only Memory that retains its data during a power outage without need for a battery. Also refers to meter's FLASH memory.
<b>Energy Register:</b>	Programmable record that monitors any energy quantity. Example: Watthours, VARhours, VAhours.
<b>Ethernet:</b>	A type of LAN network connection that connects two or more devices on a common communications backbone. An Ethernet LAN consists of at least one hub device (the network backbone) with multiple devices connected to it in a star configuration. The most common versions of Ethernet in use are 10BaseT GE Multilin Glossary-3 and 100BaseT as defined in IEEE 802.3 standards. However, several other versions of Ethernet are also available.
<b>Exception Response:</b>	Error Code (Modbus communication) transmitted in a packet from the Slave to the Master if the Slave has encountered an invalid command or other problem.

<b>Flicker:</b>	Flicker is the sensation that is experienced by the human visual system when it is subjected to changes occurring in the illumination intensity of light sources. IEC 61000-4-15 and former IEC 868 describe the methods used to determine flicker severity.
<b>Form:</b>	Wiring and Hookup configuration for the EPM 9800.
<b>Harmonics:</b>	Measuring values of the fundamental current and voltage and percent of the fundamental.
<b>Heartbeat Pulse:</b>	Energy indicator on the face of the EPM9450/9650; pulses are generated per the programmed Ke value.
<b>I<sub>2</sub>T Threshold:</b>	Data will not accumulate until current reaches programmed level.
<b>Infrared Test Pulse:</b>	Energy indicator located on the upper left side of the face of the EPM 9800 meter; pulses are generated per the programmed Ke value.
<b>Integer:</b>	Any of the natural numbers, the negatives of those numbers or zero.
<b>Internal Modem:</b>	An optional modem within the meter's enclosure that connects to the RJ-11 telephone connector.
<b>Invalid Register:</b>	In the meter's Modbus Map there are gaps between Registers. For example, the next Register after 08320 is 34817. Any unmapped Register stores no information and is said to be invalid.
<b>ITIC Curve:</b>	An updated version of the CBEMA Curve that reflects further study into the performance of microprocessor devices. The curve consists of a series of steps but still defines combinations of voltage magnitude and duration that will cause malfunction or damage.
<b>Ke:</b>	kWh per pulse; i.e. the energy.
<b>kWh:</b>	kilowatt hours; kW x demand interval in hours.
<b>KYZ Output:</b>	Output where the rate of changes between 1 and 0 reflects the magnitude of a metered quantity.
<b>LCD:</b>	Liquid Crystal Display.
<b>LED:</b>	Light Emitting Diode.
<b>Master Device:</b>	In Modbus communication, a Master Device initiates and controls all information transfer in the form of a Request Packet to a Slave Device. The Slave responds to each request.
<b>Maximum Demand:</b>	The largest demand calculated during any interval over a billing period.

<b>Modbus ASCII:</b>	Alternate version of the Modbus protocol that utilizes a different data transfer format. This version is not dependent upon strict timing, as is the RTU version. This is the best choice for telecommunications applications (via modems).
<b>Modbus RTU:</b>	The most common form of Modbus protocol. Modbus RTU is an open protocol spoken by many field devices to enable devices from multiple vendors to communicate in a common language. Data is transmitted in a timed binary format, providing increased throughput and therefore, increased performance.
<b>Network:</b>	A communications connection between two or more devices to enable those devices to send and receive data to one another. In most applications, the network will be either a serial type or a LAN type.
<b>NVRAM:</b>	Nonvolatile Random Access Memory is able to keep the stored values in memory even during the loss of circuit or control power. High speed NVRAM is used in the EPM 9450, 9650 & 9800 to gather measured information and to insure that no information is lost.
<b>Optical Port:</b>	A port that facilitates infrared communication with an EPM 9800 meter. Using an ANSI C12.13 Type II magnetic optical communications coupler and an RS-232 cable from the coupler to a PC, the meter can be programmed with GE Communicator EXT software.
<b>Packet:</b>	A short fixed-length section of data that is transmitted as a unit. Example: a serial string of 8-bit bytes.
<b>Percent (%) THD:</b>	Percent Total Harmonic Distortion. (See THD.)
<b>Protocol:</b>	A language that will be spoken between two or more devices connected on a network.
<b>PT Ratio:</b>	Potential Transformer Ratio used to scale the value of the voltage to the primary side of an instrument transformer. Also referred to as VT Ratio.
<b>Pulse:</b>	The closing and opening of the circuit of a two-wire pulse system or the alternate closing and opening of one side and then the other of a three-wire system (which is equal to two pulses).
<b>Q Readings:</b>	Q is the quantity obtained by lagging the applied voltage to a wattmeter by 60 degrees. Values are displayed on the Uncompensated Power and Q Readings screen.

<b>Quadrant (Programmable Values and Factors on the EPM 9450, 9650 and 9800):</b>	Watt and VAR flow is typically represented using an X-Y coordinate system. The four corners of the X-Y plane are referred to as quadrants. Most power applications label the right hand corner as the first quadrant and number the, remaining quadrants in a counter-clockwise rotation. Following are the positions of the quadrants: 1st - upper right, 2nd - upper left, 3rd - lower left and 4th - lower right. Power flow is generally positive in quadrants 1 and 4. VAR flow is positive in quadrants 1 and 2. The most common load conditions are: Quadrant 1 - power flow positive, VAR flow positive, inductive load, lagging or positive power factor; Quadrant 2 - power flow negative, VAR flow positive, capacitive load, leading or negative power factor.
<b>Register:</b>	An entry or record that stores a small amount of data.
<b>Register Rollover:</b>	A point at which a Register reaches its maximum value and rolls over to zero.
<b>Reset:</b>	Logs are cleared or new (or default) values are sent to counters or timers.
<b>Rolling Window Average (Power):</b>	The Rolling (Sliding) Window Average is the average power calculated over a user-set time interval that is derived from a specified number of sub-intervals, each of a specified time. For example, the average is calculated over a 15-minute interval by calculating the sum of the average of three consecutive 5-minute intervals. This demand calculation methodology has been adopted by several utilities to prevent customer manipulation of kW demand by simply spreading peak demand across two intervals.
<b>RS-232:</b>	A type of serial network connection that connects two devices to enable communication between devices. An RS-232 connection connects only two points. Distance between devices is typically limited to fairly short runs. Current standards recommend a maximum of 50 feet but some users have had success with runs up to 100 feet. Communications speed is typically in the range of 1200 bits per second to 57,600 bits per second. RS-232 connection can be accomplished using Port 1 of the EPM 9450/9650 or the Optical Port on the face of the EPM 9800.

<b>RS-485:</b>	A type of serial network connection that connects two or more devices to enable communication between the devices. An RS-485 connection will allow multi-drop communication from one to many points. Distance between devices is typically limited to around 2,000 to 3,000 wire feet. Communications speed is typically in the range of 120 bits per second to 115,000 bits per second.
<b>Sag:</b>	A voltage quality event during which the RMS voltage is lower than normal for a period of time, typically from 1/2 cycle to 1 minute.
<b>Secondary Rated:</b>	Any Register or pulse output that does not use any CT or VT Ratio.
<b>Serial Port:</b>	The type of port used to directly interface with a PC.
<b>Slave Device:</b>	In Modbus communication, a Slave Device only receives a Request Packet from a Master Device and responds to the request. A Slave Device cannot initiate communication.
<b>Swell:</b>	A voltage quality event during which the RMS voltage is higher than normal for a period of time, typically from 1/2 cycle to 1 minute.
<b>THD:</b>	Total Harmonic Distortion is the combined effect of all harmonics measured in a voltage or current. The THD number is expressed as a percent of the fundamental. For example, a 3% THD indicates that the magnitude of all harmonic distortion measured equals 3% of the magnitude of the fundamental 60Hz quantity.
<b>Time Stamp:</b>	A stored representation of the time of an event. Time Stamp can include year, month, day, hour, minute and second and Daylight Savings Time indication.
<b>TOU:</b>	Time of Use.
<b>Uncompensated Power:</b>	VA, Watt and VAR readings not adjusted by Transformer Loss Compensation.
<b>V<sub>2</sub>T Threshold:</b>	Data will stop accumulating when voltage falls below programmed level.
<b>Voltage Imbalance:</b>	The ratio of the voltage on a phase to the average voltage on all phases.
<b>Voltage Quality Event:</b>	An instance of abnormal voltage on a phase. The events the meter will track include sags, swells, interruptions and imbalances.
<b>VT Ratio:</b>	The Voltage Transformer Ratio is used to scale the value of the voltage to the primary side of an instrument transformer. Also referred to as PT Ratio.

<b>Voltage, Vab:</b>	Vab, Vbc, Vca are all Phase-to-Phase voltage measurements. These voltages are measured between the three phase voltage inputs to the meter.
<b>Voltage, Van:</b>	Van, Vbn, Vcn are all Phase-to-Neutral voltages applied to the monitor. These voltages are measured between the phase voltage inputs and Vn input to the meter. Technologically, these voltages can be “measured” even when the meter is in a Delta configuration and there is no connection to the Vn input. However, in this configuration, these voltages have limited meaning and are typically not reported.
<b>Voltage, Vaux:</b>	This is the fourth voltage input measured from between the Vaux and Vref inputs. This input can be scaled to any value. However, the actual input voltage to the meter should be of the same magnitude as the voltages applied to the Va, Vb and Vc terminals.