

# GE Consumer & Industrial *Multilin*

**F650** Digital Bay Controller User manual GEK-113000N



Firmware version: 2.20 EnerVista F650 Setup version: 2.20 Copyright © 2005 GE Multilin



#### **GE Multilin**

215 Anderson Avenue L6E 1B3 Markham, ON -CANADA T (905) 294 6222 F (905) 294 8512 E gemultilin@ge.com

Internet: www.GEMultilin.com

**GE Multilin** Avda. Pinoa, 10 48170 Zamudio SPAIN T +34 94 485 88 00 F +34 94 485 88 45 E gemultilin.euro@ge.com

1.1 IMPO	RTANT PROCEDURES	
1.1.1	CAUTIONS AND WARNINGS	1-1
1.1.2	INSPECTION CHECKLIST	
1.1.3	SAFETY INSTRUCTIONS	1-6
1.2 OVER	VIEW	
1.2.1	INTRODUCTION TO 650 FAMILY OF RELAYS	1-7
1.2.2	HARDWARE ARCHITECTURE	1-7
1.2.3	SOFTWARE ARCHITECTURE	
1.2.4	COMMUNICATIONS ARCHITECTURE	1-8
1.3 ENER	VISTA 650 SETUP SOFTWARE	
1.3.1	SYSTEM REQUIREMENTS	1-10
1.3.2	INSTALLATION	1-10
1.3.3	CONNECTING WITH THE UNIT	1-15

2. PRODUCT DESCRIPTIO	N
-----------------------	---

**1. GETTING STARTED** 

#### 2.1 OVERVIEW

2.1.1	F650 OVERVIEW
2.2 SUMM	ARY

2.2.1 ANSI DEVICE NUMBERS AND FUNCTIONS	JCTIONS 2-2	.1 ANSI DEVICE N	2.2.1
---	-------------	------------------	-------

#### 2.3 ORDERING CODE

#### 2.4 TECHNICAL SPECIFICATIONS

2.4.1	PROTECTION UNITS	
2.4.2	CONTROL	
2.4.3	MONITORING	
2.4.4	USER – PROGRAMABLE ELEMENTS	
2.4.5	METERING	
2.4.6	INPUTS	
2.4.7	REAL TIME CLOCK	
2.4.8	OUTPUTS	
2.4.9	CONTROL POWER SUPPLY	
2.4.10	COMMUNICATIONS	
2.4.11	ENVIRONMENTAL CHARACTERISTICS	
2.4.12	PACKAGING AND WEIGHT	
2.4.13	TYPE TESTS	
2.4.14	APPROVALS	

#### 2.5 EXTERNAL CONNECTIONS

#### 3. HARDWARE

#### 3.1 MODULE DESCRIPTION

#### 3.2 MECHANICAL DESCRIPTION

3.2.1	MOUNTING	
3.2.2	REAR DESCRIPTION	
3.3 WIRIN	G	
3.3.1	EXTERNAL CONNECTIONS	
3.3.2	DIGITAL INPUTS WITH TRIP CIRCUIT SUPERVISION	
3.3.3	CABLE/FIBER ETHERNET BOARD	

#### 3.4 OPTIC FEATURES

#### 3.5 TRANSCEIVER OPTICAL POWER BUDGET VERSUS LINK LENGTH

#### 4. HUMAN INTERFACES, SETTINGS & ACTUAL VALUES

#### 4.1 ENERVISTA 650 SETUP SOFTWARE INTERFACE

4.1.1	OVERVIEW	4-1
4.1.2	MAIN SCREEN	4-2
4.1.3	STARTING COMMUNICATION	4-3
4.1.4	FILE MANAGEMENT	4-7
4.1.5	ENERVISTA 650 SETUP MENUS STRUCTURE	4-12
4.1.6	FILE MENU OVERVIEW	4-13
4.1.7	SETTINGS MENU OVERVIEW	4-17
4.1.8	ACTUAL VALUES MENU OVERVIEW	4-26
4.1.9	OPERATIONS MENU OVERVIEW	4-31
4.1.10	COMMUNICATION MENU OVERVIEW	4-31
4.1.11	SECURITY MENU OVERVIEW	4-32
4.1.12	VIEW MENU OVERVIEW	4-32
4.1.13	HELP MENU OVERVIEW	4-32

#### 4.2 HUMAN MACHINE INTERFACE (HMI)

4.2.1	DISPLAY	4-33
4.2.2	FRONT LED INDICATORS	4-34
4.2.3	PUSHBUTTONS	4-34
4.2.4	FRONT PORT AND COVER SEALING SYSTEM	4-35
4.2.5	TEXT MENUS	4-36
4.2.6	GRAPHIC DISPLAY	4-55

#### 4.3 WEB SERVER

4.3.1	HOME	4-64
4.3.2	SNAPSHOT EVENTS	
4.3.3	CONTROL EVENTS	
4.3.4	ALARMS	
4.3.5	OSCILLOGRAPHY	
4.3.6	FAULT REPORT	
4.3.7	DATA LOGGER	
4.3.8	METERING	4-71

5. SETTINGS

#### 5.1 OVERVIEW

0.1 0121		
5.1.1	SETTING MAIN MENU	5-1
5.2 PROD	UCT SETUP	
5.2.1	COMMUNICATION SETTINGS	5-3
5.2.2	MODBUS USER MAP	5-6
5.2.3	FAULT REPORT	5-6
5.2.4	OSCILLOGRAPHY	5-9
5.2.5	DATA LOGGER	5-12
5.2.6	DEMAND	5-14
5.3 SYSTI	EM SETUP	
5.3.1	GENERAL SETTINGS	5-20
5.3.2	FLEX CURVES	5-20
5.3.3	BREAKER	5-22
5.3.4	SWITCHGEAR	5-24
5.4 PROT	ECTION ELEMENTS	
5.4.1	CHANGE OF SETTING TABLES IN F650 ELEMENTS	5-25
5.4.2	INVERSE TIME CURVES CHARACTERISTICS	5-29
5.4.3	PHASE CURRENT	5-39
5.4.4	NEUTRAL CURRENT	5-50
5.4.5	GROUND CURRENT	5-56
5.4.6	SENSITIVE GROUND CURRENT	5-59
5.4.7	NEGATIVE SEQUENCE CURRENT	5-64
5.4.8	VOLTAGE ELEMENTS	5-65
5.4.9	POWER	5-70
5.5 CONT	ROL ELEMENTS	
5.5.1	SETTING GROUP	5-77
5.5.2	UNDERFREQUENCY ELEMENT (81U)	5-78
5.5.3	OVERFREQUENCY ELEMENT (810)	5-78

	5.5.5	AUTORECLOSE (79)
	5.5.6	BREAKER FAILURE ELEMENT (50BF)
	5.5.7	VT FUSE FAILURE ELEMENT (VTFF)
	5.5.8	BROKEN CONDUCTOR
	5.5.9	LOCKED ROTOR
5.6	INPUT	S/OUTPUTS
	5.6.1	INPUT/OUTPUT PLACEMENT
	5.6.2	CONTROL SETTINGS FOR INPUTS/OUTPUTS
	5.6.3	INPUTS
	5.6.4	OUTPUTS
	5.6.5	CIRCUIT SUPERVISION AND CONTACT SEAL-IN CIRCUITS
	5.6.6	ANALOG BOARDS SPECIFIC SETTINGS
	5.6.7	VIRTUAL INPUTS
	5.6.8	VIRTUAL OUTPUTS
5.7	TESTI	NGS
	5.7.1	FORCE IO -INPUT TESTING
	5.7.2	FORCE IO –OUTPUT TESTING
5.8	RELAY	CONFIGURATION
	5.8.1	OUTPUTS
	5.8.2	LEDS
	5.8.3	OPERATIONS
	5.8.4	PROTECTION ELEMENTS
	5.8.5	OSCILLOGRAPHY5-128
	5.8.6	CONTROL EVENTS
	5.8.7	SWITCHGEAR
	5.8.8	HMI (HUMAN-MACHINE INTERFACE)
5.9	LOGIC	CONFIGURATION (PLC EDITOR)
	5.9.1	INTRODUCTION5-135
	5.9.2	THEORY OF OPERATION
	5.9.3	MAIN MENU
	5.9.4	CONFIGURATION GENERATION
	5.9.5	GENERATION OF LIBRARIES
	596	EXAMPLE OF APPLICATION 5-143

0.0.0	CENERATION OF EIDRARIES
5.9.6	EXAMPLE OF APPLICATION

#### 6. ACTUAL VALUES

## 6.1 FRONT PANEL 6.1.1 LEDS......

6	6.1.1	LEDS	6-1
6.2 S	STATU	S	
6	6.2.1	OPERATION BITS	6-2
6	6.2.2	BREAKER	6-2
6	6.2.3	PROTECTION	6-2
6	6.2.4	CONTROL ELEMENTS	6-8
6	6.2.5	PROTECTION SUMMARY	-13
6	6.2.6	SNAPSHOT EVENTS SUMMARY	-14
6	6.2.7	MODBUS USER MAP	-15
6	6.2.8	SWITCHGEAR STATUS	-16
6	6.2.9	CALIBRATION	-17
e	6.2.10	FLEX CURVES	-18
6	6.2.11	SYSTEM INFO	-18
6	6.2.12	RECORD STATUS	-18
6.3 N	<b>IETER</b>	RING	
e	6.3.1	PRIMARY VALUES	-22
e	6.3.2	SECONDARY VALUES	-25
e	6.3.3	PHASOR DIAGRAM	-27
e	6.3.4	FREQUENCY	-27
6	6.3.5	INPUTS / OUTPUTS	-28
6.4 R	RECOF	RDS	
6	6.4.1	EVENT RECORDER	-34
e	6.4.2	WAVEFORM CAPTURE	-36
e	6.4.3	FAULT REPORT	-37
e	6.4.4	DATA LOGGER	-39

7.	IEC 61850 PROTOCOL	7.1 IEC61850 GENERIC SUBSTATION STATE EVENT (GSSE) 7.1.1 REMOTE DEVICES 7.1.2 REMOTE INPUTS 7.1.3 REMOTE OUTPUTS	7-1 7-3 7-4
		<ul> <li>7.2 IEC 61850 PROFILE FOR F650</li> <li>7.2.1 INTRODUCTION</li> <li>7.2.2 ACSI CONFORMANCE STATEMENT</li> <li>7.2.3 LOGICAL NODES</li> <li>7.2.4 COMMON DATA CLASS</li> <li>7.2.5 DATASETS</li> <li>7.2.6 MAPPINGS BETWEEN TOC CURVES IN IEC 61850 AND F650 REL IMPLEMENTATION. 7-46</li> <li>7.2.7 UNIDADES Y ESCALAS DE LOS DATOS ANALÓGICOS</li> </ul>	7-6 7-6 7-11 7-29 7-44 .AY
8.	SECURITY	8.1 ADDING USERS 8.1.1 USER RIGHTS	8-1
		8.4 LOGING INTO ENERVISTA 650 SETUP	
9.	BOOTCODE AND FIRMWARE UPGRADE	9.1 INTRODUCTION 9.1.1 COMMUNICATION PARAMETERS	9-2
		9.3 FIRMWARE VERSION UPGRADE 9.3.1 FIRMWARE UPGRADE	9-9
		9.4 STEP LIST SUMMARY FOR VERSIONS 1.70 AND LATER 9.4.1 BOOT CODE UPGRADE (*) 9.4.2 FIRMWARE UPGRADE (*)	9-12 9-12
10	. COMMISSIONING	10.1 VISUAL INSPECTION	
		10.2 GENERAL CONSIDERATIONS ON THE POWER SUPPLY NET	<b>WORK</b>
		10.3 ISOLATION TESTS	
		10.4 INDICATORS	
		10.5 POWER SUPLY TESTING	
		10.6 COMMUNICATIONS	
		10.7 VERIFICATION OF MEASURE         10.7.1 VOLTAGES         10.7.2 PHASE CURRENTS         10.7.3 ACTIVE, REACTIVE POWER, AND COSJ METERING         10.7.4 FREQUENCY	10-7 10-7 10-8 10-8
		10.8 INPUTS AND OUTPUTS10.8.1DIGITAL INPUTS	10-9 10-10 10-10 10-10

#### **10.9 CONNECTIONS FOR TESTING PROTECTION ELEMENTS**

#### 10.10 INSTANTANEOUS OVERCURRENT (50PH, 50PL, 50N, 50G Y 50SG)

#### 10.11 INVERSE TIME OVERCURRENT (51PH, 51PL, 51N, 51G Y 46)

#### 10.12 DIRECTIONAL ELEMENTS (67P, 67N, 67G, 67SG)

10.12.1	67P ELEMENT	10-14
10.12.2	67N ELEMENT	10-14
10.12.3	67G ELEMENT	10-15
10.12.4	67SG ELEMENT	10-16

#### 10.13 UNDERVOLTAGE ELEMENTS (27P, 27X)

10.13.1	27P ELEMENT	10-17
10.13.2	27X ELEMENT	10-17

10.14 OVERVOLTAGE ELEMENTS (59P, 59X, 59NH, 59NL, 47)	
10.14.1 59P ELEMENT	10-18
10.14.2 59X ELEMENT	10-18

#### 

#### 10.15 FREQUENCY ELEMENTS (810/81U)

#### 10.16 RECLOSER (79)

10.16.1 RECLOSING CYCLE	
10.16.2 RECLOSER STATUSES	
10.16.3 EXTERNAL RECLOSE INITIATION	

#### 10.17 THERMAL IMAGE ELEMENT (49)

11. APPLICATION EXAMPLES	11.1 EXAMPLE1: COMMUNICATION & PROTECTION SETTINGS         PROCEDURE         11.1.1 DESCRIPTION OF THE EXERCISE         11.1.2 PROCEDURE TO COMMUNICATE WITH THE RELAY         11.1.3 PROCEDURE TO SET THE PROTECTION FUNCTION         11.1.4 TEST			
	11.2 EXAMPLE 2: TOC PROTECTION + RECLOSING SETTINGS         PROCEDURE         11.2.1       DESCRIPTION OF THE EXERCISE         11.2.2       PROCEDURE TO COMMUNICATE THE RELAY         11.2.3       PROCEDURE TO SET THE PROTECTION FUNCTION         11.2.4       PROCEDURE TO SET THE RECLOSER         11.2.5       PROCEDURE TO SET THE SYNCHRO CHECK	11-5 11-5 11-5 11-6 11-6		
	11.3 EXAMPLE Nº 3 – PROCEDURE TO SET AN OPERATION         11.3.1       DESCRIPTION OF THE EXERCISE         11.3.2       PROCEDURE         11.3.3       TEST	11-8 11-8 11-10		
12. FREQUENTLY ASKED QUESTIONS	12.1 COMMUNICATIONS 12.2 PROTECTION			

#### 12.3 CONTROL AND HMI 12.4 RELAY CONFIGURATION

#### 13. TROUBLESHOOTING GUIDE

**B.1 ACCESS TO F650 DATA** 

#### A. LOGIC OPERANDS

**B. MODBUS PROTOCOL** 

**B.2 MODBUS F650** B.2.1 FUNCTIONS USED......B-2 PHYSICAL LAYER ......B-3 B.2.2 DATA LINK LAYER ......B-4 B 2 3 GENERIC READING B.2.4 B.2.5 GENERIC WRITING ...... B-6 FUNCTION CODES ......B-7 B 2 6 **B.3 DATA TYPE B.4 MODBUS APPENDIX** DATA MANAGEMENT ......B-10 B.4.1 B.4.2 B43 B.4.4 OPERATIONS ......B-15 **B.5 OUTPUT WRITING B.6 EVENTS STATUS REQUEST (ALARMS)** B.6.1 SERIAL COMMUNICATION......B-22 B 6 2 B 6 3 ACKNOWLEDGEMENT OF EVENTS (ALARMS)......B-24 B.6.4 B.6.5 VIRTUAL INPUTS WRITING RETRIEVING OSCILOGRAPHY ...... B-27 B 6 7 B 6 8 B 6 9 B.6.10 TRACES AND TROUBLESHOOTING.......B-30 B.6.11 MODBUS CHECK FUNCTION ...... B-31 **B.7 MEMORY MAP** C. DNP 3.0 PROTOCOL FOR **C.1 DNP 3.0 PROTOCOL SETTINGS** F650 **C.2 DNP 3.0 DEVICE PROFILE DOCUMENT C.3 IMPLEMENTATION TABLE C.4 BINARY INPUT POINTS** C.5 DNP CONFIGURATION EXAMPLES C.5.1 CONFIGURING DNP USER MAP......C-11 C.5.2 C.5.3 MULTIPLE DNP 3.0 MASTERS COMMUNICATION WITH F650......C-15 C.6 BINARY OUTPUT AND CONTROL RELAY OUTPUT **C.7 BINARY COUNTERS** 

**C.8 ANALOG INPUTS** 

D. IEC 60870-5-104 PROTOCOL	D.1 INTRODUCTION D.2 TECHNICAL DESCRIPTION D.3 BASIC APPLICATION FUNCTIONS D.4 IEC 104 SETTINGS D.5 IEC 60870-5-104 POINT LIST
E. FACTORY DEFAULT LOGIC	E.1 FACTORY DEFAULT SETTINGS E.1.1 FACTORY DEFAULT SETTINGSE-1
F. FACTORY DEFAULT CONFIGURATION	F.1 FACTORY DEFAULT SETTINGS F.2 FACTORY DEFAULT CONFIGURATION
G. MISCELLANEOUS	G.1 F650 FIRMWARE REVISION HISTORY G.2 GE MULTILIN WARRANTY

1

To help ensure years of trouble free operation, please read through the following chapter for information to help guide you through the initial installation procedures of your new relay.

BEFORE ATTEMPTING TO INSTALL OR USE THE RELAY, IT IS IMPERATIVE THAT ALL WARNINGS AND CAUTIONS IN THIS MANUAL ARE REVIEWED TO HELP PREVENT PERSONAL INJURY, EQUIPMENT DAMAGE, AND/OR DOWNTIME.

CAUTION: THE OPERATOR OF THIS INSTRUMENT IS ADVISED THAT IF THE EQUIPMENT IS USED IN A MANNER NOT SPECIFIED IN THIS MANUAL, THE PROTECTION PROVIDED BY THE EQUIPMENT MAY BE IMPAIRED



#### Figure 1–1: FRONT VIEW OF F650 UNITS

#### a) COMMUNICATION BOARDS WITHDRAWAL / INSERTION

WARNING: MODULE WITHDRAWAL AND INSERTION SHALL ONLY BE PERFORMED BY DULY QUAL-IFIED SERVICE PERSONNEL. FOR PERSONAL SECURITY PURPOSES, BEFORE ACCOMPLISHING ANY WITHDRAWAL OR INSERTION OPERATION, THE RELAY MUST BE POWERED OFF AND ALL THE REAR TERMINALS MUST BE POTENTIAL FREE. THE RELAY MUST BE GROUNDED USING THE REAR GROUNDING SCREW.

The modular design of the relay allows withdrawal and insertion of the communication module.

Figure 1–2:: MODULE WITHDRAWAL/INSERTION shows the location of communication modules on the rear part of the relay. Skilled personnel must carry out the insertion or extraction of communication boards only after interrupting the relay auxiliary voltage and ensuring that all the rear terminals are potential free.

#### **1.1 IMPORTANT PROCEDURES**

1

Communication boards are installed on the rear of the unit, the upper port being reserved for the asynchronous communications board and CAN, and the lower port for the ETHERNET board in any of its configurations.



#### Figure 1–2: MODULE WITHDRAWAL/INSERTION

Before performing any of these actions, **control power must be removed from the relay and all the relay rear terminals must be potential free.** A grounded antistatic wristband must be used when manipulating the module in order to avoid electrostatic discharges that may cause damage to the electronic components.

WITHDRAWAL: Loose the small screws that keep the faceplate in place and extract the module.

**INSERTION:** Insert the module and press it firmly in the case, until it is completely fixed. After this, bolt the faceplate screws and replace the control power. Check that the relay is fully operative.

GE Multilin will not be responsible for any damage in the relay, connected equipment or personnel whenever this safety rules are not followed.

#### b) MAGNETIC MODULE TERMINALS



Figure 1–3: REAR VIEW OF F650 UNIT

*GE Multilin* will not be responsible for any damage in the relay, connected equipment or personnel whenever this safety rules are not followed.

1

**1.1.2 INSPECTION CHECKLIST** 

Open the relay packaging and inspect the relay for physical damage.

Refer to the label on the side of the relay verifies that the model number is the correct model ordered.

(BE)	
_	GE Multilin
MODEL:	F650BFBF1G0HI
	DIGITAL BAY CONTROLLER
SERIAL No.:	90.017.102
MFG. DATE:	OCT 14,2003
POWER:	110-250 V = 30W
	120-230 V $\sim$ 30VA 50/60 Hz

MAC:00A0F408056D	
90.017.102	
CE	

#### Figure 1-4: IDENTIFICATION LABEL (A4455P6)

- Please ensure that you receive the following items with your relay:
- Mounting screws for rear terminals and for fixing the relay to a cabinet
- CD containing EnerVista F650 Setup software
- Wiring diagram
- Certificate of Compliance

For product information, instruction manual updates, and the latest software updates, please visit the GE Multilin Home Page <u>www.geindustrial.com/multilin</u>.

Note: If there is any physical damage detected on the relay, or any of the contents listed are missing, please contact GE Multilin immediately at:

> EUROPE, MIDDLE EAST AND AFRICA: **GE MULTILIN** Av. Pinoa, 10 48170 Zamudio, Vizcaya (SPAIN) Tel.: (34) 94-485 88 54, Fax: (34) 94-485 88 38

> > E-mail: multilin.tech.euro@ge.com

AMERICA, ASIA AND AUSTRALIA: **GE MULTILIN** 

215, Anderson Avenue L6E 1B3 Markham, ON (CANADA) Tel.: +1 905 294 6222, Fax: +1 905 201 2098 E-mail: multilin.tech@ge.com

The information provided herein does not intend to cover all details of variations of the equipment nor does it take into account the circumstances that may be present in your installation, operating or maintenance activities.

Should you wish to receive additional information, or for any particular problem that cannot be solved by referring to the information contained herein, please contact GENERAL ELECTRIC MULTILIN.

F650 Digital Bay Controller

#### **1.1.3 SAFETY INSTRUCTIONS**

The F650 ground screw shown in Figure 1–5:: LOCATION OF GROUNDING SCREW must be correctly grounded.



Figure 1–5: LOCATION OF GROUNDING SCREW

Before establishing the communication with a F650 unit through the front serial port, please ensure that the computer is grounded.

In case of using a laptop, it is recommended not to have it connected to its power supply. The reason for this is that in many cases it might not be correctly grounded either due to the power supply or to the connector cables used.

This is required not only for personal protection, but also for avoiding a voltage difference between the relay serial port and the computer port, which could produce permanent damage either to the computer or the relay.

*GE Multilin* will not be responsible for any damage in the relay or connected equipment whenever this elemental safety rule is not followed.

#### **1.2.1 INTRODUCTION TO 650 FAMILY OF RELAYS**

This platform of relays has been designed to meet the goals that are appearing nowadays in the environment of new substations.

Historically, protection, control and metering functions have been performed by electromechanical elements at the beginning, then static devices, and finally by digital equipment able to integrate all these functions in a single device, called IED (Intelligent Electronic Device).

These IEDs not only must be able to perform all functions related to system protection and control, but also, using high speed communications, they must share information among them and send this information to control dispatch centers, thus reducing the quantity of auxiliary elements and wiring up to 70%.

The F650 relay belongs to this new generation of devices, and can be easily incorporated in substation automation schemes.

#### **1.2.2 HARDWARE ARCHITECTURE**

F650 units incorporate a series of interconnected modules to perform protection and control functions. Firstly, it includes a group of AC transformers for retrieving current and voltage. These magnitudes, once digitized, are sent to a digital signal processor (DSP), which performs metering functions and communicates with the main processor via a wide band bus. This architecture liberates the main processor from performing real time metering, allowing a high sampling rate, of up to 64 samples per cycle, without interfering with global performance.

F650 relays are digital devices that include a CPU that can control multiple types of input and output signals.



Figure 1–6: F650 CONCEPT BLOCK DIAGRAM

Contact Inputs/Outputs are signals associated to physical input/output contacts in the relay

Analog Inputs are signals coming from the inputs of current and voltage transformers, used for monitoring the power system signals.

Remote CAN Bus Inputs/Outputs: are signals associated to physical input/output contacts from independent modules connected to the 650 unit via a fiber optic CAN Bus.

PLC: Programmable Logic Controller. Control module that enables the unit configuration (assignment of inputs/outputs) and the implementation of logic circuits.

Protection Elements: Relay protection elements, for example: Overcurrent, overvoltage, etc.

1

#### **1.2.3 SOFTWARE ARCHITECTURE**

The firmware (software embedded in the relay) has been designed using object oriented programming techniques (OOP). These techniques are based on the use of objects and classes, and provide the software architecture with the same characteristics as the hardware architecture, i.e., modularity, scalability and flexibility.

#### **1.2.4 COMMUNICATIONS ARCHITECTURE**

The main processor performs protection, control, and communication functions, incorporating two internal processors, one for generic use and a second one dedicated for communications.

A dedicated serial port is used for communication between the main processor and the human-machine interface. Serial connection provides great immunity against electromagnetic disturbances, thus increasing system safety.

All F650 units incorporate an RS232 serial port on the front of the relay. There is also a possibility to incorporate up to two additional communication modules on the rear.

One of the modules provides asynchronous serial communications, using different physical media (RS485, plastic or glass fiber optic) depending on the selected model. The module incorporates two identical ports, COM1 and COM2. COM2 port is multiplexed with the front port. Additionally, this module may incorporate a glass fiber optic port for CAN BUS communications, used for the connection to the Remote CAN BUS I/O module. This feature allows increasing up to 100% the I/O capability, when the maximum number of I/Os available inside the relay (up to 32 inputs and 16 outputs) is not enough for a specific application.

Available options are:

#### Table 1–1: TABLE 1-1 REAR SERIAL COMMUNICATIONS BOARD 1

Board Code	Functionality
F	Without additional communication ports
А	Two RS485 ports
Р	Two Plastic F.O. ports
G	Two Glass F.O. ports
Х	Two RS485 ports and a CAN port for remote CAN Bus Inputs/Outputs
Y	Two Plastic F.O. ports and a CAN port for remote CAN Bus Inputs/Outputs
Z	Two Glass F.O. ports and a CAN port for remote CAN Bus Inputs/Outputs

The other module provides Ethernet communications (COM3 port), using 10/100BaseTX (self-negotiable speed) or 100BaseFX connectors, depending on the selected model. Most complete models include a double redundant 100BaseFX fiber optic port. Redundancy is provided at a physical media level; the unit incorporates internally duplicated and independent controllers for extended system reliability and accessibility.

#### Available Options are:

#### Table 1–2: REAR ETHERNET COMMUNICATIONS BOARD 2

Board Code	Functionality
В	One 10/100BaseTX port (self-negotiable speed)
С	One 10/100BaseTX port and one 100BaseFX port.
D	One 10/100BaseTX port and two 100BaseFX ports

For options C and D it is required to select the active physical media, by means of an internal selector inside the module. The factory configuration for this selection is the 10/100BaseTX port.

Finally, internal communication with input and output modules is performed via an internal CAN bus, independent from the one used for remote CAN BUS I/Os. This fact provides increased communication speed, as well as the possibility of acknowledgement of modules, abnormalities, etc. As this is a serial port supporting a communications protocol, it provides extraordinary immunity against external or internal disturbances.





#### **1.3.1 SYSTEM REQUIREMENTS**

The EnerVista F650 Setup software interface is the preferred method to edit settings and view actual values because the PC monitor can display more information in a simple comprehensible format.

The following minimum requirements must be met for the EnerVista F650 Setup software to properly operate on a PC:

- Pentium® class or higher processor (Pentium® II 300 MHz or higher recommended)
- Windows® NT 4.0 (Service Pack 3 or higher), Windows® 2000, Windows® XP
- Internet Explorer® 5.0 or higher
- 64 MB of RAM (128 MB recommended)
- 40 MB of available space on system drive and 40 MB of available space on installation drive
- RS232C serial and Ethernet port for communications to the relay

**1.3.2 INSTALLATION** 

After ensuring the minimum requirements for using EnerVista F650 Setup are met (see previous section), use the following procedure to install the EnerVista F650 Setup from the GE EnerVista CD.

- 1. Insert the GE EnerVista CD into your CD-ROM drive.
- 2. Click the Install Now button and follow the installation instructions to install the no-charge EnerVista software.
- 3. When installation is complete, start the EnerVista Launchpad application.
- 4. Click the IED Setup section of the Launch Pad window.



Figure 1–8: LAUNCHPAD WINDOW

5. In the EnerVista Launch Pad window, click the Add Product button and select the "F650 Bay Controller" relay from the Install Software window as shown below. Select the "Web" option to ensure the most recent software release, or select "CD" if you do not have a web connection, then click the Add Now button to list software items for the F650.



Figure 1–9: ADD PRODUCT WINDOW

6. If "Web" option is selected, chose the F650 software program and release notes (if desired) from the list and click the **Download Now** button to obtain the installation program.

EnerVieta Larm	choud				-17
() GE Multitu	•	Eno	Vista	LAU	NCH √PAD
				0	Options - Log File
MANUTATION IS	neseroia Opprade GE Setup Pro	sgram Alst at the president		×	
LE	Setup Programs	Venion 172 2	Size	Released	
Determent Library					
atomer Library					
Eutherightens -		Upgrade Now			
	Me		_		D413.24

Figure 1–10: WEB UPGRADE WINDOW

- 7. EnerVista Launchpad will obtain the installation program from the Web or CD. Once the download is complete, doubleclick the installation program to install the EnerVista F650 Setup software.
- 8. Select the complete path, including the new directory name, where the EnerVista F650 Setup will be installed.

#### **1.3 ENERVISTA 650 SETUP SOFTWARE**

- 9. Click on **Next** to begin the installation. The files will be installed in the directory indicated and the installation program will automatically create icons and add EnerVista F650 Setup to the Windows start menu.
- 10. Follow the on-screen instructions to install the EnerVista F650 Setup software. When the **Welcome** window appears, click on **Next** to continue with the installation procedure.



Figure 1–11: ENERVISTA F650 SETUP INSTALLATION

11. When the **Choose Destination Location** window appears, and if the software is not to be located in the default directory, click **Change...** and type in the complete path name including the new directory name and click **Next** to continue with the installation procedure.

Ener¥ista F Choose I Select fo	650 Setup - InstallShield Wizard Destination Location older where setup will install files.	×
	Install EnerVista F650 Setup to: C:\GE Power Management\F650PC Change	]
InstallShield -	<pre></pre>	

Figure 1–12: ENERVISTA F650 SETUP INSTALLATION CONT.

#### 1.3 ENERVISTA 650 SETUP SOFTWARE

12. The default program group where the application will be added to is shown in the **Selected Program Folder** window. Click Next to begin the installation process, and all the necessary program files will be copied into the chosen directory.

Ener¥ista F650 Setup - InstallShield Wizard	×
Select Program Folder	
Please select a program folder.	
	_
Setup will add program icons to the Program Folder listed below. You may type a new folder name, or select one from the existing folders list. Click Next to continue.	
Program Folder:	
GE Power Management	
Existing Folders:	
ARCserve Client Agent for Windows NT	
Bachmann	
Beyond Compare	
EETools	
enerVista GE Power Management	
GE_NESIS	
< <u>B</u> ack <u>N</u> ext > Cancel	
	_

Figure 1–13: SELECT PROGRAM FOLDER

13. To finish with the installation process, select the desired language for startup.

EnerVista F650 Setup - InstallShield Wizard						
Select language						
Select EnerVista F650 Setup language:						
English						
C French						
🔿 Spanish						
C Russian						
InstallShield						
	< Back	Next >	Lancel			

#### Figure 1–14: LANGUAGE WINDOW

14. Click **Finish** to end the installation. The F650 device will be added to the list of installed IEDs in the EnerVista Launchpad window, as shown below.



Figure 1–15: ENERVISTA LAUNCHPAD

#### **1.3.3 CONNECTING WITH THE UNIT**

This section is intended as a quick start guide to using the EnerVista F650 Setup software. Please refer to section 4.1 in this manual for more information about the EnerVista F650 Setup software interface.

#### a) CONFIGURING AN ETHERNET CONNECTION

Before starting, verify that the Ethernet network cable is properly connected to the Ethernet port on the back of the relay.

- Install and start the latest version of the EnerVista F650 Setup software (available from the GE EnerVista CD or online from http://www.GEindustrial.com/multilin (see previous section for installation instructions).
- 2. Go to "*Communication>Computer*" and enter the following data referred to communications:
- 3. Select Control Type as MODBUS TCP/IP from the drop-down list. This option will display a number of interface parameters that must be entered for proper Ethernet communications.
- 4. Enter the relay IP address (from "*Setpoint>Product Setup >Communication Settings>Net-work>IP ADDRESS*") in the IP Address field in MODBUS TCP/IP SETUP.
- Enter the relay ModBus address (from "Setpoint>Product Setup >Communication Settings>ModBus Protocol>ModBus Address COM1/COM2 setting") in the Unit Identifier (Slave Address) field.
- 6. Enter the ModBus port address (from "Setpoint>Product Setup >Communication Settings>ModBus Protocol>ModBus Port Number" setting) in the ModBus Port field.
- 7. The Device has now been configured for Ethernet communications. Proceed to press the ON button to begin communicating.

1

#### b) CONFIGURING AN RS232 CONNECTION

Before starting, verify that the RS232 serial cable is properly connected to the RS232 port on the front panel of the relay.

- Install and start the latest version of the EnerVista F650 Setup software (available from the GE EnerVista CD or online from http://www.GEindustrial.com/multilin (see previous section for installation instructions).
- 2. Go to "Communication>Computer" and enter the following data referred to communications:
- 3. Select Control Type as No Control Type from the drop-down list. This option will display a number of interface parameters that must be entered for proper serial communications.
- 4. Enter the relay Slave Address ("Setpoint>Product Setup >Communication Settings>ModBus Protocol" menu) in the Slave Address field.
- Enter the physical communications parameters (Baudrate and parity settings) from "Setpoint>Product Setup >Communication Settings>Serial Ports" menu, in their respective fields.
- The Device has now been configured for RS232 communications. Proceed to press the ON button to begin communicating.

#### **1.3.4 COMMUNICATIONS**

To communicate with the relay via the faceplate RS232 port, a standard "straight through" serial cable is used. The DB9 male end is connected to the relay and the DB9 or DB25 female end is connected to the PC COM1 or COM2 port as described in the figure below.

Direct connection to the Ethernet port will be carried out using a crossover cable. If this connection is performed through a hub or switch, we will use direct Ethernet cable.

To communicate with the relay rear RS485 port from a computer RS232 port, an RS232/RS485 converter box is needed. We recommend using the F485 converter, manufactured by GE. This converter box is connected to the computer using a straight through serial cable. A shielded twisted pair (20, 22 or 24 AWG according to the American standards; 0.25, 0.34 or 0.5 mm<sup>2</sup> according to the European standards) cable is used to connect the converter box to the relay rear communications terminals. In order to minimize communication errors that could be caused by external noise, it is recommended to use a shielded twist pair. In order to avoid loops where external currents could flow, the cable shield must be grounded only at one end.

The converter box (-, +, GND) terminals are connected to the relay (SDA, SDB, GND) terminals respectively. For long communications cables (longer than 1 km), the RS485 circuit must be terminated in a RC network (i.e. 120 ohm, 1 nF). This circuit is shown on Figure 1–17:: RS485 CONNECTION FOR F650 UNITS, associated to text Zt(\*).



#### Figure 1–16: RELAY- PC CONNECTION FOR RS232 FRONT PORT

To minimize errors from noise, the use of shielded twisted pair wire is recommended. For a correct operation, polarity must be respected, although if it is not so, there is no danger to damage the unit. For instance, the relays must be connected with all RS485 SDA terminals connected together, and all SDB terminals connected together. This may result confusing sometimes, as the RS485 standard refers only to terminals named "A" and "B", although many devices use terminals named "+" and "-".

As a general rule, terminals "A" should be connected to terminals "-", and terminals "B" to "+". The GND terminal should be connected to the common wire inside the shield, when provided. Otherwise, it should be connected to the shield. Each relay should also be daisy chained to the next one in the link. A maximum of 32 relays can be connected in this manner without exceeding driver capability. For larger systems, additional serial channels must be added. It is also possible to use commercially available repeaters to increase the number of relays on a single channel to more than 32. Do not use other connection configuration different than the recommended.

Lightning strikes and ground surge currents can cause large momentary voltage differences between remote ends of the communication link. For this reason, surge protection devices are internally provided. To ensure maximum reliability, all equipment should have similar transient protection devices installed.





1

#### 2.1.1 F650 OVERVIEW

The F650 is a protection, control, monitoring, metering and registering unit, suitable for many different applications, such as main protection for distribution feeders and transmission lines, as well as backup protection for transformers, busbars, capacitor banks, etc. The main features of F650 devices include:

- · Directional overcurrent protection for phases, neutral, ground and sensitive ground
- Under and overvoltage protection
- Under and overfrequency protection
- Autorecloser
- Synchronism
- Metering
- Oscillography registers, fault reports, data logger
- Bay control (open/close commands, etc.)
- Bay mimic.
- Communications (RS232/RS485/fibre optic/Ethernet)
- Fully programmable front buttons, 15 LED's and input/output contacts





#### 2.2.1 ANSI DEVICE NUMBERS AND FUNCTIONS

DEVICE	FUNCTION	DEVICE	FUNCTION
NUMBER		NUMBER	
25	Synchronism	51PV	Phase Time Overcurrent with Voltage Restraint (two elements, High and Low)
27P	Phase Undervoltage	51SG	Ground Time Overcurrent for sensitive ground systems (measured from 5 <sup>th</sup> current transformer)
27X	Auxiliary Undervoltage	59N	Neutral Overvoltage (two elements, High and Low)
32	Sensitive Directional Power	59P	Phase Overvoltage
32FP	Forward Power	59X	Auxiliary Overvoltage
46	Negative Sequence Time Overcurrent	67P	Phase Directional
47	Negative Sequence Overvoltage	67N	Neutral directional
48	Locked Rotor	67G	Ground Directional
49	Protection against Overload by thermal model	67SG	Sensitive Ground Directional
50G	Ground Instantaneous Overcurrent (measured from 4 <sup>th</sup> current transformer)	79	Automatic Recloser (Four shot recloser)
50N	Neutral Instantaneous Overcurrent (calculated from the phase currents)	810	Overfrequency
50P	Phase Instantaneous Overcurrent (two elements, High and Low)	81U	Underfrequency
50SG	Ground Instantaneous Overcurrent for sensitive ground systems (measured from 5 <sup>th</sup> current transformer)	12/11	Broken Conductor
50ISG	Isolated Ground Instantaneous Overcurrent (measured from 5 <sup>th</sup> current transformer)	50BF	Breaker Failure
51G	Ground Time Overcurrent (measured from 4 <sup>th</sup> current transformer)	VTFF	VT Fuse Failure
51N	Neutral Time Overcurrent (calculated from the phase currents)		

#### Table 2–1: OTHER DEVICE FUNCTIONS

INPUTS/OUTPUTS	METERING	COMMUNICATIONS
9 Analog Inputs: 5 current inputs (3 for phases, 1 for ground, 1 for sensitive ground), 4 voltage inputs (3 for phases, 1 for busbar or auxiliary voltage)	Metering Current for phases, ground and sensitive ground inputs	Front RS232 port, Two rear RS485/fibre optic ports, 10/100 TX and 100 FX Mbps Ethernet port
Digital Programmable Contact Inputs (up to 32)	Voltages phase to phase and phase to ground	ModBus Communications RTU and over TCP/IP
Digital Programmable Contact Outputs (up to 16)	Real, Reactive and Apparent Power and Power Factor	DNP Multimaster (3.0 Level 2)
32 Latched Virtual Inputs 32 Self-Reset Virtual Inputs	Three Phase Energy	IEC 870-5-104
Virtual Outputs (up to 512)	Frequency	ModBus User Map
Tripping and closing circuit supervision	Sequence components of currents and voltages	

USER INTERFACE	RECORDS	OTHERS		
Alphanumerical display (4x20)	Data Logger	Breaking Arcing Current (I2t)		
Graphic display (16 x 40)	Demand	Breaker Control		
User Programmable LEDs (15)	Event Recorder (up to 128 configurable events)	IRIG-B synchronization		
User Programmable Keys (up to 5)	Fault Locator and Fault report (up to 10 records)	Logic Equations (PLC Editor)		
Easy menu management thanks to shuttle key	Oscillography (up to 20 records)	Settings Groups (up to 3)		
Configurable One-Line Diagram (Graphic model only)	Snapshot Events (up to 479)	Operations (up to 24)		
Phasor Diagram (available in EnerVista F650 Setup)		Web Server Application		

F650 units are supplied as ½ 19" rack, 6 units high devices, containing the following modules: power supply, CPU, I/O modules, communication modules. Each of these modules can be supplied in different versions that must be specified when ordering. The required information to completely define an F650 model is shown on TABLE 2-1.

#### Table 2–2: ORDERING CODE

2

F650	-	-	-	F	-	G	-	-		DESCRIPTION
	В									Basic display (4x20 characters)
	М									Graphic display (240x128 pixels)
										REAR SERIAL COMMUNICATIONS BOARD 1
		F								None
		Α								Redundant RS485
		Ρ								Redundant plastic fiber optic
		G								Redundant glass fiber optic
		Х								Redundant RS485 + fiber remote CAN bus I/O
		Y								Redundant plastic fiber optic + fiber remote CAN bus I/O
		Z								Redundant glass fiber optic + fiber remote CAN bus I/O
		С								Cable remote CAN Bus I/O
		М								RS485 + cable remote CAN Bus I/O
										REAR ETHERNET COMMUNICATIONS BOARD 2
			В							10/100 Base TX
			С							10/100 Base TX + 100 Base FX
			D							10/100 Base TX + Redundant 100 Base FX
			Е							Redundant 10/100 Base TX
										I/O BOARD IN SLOT F
					1					16 Digital Inputs + 8 Outputs
					2					8 Digital Inputs - 8 Outputs + 2 trip/close circuit supervision
							-	1		I/O BOARD IN SLOT G
							0			None
							1			16 Inputs + 8 Outputs
								LO		24-48 Vdc (range 19.2 – 57.6)
								н		110-250 Vdc (range 88 – 300)
										120-230 Vac (range 96 – 250)
								LOR		Redundant LO
								HIR		Redundant HI
										LANGUAGE
										English/English
									F	French/English
									Ρ	Russian/English (*)
									S	Spanish/English

SPECIAL MODELS: MOD001: 6A output contacts instead of 16A.

(\*) Note: Russian language available only for basic display models.

For those applications requiring a high number of inputs and outputs, F650 units can be connected to a CIO module (Remote CAN Bus I/O module) for using up to 2 additional boards.

#### **2 PRODUCT DESCRIPTION**

F650 units allow monitoring and configuring these I/O boards as if they were internal boards, located on slots F and G. In this case, slots are labeled as H y J.

The required information to completely define a CIO Module is shown on TABLE 2-2.

#### Table 2–3: ORDERING CODE FOR CIO MODULE

CIO	Н	-	J	-	-	DESCRIPTION
						I/O BOARD IN SLOT H
		1				16 inputs + 8 outputs
		2				8 inputs + 4 circuit supervision circuits + 6 outputs + 2 outputs with tripping current supervision (latching)
						I/O BOARD IN SLOT J
				0		None
				1		16 inputs + 8 outputs
				2		8 inputs + 4 circuit supervision circuits + 6 outputs + 2 outputs with tripping current supervision (latching)
						AUXILIARY VOLTAGE
					LO	24-48 Vdc (range 19.2 – 57.6)
					HI	110-250 Vdc (range 88 – 300)
						120-230 Vac (range 96 – 250)

#### NOTE: TECHNICAL SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE

#### 2.4.1 PROTECTION UNITS

2

Phase and ground units use as operation magnitude the current value received by the unit in current inputs, while the neutral unit uses the calculated current value from the three phase currents.

The isolated ground unit will be used only for those applications where the neutral is completely isolated, and it uses the fifth CT of the unit. This CT has a sensitivity that is 10 times higher than the universal model (connected to 1A or 5A transformers). Therefore, it does not admit such a high permanent overload.

#### a) PHASE TIME OVERCURRENT WITH VOLTAGE RESTRAINT (51PH/51PL)

Current Input	Phasor (without harmonics) or RMS
Rated current	For connection to 1 or 5 A CTs.
Pickup level	0.05 to 160.00 A in steps of 0.01 A
Reset level	98% of the pickup level
Level Accuracy	$\pm 0.5\%$ of the reading $\pm$ 10 mA from 0.05 to 10 A
	$\pm 1.5\%$ of the reading for higher values.
Curve Shapes	IEEE extremely / very / moderately inverse
	IEC A/B/C/long-time inverse/short time inverse curve
	IAC extremely / very / normally / moderately inverse
	ANSI extremely / very / normally / moderately inverse
	l <sup>2</sup> t
	Definite time
	Rectifier curve
	FlexCurve™ A/B/C/D user curve
Curve Multiplier (Time Dial)	0.00 to 900.00 s in steps of 0.01 s
Reset type	Instantaneous or time delayed according to IEEE
Timing accuracy	Operate at > 1.03 times the pickup ±3.5% of operate time or
	30 ms. (whichever is greater)
Voltage restraint	Selectable by setting
Saturation Level	48 times the pickup level
Snapshot Events	Selectable by setting

#### b) GROUND TIME OVERCURRENT (51G)

Current Input	Phasor (without harmonics) or RMS
Rated current	For connection to 1 or 5 A CTs.
Pickup level	0.05 to 160.00 A in steps of 0.01 A
Reset level	98% of the pickup level
Level Accuracy	$\pm 0.5\%$ of the reading $\pm$ 10 mA from 0.05 to 10 A
	$\pm 1.5\%$ of the reading for higher values.

Curve Shapes	IEEE extremely / very / moderately inverse
	IEC A/B/C/long-time inverse/short time inverse curve
	IAC extremely / very / normally / moderately inverse
	ANSI extremely / very / normally / moderately inverse
	l <sup>2</sup> t
	Definite time
	Rectifier curve
	FlexCurve™ A/B/C/D user curve
Curve Multiplier (Time Dial)	0.00 to 900.00 s in steps of 0.01 s
Reset type	Instantaneous or time delayed according to IEEE
Timing accuracy	Operate at > 1.03 times the pickup ±3.5% of operate time or
	30 ms. (whichever is greater)
Saturation Level	48 times the pickup level
Snapshot Events	Selectable by setting

#### c) NEUTRAL TIME OVERCURRENT (51N)

Current Input	Fundamental Phasor (without harmonics)
Rated current	For connection to 1 or 5 A CTs.
Pickup level	0.05 to 160.00 A in steps of 0.01 A
Reset level	98% of the pickup level
Level Accuracy	$\pm 0.5\%$ of the reading $\pm 10$ mA from 0.05 to 10 A $\pm 1.5\%$ of the reading for higher values
Curve Shapes	IEEE extremely / very / moderately inverse IEC A/B/C/long-time inverse/short time inverse curve IAC extremely / very / normally / moderately inverse ANSI extremely / very / normally / moderately inverse I <sup>2</sup> t Definite time Rectifier curve FlexCurve <sup>™</sup> A/B/C/D user curve
Curve Multiplier (Time Dial)	0.00 to 900.00 s in steps of 0.01 s
Reset type	Instantaneous or time delayed according to IEEE
Timing accuracy	Operate at > 1.03 times the pickup $\pm 3.5\%$ of operate time or 30 ms. (whichever is greater)
Saturation Level	48 times the pickup level
Snapshot Events	Selectable by setting

#### d) SENSITIVE GROUND TIME OVERCURRENT (51SG)

Current Input	Phasor (without harmonics) or RMS
Rated current	For connection to 1 or 5 A CTs.
Pickup level	0.005 to 16.000 A in steps of 0.001 A
Reset level	98% of the pickup level
Level Accuracy	$\pm 1.5\%$ of the reading $\pm$ 1 mA from 0.005 to 16 A

ANSI extremely / very / normally / moderately inverse I <sup>2</sup> t Definite time Rectifier curve FlexCurve™ A/B/C/D user curve
Curve Multiplier (Time Dial) 0.00 to 900.00 s in steps of 0.01 s
Reset type Instantaneous or time delayed according to IEEE
Timing accuracyOperate at > 1.03 times the pickup ±3.5% of operattime or 30 ms. (whichever is greater)
Saturation Level 48 times the pickup level
Snapshot Events Selectable by setting

#### e) PHASE AND GROUND INSTANTANEOUS OVERCURRENT (50PH/50PL/50G)

Current Input	Phasor (without harmonics) or RMS
Rated current	For connection to 1 or 5 A CTs.
Pickup level	0.05 to 160.00 A in steps of 0.01 A
Reset level	97% of the pickup level
Level Accuracy	$\pm 0.5\%$ of the reading $\pm$ 10 mA from 0.05 to 10 A
	$\pm 1.5\%$ of the reading for higher values
Overreach	< 2%
Trip delay	0.00 to 900.00 s. in steps of 0.01 s.
Reset delay	0.00 to 900.00 s. in steps of 0.01 s.
Operate time	20 ms at 3 x Pickup at 50 Hz, typically
Timing accuracy	$\pm 3\%$ of operate time or 30 ms. (whichever is greater)
Snapshot Events	Selectable by setting

#### f) NEUTRAL INSTANTANEOUS OVERCURRENT (50N)

Current Input	Fundamental Phasor (without harmonics)
Rated current	For connection to 1 or 5 A CTs.
Pickup level	0.05 to 160.00 A in steps of 0.01 A
Reset level	97% of the pickup level
Level Accuracy	$\pm 0.5\%$ of the reading $\pm$ 10 mA from 0.05 to 10 A
	$\pm 1.5\%$ of the reading for higher values
Overreach	< 2%
Trip delay	0.00 to 900.00 s. in steps of 0.01 s.
Reset delay	0.00 to 900.00 s. in steps of 0.01 s.
Operate time	20 ms at 3 x Pickup at 50 Hz, typically
Timing accuracy	$\pm 3\%$ of operate time or 30 ms. (whichever is greater)
Snapshot Events	Selectable by setting

#### g) SENSITIVE GROUND INSTANTANEOUS OVERCURRENT (50SG)

Current Input	Phasor (without harmonics) or RMS
Rated current	For connection to 1 or 5 A CTs.
Pickup level	0.005 to 16.000 A in steps of 0.001 A
Reset level	97% of the pickup level
Level Accuracy	$\pm 1.5\%$ of the reading $\pm$ 1 mA from 0.005 to 16 A
Overreach	< 2%
Trip delay	0.00 to 900.00 s. in steps of 0.01 s.
Reset delay	0.00 to 900.00 s. in steps of 0.01 s.
Operate time	20 ms at 3 x Pickup at 50 Hz
Timing accuracy	±3% of operate time or 30 ms. (whichever is greater)
Snapshot Events	Selectable by setting

#### h) ISOLATED GROUND INSTANTANEOUS OVERCURRENT (50IG)

Current Input	Fundamental Phasor (without harmonics)
Voltage Input	Fundamental Phasor (without harmonics)
Current Pickup level	0.005 to 0.400 A in steps of 0.001 A
Voltage Pickup level	2 to 70 V in steps of 1 V
Reset level	97-98% of the pickup level
Level Accuracy	$\pm 1.5\%$ of the reading $\pm$ 1 mA from 0.005 to 16 A
Trip delay	0.00 to 900.00 s. in steps of 0.01 s.
Time to instantaneous	0.00 to 900.00 s. in steps of 0.01 s.
Timing accuracy	$\pm$ 3% of operate time or 30 ms. (whichever is greater)
Snapshot Events	Selectable by setting

#### i) NEGATIVE SEQUENCE (46)

Current Input	Fundamental Phasor (without harmonics)
Pickup level	0.05 to 160.0 A in steps of 0.01 A
Reset level	98% of the pickup level
Level Accuracy	$\pm 0.5\%$ of the reading $\pm$ 10 mA from 0.05 to 10 A $\pm 1.5\%$ of the reading for higher values
Curve Shapes	IEEE extremely / very / moderately inverse IEC A/B/C/long-time inverse/short time inverse curve IAC extremely / very / normally / moderately inverse ANSI extremely / very / normally / moderately inverse I <sup>2</sup> t Definite time Rectifier curve FlexCurve <sup>™</sup> A/B/C/D user curve
Curve Multiplier (Time Dial)	0.00 to 900.00 s in steps of 0.01 s
Reset type	Instantaneous or time delayed according to IEEE
Timing accuracy	Operate at > 1.03 times the pickup $\pm 3.5\%$ of operate time or 30 ms. (whichever is greater)
# 2.4 TECHNICAL SPECIFICATIONS

Saturation Level Snapshot Events

#### j) PHASE DIRECTIONAL (67P)

2

Directionality Polarizing

Polarizing voltage threshold Characteristic angle Block Logic Angle accuracy Operate time

# k) GROUND DIRECTIONAL (67G)

Directionality Polarizing Polarizing Voltage Polarizing Current Operating Current Polarizing Voltage threshold Polarizing Current threshold Characteristic angle Block Logic Angle accuracy Operate time

# I) NEUTRAL DIRECTIONAL (67N)

Directionality	Forward and reverse selectable by setting
Polarizing	Voltage, current, dual
Polarizing Voltage	$V_{N}$ (measured or calculated, selected by setting)
Polarizing Current	lsg (measured from 5 <sup>th</sup> current transformer)
Operating Current	I <sub>N</sub>
Polarizing Voltage threshold	0 to 300 Vac in steps of 1 V
Polarizing Current threshold	0.005 A
Characteristic angle	-90° to +90° in steps of 1°
Block Logic	Permission or Block selectable by setting

48 times the pickup level Selectable by setting

Forward and reverse selectable by setting Quadrature Voltage: ABC seq: Phase A (VBC), Phase B (VCA), Phase C (VAB) ACB seq: Phase A (VCB), Phase B (VAC), Phase C (VBA) 0 to 300 Vac in steps of 1 V -90° to +90° in steps of 1° Permission or Block selectable by setting  $\pm 2°$  for I>0.1 A and V>5 Vac <30ms, typically

Voltage, current, dual  $V_N$  (measured or calculated, selected by setting) Isg (measured from 5<sup>th</sup> current transformer) Ig (measured from 4<sup>th</sup> current transformer) 0 to 300 Vac in steps of 1 V 0.005 A -90° to +90° in steps of 1° Permission or Block selectable by setting ±2° for I>0.1 A and V>5 Vac <30ms, typically

Forward and reverse selectable by setting

Angle accuracy Operate time  $\pm 2^{\circ}$  for I>0.1 A and V>5 Vac <30ms, typically

# m) SENSITIVE GROUND DIRECTIONAL (67SG)

Directionality	Forward and reverse selectable by setting
Polarizing	Voltage
Polarizing Voltage	$V_N$ (measured or calculated, selected by setting)
Operating Current	lsg (measured from 5 <sup>th</sup> current transformer)
Polarizing Voltage threshold	0 to 300 Vac in steps of 1 V
Characteristic angle	-90° to +90° in steps of 1°
Block Logic	Permission or Block selectable by setting
Angle accuracy	$\pm 2^{\circ}$ for I>0.1 A and V>5 Vac
Operate time	<30ms, typically

# n) THERMAL MODEL (49)

Current Input
Rated current
Pickup level
Reset level
Level Accuracy

Timing accuracy Heating constant Cooling constant Snapshot Events

# For connection to 1 or 5 A CTs. 0.05 to 160.0 A in steps of 0.01 A 97% of the pickup level $\pm 0.5\%$ of the reading $\pm$ 10 mA from 0.05 to 10 A $\pm 1.5\%$ of the reading for higher values $\pm 3.5\%$ of operate time or 30 ms. (whichever is greater) Between 3 and 600 minutes 1 to 6 times the heating constant Selectable by setting

Fundamental Phasor (without harmonics)

# o) PHASE OVERVOLTAGE (59P)

Voltage Input	Fundamental Phasor (without harmonics) of phase-to-phase voltages
Pickup level	3 to 300 in steps of 1 V
Reset level	97% of the pickup level
Level Accuracy	$\pm 1\%$ reading $\pm 0.1\%$ Full Scale from 10 to 275 V
Trip delay	0.00 to 900.00 s. in steps of 0.01 s.
Reset delay	0.00 to 900.00 s. in steps of 0.01 s.
Timing accuracy	±3.5% of operate time or 30 ms. (whichever is greater)
Logic	Any/Two/All phases logic selectable by setting
Snapshot Events	Selectable by setting

# p) PHASE UNDERVOLTAGE (27P)

2

Pickup level Reset level Level accuracy Curve Shapes Reset type Curve Multiplier (Time Dial) Timing accuracy Minimum Voltage Threshold Logic Supervised by Breaker Snapshot Events Fundamental Phasor of phase-to-ground or phase-tophase voltages (selectable by setting) 3 to 300 in steps of 1 V 103% of the pickup level  $\pm$ 1% reading  $\pm$ 0.1% Full Scale from 10 to 275 V Fixed time or inverse curve Instantaneous 0.00 to 900.00 s. in steps of 0.01 s.  $\pm$ 3.5% of operate time or 30 ms. (whichever is greater) 0 to 300 in steps of 1 V Any/Two/All phases logic selectable by setting Selectable by setting

#### q) NEUTRAL OVERVOLTAGE (59NH/59NL)

Voltage Input	Fundamental Phasor of the neutral voltage
Pickup level	3 to 300 in steps of 1 V
Reset level	97% of the pickup level
Level accuracy	$\pm 1\%$ reading $\pm 0.1\%$ Full Scale from 10 to 275 V
Trip delay	0.00 to 900.00 s. in steps of 0.01 s
Reset delay	0.00 to 900.00 s. in steps of 0.01 s
Timing accuracy	$\pm 3.5\%$ of operate time or 30 ms. (whichever is greater)
Snapshot Events	Selectable by setting

#### r) NEGATIVE SEQUENCE OVERVOLTAGE (47)

Voltage Input	Fundamental Phasor
Pickup level	3 to 300 in steps of 1 V
Reset level	97% of the pickup level
Level accuracy	$\pm 1\%$ reading $\pm 0.1\%$ Full Scale from 10 to 275 V
Trip delay	0.00 to 900.00 s. in steps of 0.01 s
Reset delay	0.00 to 900.00 s. in steps of 0.01 s
Timing accuracy	±3.5% of operate time or 30 ms. (whichever is greater)
Snapshot Events	Selectable by setting

# s) AUXILIARY OVERVOLTAGE (59X)

Voltage Input	Fundamental Phasor
Pickup level	3 to 300 in steps of 1 V
Reset level	97% of the pickup level

#### **2 PRODUCT DESCRIPTION**

Level accuracy Trip delay Reset delay Timing accuracy Snapshot Events

#### 2.4 TECHNICAL SPECIFICATIONS

 $\pm$ 1% reading  $\pm$ 0.1% Full Scale from 10 to 275 V 0.00 to 900.00 s. in steps of 0.01 s 0.00 to 900.00 s. in steps of 0.01 s ±3.5% of operate time or 30 ms. (whichever is greater) Selectable by setting

#### t) AUXILIARY UNDERVOLTAGE (27X)

Voltage Input Pickup level Reset level Level accuracy **Curve Shapes** Reset type Curve Multiplier (Time Dial) Timing accuracy **Snapshot Events** 

**Fundamental Phasor** 3 to 300 V in steps of 1 V 97% of the pickup level  $\pm$ 1% reading  $\pm$ 0.1% Full Scale from 10 to 275 V Fixed time or inverse curve Instantaneous 0.00 to 900.00 s. in steps of 0.01 s ±3.5% of operate time or 30 ms. (whichever is greater) Selectable by setting

# u) UNDERFREQUENCY (81U)

Pickup level	20.00 to 65.00 Hz in steps of 0.01 Hz
Reset level	Pickup + 0.03 Hz
Level accuracy	$\pm$ 0.01 Hz of the reading
Trip delay	0.00 to 900.00 s. in steps of 0.01 s
Reset delay	0.00 to 900.00 s. in steps of 0.01 s
Minimum voltage threshold	30 to 300V in steps of 1 V
Timing accuracy	±3.5% of operate time or 100 ms. (whichever is greater)
Snapshot Events	Selectable by setting

#### v) OVERFREQUENCY (810)

Pickup level Reset level Level accuracy Trip delay Reset delay Minimum voltage threshold Timing accuracy **Snapshot Events** 

Selectable by setting

20.00 to 65.00 Hz in steps of 0.01 Hz Pickup - 0.03 Hz ±0.01 Hz of the reading 0.00 to 900.00 s. in steps of 0.01 s 0.00 to 900.00 s. in steps of 0.01 s 30 to 300V in steps of 1 V ±3.5% of operate time or 100 ms. (whichever is greater) Selectable by setting

# w) FORWARD POWER (32FP)

Current, Voltage Number of stages Pickup level (two stages) Reset level Level accuracy for primary magnitudes Trip delay (two stages) Timing accuracy Block Time after close Snapshot Events Fundamental Phasor (primary values) 2 0.00-10000.00 MW in steps of 0.01 MW 97% of the pickup level ±3% complete range. 0.00 to 900.00 s in steps of 0.01 s ±3.5% of operate time or 30 ms. (whichever is greater) 0.00 to 900.00 s in steps of 0.01 s Selectable by setting

#### x) SENSITIVE DIRECTIONAL POWER (32)

Current, Voltage Fundamental Phasor (primary values) Number of stages 2 Pickup level (two stages) -10000.00 to 10000.00 MW (primary values) in steps of 0.01 MW Characteristic Angle (two stages) 0.00 to 359.99 in steps of 0.01 Reset level 97% of the pickup level Accuracy for primary magnitudes ±3% complete range Trip delay (two stages) 0.00 to 900.00 s in steps of 0.01 s Timing accuracy ±3.5% of operate time or 30 ms. (whichever is greater) Block Time after close 0.00 to 900.00 s in steps of 0.01 s **Snapshot Events** Selectable by setting

#### y) BROKEN CONDUCTOR (I2/I1)

Pickup level Reset level Trip delay Timing accuracy Minimum Phase Current Threshold Snapshot Events Operation Threshold 20.0-100.0% (I2/I1 ratio) in steps of 0.1% 97% of the pickup level 0.00 to 900.00 s in steps of 0.01 s ±3.5% of operate time or 30 ms. (whichever is greater) 0.05 A Selectable by setting 0.000 to 1.000 A in steps of 0.001 A

Note: The I2/I1 current inhibition level for the different firmware versions is as follows

Firmware Version	Current Inhibition Level
1.50 or Lower	10 mA
1.60 or Higher	50 mA
1.80 or Higher	Selectable by setting from 0.000 to 1.000 in steps of 0.001 A

2

# z) LOCKED ROTOR (48)

Current Input	Phasor (without harmonics) or RMS
Rated current	For connection to 1 or 5 A CTs.
Full Load Current	0.10 to 10.00 KA in steps of 0.01 KA
Pickup level	1.01 to 109.00 in steps of 0.01
Reset level	97% of the pickup level
Level accuracy for primary magnitudes	±3% complete range.
Trip delay	0.00 to 900.00 s. in steps of 0.01 s.
Reset delay	0.00 to 900.00 s. in steps of 0.01 s.
Operate time	20 ms at 3 x Pickup at 50 Hz, typically
Timing accuracy	±3.5% of operate time or 30 ms. (whichever is greater)
Snapshot Events	Selectable by setting

# 2.4.2 CONTROL

# a) AUTORECLOSE (79)

Schemes	Three-pole tripping schemes
Number of shots	Up to 4 reclose attempts before lockout
Dead time	Independent dead time setting before each shot adjustable between 0 and 900 s in steps of 0.01 s $$
Reclaim time	0.00 to 900.00 s in steps of 0.01 s
Condition permission	Selectable by setting
Hold time	0.00 to 900.00 s in steps of 0.01 s
Reset time	0.00 to 900.00 s in steps of 0.01 s
Snapshot Events	Selectable by setting
Possibility to modify protection settings after each shot progra shot)	mmable through PLC (block signals available after each

# b) SYNCHROCHECK (25)

Dead/live levels for line and bus	0.00 to 300.00 in steps of 0.01 V
Maximum voltage difference	2.00 to 300.00 V in steps of 0.01 V
Maximum angle difference	2.0° to 80.0° in steps of 0.1°
Maximum frequency slip	10 to 5000 mHz in steps of 10 mHz
Synchronism time	0.01 to 600.00 s in steps of 0.01 s
Angle accuracy	2°
Dead Source function	None (DL-DB) Dead Line - Dead Bus (LL-DB) Live Line-Dead Bus (DL-LB) Dead Line – Live Bus
Snapshot Events	Selectable by setting

# 2.4 TECHNICAL SPECIFICATIONS

# c) FUSE FAILURE

2

Algorithm based on positive sequence of voltage and current Activation by  $V_2/V_1$  ratio

# d) BREAKER FAILURE (50BF)

Fundamental Phasor (without harmonics)
For connection to 1 or 5 A CTs.
0.05 to 160.00 A in steps of 0.01 A
0.05 to 160.00 A in steps of 0.01 A
0.05 to 160.00 A in steps of 0.01 A
0.05 to 160.00 A in steps of 0.01 A
97% of the pickup level
$\pm 0.5\%$ of the reading $\pm$ 10 mA from 0.05 to 10 A
$\pm 1.5\%$ of the reading for higher values.
$\pm 3.5\%$ of operate time or 30 ms. (whichever is greater)
Selectable by setting

#### e) BREAKER SETTINGS

Number of Switchgear	1 to16 (selection of switchgear for breaker control)
Maximum KI <sup>2</sup> t	0.00 to 9999.99 in steps of 0.01 (kA) <sup>2</sup> s
KI <sup>2</sup> t integration Time	0.03 to 0.25 s in steps of 0.01 s
Maximum openings	0 to 9999 in steps of 1
Maximum Openings in one hour	1 to 60 in steps of 1
Snapshot Events	Selectable by setting

#### f) BREAKER MAINTENANCE

Kl<sup>2</sup>t Breaker Counters for Phases A, B, C Breaker Openings Counter Breaker Closings Counter

# 0 to 9999 in steps of 1 0 to 9999 in steps of 1

0.00 to 9999.99 in steps of 0.01 (kA)<sup>2</sup> s

# g) SWITCHGEAR

Switchgear Snapshot Events 1 to16 (configurable in "relay configuration" screen). Selectable by setting (for each switchgear in "system setup")

# a) OSCILLOGRAPHY

Maximum Records:	Up to 20 Oscillography records.
Sampling rate:	Programmable to 4, 8, 16, 32 or 64 samples per power cycle
Capacity per record:	27592 samples
	No of Oscillos * No of samples/cycle
Trigger position:	5% to 95% of total length
Trigger:	Programmable via PLC
Data:	5 current channels and 4 voltage channels
	Up to 16 digital channels programmable through PLC
Data Storage:	In non volatile memory (flash) without battery
Format:	International Standard COMTRADE ASCII - IEEE C37.111-1999.
Automatic Overwrite:	Selectable by setting. (Oscillography records can be concatenated)
Snapshot Events:	Selectable by setting

# b) FAULT LOCATOR

Method:	Single-ended
Positive Sequence Module:	0.01 to 250.00 Ohm in steps of 0.01 Ohms
Positive Sequence Angle:	25 to 90° in steps of 1°
Zero Sequence Module:	0.01 to 750.00 Ohms in steps of 0.01 Ohm
Zero Sequence Angle:	25 a 90° in steps of 1°
Line Length:	0.0 to 2000.0 in steps of 0.1 (miles or km)
Accuracy:	5% (typical)
Display Fault on HMI:	Selectable by setting
Snapshot Events:	Selectable by setting
Maximum Records:	Up to 10 fault report records.
Data:	Fault date and time, pre-fault currents and voltages, fault currents and voltages, fault type, distance to the fault (fault location), line parameters, recloser and breaker status information.
Data Storage:	In non volatile memory (flash) without battery available through communications
	In volatile memory (ram) available through HMI (if selectable by setting)
Format:	Text in ASCII format

# c) SNAPSHOT EVENTS

Capacity:	479 scrolling events
Time-tag	1 ms using an internal clock of 100 $\mu$ s
Timing Accuracy:	1 ms (using the IRIG-B synchronization input)
Triggers:	Any element pickup, dropout
	Digital input /output change of state
	By virtual inputs and control events
Data Storage	In non volatile memory (flash) without battery
The snapshot event recording procedur	e can be enabled or disabled by setting for each protection function

# d) CONTROL EVENTS

Capacity:	128 events programmable through PLC
Time-tag:	1 ms using an internal clock of 100 $\mu$ s
Timing Accuracy:	1 ms (using the IRIG-B synchronization input)
Triggers:	By any digital signal programmable through PLC
Alarm	Possibility to display the event as an alarm on the alarms panel. Information available always through Communications for all models and also in HMI for models with graphical display (M in ordering code).
Data Storage:	In non volatile memory (flash) without battery
Control events are also displayed in the	snapshot events recording

# e) DEMAND

Channels:	9
Parameters:	la (kA RMS), lb (kA RMS), lc (kA RMS), lg (kA RMS), lsg (kA RMS), l2 (kA), P (MW), Q (MVAr) and S (MVA)
Current and Power Method	Thermal Exponential, Block Interval, Rolling Demand
Measurements:	Each channel shows the present and maximum measured value, with date and time for the maximum recorded value.
Samples:	5, 10, 15, 20, 30, 60 minutes.
Accuracy:	±1%
Trigger Input	Selectable by setting (operation mode selection for the Block Interval calculation method)
Snapshot Events:	Selectable by setting

# f) DATA LOGGER

Number of Channels:	1 to 16
Parameters	Any available analog actual value
Samples	1 sec., 1, 5, 10, 15, 20, 30, 60 min.
Storage Capacity	Fixed, 32768 measures

# 2.4.4 USER - PROGRAMABLE ELEMENTS

# a) PLC LOGIC

Programming language:	The logical configuration is performed using graphical functions based on the IEC 61131-3 standard.
Lines of code:	512
Supported operations:	NOT, XOR, OR (2 to 8 inputs), AND (2 to 8 inputs), NOR (2 to 8 inputs), NAND (2 to 8 inputs), Latch (Reset Dominant), Edge Detectors, Timers. 2 inputs default gates, from 3 to 8 inputs provided in library format.
Libraries:	Logical gates fully programmable by user. To create user-programmable logic to be distributed as a single object.
Inputs:	Any logical variable, contact or virtual input
Number of timers:	8 maximum in each logic scheme (provided in library format)
b) FLEXCURVES	
Number:	4 (A through D)
Reset points:	40 (0 through 1 of pickup)
Operate points:	80 (1 through 20 of pickup)
Time delay:	0 to 65535 ms in steps of 1
Saturation Level	20 times the pickup level
c) USER-PROGRAMMABLE LEDS	
Number:	15 configurable LEDs plus a ready non configurable LED
Programmability:	from any logical variable, contact, or virtual input
Reset mode:	Self-reset or Latched.
	The first 5 LED's are latched by hardware (red color ones), usually configured for trip signals.
	The following 10 ones (yellow and green) are self-reset but can be latched through PLC configuration.
Reset Signal:	The LED's can be reset by hardware, pressing the front "esc" key during more than 3 seconds or using the LED reset signal through PLC configuration.
d) USER-DEFINABLE DISPLAYS	
Number of configurable displays:	1 (one line diagram fully configurable). In graphical displays only
Number of fixed displays:	6, Metering (in primary values), Snapshot events (all and new), Alarms, Inputs and outputs screen with test functionality for inputs and outputs. In graphical dis- plays only

Number of selectable displays:

Logotype, metering or both in scrolling mode, can be selectable as default screen in text display for all models (basic and mimic). The metering screen contains current and voltages for phases and ground in primary values.

Number of configurable Keys: Operation:	5 drive PLC operands
	2.4.5 METERING
a) CURRENT	
Accuracy:	$\pm 0.5\%$ of the reading $\pm$ 10 mA from 0.05 to 10 A (for phases and ground)
	$\pm 1.5\%$ of the reading $\pm$ 1 mA from 0.005 to 5 A (for sensitive ground)
	$\pm 1.5\%$ of the reading for higher values
b) VOLTAGE	
Accuracy:	$\pm 1\%$ reading $\pm 0.1\%$ Full Scale from 10 to 275 V
c) REAL POWER (WATTS)	
Accuracy:	$\pm$ 1% of the reading at-0.8 < PF = -1 and 0.8 <pf=1< td=""></pf=1<>
d) REACTIVE POWER (VARS)	
Accuracy:	$\pm$ 1% of the reading at-0.2 = PF = 0.2
e) APPARENT POWER (VA)	
Accuracy:	±1% of the reading
f) WATT-HOURS (POSITIVE AND N	NEGATIVE)
Accuracy:	$\pm$ 1% of the reading
Range:	±0 to 2147 MWh
Parameters:	3-phase only
Update rate:	100 ms
g) WAR-HOURS (POSITIVE AND N	NEGATIVE)
Accuracy:	±1% of the reading
Range:	±0 to 2147 MVArh
Parameters:	3-phase only
Update rate:	100 ms
h) POWER FACTOR	
Accuracy:	0.02
Parameters:	3-Phase and single phase

e) USER-PROGRAMMABLE FRONT KEYS

2

# **2 PRODUCT DESCRIPTION**

#### i) FREQUENCY

Accuracy:	±10 mHz at 50 Hz ±12 mHz at 60 Hz
j) ANGLE	
Accuracy:	2°

#### a) AC CURRENT INPUTS

CT Ratio:	1.0 to 6000.0 in steps of 0.1
Rated currents:	Appropriate for 1 or 5 A. F650 has universal range for CT (valid for 1 or 5 A to only one terminal).
Relay Burden:	< 0.04 Ohm
Current Withstand	Continuous at 20 A
	1 second at 500 A for phases and ground 1 second at 50 A for sensitive ground

# b) AC VOLTAGE INPUTS

VT Ratio	1.0 to 6000.0 in steps of 0.1
Rated Voltages	275 Vac
Metering range:	From 2 to 275 Vac
Relay Burden:	0.05 VA at 120 Vac (50 or 60 Hz)
Voltage Withstand:	Continuous at 260 V to neutral
	1 min/hr at 420 to neutral

VAC inputs do not need varistors, as the impulse test is applied to 100% of the transformers

# c) DIGITAL INPUTS

Input Activation Voltage Threshold:	1 to 255 Vdc in steps of 1 V (selectable by setting)
Impedance:	> 100 kOhm
Maximum error:	$\pm 10\%$ setting $\pm 2.5$ V
Load for voltage supervision inputs:	2 mA + V/100 kOhm
Voltage threshold for voltage supervision inputs	< 10 V (fixed)
Debounce Time:	1 to 50 in steps of 1 ms
Recognition time:	< 1ms
Timing resolution:	1 ms

For Input Activation Voltage Threshold and Debounce Time there is a single setting for all inputs in the same group (inputs sharing the same common). In mixed and supervision boards there are two groups of inputs, called A and B.

Input Type and Delay Input Time are not grouped; there is a different setting for each input.

2

Input Type	Positive-Edge / Negative-Edge / Positive/ Negative
Delay Input Time	0 to 60000 ms in steps of 1 ms (Input signal time delay)

# d) IRIG-B INPUT

2

Amplitude modulation:	DC SHIFT = Demodulated input (no carrier)	
Input Voltage:	TTL	
Input Burden:	1.5 mA	
Input Impedance:	3.3 kOhm	
Minimum Input Voltage:	2.4 V	
Maximum Input Voltage:	+/- 24 V	
Formats:	B000 (*) B001, B002 and B003 (*) (*) Signal combinations recognized in accordance with IRIG Standard 200-95	
Isolation:	2 kV	

#### 2.4.7 REAL TIME CLOCK

Accuracy:	Typical ±20 ppm
Backup energy:	More than 1 week

# 2.4.8 OUTPUTS

Carry continuous:	16 A
Make and Carry for 1 sec	60 A
Break at L/R of 40 ms:	0.3 A DC max. at 125 Vdc 0.25 A DC max. at 250 Vdc
Operate Time:	< 8 ms
Contact material:	Silver Alloy
Output Logic Type, Output Type and Pul	lse Output Time are selectable by setting for each output
Output Logic Type	Positive / Negative
Output Type	Normal / Pulse / Latch (Selectable by setting for each output)

Pulse Output Time 0 to 60000 ms in steps of 1 ms (applicable only to signals set as pulse type)

Separate operate and reset signal can be configured by any digital signal programmable through PLC

Contact Outputs (F31-F33, F34-F36) for board type 2 (supervision) in slot F: The current seal-in circuit is used for verifying the current condition in a circuit during the time that the tripping contact remains closed. If the current in the tripping circuit is maintained over 100 mA, the function is sealed independently of the status of the function that caused the trip.

LOW RANGE (LO)		
Nominal DC Voltage:	24 to 48 V	
Min/Max DC Voltage	19.2 / 57.6 V	
Note:	Low range is DC only	
HIGH RANGE (HI)		
Nominal DC Voltage:	110 to 250 V	
Min/Max DC Voltage	88 / 300 V	
Nominal AC Voltage:	120 to 230 V	
Min/Max AC Voltage	102 / 250 V	
ALL RANGES		
Voltage Loss hold-up time	200 ms typical, worst case 100 ms without unit reset	
Power consumption	Typical =25 VA, Maximum =45 VA	
Display backlight auto power-off mode after 15 minutes without touching any key, in order to ensure long life and minimum consumption.		

2.4.10 COMMUNICATIONS

COM2
RS232
300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600 y 115200 bauds
19200
ModBus <sup>®</sup> RTU / DNP 3.0
1200 m
2 kV
COM1, COM2
(rear COM2 multiplexed with front port)
None
Two RS485 ports
Two RS485 ports with CAN for inputs/outputs module
Two 1mm-plastic F.O. ports
Two 1mm-plastic F.O. ports Two 1mm-plastic F.O. ports with CAN for inputs/outputs module
Two 1mm-plastic F.O. ports Two 1mm-plastic F.O. ports with CAN for inputs/outputs module Two multimode glass F.O. ports with ST connectors
Two 1mm-plastic F.O. ports Two 1mm-plastic F.O. ports with CAN for inputs/outputs module Two multimode glass F.O. ports with ST connectors Two multimode glass F.O. ports with ST connectors with CAN for inputs/outputs module
Two 1mm-plastic F.O. ports Two 1mm-plastic F.O. ports with CAN for inputs/outputs module Two multimode glass F.O. ports with ST connectors Two multimode glass F.O. ports with ST connectors with CAN for inputs/outputs module Wave length: 1300nm
Two 1mm-plastic F.O. ports Two 1mm-plastic F.O. ports with CAN for inputs/outputs module Two multimode glass F.O. ports with ST connectors Two multimode glass F.O. ports with ST connectors with CAN for inputs/outputs module Wave length: 1300nm Fiber type: multimode 62.5/125 μm or 50/125 μm
Two 1mm-plastic F.O. ports Two 1mm-plastic F.O. ports with CAN for inputs/outputs module Two multimode glass F.O. ports with ST connectors Two multimode glass F.O. ports with ST connectors with CAN for inputs/outputs module Wave length: 1300nm Fiber type: multimode 62.5/125 μm or 50/125 μm 300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600 y 115200 bauds

Protocols available:	ModBus <sup>®</sup> RTU / DNP 3.0
Typical distance:	1200 m
Isolation:	2 kV
CAN PORT:	
Rear port:	CAN port in models X, Y, Z for asynchronous rear ports
Туре:	Multimode glass F.O. port with ST connectors
Wave length:	1300 nm
Fiber type:	multimode 62.5/125 μm or 50/125 μm
Isolation:	2 kV
ETHERNET PORT:	
Rear port:	COM3
Type (depending on model):	
Model B:	10/100BaseTX self-negotiable
Model C:	10/100BaseTX + 100Base FX
Model D:	10/100BaseTX + Double 100BaseFX (Physical media redundancy)
10/100BaseTX	RJ45 connector
100BaseFX	ST connectors
Wave length:	1300 nm
Fiber type:	multimode 62.5/125 μm or 50/125 μm
Protocols available:	ModBus® TCP/IP
	DNP over TCP/IP and UDP/IP
	IEC 870-5-104
	Http, ftp, tftp (allow the use of a standard Internet browser)
Typical distance:	1.65 km
Response time to ModBus commands:	10 ms Typical
Isolation:	2 kV
In Models C and D, the 10/100BaseTX	port is selected by an internal switch (see 3.3.3)
Two witness LED's for transmission and	reception are included

# 2.4.11 ENVIRONMENTAL CHARACTERISTICS

Operating temperature:	- 10°C to + 60°C
Storage temperature:	- 40°C to + 80°C
Humidity (non condensing):	95%
Altitude	Up to 2000 m
Installation category	II

# 2.4.12 PACKAGING AND WEIGHT

Net weight:	5 kg
Packaged:	6 kg
Package dimensions:	30x40x40 cm (DxWxH)

# 2.4.13 TYPE TESTS

Category	Standard	Class	Test
EMC	IEC 61000-4-1 IEC 60255-22-1		Oscillatory waves immunity
	IEC 61000-4-2 IEC 60255-22-2	IV	Electrostatic discharge immunity test
	IEC 61000-4-3 IEC 60255-22-3	Ш	Radiated electromagnetic field disturbance test
	IEC 61000-4-4 IEC 60255-22-4	IV	Electrical fast transient
	IEC 61000-4-5 IEC 60255-22-5	IV	Surge immunity test
	IEC 61000-4-6 IEC 60255-22-6	Ш	Conducted electromagnetic field distur- bance test
	IEC 61000-4-8 EN 61000-4-8	IV	Power frequency magnetic field immunity
	ENV50204	Ш	Radiated electromagnetic field disturbance test – 1890 MHz.
EMC Emisivity	IEC 60255-25 EN 61000-6-4	А	Conducted and radiated emissions
Product	IEC 60255-5	2 kV	Insulation resistance – dielectric test
	IEC 60255-5	6kV .5J	Impulse test
	IEC 60255-11	100 ms	Power supply Voltage dips/interruptions/vari- ations:
Mechanical	IEC 60255-21-1	I	Vibration test (sinusoidal)
	IEC 60255-21-2	Ι	Shock and bump
	IEC 60255-21-3	I	Seismic

Type test report available upon request.

F650 has been designed to comply with the highest existing requirements. More specifically, UNIPEDE recommendations for high voltage substations are followed, even if for most applications such high classes are not required.

The relay complies with ANSI C37.90 standards, and has been designed to comply with international standards.

#### 2.4.14 APPROVALS

ISO9001 Registered system.

CE marking: Meets the CE standards relevant for protections.

F650 units can hold two different options for F module:

Option 1:Board with 16 inputs and 8 outputs.

Option 2: Board with 8 digital inputs, 4 circuit supervision outputs, 6 conventional outputs, and two current sensing outputs Each model has a different wiring diagram, as follows:



Figure 2–2: WIRING DIAGRAM FOR MODELS WITH OPTION 1 (189C4216H3)

# **2 PRODUCT DESCRIPTION**

# The option 2 wiring diagram is shown below:



# Figure 2–3: WIRING DIAGRAM FOR MODELS WITH OPTION 2 (189C4216H2)

#### 3.1.1 OVERVIEW

This software package uses ModBus protocol, and it is designed to communicate with a single relay at a time. GE offers different communication software packages, such as GE-POWER, which can be used to communicate simultaneously with several relays.

EnerVista 650 Setup software provides an easy way to configure, monitor and manage all F650 features.

a )Setting files

EnerVista 650 Setup software provides two ways of working with setting files:

- 1.OFF LINE Mode: Creating or editing setting files not connected to the relay, to be stored later in the proper unit.
- 2. ON LINE Mode: Connecting to the relay. This on line mode allows settings modifications, reading metering values, internal status, oscillography records, event records, etc.
- b) Configuration

The relay allows to fully program all the inputs, outputs, LEDs, control events, operations, block signals in protection elements, switchgear, one line diagram in HMI, and create internal logic.

For simple relay configurations a direct configuration can be used (Relay configuration screen), and for more complex configurations a PLC Editor tool is provided (Logic Configuration screen).

- c) Monitoring of all metering values, internal states, inputs and outputs provided by F650 device.
- d) Performing the previously configured operations
- e) Updating of operating system, firmware version and web server utility.
- f) One line diagrams configuration (bay mimics) for its use in models with graphical display only.
- g) Registering data info for control events, snapshot events, alarms, fault reports, oscillography files, data logger, etc.

# 3.1 ENERVISTA 650 SETUP SOFTWARE INTERFACE

3.1.2 MAIN SCREEN

EnerVista 650 Setup software provides the following areas:

- Title
- Main menu bar
- Main icon bar
- Working area
- Status bar



Figure 3–1: ENERVISTA 650 SETUP MAIN SCREEN

To start communicating with the relay go to "*Communication>Computer>Computer settings*" section in the main EnerVista 650 Setup menu.

Safety instructions must be followed before connecting the computer to the relay. Safety instructions are detailed in section 1.1.3 SAFETY INSTRUCTIONS. Connect the relay ground terminal and the communicating computer to a good grounding. Otherwise, communication may not be viable, or even, in worst cases, the relay and/or the computer could result damaged by overvoltages.

For on-line working, previously ensure that all relay communication parameters, such as baudrate, slave ModBus address, etc, match the computer settings.

com oren ser mu	5		🗸 ОК
ilave Address:	254		Cancel
ommunication Port #:	COM1		
aud Rate:	19200 💌		Store
arity:	NONE		SPrint screen
ontrol type:	No control type	•	
tartup Mode:	File mode	-	
	Dordano		
	TDOL		
MMUNICATION CON	TROL	1	
OMMUNICATION CON tatus	TROL talking to an F650.	COM Maxin for a	MUNICATION OPTIMIZATION - num time to wait response (ms): 1000

#### Figure 3–2: COMMUNICATION PARAMETERS MENU

The "Communication > computer" screen is divided in several subsections:

Computer settings: Main communication parameters for serial communication and control type selection.

ModBus/TCP Setup (if ModBus /TCP is selected as control type): Communication parameters for ModBus TCP communication.

Communication control: Device communication status (communicating or not communicating).

Communication optimization: allows optimizing the communication time outs and failure establishing.

#### **COMPUTER SETTINGS**:

Shows the communication parameters necessary in order to establish communication with the unit. Such as slave address, communication port, baud rate, parity, control type and startup mode.

Baud rate, parity, data bits, stop bits and ModBus slave address for com2 (RS232 front port and second serial port in the rear communication board) are displayed in the default text logotype main screen.

**ModBus Slave Address:** ModBus addresses used for serial and Ethernet communication. These parameters can be accessed through the relay HMI and EnerVista 650 Setup software. In Relay HMI: go to *"Main screen>View or Change Settings menu >Product Setup>Communication> ModBus Protocol"*.

To move through the HMI, press intro (press in shuttle key) to enter in the internal menus and "esc" to exit.

In EnerVista 650 Setup go to "Setpoint>Product Setup>Communication Settings>ModBus Protocol"

Communication ports: port used in the computer for serial communication.

**Baud Rate:** Baud rate for serial communication (from 1200 up to 115200 bauds in EnerVista 650 Setup, from 300 to 115200 in relay).

Parity: parity for serial communication. None, odd or even can be selected.

Baud rate and parity are serial communication parameters located both in serial ports menu. In relay HMI: go to "Main screen>View or Change Settings menu >Product Setup>Communication> Serial Ports". In EnerVista 650 Setup, go to "Setpoint>Product Setup>Communication Settings>Serial Ports".

Control Type: The available control modes are:

- No Control Type, this option selects the serial communication mode, for use with serial communication ports (front port, RS485, or plastic or glass fiber optic).
- MODBUS/TCP, this option selects ModBus TCP/IP communication mode, for communication through the Ethernet
  port. In this case, the top right window will show the typical parameters to be programmed; IP address, port address
  and unit identifier in the MODBUS TCP SETUP section.

To access the relay IP address in relay HMI, go to "Main screen>View or Change Settings menu >Product Setup>Communication> Ethernet>Ethernet 1 or 2". In EnerVista 650 Setup, go to "Setpoint>Product Setup>Communication Settings>Network (Ethernet)>Ethernet 1 or 2".

For port address and unit identifier, in relay HMI go to "*Main screen>View or Change Settings menu >Product Setup>Communication>ModBus Protocol*". In EnerVista 650 Setup, go to "*Setpoint>Product Setup>Communication Settings>ModBus Protocol*".

MODEM, this option displays the parameter to set in case of using a modem for the communication, such as Phone
number, Time out (sec), init. command, type of dialing (tones or pulses).

#### **COMMUNICATION CONTROL:**

The Communication Control subsection is located on the bottom left communication window and shows the communication status in the relay. There are two legends, "Status" in which the communication text status will be displayed and "Communication" which includes two buttons to start (ON) and stop (OFF) the communication with the relay.

Relay NOT communicating: In status, a message will be displayed with the communication status, e.g. 650 Setup is not talking to an F650. The ON button will be available to press and the OFF button will be disabled (in grey color). In this stage the relay is not communicating to the computer and the communication parameters can be modified to establish the communication lately by pressing in the ON communication button.

3-4

Relay communicating: In status, a message will be displayed with the communication status, e.g. 650 Setup is now talking to an F650. The ON button will be disabled (in grey color) and the OFF button will be available to press. In this stage the relay communicating to the computer and the communication parameters cannot be modified. In the example on Figure 3–2: COMMUNICATION PARAMETERS MENU, communication has not been established yet.

#### COMMUNICATION OPTIMIZATION:

The parameters shown on the bottom right window (Communication optimization) can improve communication, although it is recommended to leave the default values indicated by the EnerVista 650 Setup. These parameters are the maximum time to wait for a response in the relay (in ms) and the maximum attempts to perform before assuming communications failure.

The rest of options available in the Communication menu in EnerVista 650 Setup are:

- Modem: Allows configuring the unit for remote communications via modem, using telephonic line. It is only available if the relay is not communicating and if modem has been select on Communication>computer control type selection. Go to "Communication>Modem"
- Troubleshooting (Serial or Ethernet connection): Lets the user to perform reading or writing in ModBus addresses, for verifying communications and access to different positions in the ModBus memory map. Only available if the communication has already been established. Go to "Communication>Troubleshooting". An example is provided in Figure 3–3:

COMMUNICA	TION / TROUB	LESHOOTI	ING					
-MEMORY M	AP INSPECTION	I (READ DA	TA) ——					
Group Ad	dress	# of					Transmit	ок
Active (HE	Х) Туре	elem	Selecti	ion	Values		Total	
1 1	SP 🔻	1	HEX	-			0	CANCEL
<b>₽</b> 2 B0	00 SP 💌	13	CHAR	- "	F650MZDF2G1HI"		164	Print Screen
3 3	SP 🔻	3	INT	-			0	
<b>4</b>	SP 💌	4	UINT	•			0	
5 5	AV 🔻	5	LONG	•			0	
- MEMORY M/	AD INSERTION		τα) —					]
Group Ad	dress #of		,				Transmit	
Active (HE	X) elem	Selectio	n		Values		Total	
□ 1 <u>1</u>	1	WORD	<b>▼</b> a				0	
2 2	2	WORD	- b				0	
□ 3 <sub>3</sub>	3	WORD	• C			SENU	0	
□ 4   4	4	WORD	▼ d				0	
					CLEAR TRANS	міт тот	ALS	

#### Figure 3–3: COMMUNICATION TROUBLESHOOTING SCREEN

- Calibration (Serial or Ethernet connection): Allows retrieving the unit calibration settings and storing them in a file (with extension \*.cal). For reading or storing the calibration settings in the relay go to "Communications>Calibration>Get or Set calibration settings" and select the intended calibration file. The calibration retrieval process is necessary to be performed before updating the unit boot code, when the operating system is updated all the data in the relay is deleted, including the factory calibration settings. When only the firmware is updated (for versions higher than 1.50), the calibration settings are automatically saved in the relay.
- Upgrade firmware version (Ethernet connection): Go to "Communications>Upgrade firmware version", this menu allows the user to update the firmware version of the relay through Ethernet communication. Firmware is related to the relay internal program, designed by GE Multilin, which performs the protection and control functions, and which is run by the relay main microprocessor.
- Upgrade operating system (Serial and Ethernet connection): Go to "Communications>Upgrade operating system". This option allows the user to update the relay boot code. This is the program that supports the firmware and provides auxiliary services for access to electronic devices included in the relay.

#### **IMPORTANT NOTE:**

#### READ CAREFULLY THE FLASH MEMORY UPDATE PROCEDURE AND CLOSE ALL THE RUNNING APPLICATIONS BEFORE PERFORMING FIRMWARE AND boot code UPDATING PROCCESS

Before updating firmware check that the firmware version that is going to be updated match the boot code version of the relay. Otherwise it is necessary to update the boot code before proceeding to update the firmware. Other combinations of firmware and boot code different from the listed below will not be operative

The boot code version is available in the logotype main screen in HMI; it is the number between brackets in the first line, e.g. F6501.70 (2.35). The boot code version is 2.35

Firmware version up to 1.5X must be used with Boot Code 2.30 (or 2.20 and 2.35)

Firmware version from 1.6X up to 1.7X must be used with Boot Code 2.35

Thanks to the use of a double flash memory, one with the Bootcode startup program and the boot code, and a second one with the application program (firmware), a high reliability is guaranteed when updating the unit firmware, as even in the case of a communication breakdown during the firmware upgrade process, we can retry the process for an unlimited number of times.

- Upgrade 650 web server (Ethernet connection): Go to "Communications> Upgrade 650 web server". The relay web
  server application can be updated to further versions (if available) using this menu without modifying the relay boot
  code.
- Upload info files to relay (Ethernet connection): Go to "Communications>Upload info files to relay". This
  functionality is used to store setting files (\*.650) inside the relay, as well as auxiliary files used by the programmable
  logic graphical editor (\*.pep, \*.aut, \*.lib).
- Download info files from relay (Ethernet connection): Go to "Communications>Download info files from relay". This functionality is used for retrieving the files (\*.650 and \*.pep, \*.aut, \*.lib) that have been previously stored in the relay flash memory.

#### **IMPORTANT NOTE:**

\*.650 files contain protection, control settings, relay configuration and compiled logic equations. This file can be retrieved from the relay, using the *"File>Get info from relay"* option in EnerVista 650 Setup (through serial or Ethernet communication). *"File>Send info to relay"* option stores this \*.650 file in the relay.

\*.pep, \*.aut and lib files contain the logic configuration projects necessary to modify the logic (virtual outputs) in the relay. These files can be stored in the relay, using the *"Communication>Upload info files to relay"* option in EnerVista 650 Setup (through Ethernet communication). They can be retrieved using *"Communication>Download info files to relay"* option in EnerVista 650 Setup (through Ethernet communication). They can be retrieved using *"Communication>Download info files to relay"* option in EnerVista 650 Setup program (Ethernet communication). Take into account that the \*.pep, \*.aut and library files are necessary to modify the PLC logic (virtual outputs). Without these files setting and configuration can be modified but not logic equations (virtual outputs). It is advisable to use the *"Communication>Upload info files to relay"* option to store these logic configuration files into the relay.

It is important to distinguish between "Send / Get info to relay" and "Upload / Download info files to/from relay". "File>Send/Get info to relay" sends/gets settings and configuration and compiled logic equation to/from the relay (\*.650 format), and the relay automatically starts working with the new settings once they are stored. "Communications>Upload/Download info files to relay", stores/retrieves in the relay flash memory: settings, configuration and compiled logic equations (\*.650) besides the PLC files (\*.pep, \*.aut, \*.lib). This is only a physical storage (file backup).

**3.1.4 FILE MANAGEMENT** 

File management with EnerVista 650 Setup software:

#### 3.1.4.1 OFF LINE MODE WITHOUT CONNECTION TO THE RELAY



Figure 3-4: OFF-LINE MODE FILE MANAGEMENT

3

**NOTE 1**: Depending on the type of Inputs/Outputs incorporated in relay slots F and G, configuration options will be different. There are 2 template files available for working off-line with any F650 available model:

F650\_F1G0\_V200.650: Board 1 in slot F and without any board in slot G. F650\_F1G1\_V200.650: Board 1 in slot F and board 1 in slot G. F650\_F1G4\_V200.650: Board 1 in slot F and board 4 in slot G. F650\_F1G5\_V200.650: Board 1 in slot F and board 5 in slot G.

F650\_F2G0\_V200.650: Board 2 in slot F and without any board in slot G.

F650\_F2G1\_V200.650: Board 2 in slot F and board 1 in slot G.

F650\_F2G4\_V200.650: Board 2 in slot F and board 4 in slot G.

F650\_F2G5\_V200.650: Board 2 in slot F and board 5 in slot G.

FILE TYPE	SETTINGS & CONFIGU	JRATION FILE *.650	LOGIC CONFIGURATION FILES (*.PEP, *AUT, *.LIB)				
			*.PEP	*.AUT	*.LIB		
Relevant sections inside the file	Protection Settings and Configuration Section	Compiled logic equations section	Header for Logic project	Graphical edition container. Logic equations in FDB format.	User programmable logic objects		
Created by	EnerVista 650 Setup	Logic configuration graphic editor (PLC Editor)	Logic configuration graphic editor (PLC Editor)	Logic configuration graphic editor (PLC Editor)	Logic configuration graphic editor (PLC Editor)		
Definition and contents	Definition and Settings, input/output and LEDs configuration, graphic display configuration, etc.		PLC project file containing the necessary information relative to the relay model, logic libraries included in the project (*.lib), graphic file name (*.aut), etc.	PLC Project file containing all the drawings used by the logic, required by F650 relay based on IEC 61131-3 standard. Functional block diagram (FDB).	Library file to be included as an object in a PLC project. Logic packages that can be stored into libraries and be distributed in different PLC projects.		
File storage in the PC	EnerVista 650 Setup: " <i>File&gt;Save</i> *"	EnerVista 650 Setup: " <i>File&gt;Save</i> *" It is necessary to store the logic configuration files used to create the PLC project for further logic modifications.	PLC Editor: " <i>File&gt;Save</i> <i>Project</i> "	PLC Editor: " <i>File&gt;Save Project</i> "	PLC Editor: " <i>File&gt;Save Library</i> "		
File Retrieval of previously stored files in PC	EnerVista 650 Setup: " <i>File&gt;Open</i> *"	EnerVista 650 Setup: " <i>File&gt;Open</i> *" It is necessary to have the logic configuration files used to create the PLC project	PLC Editor: " <i>File&gt;Open</i> <i>Project</i> "	PLC Editor: " <i>File&gt;Open Project</i> "	PLC Editor: " <i>File&gt;Library&gt;New</i> <i>Library</i> "		
Basic information transfer mode to the relay	Connect with the relay ("Communications>Cc Open the created file (", Send to relay from the m Note that texts used in t outputs, etc. are not ser sent to relay are operati	<b>EXAMPLE File&gt;Open *</b> ") Thenu: <b>"File&gt;Send info to relay</b> " the configuration of inputs, to the relay. The only texts ons, events, and LEDs.	Connect with the Launch F650 PL Open the create Compile the proj Now the logic (v) (" <i>Run&gt;Send Eq</i> not stored in the edited.	e relay (" <b>Communication</b> C Editor (" <b>Setpoint&gt;Log</b> d PLC project (" <i>File&gt;Op</i> ject (" <i>Run&gt;Compile</i> ") irtual outputs) can be ser <i>tuations to Relay</i> "). Texts relay, only in the logic co	ns>Computer") ic Configuration") en Project") at directly to relay s of virtual outputs are onfiguration files to be		

# Table 3–1: TYPES OF FILES GENERATED BY ENERVISTA 650 SETUP SOFTWARE OPERATION MODE OFF-LINE:

3

#### 3.1 ENERVISTA 650 SETUP SOFTWARE INTERFACE

In case of using element libraries (either existing ("*File Library>Open Library*") or created by the user ("*File Library>New Library*")), the program will create and manage the corresponding files (\*.lib) in a folder named FDB (Functional Block Diagram). These files are used for the PLC project compilation. It is necessary to store them with the other logic configuration files that built the PLC project (\*.pep, \*.aut, \*.lib).

Besides sending basic information to the relay (Settings + configuration) in \*.650 format, it is recommended to store \*.650, \*.pep, \*.aut and \*.lib files inside the relay ("*Communication>Upload info files to relay*"), to ensure that logic configuration files will be available in the future for further logic modifications; either if these files are not used by the relay, they are required for connecting to a relay and analyzing its configuration. The program manages the logic configuration files globally, so that when the user selects to save file \*.pep in the relay, the associated \*.aut and \*.lib files are also stored.

File storage inside the relay (RECOMMENDED)	"Communication > Upload info files to relay" through Ethernet
Retrieval of files stored in the relay (RECOMMENDED)	"Communication > Download info files from relay" through Ethernet

# 3.1.4.2 ON LINE MODE CONNECTED TO THE RELAY



Figure 3–5: ON LINE MODE FILE MANAGEMENT

#### LOGIC CONFIGURATION FILES (\*.PEP, \*.AUT, \*.LIB) **FILE TYPE SETTINGS & CONFIGURATION FILE \*.650** \*.PEP \*.AUT \*.LIB Graphical edition Compiled logic equations Relevant container. Logic Protection Settings and User programmable Header for Logic section (relay configuration sections equations (Virtual Configuration Section project logic objects inside the file and logic configuration) Outputs) in FDB format Logic configuration Logic configuration Logic configuration graphic Logic configuration graphic editor (PLC Editor) graphic editor (PLC Editor) graphic editor (PLC Editor) EnerVista 650 Setup editor (PLC Editor) and relay Created by configuration screen PLC project file PLC Project file containing the Library file to be included as an object containing all the Relay configuration file necessary drawings used by containing all protection elements, settings, input/ in a PLC project. Logic packages that information relative the logic, required by F650 relay based on IEC Equations corresponding to to the relay model, Definition and the logic created and logic libraries can be stored into output and LEDs contents compiled in the PLC Editor configuration, graphic included in the libraries and be 61131-3 standard. project (\*.lib), graphic file name distributed in different display configuration, etc. Functional block PLC projects. diagram (FDB). (\*.aut), etc. Connect with the relay ("Communications>Computer") Connect with the relay ("Communications>Computer") Launch 650 PLC Editor ("Setpoint>Logic Configuration") Send settings and configuration from file: Open the created PLC project ("File>Open Project") Send configuration and logic compiled equation to relay Compile the project ("Run>Compile") "File>Send info to relay", Send protection and select \*.650 file, choose control settings to relay: "Relay and Logic Configuration" option in File>Send info to relay", select \*.650 file, screen and press send. choose Protection and When the message Control settings option in "Configuration stored" screen and press send appear in the relay HMI the configuration has been stored. Basic Modify settings and configuration directly in the relay: information Go to "**Settings>Relay** transfer mode Configuration> Now the logic (virtual outputs) can be sent directly to relay ("*Run>Send Equations to Relay*"). Texts of virtual outputs are to the relav >>Outputs >>LEDs not stored in the relay, only in the logic configuration files to be Go to "Setpoint> >>Product Setup >>Operations edited. >>Protection Elements >>Oscillography >>System Setup >>Protection Elements >>Operations >>Control Elements >>Control Events >>Inputs/Outputs" in >>Switchgear EnerVista 650 Setup and >>Inputs >>Virtual Inputs modify the selected settings and press store >>Operations >>MMI (HMI)" to send them to the relay. in EnerVista 650 Setup, modify the selected values and press store to send them to the relay. PLC Editor: EnerVista 650 Setup: 'File>Save Project' "File>Save Library" The relay provides this EnerVista 650 Setup: information in a basic format File>Get info from The relay will not The relay will not The relay will not (compiled equations). It is provide this provide this provide this relay". User definable File storage in necessary to have the logic information unless information unless information unless PC texts retrieved are configuration files used for the \*.pep file is the \*.pep file is stored the \*.pep file is operations, events, and creating the PLC project to stored in the relay stored in the relay. in the relay. LEDs. view the logic in a graphical way (FDB) and be able to To store the logic configuration files in the relay use the modify it (virtual outputs). 'Communication>Upload info files to relay' option File storage inside the relay in a flash memory (RECOMMENDED): "Communication>Upload info files to relay" through Ethernet Communication/Download info files from relay" through File Retrieval of relay hard disk stored files (RECOMMENDED): Ethernet

#### Table 3–2: TYPES OF FILES CREATED BY ENERVISTA 650 SETUP– ONLINE OPERATION MODE

#### **REMINDER**:

Logic programming support files (\*.pep, \*.aut, \*.lib) CANNOT be retrieved directly from the relay.

It is necessary

\* Either to have stored these files in the PC

\* Or to have uploaded previously the files into the relay ("Communication>Upload info files to relay")

#### 3.1.5 ENERVISTA 650 SETUP MENUS STRUCTURE

The EnerVista 650 Setup menus structure is shown in EnerVista 650 SETUP MENUS STRUCTURE.

#### Unless specified, options are available in both On-line and Off-line mode.

Options enabled only in On-line mode are marked as (\*)

Options enabled only in Off-line mode are marked as (\*\*)

The "*View > Language*" submenu allows the user to change the default language for the EnerVista 650 Setup program and it is only enabled when the relay is not communicating and no file has been opened.

#### Table 3–3: ENERVISTA 650 SETUP MENUS STRUCTURE

FILE	SETPOINT	ACTUAL	OPERATIONS (*)	COMMUNICATION	SECURITY	VIEW	HELP
Open (**)	Product Setup	Front Panel	NA	Computer	Login user	Traces	Instruction Manual
Save As (**)	System Setup	Status	NA	Modem (*)	Change Password	ModBus Memory Map	About EnerVista 650 Setup
Close (**)	Protection Elements	Metering	NA	Troubleshooting (*)	User Management	Languages (**)	
Config File Converter	Control Elements	Inputs/Outputs	NA	Calibration (*)			
Properties (**)	Inputs/Outputs	Records (*)	NA	Upgrade firmware version (*)			
Get info from relay (*)	Relay Configuration		NA	Upgrade operating system (*)			
Send info to relay (*)	Logic Configuration		NA	Upgrade F650 Web Server			
Print Setup (**)	Clock (*)		NA	Upload info files to relay			
Print Preview (**)			NA	Download info files from relay			
Print (**)			NA				
Print to file (**)			NA				
Exit			NA				

# 3.1.6 FILE MENU OVERVIEW

# Table 3–4: GENERAL OVERVIEW OF FILE MENU:

# FILE

Open (**)	Open a settings and configuration file for off-line working.
Save As (**)	Save *.650 settings and configuration file.
Close (**)	Close the opened *.650 file in EnerVista 650 Setup.
Config File (*.650) Converter	Tool to convert the *.650 files from one version to another
Properties (**)	File properties for *.650.
Get info from relay (*)	Retrieve the *.650 settings and relay configuration compiled equations from the relay.
Send info to relay (*)	Send and write the *.650 settings and configuration to the relay.
Print Setup (**)	To configure printer settings.
Print Preview (**)	Preview of settings and configuration file printing format.
Print (**)	Launch the *.650 file to be printed.
Print to file (*.xls) (**)	*.650 printed to file in excel format.
Exit	Quit the application closing all the open windows.

Options enabled only in On-line mode are marked as (\*). Options enabled only in Off-line mode are marked as (\*\*)

# 3.1.6.1 OPEN, SAVE AS AND CLOSE

In these options, the program opens a dialog box (with default path to Files>Config program folder) where the setting and configuration files can be selected for their "off-line" edition. For enabling access to this menu, there must be no communication between the PC program and the relay. (Mode off-line: "Communication>Computer>OFF").

Open		? ×
Look in:	🔁 Config 💽 🔸 🖻 📸	
History History Desktop My Documents My Computer	<ul> <li>▶ F650_F1G0_V170.650</li> <li>▶ F650_F1G1_V170.650</li> <li>▶ F650_F2G0_V170.650</li> <li>▶ F650_F2G1_V170.650</li> </ul>	
My Network P	File name:         F650_F2G0_V170.650         Image: Config Files (*.650)         Image: Config Files (*.6	Open Cancel

Figure 3–6: OPEN FILE MENU

Once the \*.650 file with the appropriated relay model (FXGX) is selected, the program will enable the off-line options to fully program the unit. The enabled menus in the EnerVista 650 Setup program are: File, Settings, Actual, Communication, View and Help.

The off-line mode displays the File, Settings, Actual, Communication, View and Help submenus to program the unit.

The Actual values submenus are for structure purposes only Values are not refreshed while the relay is not communicating.

The "Save as" and "Close" submenus are used to save the \*.650 file into the computer and to close the current file. To work in off line mode for settings and configuration edition it is not necessary to use the "Close" option, a new \*.650 can be opened without closing the previous one. The "Close file" option is used to clear all data in EnerVista 650 Setup program, enabling "Language", "Upload firmware" and "boot code" options.

# 3.1.6.2 CONFIG FILE (\*650) CONVERTER

source model	32			
Model	Version	Part		
F650***F2G1***	1.50	31.10.3.0		
Destination Model			<u>10 - 10</u>	
Model	Version	Part		
F650***F2G1***	1.60	15.3.4.0		
F650***F2G1***	1.50	31.10.3.0		
				Convert 🖸
				Cancel

# 3

Figure 3–7: CONFIG FILE (\*650) CONVERTER MENU

This tool provides automatic conversion of configuration files from a firmware version to a previous or later version.

Open the source \*.650 file and select the version and model to be converted to.

It is possible to change the model type (FXGX) using the conversion tool. It must be taken into account that part of the logic can be readjusted to fit the new input and output boards selection. Notice also that the external wiring of inputs and outputs board are different for type 1, 2, 4 and 5.

#### 3.1.6.3 PROPERTIES

When this option is selected, the program will show a screen including the relay model information, firmware version, etc. of the file being edited, as shown on Figure 3–8:

roperties	>
Part :	
15.3.4.0	
	_
	1
	Part : [15.3.4.0

Figure 3–8: FILE PROPERTIES MENU

#### 3.1.6.4 PRINTING OPTIONS (PRINT SETUP/PRINT PREVIEW/PRINT/PRINT TO FILE)

The printing options are active only in off-line mode, in "File edition", and not in on-line mode, connected with the relay.

# **3 HUMAN INTERFACES**

#### 3.1.6.5 PRINT SETUP

Option to configure the printing options and settings for the printing device.

#### 3.1.6.6 PRINT PREVIEW

Option to preview the whole settings and configuration file (\*.650) in paper format to be printed as shown in Figure 3–9:.

GE Power Management	F650 SETPOINT FILE INFORMATION	EnerVista F650 Set
File Harms: F650_F2G1_V162.658 Comment: Model: F658**F2G1** Venior: 1.82 Part: 2.46.4.0		
	SETPOINTS	
	SERIAL PORTS	
KANE COM1 Blaud Rate COM2 Blaud Rate Party	VALUE 19200 19300 NONE	UNIT
	NE TWORK (ETHE RHET) 1	
HAME IP Address Oct1 IP Address Oct2 IP Address Oct3 IP Address Oct3 IP Address Oct3 IM Admiss Oct3 Metmask Oct3 Metmask Oct3 Metmask Oct4 Oct9 Oct3 Oct4 Oct3 Oct4 Oct3 Oct4 Oct3 Oct4 Oct3 Oct4 Oct3 Oct4 Oct3 Oct4 Oct3 Oct4 Oct3 Oct4 Oct3 Oct4 Oct4 Oct3 Oct4 O	VALUE 0 (0): 265( 0 (0): 255( 0 (0): 255(	unit
	NE TWORK (E THE RHE T) 2	
HAME IP Address Oct1 IP Address Oct2 IP Address Oct3 IP Address Oct3 Netwark Oct3 Netwark Oct3 Netwark Oct3 Netwark Oct4	VALUE 010:255 010:255 010:255 010:255 010:255 010:255 010:255 010:255	uarr

Figure 3–9: PRINT PREVIEW OF SETTINGS FILE

# 3.1.6.7 PRINT

In this option, the program will print the relay configuration using the PC default (active) printer on port COMx or LPT. This option is active only in off-line mode, in file edition, and not in on-line mode, connected with the relay.

#### 3.1.6.8 PRINT TO FILE (\*XLS)

Possibility to export the configuration file to an Excel file using the "Print to file (\*.xls)" option.
#### 3.1.7 SETTINGS MENU OVERVIEW

#### Table 3–5: GENERAL OVERVIEW OF SETPOINT MENU IN ENERVISTA 650 SETUP:

SETPOINT

Product Setup	Communications settings for all protocols and physical mediums. ModBus user map definition, fault report, oscillography, data logger and demand settings.
System Setup	General Settings, Flex Curves Definition, Breaker settings and maintenance, and switchgear snapshot events management.
Protection Elements	Phase, Neutral, Ground, Sensitive Ground and Negative Sequence Current Settings. Voltage Elements settings and Power Settings management.
Control Elements	Setting groups, under and overfrequency settings, synchrocheck, autoreclose, breaker failure, VT fuse failure, broken conductor and locked rotor settings management.
Inputs/Outputs	Contact I/O settings for all boards available in device, Remote Comms.
Relay Configuration	Configuration of Outputs, LEDs, Operations, Protection Elements, Oscillography, Operations, Control Events, Switchgear, Inputs, Virtual Inputs, Operations and HMI. Whole relay configuration with internal relay signals or user-definable ones as logic (virtual outputs).
Logic Configuration	Logic configuration graphic editor (PLC Editor). It is a PLC Project file editor that contains all the internal drawings used to make the logic (virtual outputs) based on IEC 61131-3 standard. Functional block diagram (FDB).
Clock (*)	Relay synchronization to computer clock or to user-definable date and time. On-line mode only.

Options enabled only in On-line mode are marked as (\*). Options enabled only in Off-line mode are marked as (\*\*)

#### 3.1.7.1 PRODUCT SETUP

# Table 3–6: GENERAL OVERVIEW OF PRODUCT SETUP MENU:

PRODUCT SETUP

Communication Settings	Serial Ports, Network (Ethernet), ModBus Protocol, DNP Slave and IEC 870-5-104 settings.
ModBus User Map	ModBus user map definition. The ModBus user map is formed by 256 records, selectable from the complete relay ModBus map.
Fault Report	Fault report settings. Possibility to show fault reports on HMI screen.
Oscillography	Oscillography settings (trigger position, samples per cycle, etc). The trigger and digital channels (up to 16) must be configured in " <b>Settings&gt;Relay configuration</b> ".
Data Logger	Data logger configuration
Demand	Demand settings. The demand trigger and demand reset signals must be configured in " <b>Settings&gt;Relay configuration</b> "

# e) COMMUNICATION SETTINGS

This section details the settings related to communication parameters for the different protocols available in the F650.

#### Table 3–7: GENERAL OVERVIEW OF COMMUNICATION SETTINGS MENU:

COMMUNICATI ON SETTINGS		
	Serial Ports	Baud rate and parity for COM1 and COM2 serial communication ports.
	Network (Ethernet)	Ethernet communication parameters for COM3 (IP Address, Netmask, Gateway IP, etc.) NOTE: The ModBus Slave address used by Ethernet ports is the one set for COM2.EnerVista 650 Setup software allows programming two different Ethernet addresses, but the first IP has always to be set as the second IP Address is an Alias.
	ModBus Protocol	ModBus Slave Addresses for serial and Ethernet communication and the ModBus port number used for ModBus TCP/IP
	DNP3 Slave	Physical port, Slave Address for DNP, IP Addresses for Masters, TCP/ UDP Port, Unsolicited Response parameters, Analog scale factors and deadbands, message fragment size, Binary input block.
	IEC 870-5-104,	TCP Port, Common Addr of ASDU, Cyclic Meter Period and, Synchronization Event settings.
	SNTP (*)	Sinchronization over Ethernet settings
	L	

Options enabled only in On-line mode are marked as (\*). Options enabled only in Off-line mode are marked as (\*\*)

# 3.1.7.2 SYSTEM SETUP

This section shows the settings related to the system setup definition such as shown in the following table.

# Table 3–8: GENERAL OVERVIEW OF SYSTEM SETUP MENU:

SYSTEM SETUP		
	General Settings	This screen describes and enables the settings of the power system where the relay will operate. Some of these settings will be used only for metering values presentation purposes; however, some of them apply directly to the sampling and analog-digital conversion process (rated frequency setting). Therefore, these settings need to be adjusted so that they fit the system settings.
	Flex Curves	Flex Curves – Programmable user curves: The relay incorporates 4 user curves called Flex Curve A, B, C and D. The points for these curves are defined by the user in " <i>Settings-System Setup-Flex Curves-Edit Curve</i> " menu in EnerVista 650 Setup. User defined flex curves can be selected as an operation curve in all the time overcurrent functions in the relay.
	Breaker settings	Breaker settings, maintenance and switchgear selection of the device configured as breaker in the F650. The selected switchgear will be used in recloser, breaker failure and synchronism functions. The settings are Number of Switchgear, Maximum KI <sup>2</sup> t, KI <sup>2</sup> t Integ. Time, Maximum Openings, Max.Openings 1 hour.
	Breaker maintenance	These settings correspond to the initialization of (KI) <sup>2</sup> t counters, and the counting of number of openings and closings of the switchgear configured as breaker. These Counters allow the breaker Maintenance. They are used to cumulate the breaker ageing produced by a trip or a breaker opening. In order to incorporate the breaker historic, in case of existing breakers, the system allows assigning an initial value to accumulated amperes, and to the number of opening and closing operations.
	Switchgear	Configuration of snapshot events for each switchgear (enable or disable)

# 3.1.7.3 PROTECTION ELEMENTS

This option shows all the protection-grouped elements available in the relay as shown in Table 3–9:. Each of these groups includes the specific protection units of the same type. For example phase currents group includes TOC, IOC, directional units, etc. There are three groups available, so there are three protection units of each function that can work in grouped mode or ungrouped (altogether).

# Table 3–9: GENERAL OVERVIEW OF PROTECTION ELEMENTS MENU:

PROTECTION ELEMENTS		
	Phase Current	All overcurrent grouped functions for phase current.
	Neutral Current	All overcurrent grouped functions for neutral current. (Calculated from phases, not measured)
	Ground Current	All overcurrent grouped functions for ground current. (Measured from 4 <sup>th</sup> current input)
	Sensitive Ground Current	All overcurrent grouped functions for sensitive ground current. (Measured from 5 <sup>th</sup> current input)
	Negative Sequence Current	Negative sequence time overcurrent function
	Voltage Elements	All under and overvoltage grouped functions for phases, neutral, auxiliary voltage and negative sequence.
	Power	Forward and directional power grouped protection functions.

# Table 3–10: DIFFERENT PROTECTION ELEMENTS INCLUDED

PHASE CURRENT		
	Phase TOC High	Phase time overcurrent, high level (51PH)
	Phase TOC Low	Phase time overcurrent, low level (51PL)
	Phase IOC High	Phase instantaneous overcurrent, high level (50PH)
	Phase IOC Low	Phase instantaneous overcurrent, low level (50PL)
	Phase Directional	Phase directional unit (67P). Quadrature Voltage for polarization
	Thermal Model	Thermal model or Thermal image unit for phases (49)
NEUTRAL CURRENT		
	Neutral TOC	Neutral time overcurrent (51N)
	Neutral IOC	Neutral instantaneous overcurrent (50N)
	Neutral Directional	Neutral directional unit (67N). Voltage, current and dual polarization.
GROUND CURRENT		
	Ground TOC	Ground time overcurrent (51G)
	Ground IOC	Ground instantaneous overcurrent (50G)
	Ground Directional	Ground directional unit (67G). Voltage, current and dual polarization.
SENSITIVE GROUND CURRENT		
	Sensitive Ground TOC	Sensitive ground time overcurrent (51SG)
	Sensitive Ground IOC	Sensitive ground instantaneous overcurrent (50SG)
	Isolated Ground IOC	Isolated ground overcurrent (50IG)
	Sensitive Ground Directional	Sensitive ground directional unit (67SG)
NEGATIVE SEQUENCE CURRENT		
	Negative Sequence TOC	Negative sequence time overcurrent (46P)
VOLTAGE ELEMENTS		
	Phase UV	Phase undervoltage (27P)
	Phase OV	Phase overvoltage (59P)
	Neutral OV High	Neutral overvoltage, high level (59NH)
	Neutral OV Low	Neutral overvoltage, low level (59NL)
	Negative Sequence OV	Negative sequence overvoltage (47)
	Auxiliary OV	Auxiliary overvoltage (59X)
	Auxiliary UV	Auxiliary undervoltage (27X)
POWER		
	Forward Power	Forward power (32FP), in primary values.
	Directional Power	Directional power (32), in primary values.

# 3.1 ENERVISTA 650 SETUP SOFTWARE INTERFACE

# 3.1.7.4 CONTROL ELEMENTS

This option shows all the control elements available in the relay as shown in Table 3–11:. Some of the elements are grouped ones such as underfrequency, overfrequency and broken conductor.

# Table 3–11: GENERAL OVERVIEW OF CONTROL ELEMENTS MENU:

CONTROL ELEMENTS		
	Setting Group	F650 units incorporate a flexible grouping capability for protection units. This means that protection units can be used in either single setting group (default mode-all units can operate simultaneously) or three setting groups (in this mode, protection units are grouped in three independent tables, with only one of them active at a given time). Protection element grouping involves only Protection elements together with broken conductor detection and over and under frequency, which are usually considered as control elements. The rest of control elements such as recloser, fuse failure, breaker failure, synchronism, and breaker settings are not involved in the tabled groups concept.
	Underfrequency	Underfrequency unit (81U). Grouped element
	Overfrequency	Overfrequency unit (810). Grouped element
	Synchrocheck	Synchronism check unit (25). Not grouped, a single unit provided
	Autoreclose	Recloser (79). Not grouped, a single unit provided
	Breaker Failure	Breaker failure (50BF). Not grouped, a single unit provided
	VT Fuse Failure	Fuse Failure (VTFF). Not grouped, a single unit provided
	Broken Conductor	Broken or fallen conductor detection function (I2/I1). Grouped element. Ratio between the negative sequence current, I2, and the positive sequence current I1. In normal and balanced load situations, this ratio is zero, while in severe load fault conditions, an unbalance is produced and this ratio is increased.
	Locked Rotor	Locked rotor detection function (48). Grouped element.

# INPUTS/ OUTPUTS

**3 HUMAN INTERFACES** 

3.1.7.5 INPUT/OUTPUTS

Ŀ.		
	Contact I/O	Inputs and outputs settings for all boards in F650. The I/O settings configuration can only be performed through EnerVista 650 Setup, not HMI available.
	Force Outputs (*)	This menu allows activating each contact output in the relay, to facilitate maintenance testing. On line mode only.
	Virtual Inputs (*)	This menu allows operating virtual inputs. These variables are used as inputs to logic schemes configured in the relay. Virtual inputs can be operated in a latched mode (32 latched virtual inputs) or in Self-reset mode (32 self reset virtual inputs).
	Remote Comms.	This menu allows configuring remote inputs coming from other devices through GSSE messages.

Options enabled only in On-line mode are marked as (\*). Options enabled only in Off-line mode are marked as (\*\*)

This section shows the settings related to inputs and outputs for the different boards available in F650 (F, G, H, J).

Section that contains the settings for all input and output boards and the Force Outputs and Virtual inputs activation tools.

# Table 3–13: GENERAL OVERVIEW OF "INPUTS/OUTPUTS>CONTACT I/O" SETTINGS MENU.

Table 3–12: GENERAL OVERVIEW OF "INPUTS/OUTPUTS" SETTINGS MENU.

CONTACT I/O

_	Board F	Board located in first slot, always connected, either type 1 or 2.
	Board G	Board located in second slot, depends on model definition. If model is type G0 there is no board in second slot.
	Board H	Board located in first slot of CIO Module (external inputs/outputs module)
	Board J	Board located in second slot of CIO Module (external inputs/outputs module)

## 3.1.7.6 RELAY CONFIGURATION

This is the relay configuration section in which the relay can be configured using internal states or already compiled equation on PLC Editor.

# Table 3–14: GENERAL OVERVIEW OF RELAY CONFIGURATION MENU:

RELAY CONFIG		
	Outputs	Configuration of contact output operate and reset signals for all boards.
	LEDs	15 LEDs fully configurable from any logical variable, contact or virtual input. First 5 LEDs are latched by hardware, the rest are self-reset but can be latched through PLC configuration. From the LED configuration screen, it is possible to print the vertical LED label for the relay
	Operations	Configurable operations up to 24. Operation texts, interlocks, final states, frontal keys, time outs and masters.
	Protection Elements	This tab allows assigning operands (logic signals) as inputs to different protection elements. To block, reset, initiate the different protection elements inputs.
	Oscillography	Trigger and up to 16 digital channels to be included in oscillography records, are programmable from any logical variable, contact or virtual input. Text configuration is only for off-line mode. <b>NOTE:</b> This screen is used for the configuration of digital channels and oscillography trigger. The rest of parameters, such as function enabling/ disabling, sampling rate, number of oscillography files, etc. must be set on the <b>Settings&gt;Product Setup&gt;Oscillography</b> menu.
	Control Events	Up to 128 user programmable events from any logical variable, contact or virtual input. Possibility to display the event as an alarm on the alarms panel. Control events are also displayed in the snapshot events recording. 1 ms time tagging. A control event is a logic signal associated to an operand or combination of operands, that allows following the status of that signal.
	Switchgear	Up to 16 configurable switchgear elements. A switchgear element can be a breaker, a line selector switch, a grounding selector switch, a busbar selector switch, etc. This screen allows configuration of type of contacts, opening and closing time, contact assignation and text for events related to switchgear. There are 64 pre-established events for switchgear, which correspond to opening, closing, Error01 and Error11 of the 16 programmable switchgear elements.
	Remote outputs	Up to 32 DNA bits and 6?????? bits to be transmitted to remote devices over CAN using GSSE messages
	Inputs	Text configuration for off-line mode file management for all the contact inputs available in device.
	Virtual Inputs	Text configuration for off-line mode file management. 32 latched and 32 self reset virtual inputs.
	MMI (HMI-Human Machine Interface)	Screen for one line diagram configuration. This menu shows a scenario to draw a simplified one-line diagram of a bay in a feeder, line, transformer, etc. The menu includes a library for power elements, metering elements, text and drawings. See an example in Figure 3–11:

The following figures show an example of the default factory configuration for F650.

lay configuration							
outs Leds Operations Protection elem	ents Oscillography Control	Events   Switchgear   Inputs   Virtual In	nputs   M	м			
							nr
SELECT	NAME	SOURCE		OR	NOT		
Contact Output Operate 01(Board F)	CONT OP OPER_F_01	AR BLOCK BY LEVEL	-				ncel
Contact Output Operate 02(Board F)	CONT OP OPER_F_02	Press for logic		×			
Contact Output Operate 03(Board F)	CONT OP OPER_F_03	VO_048_50G_PKP	-			🛛 🗌 🔚 S	tore
Contact Output Operate 04(Board F)	CONT OP OPER_F_04	VO_049_51G_PKP	-			1.000	
Contact Output Operate 05(Board F)	CONT OP OPER_F_05	Press for logic		×		🔤 🔤 🔊 Prir	nt scre
Contact Output Operate 06(Board F)	CONT OP OPER_F_06	VO_053_51P_PKP	•				
Contact Output Operate 07(Board F)	CONT OP OPER_F_07	Press for logic		V			
Contact Output Operate 08(Board F)	CONT OP OPER_F_08	Press for logic		V			
Contact Output Operate 01(Board G)	CONT OP OPER_G_01	VO_082_ALL_FREQUENCY_TRIP	-				
Contact Output Operate 02(Board G)	CONT OP OPER_G_02	VO_079_ALL_VOLTAGE_TRIP	-				
Contact Output Operate 03(Board G)	CONT OP OPER_G_03	VO_068_50G_TRIP	-				
Contact Output Operate 04(Board G)	CONT OP OPER_G_04	VO_067_51G_TRIP	-				C
Contact Output Operate 05(Board G)	CONT OP OPER_G_05	Press for logic		V		Used Rei	ay con
Contact Output Operate 06(Board G)	CONT OP OPER_G_06	VO_057_51P_TRIP	-			4	7%
Contact Output Operate 07(Board G)	CONT OP OPER_G_07	AR RCL IN PROGRESS	-			Used PL	`equat
Contact Output Operate 08(Board G)	CONT OP OPER_G_08	AR LOCKOUT	-				s equai
Contact Output Operate 01(Board H)	CONT OP OPER_H_01	None	-				2%
Contact Output Operate 02(Board H)	CONT OP OPER_H_02	None	•			Used Me	mory:
Contact Output Operate 03(Board H)	CONT OP OPER_H_03	None	•				12/
Contact Output Operate 04(Board H)	CONT OP OPER_H_04	None	•				4/3
Contact Output Operate 05(Board H)	CONT OP OPER_H_05	None	-				
Contact Output Operate 06(Board H)	CONT OP OPER_H_06	None	•	-			
Contact Output Operate 07(Board H)	CONT OP OPER_H_07	None	•				
Contact Output Operate 08(Board H)	CONT OP OPER_H_08	None	•				
Contact Output Operate 09(Board H)	CONT OP OPER H 09	None	-			<b>▼</b>	





Figure 3–11: HMI CONFIGURATION

# 3.1.7.7 LOGIC CONFIGURATION

This logic configuration allows creating more complex configurations, using the graphical PLC, than using the tables from Relay Configuration. For file management detailed information go to section 3.1.4.

#### Table 3–15: GENERAL OVERVIEW OF LOGIC CONFIGURATION MENU:

LOGIC CONFIG

*.pep	Header for Logic project: PLC project file containing the necessary information relative to the relay model, logic libraries included in the project (*.lib), graphic file name (*.aut), etc.
*.aut	PLC Project file containing all the drawings used by the logic, required by F650 relay based on IEC 61131-3 standard. Functional block diagram (FDB).
*.lib	User programmable logic objects: Library file to be included as an object in a PLC project. Logic packages that can be stored into libraries and be distributed in different PLC projects.

# 3.1.7.8 CLOCK

This menu allows to update the date and time of the relay, either synchronizing them with the PC clock, or entering the information manually.

	Month Day Year OK
Relay Date	Print Scre
Computer Date	11 / 02 / 2004
	Hour Minute Second
Relay Time	
Computer Time	10 : 39 : 43
Note: Relay's cloc of the buttons belo	k can only be changed by clicking on one w:

# 3.1.8 ACTUAL VALUES MENU OVERVIEW

The menu bar in the main screen of EnerVista 650 Setup software shows the ACTUAL menu option. This option concentrates and displays all the status of protection, control elements, metering, counters information, oscillography, events, fault locator, etc. This section shows only the structure of menus in EnerVista 650 Setup.

## Table 3–16: GENERAL OVERVIEW OF ACTUAL VALUES MAIN MENU:

ACTUAL	ACT	UAL	
--------	-----	-----	--

Front Panel>LEDs	The relay front LEDs status is shown on this menu.
Status	Protection and control status signals for all available protection functions in device.
Metering	All metering values available in device. Primary and secondary values, frequency and phasor diagram provided.
Inputs/Outputs	All input and output status provided. For contact inputs and contact outputs as well as virtual input and virtual output signals.
Records	Only enabled in on line mode, retrieval of all the available records in device. Snapshot events, control events, oscillography and fault reports.

# 3.1.8.1 FRONT PANEL

The front panel menu shows only the LEDs submenu where all the front LEDs can be monitored.

# 3.1.8.2 STATUS

The following menu includes all the available protection status in the device.

3

# Table 3–17: GENERAL OVERVIEW OF STATUS MENU:

STATUS

Operation bits	Up to 24 elements. OPERATION BIT XX is (0) when the configured time out for the operation XX expires or when success conditions are met. And it is (1) if operation XX is executed and interlocks are fulfilled.
Breaker	Breaker status (open, closed or undefined). The rest of the status signals corresponding to the switchgear XX configured as breaker are in the " <i>Status&gt;Switchgear Status&gt;Switchgear XX</i> " menu.
Protection	Status of all the protection units in the device.
Control Elements	Status of all the control units available in the device.
Protection Summary	This screen shows a complete list of all protection and control elements in the relay, showing their status (enabled or not).
Snapshots events summary	Summary of the snapshot events status (enabled or disabled) for protection, control, inputs and outputs boards and switchgear.
ModBus User Map	Up to 256 elements. Value in SIGNED INT 16 BIT format of the reading for the selected address configured in " <i>Settings&gt;Product</i> <i>Setup&gt;ModBus User Map</i> "
Switchgear Status	Up to 16 blocks of switchgear status signals for the 16 configurable devices. Status signals such as inputs for A and B contacts, status for A and B, open and close status, error 00 and error 11, open init and close init, fail to open and fail to close signals.
Calibration	Internal states for calibration. Factory calibration and calibration error signals.
Flex Curves	Flex curve status for A, B, C and D user curves. (0) if it is not configured, (1) if it is configured. To configure a flex curve go to " <i>Settings&gt;System Setup&gt;Flex Curves</i> " menu.
System Info	This screen can monitor the system parameters and the internal status of the Relay boot code. Not enabled by default, password required
Records Status	Information related to the different records stored in the Relay, such as: Fault reports, control events, oscillography, data logger, demand, energy, and breaker maintenance.
SNTP-IRIG-B	Information related to synchronization via IRIG_B or SNTP

# Table 3–18: DIFFERENT CONTROL ACTUAL VALUES INCLUDED IN THE CONTROL ELEMENTS MENU

CONTROL		
	Frequency	Status signals (pickups and operations) for under and overfrequency units.
	Synchrocheck	Status signals for synchrocheck function (25).
	Autoreclose	Status signals for autoreclose function (79). Close signal, recloser status (ready, lockout, etc), block signals after each shot.
	Breaker Failure	Status signals for breaker failure function (50BF).
	VT Fuse Failure	Fuse failure detection signal.
	Broken Conductor	Status signals (pickups and operations) for broken conductor (I2/I1).
	Setting Groups	Status signals (activations and blocks) for the relay setting group change. By default the "setting group" setting is disabled and all the grouped elements can be enabled at the same time.
	Locked Rotor	Status signals (pickups and operations) for locked rotor units.

# Table 3–19: DIFFERENT PROTECTION ACTUAL VALUES INCLUDED IN THE PROTECTION MENU

# PROTECTION

Protection Blocks	This screen shows all the protection element blocks available. Protection elements block signals can be configured at " <i>Settings&gt;Relay Configuration &gt; Protection Elements</i> ".
Phase Current	Protection status signals (pickups and operations) for time overcurrent, instantaneous overcurrent and directional protection functions for phase current.
Neutral Current	Protection status signals (pickups and operations) for time overcurrent, instantaneous overcurrent and directional protection functions for neutral current (calculated from phases).
Ground Current	Protection status signals (pickups and operations) for time overcurrent, instantaneous overcurrent and directional protection functions for ground current (measured from 4 <sup>th</sup> current input).
Sensitive Ground Current	Protection status signals (pickups and operations) for time overcurrent, instantaneous overcurrent, isolated and directional protection functions for ground current (measured from 4 <sup>th</sup> current input).
Negative Sequence Current	Protection status signals (pickups and operations) for negative sequence time overcurrent function.
Thermal Model	Protection status signals for thermal model. Reset, alarm and operation signals for phases and for unit, besides the thermal image values in percentage for all phases and units.
Voltage	Protection status signals (pickups and operations) for all voltage functions, undervoltage, overvoltage, neutral overvoltage, negative sequence overvoltage and auxiliary under and over voltage.
Power	Protection status signals (pickups and operations) for forward and directional power units.

# Table 3–20: SHOWS THE ACTUAL VALUES RELATED TO RECORDING FUNCTIONS IN THE RECORDS STATUS MENU:

RECORD STATUS		
	Fault Reports	This menu shows the fault report status signals, as fault report trigger, fault date, fault type and location, besides the fault report number.
	Control Events	Status of the control events (if the signal configured to launch the control event is active or not).
	Oscillography	Status of signals related to oscillography recording, such as status or digital channels, oscillography trigger, number of records available, etc.
	Data Logger	Data logger information about oldest and newest sample time stamp, and number of channels and days configured in data logger settings.
	Demand	Demand trigger and reset inputs status.
	Energy	Freeze, unfreeze and reset input signals for energy counters.
	Breaker Maintenance	All signals related to breaker maintenance, such as number of openings, closings, (KI) <sup>2</sup> t counters, alarm signal for (KI) <sup>2</sup> t, etc.

# 3.1 ENERVISTA 650 SETUP SOFTWARE INTERFACE

# 3.1.8.3 METERING

The Metering menu includes all the measurements available in the device. Primary and secondary values, and also the data related to the recording functions in the relay.

#### Table 3–21: GENERAL OVERVIEW OF METERING MENU:

 Primary Values
 Primary values measurements for currents, voltages, power, energy and demand

 Secondary Values
 Secondary values measurements for currents, voltages and power.

 Phasor Diagram
 Current, voltage and sequence components.

 Frequency
 Line and Bus frequencies.

## 3.1.8.4 INPUTS/OUTPUTS

INPUTS/

OUTPUTS

METERING

The Inputs/Outputs menu includes all the inputs and outputs signals available in the device. Contact and virtual type.

# Table 3–22: GENERAL OVERVIEW OF INPUTS/OUTPUTS MENU:

3

1	
Contact Inputs	Status of digital inputs in the Relay for each board according to the relay model.
Contact Output Status	Status of digital outputs in the Relay for each board according to the relay model.
Contact Outputs Operates	Status (activated or not) of the variables used to operate a contact output. To configure these signals go to "Settings>Relay Configuration>Outputs" menu.
Contact Outputs Resets	Status (activated or not) of the variables used to reset a contact output. To configure these signals go to "Settings>Relay Configuration>Outputs" menu. This output reset Command will only be effective if the " <i>latch</i> " option has been Selected for the " <i>Output Type</i> " setting on the I/O board, thus when the contact output has been configured to emulate function 86 (latching relay).
IO Board Status	Status of I/O boards. This status provides if the hardware it is OK (boards matching relay model, correctly inserted in their tracks, in good state and communicating through the internal CAN Bus).
Virtual Inputs	Status of Virtual inputs latched (32) and self-reset (32).
Virtual Outputs	Status of virtual outputs (configured in PLC Editor). Up to 512.
Remote Outputs	States of remote outputs
Remote Inputs	Status of remote device and remote inputs
Analog Inputs (*)	Measurements coming from analog inputs (DCMA)

Options enabled only in On-line mode are marked as (\*). Options enabled only in Off-line mode are marked as (\*\*)

# 3.1.8.5 RECORDS

The Records menu is only available in on line mode and includes the possibility to retrieve all the records available in the device. By serial or Ethernet.

# Table 3–23: GENERAL OVERVIEW OF RECORDS MENU:

RECORDS (*)		
	Event recorder (*)	Retrieval and visualization of snapshot event (all and new), control events and alarm panel. By serial or Ethernet (ModBus RTU or TCP/IP)
	Waveform capture (*)	Retrieval of oscillography files, by serial or Ethernet.
	Fault Report (*)	Retrieval and visualization of fault report files, by serial or Ethernet.
	Data logger (*)	Retrieval and visualization of data logger files. Only by Ethernet.

## 3.1.9 OPERATIONS MENU OVERVIEW

Option only available in on line mode, showing all the operations previously configured in the relay with their corresponding texts.

#### Table 3–24: GENERAL OVERVIEW OF OPERATIONS MENU:



Options enabled only in On-line mode are marked as (\*). Options enabled only in Off-line mode are marked as (\*\*)

#### 3.1.10 COMMUNICATION MENU OVERVIEW

The communication menu includes the computer screen to start communicating with the relay, the different update procedures available in device: firmware, boot code, web server and other file storing capabilities (upload and download info files to/from relay).

For more detail information go to section starting communication for communication menus description and refer to the flash memory update procedures.

#### Table 3–25: GENERAL OVERVIEW OF COMMUNICATION MENU:

#### COMMUNICATION

Computer	Menu to start communication with the relay.
Modem (**)	Menu to set modem communication parameters (only available if control type is set to modem in computer menu).
Troubleshooting (*)	Menu that Lets the user to perform reading or writing in ModBus addresses, for verifying communications and access to different positions in the ModBus memory map.
Calibration (*)	Retrieval and store calibration settings from/to relay.
Upgrade firmware version (**)	Menu to update the relay firmware version through Ethernet
Upgrade boot code (**)	Menu to update the relay boot code (front RS323 and Ethernet connection)
Upgrade F650 web server	Menu to update the web server application (if available)
Upload info files to relay	Hard disk storage of settings and configuration files on the relay.
Download info files from relay	Retrieval of settings and configuration files that had been previously stored in the relay hard disk.

#### 3.1.11 SECURITY MENU OVERVIEW

The security menu includes all the menus related to security control in EnerVista 650 Setup. EnerVista 650 Setup security users and passwords are not related to passwords in HMI. Each security level has its own access for HMI management and EnerVista 650 Setup management.

# Table 3–26: GENERAL OVERVIEW OF SECURITY MENU:



Options enabled only in On-line mode are marked as (\*). Options enabled only in Off-line mode are marked as (\*\*)

#### 3.1.12 VIEW MENU OVERVIEW

The view menu includes the computer screen to start communicating with the relay, the different update procedures available in device: firmware, boot code, web server and other file storing capabilities (upload and download info files to/ from relay).

The ModBus memory map is detailed in the complete instruction manual (English only) and can be obtained from EnerVista 650 Setup program.

# Table 3–27: GENERAL OVERVIEW OF VIEW MENU:



HELP

Traces (*)
ModBus Memory map
Languages (**)

To inspect ModBus communication traces between the EnerVista 650 Setup and the relay. Complete ModBus memory map description. Option to change the EnerVista 650 Setup default language. Only available if the relay is not communicating and no file (\*650) is open.

Options enabled only in On-line mode are marked as (\*). Options enabled only in Off-line mode are marked as (\*\*)

#### 3.1.13 HELP MENU OVERVIEW

Complete instructions manual and data about EnerVista 650 Setup release.

#### Table 3–28: GENERAL OVERVIEW OF HELP MENU:

Instructions Manual
About EnerVista 650 Setup

Instructions manual in the language selected in "View>Languages" menu.

Release version and date of EnerVista 650 Setup program.

3

The HMI interface consists of several functional panels. The faceplate can be unscrewed to allow easy access to the removable modules. There is also a removable dust cover that fits over the display and other cover that protects the front RS232 Communications port and the commands buttons that can be sealed. The following figure shows the HMI in F650.



Figure 3–13: HMI INTERFACE

3.2.1 DISPLAY

F650 units are available with two different options for the front display. The first option is an alphanumerical display of 4 lines with 20 characters each, and the second option is a graphical display of 16 lines with 40 characters each (128x240 pixels), being B the ordering code option for the text display model (basic), and M the code for the mimic display (graphical).

The boot code and firmware versions can be seen in the relay text main screen, this screen is the default screen in the text menu for all models: After the text "F650", appears the relay firmware version (2.00 in the example), and between brackets the boot program version (3.0 in the example), followed by "General Electric", the relay model and the default front RS232 port (COM2) communication parameters.



Figure 3–14: TEXT MAIN SCREEN

#### **3.2.2 FRONT LED INDICATORS**

The relay provides 16 LED indicators, 15 user programmable plus one non-configurable LED (READY) that shows if the relay is in service.

Programmable LEDs are divided into groups of 5 LEDs, each of the groups having a different color. The first group of LED indicators is latched by hardware (red color ones), usually configured for trip signals. The second group (yellow color) and third group (green color) of LED indicators are self-reset type and will be reset once the condition has been cleared, but can be latched using logic through PLC configuration.

The ESC key is used to reset any latched led indicator, once the condition has been cleared. Keep the ESC button pressed for more than 3 seconds; all LEDs will light up, verifying their correct operation. When releasing the ESC key, all indicators programmed with memory, such as tripping LEDs, will be reset.

The latched conditions can also be reset via communications using the LED reset input (to configure this signal go to "Settings>Relay Configuration>Protection elements>LED RESET INPUT"). By default this LED reset input signal is set to LEDS RESET operation.

#### 3.2.3 PUSHBUTTONS

#### The front panel provides:

Push buttons: keypad (5 user programmable plus ESC non configurable), shuttle key or shuttle key for easy navigation, command pushbutton to select operations mode.

RS232 port: intended for connection to a portable PC.

# 3.2.3.1 KEYPAD AND SHUTTLE KEY

This button can be used for closing the user programmable switchgear. It is fully programmable by the user. This button can be used for closing the user programmable switchgear. It is fully programmable by the user. User programmable User programmable User programmable (ESC) Escape key. When pressed during more than 3 seconds, it will test all LEDs and reset the trip LEDs. shuttle key or Shuttle Key (it can be both rotated and pressed): Used for selecting menus, submenus, settings and for confirmation. Press or rotate the shuttle key to enter the text main menu from the text standby screen.

Figure 3–15: KEYPAD AND SHUTTLE KEY DESCRIPTION

3

# 3.2.3.2 COMMAND PUSH BUTTON

The unit incorporates a command pushbutton located at the bottom right side of the faceplate, with three options: local, remote, and off. The first option (LOCAL) allows executing operations in local mode (HMI, front RS232 port, and rear COM2 port). The second option (REMOTE) allows operation execution only through remote communications (COM1 and COM3 - Ethernet). The third option (OFF) blocks the execution of operations. Each position is identified with an LED indicator, as follows:

LOCAL operations (green) REMOTE operations (green) OFF (red )

Press the command button to switch from local to remote operations mode and vice versa. OFF status (operation inhibited for maintenance and safety) can be reach pressing the commands pushbutton during several seconds (local-remote-off sequence).

#### 3.2.4 FRONT PORT AND COVER SEALING SYSTEM

Figure 3–16: shows the detail of the front RS232 communication port and local/remote button access cover sealing system. The sealing system is similar to the one used in energy meters, using wire and plumb seal.

High quality plastic have been used in the design to withstand extreme environmental conditions, both mechanical and electrical, sun radiation, humidity, etc. in order to guarantee a long life for the unit.



Figure 3–16: DETAIL OF FRONT PORT AND COVER SEALING SYSTEM

# 3.2.5.1 NAVIGATION IN TEXT MENU

Text menu is available for all models, this is the main menu for visualizing actual values, metering, changing settings, etc. through the HMI. In models with graphical display (M in ordering code) besides this text main menu there are several screens providing more performance for control purposes.

Press (or rotate left or right) the shuttle key to enter the main menu, starting from the standby screen (default main screen). The default main screen can be accessed pressing ESC key till it appears. In all the navigation Press the shuttle key to select the desired header display (top-level menu). Each press of the shuttle key advances through the main heading pages as illustrated below. To return to previous menus press the ESC key. To move inside the top-level menu without changing to other low levels, rotate the shuttle key left to move up and right to move down.

When rotating the shuttle key the selected menu is marked by a single scroll bar character. The mark (>) in the right part of any menu means that contains more than one level.

Symbol	Action performed	Navigation in menu
⇒	Press Shuttle Key	Enter next level
⇐	Press Esc Key	Exit to previous level
L–R	Rotate Shuttle Key	move up and down in the same level
L	Rotate Left Shuttle Key	move up in the same level
R	Rotate Right Shuttle Key	move down in the same level
	Menu selection	Menu selection
>	More menus to display	More menus to display

Figure 3–17: shows an example of main menu navigation:



Figure 3–17: NAVIGATION IN MAIN TEXT MENU

# 3.2.5.2 TEXT MENU HIERARCHY

The structure of HMI text menu is similar to the EnerVista 650 Setup in the actual values and settings (view and change) menus.

The main menu shows the following options:

# Table 3–29: GENERAL OVERVIEW OF MAIN TEXT MENU:

NAME	DESCRIPTION	NAVIGATION IN MENU
Actual Values	Actual values of all the signals available in device. Status of protection and control elements, measurements, inputs and outputs, etc.	Press shuttle key to enter next level. Press ESC to return to default main screen.
Snapshot events	Visualization of all snapshot events in text mode (two screens for each snapshot event). In graphical displays there can be seen in a dedicated screen.	Press shuttle key to visualize snapshot events in text menu. Press ESC to return to default main screen.
Fault Report	Fault reports information available in HMI (two screens for each fault report)	Press shuttle key to enter next level. Move L-R to see all the available fault reports in device. Press shuttle key to enter particular information for fault report selected.
View Settings	Visualization of all protection and control settings available in device.	Press shuttle key to enter next level. Move L-R to select submenu. Press ESC to return to previous level.
Change Settings	Menu that allows changing all protection and control settings available in device. Inputs and outputs settings, relay configuration and logic configuration are not available in HMI, only via EnerVista 650 Setup software.	Press shuttle key to enter next level. Move L-R to select submenu. Press esc to return to previous level.
Date & Time	Date and time visualization and modification by user	First mode is visualization. Press again shuttle key to start modification in date and time. Press ESC to return to previous level.
Commands	Operations execution in local mode.	Move L-R to pre select operation. Press shuttle key to select and confirm. Press ESC to return to previous level.
Password	Password menu for settings and commands	Move L-R to select submenu. Press shuttle key to enter next level. Press ESC to return to previous level.
Select Main Screen	Selection of default main screen in text menu.	Move L-R to select the default main screen type. Press shuttle key to confirm.
Select Language	Language selection. Between default language (see ordering code) and English.	Move L-R to select the default language. Press shuttle key to confirm selection. Switch the relay off and on.
< - return	Return to previous level	Press shuttle key to return to previous level.

# a) ACTUAL VALUES

The Actual Values menu option in HMI concentrates and displays all the status of protection, control elements, metering, counters information, oscillography, events, fault locator, etc.

# Table 3–30: GENERAL OVERVIEW OF ACTUAL VALUES MAIN MENU:

Front Panel	>		
		LEDs	
Status	>		
		Operation Bits	
		Breaker	
		Protection >	
			Protection Blocks
			Phase Current
			Neutral Current
			Ground Current
			Sens. Ground Current
			Neg. Seq. Current
			Thermal Model
			Voltage
			Power
		Control Elements >	
			Frequency
			Synchrocheck
			Autoreclose
			Breaker Failure
			VT Fuse Failure
			Broken Conductor
			Setting Groups
			Locked Rotor
		Switchgear Status >	
			Switchgear 1
			Switchgear
			Switchgear 16
		Calibration	
		Flex Curves	
		System Info	
		SNTP/IRIG_B	
		Records Status >	
			Fault Reports
			Control Events
			Oscillography
			Data logger
			Demand
			Energy
			Breaker Maintenan.
Metering	>		
		Primary Values >	
			Current
			Voltage
			Power
			Energy
			Demand
		Secondary Values >	
			Current

	Voltage
	Power
Phasor Diagram	
Frequency	
Contact Inputs >	
	Board F/ Board G/ Board H/ Board J
Cont. Output St. >	
	Board F/ Board G/ Board H/ Board J
Cont. Output Op. >	
	Board F/ Board G/ Board H/ Board J
Cont. Output Rs. >	
	Board F/ Board G/ Board H/ Board J
IO Board Status	
Virtual Inputs >	
	Virtual Inp.Latched
	Virtual Inp.SR
Virtual Outputs	
Remote Outputs >	
	DNA
	User St
Remote Inputs >	
	Remote Input
	Remote Devices
Analog Inputs >	
	Board F/ Board G/ Board H/ Board J
	Phasor Diagram Frequency Contact Inputs > Cont. Output St. > Cont. Output St. > Cont. Output Op. > Cont. Output Rs. > Cont. Output Rs. > Cont. Output Rs. > Cont. Output Rs. > Cont. Output Status Virtual Inputs > Cont. Outputs Remote Outputs > Cont. Remote Inputs > Cont. Analog Inputs > Cont. Analog Inputs > Cont. Provide Analog Inputs Provi

To enter this menu press the shuttle key when the option Actual Values is selected in main menu. A secondary level will be displayed with different sublevels as shown on Table 3–30:. Rotating the shuttle key, (left for moving up and right for moving down) select the next level to be displayed, press the shuttle key again to enter in next level and press ESC key to return to previous level if desired. This navigation will be performed the same for all the menus in Actual Values. Once the last sublevel is reached, move up and down to visualize the actual values selected.

One example of data screen for actual values is shown in Figure 3–18:.

First Line: Header of last level in actual values (Phase Current in the example)

Second Line: Data identifier (in the example PH IOC1 HIGH A, is the pickup signal for the first instantaneous overcurrent function level high for phase A).

Third line: Status of the displayed actual value.

Fourth Line: Relative position in the menu (it is the first value of 114)

Phase Current
PH IOC1 HIGH A PKP
OFF
(1/114)

# Figure 3–18: ACTUAL VALUES SCREEN DATA

In the Actual Values menus are different types of data, each type of data will display its particular status type (on and off, 0 or 1, ok or fail, analog values, etc.)

# 3.2.5.3 SNAPSHOT EVENTS

To enter this menu press the shuttle key when the option Snapshot events is selected in main menu (). In this menu all the snapshot events stored can be displayed.

Snapshot events are changes in the relay internal status.

One snapshot event is displayed in two text screens:

The first screen display the status, date and time of the snapshot event: the snapshot event identifier, its status, event number and the date and time of the occurrence. If the snapshot event identifier does not fit the first line, the whole text will be shown using as well the second line alternating with the status and event number.

The second screen displays currents and voltages in primary values for that particular snapshot event. Ia, Ib, Ic and Ig for currents and Vab, Vbc, Vca and V0 for voltages. To access the metering screen in snapshot events menu, press shuttle key from the snapshot event first screen. To exit from the metering screen pres ESC.

To select different snapshot events to be displayed, rotate the shuttle key to select the snapshot event and then press the shuttle key to enter the metering screen. Press esc to exit the metering screen and return to snapshot events menu.

Figure 3–19: shows an example of snapshot events navigation:



# Figure 3–19: SNAPSHOT EVENTS NAVIGATION IN HMI

#### 3.2.5.4 FAULT REPORT

To enter this menu press the shuttle key when the option Fault report is selected in main menu (). This menu displays information about the last ten faults recorded in the relay.

The Relay HMI allows two types of visualization for the fault reports stored in the Relay:

1. Showing the fault warning messages in the text display when the fault is produced. This option has to be enabled by setting. To change from the HMI go to the menu "*Change Settings >Product Setup > Fault Report > Show Fault On HMI*" and enable it.

2. Only saving and allowing viewing the information from the last ten faults recorded in the relay.

In the first option, when a fault occurs a warning message is displayed, including information about the fault in two screens, one with general fault information, and a second one with the measured values in the moment of the fault.

The fault-warning message must be acknowledged by the user; this means that the user must press the shuttle key for this screen to disappear, The HMI will not allow to perform any other operation until the screen is acknowledged. In the event of several consecutive faults, the HMI will always show the most recent fault, and the user will need to acknowledge all of them, up to a maximum of ten faults.

In the second option, viewing the fault reports in the menu available in the HMI, the Fault Report menu in the main text screen must be accessed by pressing the shuttle key. The display will show the information about the last ten faults produced, and both the general information and the metering screens can be viewed for each fault. Displayed information starts in the most recent fault, and the user can switch to another fault by rotating the shuttle key.

Displayed information is stored in the relay volatile memory, so if the relay is turned off this information will be lost, as well as if a "Clear Fault Report" command is executed. However, fault reports stored in the relay non-volatile memory will remain after the Fault reset, and they can be obtained from the relay using EnerVista 650 Setup software, at the "Actual>Records>Fault report" menu.

If there is no fault report available through the display, the relay will show a "Fault report not available" message.

The format of the displayed screens is as follows:



-

Possible fault types are as follows:

GROUND	Ground faults
	AG phase A to ground
	ABG phase AB to ground
	BG phase BG to ground
	BCG phase BCG to ground
	CG phase CG to ground
	CAG phase CAG to ground
PHASE	Phase to phase faults
	AB phase A to phase B
	BC phase B to phase C
	CA phase C to phase A
3PHASE	Three-phase faults (shown on the display as 3PH)
NAF	Fault type not calculated

# 3.2.5.5 VIEW SETTINGS

To enter this menu press the shuttle key when the option "View Settings" is selected in main menu. A secondary level will be displayed with different sublevels as shown on Table 3–31:.Rotating the shuttle key, (left for moving up and right for moving down) select the next level to be displayed, press the shuttle key again to enter in next level and press esc key to return to previous level if desired. This navigation will be performed the same for all the menus in "View Settings". Once the last sublevel is reached, move up and down to visualize the settings selected.

# Table 3–31: GENERAL OVERVIEW OF "VIEW/CHANGE SETTINGS" MAIN MENU

MAIN SETTINGS MENU	FIRST LEVEL	SECOND LEVEL	THIRD LEVEL
Product Setup >			
	Communication >		
		Serial Ports	
		Ethernet >	
			Ethernet 1
			Ethernet 2
		ModBus Protocol	
		DNP3 Slave >	
			DNP3 Slave 1
			DNP3 Slave 2
			DNP3 Slave 3
		IEC 870-5-104	
		SNTP	
	Fault Report		
	Oscillography		
	Demand		
System Setup >			
- /	General Settings		
	Breaker >		
		Breaker Settings	
		Breaker Maintenance	
Protection Element >			
	Phase Current >		
		Phase TOC High >	
			Phase TOC High 1
			Phase TOC High 2
			Phase TOC High 3
		Phase TOC Low >	
			Phase TOC Low 1
			Phase TOC Low 2
			Phase TOC Low 3
		Phase IOC High >	
			Phase IOC High 1
			Phase IOC High 2
			Phase IOC High 3
		Phase IOC Low >	
			Phase IOC Low 1
			Phase IOC Low 2
			Phase IOC Low 3
		Phase Directional >	
			Phase Directional 1
			Phase Directional 2
			Phase Directional 3
		Thermal Model >	
			Thermal Model 1

MAIN SETTINGS MENU	FIRST LEVEL	SECOND LEVEL	THIRD LEVEL
			Thermal Model 2
			Thermal Model 3
	Neutral Current >		
		Neutral TOC >	
			Neutral TOC 1
			Neutral TOC 2
			Neutral TOC 3
		Neutral IOC >	
			Neutral IOC 1
			Neutral IOC 2
			Neutral IOC 3
		Neutral Dir >	
			Neutral Dir 1
			Neutral Dir 2
			Neutral Dir 3
	Ground Current >		
		Ground TOC >	
			Ground TOC 1
			Ground TOC 2
			Ground TOC 3
		Ground IOC >	
			Ground IOC 1
		Cround Dir	Ground IOC 3
		Ground Dir >	
			Ground Dir 2
			Ground Dir 3
	Sens. Ground Curr >		
		Sens. Ground TOC >	
			Sens. Ground TOC 1
			Sens. Ground TOC 2
			Sens. Ground TOC 3
		Sens. Ground IOC >	
			Sens. Ground IOC 1
			Sens. Ground IOC 2
			Sens. Ground IOC 3
		Isolated Gnd IOC >	
			Isolated Gnd IOC 1
			Isolated Gnd IOC 2
			Isolated Gnd IOC 3
		Sens. Ground Dir. >	
			Sens. Ground Dir. 1
			Sens. Ground Dir. 2
			Sens. Ground Dir. 3
	Neg. Seq. Current >		
		Neg. Seq. TOC >	
			Neg. Seq. TOC 1
			Neg. Seq. TOC 2
			Neg. Seq. TOC 3
	Voltage Elements >		
		Phase UV >	

# 3.2 HUMAN MACHINE INTERFACE (HMI)

**3 HUMAN INTERFACES** 

MAIN SETTINGS MENU	FIRST LEVEL	SECOND LEVEL	THIRD LEVEL
			Phase UV 1
			Phase UV 2
			Phase UV 3
		Phase OV >	
			Phase OV 1
			Phase OV 2
			Phase OV 3
		Neutral OV High >	
			Neutral OV High 1
			Neutral OV High 2
			Neutral OV High 3
		Noutral OV Low	Neutral OV High 5
			Noutral OV/Low 1
			Neutral OV Low 1
			Neutral OV Low 2
		New Occ. OV	Neutral OV Low 3
		Neg. Seq. OV >	
			Neg. Seq. OV 1
			Neg. Seq. OV 2
			Neg. Seq. OV 3
		Auxiliary OV >	
			Auxiliary OV 1
			Auxiliary OV 2
			Auxiliary OV 3
		Auxiliary UV >	
			Auxiliary UV 1
			Auxiliary UV 2
			Auxiliary UV 3
	Power >		
		Forward Power >	
			Forward Power 1
			Forward Power 2
			Forward Power 3
		Directional Power >	
			Directional Power 1
			Directional Power 2
			Directional Power 3
Control Elements >			
	Setting Group		
		Linderfrequency 1	
	Quartraguagau	Undernequency 3	
	Overnequency >	Ouerfree successor 4	
		Overfrequency 2	
	Questional	Overrrequency 3	
	Synchrocheck		
-	Autoreclose		
	Breaker Failure		
	VT Fuse Failure		
	Broken Conductor >		
		Broken Conductor 1	

# 3.2 HUMAN MACHINE INTERFACE (HMI)

MAIN SETTINGS MENU	FIRST LEVEL	SECOND LEVEL	THIRD LEVEL
		Broken Conductor 2	
		Broken Conductor 3	
	Locked Rotor >		
		Locked Rotor 1	
		Locked Rotor 2	
		Locked Rotor 3	
Inputs/outputs >			
	Remote Comms.		

#### 3.2.5.6 CHANGE SETTINGS

To enter this menu press the shuttle key when the option "Change Settings" is selected in main menu. A secondary level will be displayed with different sublevels as shown on Table 3–31:. Rotating the shuttle key, (left for moving up and right for moving down) select the next level to be displayed press the shuttle key again to enter in next level and press ESC key to return to previous level if desired. This navigation will be performed the same for all the menus in "Change Settings". Once the last sublevel is reached, move up and down to visualize the settings selected.

To change a particular setting, press the shuttle key on the setting to be modified. After selecting the setting, the value for that setting will appear between brackets. Choose the new value moving up and down the shuttle key. After selecting the appropriate value press again the shuttle key to fix that value. To save the new settings, go to the end of the menu rotating the shuttle key right, and select the menu "Press intro to save settings". When pressing the shuttle key inside this menu the new settings will be saved.

Figure 3–21: shows an example of change settings navigation:



#### Figure 3–21: CHANGE SETTINGS PROCEDURE IN HMI

# 3.2.5.7 DATE & TIME

The "Date & Time" menu will show the relay date and time information in the following format:

Date:Day/Month/Year

Time:Hour:Minutes:Seconds

To modify date and time, press the shuttle key. The relay will show the year between brackets at the top of the screen. By rotating the shuttle key, reach the desired value for the year, and press the shuttle key to select and store that value. After the year, the relay will show the month. Proceed as in the case of the year. The date & time modification sequence is as follows:

	Rotate the shuttle key to select the "Date and Time" menu and press to enter in it
Fault report View settings	The date and time data will appear in the format related above.
Change settings ■ Date & Time	Pressing the shuttle key the year can be modified rotating the shuttle key, after selecting the desired value, press again the shuttle key to store the value.
⇒	'Year'
	Date: Day/Month/ <year></year>
Date: 07/Nov/2004	Time: Hour:Minutes:Seconds
Sunday	After storing the value for Year, Month will appear between brackets and can be modified
·Vear'	'Month'
Date: 07/Nov/<2004>	Date: Day/< <b>Month&gt;</b> /Year
Time: 14:39:54	Time: Hour:Minutes:Seconds
<del>_</del>	After storing the value for Month, Day will appear between brackets and can be modified
'Month'	'Day'
Date: 0// <nov>/2004 Time: 14:39:54</nov>	Date: < <b>Day</b> >/Month/Year
	Time: Hour:Minutes:Seconds
L⇒	After storing the value for Day. Hour will appear between brackets and can be
	Aller storing the value for Day, nour will appear between blackets and can be
'Day'	modified
'Day' Date: <07>/Nov/2004 Time: 14:39:54	modified 'Hour'
'Day' Date: <07>/Nov/2004 Time: 14:39:54	modified 'Hour' Date: Day/Month/Year
'Day' Date: <07>/Nov/2004 Time: 14:39:54 →	modified 'Hour' Date: Day/Month/Year Time: < <b>Hour</b> >:Minutes:Seconds
'Day' Date: <07>/Nov/2004 Time: 14:39:54 → 'Hour' Date: 07/Nov/2004	<ul> <li>After storing the value for Day, flour will appear between brackets and can be modified</li> <li>'Hour'</li> <li>Date: Day/Month/Year</li> <li>Time: <hour>:Minutes:Seconds</hour></li> <li>After storing the value for Hour, Minutes will appear between brackets and can be modified</li> </ul>
<sup>•</sup> Day' Date: <07>/Nov/2004 Time: 14:39:54 <i>→</i> <sup>•</sup> Hour' Date: 07/Nov/2004 Time: <14>:39:54	<ul> <li>After storing the value for Day, floar will appear between brackets and can be modified</li> <li>'Hour'</li> <li>Date: Day/Month/Year</li> <li>Time: <hour>:Minutes:Seconds</hour></li> <li>After storing the value for Hour, Minutes will appear between brackets and can be modified</li> <li>'Minute'</li> </ul>
<sup>•</sup> Day' Date: <07>/Nov/2004 Time: 14:39:54 → •Hour' Date: 07/Nov/2004 Time: <14>:39:54	<pre>After storing the value for Day, floar will appear between brackets and can be modified 'Hour' Date: Day/Month/Year Time: <hour>:Minutes:Seconds After storing the value for Hour, Minutes will appear between brackets and can be modified 'Minute' Date: Day/Month/Year</hour></pre>
'Day' Date: <07>/Nov/2004 Time: 14:39:54 → 'Hour' Date: 07/Nov/2004 Time: <14>:39:54 →	<ul> <li>After storing the value for Day, floar will appear between brackets and can be modified</li> <li>'Hour'</li> <li>Date: Day/Month/Year</li> <li>Time: <a href="https://www.energy.com">https://www.energy.com</a></li> <li>After storing the value for Hour, Minutes will appear between brackets and can be modified</li> <li>'Minute'</li> <li>Date: Day/Month/Year</li> <li>Time: Hour:</li> </ul>
'Day' Date: <07>/Nov/2004 Time: 14:39:54 → 'Hour' Date: 07/Nov/2004 Time: <14>:39:54 → 'Minute' Date: 07/Nov/2004 Time: 14:<39>:54	<ul> <li>After storing the value for Day, floar will appear between brackets and can be modified</li> <li>'Hour'</li> <li>Date: Day/Month/Year</li> <li>Time: <a href="https://www.energy.com">https://www.energy.com</a></li> <li>After storing the value for Hour, Minutes will appear between brackets and can be modified</li> <li>'Minute'</li> <li>Date: Day/Month/Year</li> <li>Time: Hour:<minute>:Seconds</minute></li> <li>After storing the value for Minutes, Seconds will appear between brackets and can be modified</li> </ul>
'Day' Date: <07>/Nov/2004 Time: 14:39:54 → 'Hour' Date: 07/Nov/2004 Time: <14>:39:54 → 'Minute' Date: 07/Nov/2004 Time: 14:<39>:54	<ul> <li>After storing the value for Day, floar will appear between brackets and can be modified</li> <li>'Hour'</li> <li>Date: Day/Month/Year</li> <li>Time:  </li></ul>
'Day' Date: <07>/Nov/2004 Time: 14:39:54 → 'Hour' Date: 07/Nov/2004 Time: <14>:39:54 → (Minute' Date: 07/Nov/2004 Time: 14:<39>:54	<ul> <li>After storing the value for Day, floar will appear between brackets and can be modified</li> <li>'Hour'</li> <li>Date: Day/Month/Year</li> <li>Time: <a href="https://www.energy.com/">https://www.energy.com/</a></li> <li>After storing the value for Hour, Minutes will appear between brackets and can be modified</li> <li>'Minute'</li> <li>Date: Day/Month/Year</li> <li>Time: Hour:</li> <li>Minute&gt;:Seconds</li> <li>After storing the value for Minutes, Seconds will appear between brackets and can be modified</li> <li>'Second'</li> <li>Date: Day/Month/Year</li> </ul>
'Day' Date: <07>/Nov/2004 Time: 14:39:54 → 'Hour' Date: 07/Nov/2004 Time: <14>:39:54 → 'Minute' Date: 07/Nov/2004 Time: 14:<39>:54	<ul> <li>After storing the value for Day, floar will appear between brackets and can be modified</li> <li>'Hour'</li> <li>Date: Day/Month/Year</li> <li>Time: <a href="https://www.englight.com">https://www.englight.com</a></li> <li>After storing the value for Hour, Minutes will appear between brackets and can be modified</li> <li>'Minute'</li> <li>Date: Day/Month/Year</li> <li>Time: Hour:</li> <li>After storing the value for Minutes, Seconds will appear between brackets and can be modified</li> <li>'Second'</li> <li>Date: Day/Month/Year</li> <li>Time: Hour: Minute:</li> <li>Seconds</li> </ul>

Figure 3-22: CHANGE DATE AND TIME PROCEDURE IN HMI

# **3.2 HUMAN MACHINE INTERFACE (HMI)**

# 3.2.5.8 COMMANDS

Commands are configured using EnerVista 650 Setup, and they can be executed using the pushbuttons on the relay front.

Using EnerVista 650 Setup software, the user can configure up to 24 commands with a descriptive text. When executing the operation from the relay front, the operation description text will be displayed.

Example of commands (operations) executions via HMI



Figure 3–23: COMMANDS IN HMI

#### 3.2.5.9 PASSWORDS

F650 units incorporate independent passwords for protection and control, in order to prevent unauthorized keypad and display access to the relay.

#### Settings Password:

This password allows restricting access to settings changes in the relay protection elements.

#### Commands Password:

This password is required for executing operation commands through the keypad and display.

If the Commands Password is activated, when the user tries to execute an operation, the relay will request this password, and in case of using the single-line diagram for graphical display models, all objects will not be operational until this password is entered, either logging in *Login Pwd Commands*, or entering the password in the *Commands* menu.

Relay settings view, measures, and other monitored information are not password-protected, and they can be accessed by all users.

Access to the password menu is located at the **Password** option in the relay text menu. This menu includes the following options:

- "Login Pwd Settings"
- "Logout Pwd Settings"
- "Change Pwd Settings"
- "Login Pwd Commands"
- "Logout Pwd Commands"
- "Change Pwd Commands"
- "Forgot Password?"

Among the available options in this menu, there are three types of functionality:

Login:	For entering the password, either for settings or commands, and enable access to settings or commands. Once entering the password the relay is no longer password protected, and access is enabled to settings modification or commands execution.
Logout.	Once the necessary setting changes or operation commands have been executed, the user can log out, so that the relay is password protected again.

*Change*: This menu allows setting or modifying the desired password.

Forgot Password: This menu provides the encrypted password, so that it can be recovered if the user loses or forgets it.

Passwords are restricted for Settings change and Commands execution. To password-protect the relay, it is first necessary to set the desired password, using the corresponding "Change Pwd ..." menu. The default password is **0000**. This password provides access to the whole relay functionality.

Once a new password has been set, the user must log in to access the protected functionality; otherwise, the relay will request the password when trying to change settings or execute commands. Once the password is entered the relay is unprotected (as if the user had logged in), and the user must log out to protect again the relay.

#### a) PASSWORD RANGE

The valid range for F650 passwords is a number from 0000 to 9999.

The default password is 0000, which provides access to the whole relay functionality. This is the default option for enabling relay use without using passwords.

#### b) ENTERING THE PASSWORD (LOGIN PWD)

This operation is the same for both the settings and commands passwords. The only difference will be the access menu. For entering the password, the user must access the *Login* menus inside the *Password* menu.

Login Pwd Settings or Login Pwd Commands:

The relay requests the password with the following message on the screen:

#### Setting passwd.

#### Login: < 1000 >

For entering the desired password, the user must rotate the shuttle key to the left (decrease) or to the right (increase), and establish the desired number. Once entered, the selected password between brackets has been entered, the relay will show the message "**Processing passwd. Wait...**". If the password is correct, the relay will allow access to the settings change or command execution. It is not necessary to enter the password every time a change is to be performed. The relay will request the password 15 minutes after the last keypad action has taken place. This period of time is the same that takes the relay to turn off the display backlighting.

# c) LOGGING OUT (LOGOUT PWD)

To disable access to settings and commands, the user must logout.

Logout Pwd Settings or Logout Pwd Commands:

For safety reasons, if the user does not log out, the relay will do it automatically 15 minutes after the last keypad action.

## d) CHANGING THE PASSWORD (CHANGE PWD COMMANDS)

To set a password in the relay, both for settings and commands, the corresponding menu must be accessed inside the *Password* menu:

#### Change Pwd Settings or Change Pwd Commands:

To modify the password, the user must first introduce the existing password; if the relay has the default factory password, this would be 0000.

For modifying the password, the relay requests the existing password with the following message:

#### (Setting or Command) passwd.

#### Login: < 0000 >

Once the entered password has been acknowledged, the new password must be entered:

(Setting o Command) passwd.

#### New passwd: < 1000 >

Once the new password has been entered, the relay returns to the general Passwords menu.

# e) PASSWORD RECOVERY (FORGOT PASSWORD?)

If the relay passwords need to be recovered, the "Forgot Password?" menu must be accessed. This menu is the last option inside the text **Passwords** menu.

This menu will show two passwords, which correspond to the encrypted protection settings, and commands passwords, as shown in the following example:

Cod Settings: [35c0]

#### Cod Commands: [35c0]

#### <Push Intro>

In order to obtain the decoded password from the encrypted codes provided by the relay, it is necessary to contact GE Multilin and provide these encrypted codes.

# 3.2.5.10 SELECT MAIN SCREEN

The relay display offers the possibility to select the default main screen. For this purpose, the user must access the "Select Main Screen" menu through the HMI. This menu includes the following options:

#### Logotype

This option selects as main screen the relay logotype including the firmware and boot code versions, the relay model and the communication parameters for local port COM2.

F650 1.72 (2.35) General Electric F650MZDF2G1HIR 19200N81: MODBUS: 254

# Figure 3–24: DEFAULT LOGOTYPE SCREEN

# Metering

This option shows a Metering screen including the phase and ground currents as well as phase-to-phase voltage, and zero sequence voltage values, all of them in primary values.

la Ib	0.000 0.000	Vab Vbc	0.000 0.000
lc	0.000	Vca	0.000
lg	0.000	V0	0.000



#### All

This option alternates in time the two previous options.
# 3.2.5.11 SELECT LANGUAGE

Option only available for versions 1.70 or higher.

The relay display offers the possibility to select the default language for the relay. For this purpose, the user must access the "**Select language**" menu located at the end of the main menu through the HMI. This menu allows the user to set the default language of the relay between English (always available) and second language selected in the relay model. (see section 2.3 ORDERING CODE).

For example one relay in French language (e.g. F650MZDF2G1HIR**F**) can be displayed in French or in English only by changing the language setting in HMI. It is necessary to switch off and on the relay to start working with the new language configuration in the relay. In EnerVista 650 Setup it is possible to select the language for the software (View>Languages).

Example of language selection in HMI



Figure 3–26: LANGUAGE SELECTION IN HMI

# 3.2.6.1 ONE-LINE DIAGRAM

In models with graphic display (F650M) default main screen is the single-line diagram. This single-line diagram can be configured using EnerVista 650 Setup software by choosing the *HMI* menu inside *Relay Configuration* (*Settings>Relay Configuration>HMI*).



Figure 3–27: ONE-LINE DIAGRAM

The bottom of the display shows a legend that indicates the possible selections that can be made from this screen.

### Esc: Menu.Intro: Next.L-R: Select.

The meaning of these options is as follows:

# Esc: Menu.

Pressing the ESC key, the user will access the relay main menu, similar to the one displayed by the textdisplay model (F650B).

Pressing again the ESC key; the menu selection screen (Actual Values, Snapshot events, etc.) will be displayed. This main menu screen is identical to the one described for the text display. Its functionality is described in section 3.2.5 in this manual.

# Intro: Next.

Pressing the shuttle key, the user access the next graphical screen, which in this case corresponds to the primary metering values screen.

# L-R: Select

Once the different switchgear elements to be operated have been configured using EnerVista 650 Setup, the user will be able to operate them from the graphic display.

If a single-line diagram has been previously configured in the EnerVista 650 Setup, in the HMI option inside the **Relay Configuration** menu, the different switchgear elements configured for the display will be operative from the graphic display. By rotating the shuttle key to the left and right, the cursor moves among the elements and blinks on each of them. When an element is selected by pressing the shuttle key, the relay will indicate the command to be executed, and the user will need to confirm it by pressing again the shuttle key.

The following sections describe only the operation of screens that are specific for the graphic display models.

# 3.2.6.2 METERING SCREEN

The Metering screen displays relay analog measures in their primary values. Available metering values are as follows:

Metering Screen		Total metering 56
Phasor la	Primary	0.000 KA
Phasor Ik	Primary	0.000 KA
Phasor lo	Primary	0.000 KA
Phasor lo	Primary	0.000 KA
Phasor Is	g Primary	0.000 KA
RMS la P	rimary	0.000 KA
RMSIbP	rimary	0.000 KA
<b>RMS IC P</b>	rimary	0.000 KA
RMS lg P	rimary	0.000 KA
RMS Isq	Primary	0.000 KA
10 Primar	y -	0.000 KA
Intro: Next.	ESC: Prev	L-R:Scroll.

# Figure 3–28: METERING SCREEN

As in the rest of graphical display screens, the bottom part shows a legend that indicates the possible options for the user. In this case, the options are:

### Intro: Next.Esc: Prev.L-R: Scroll.

# Intro: Next.

Pressing the shuttle key the user accesses the next screen, in this case the ALL EVENTS screen.

### Esc: Prev.

Pressing the ESC key the user returns to the previous screen (One-line diagram)

### L-R: Scroll.

Rotating the shuttle key to the left (L) or right (R) the user can access all the Metering values in the screen. Rotating the shuttle key left will move up in the screen, and rotating right will move down.

METERING SCREEN ANALOG MEASURES IN PRIMARY VALUES							
Phasor la Primary	V0 Primary	Phase A Real Pwr	Line Frequency Primary				
Phasor Ib Primary	V1 Primary	Phase B Reactive Pwr	Bus Frequency Primary				
Phasor Ic Primary	V2 Primary	Phase B Apparent Pwr	Vx Primary				
Phasor Ig Primary	Vab Primary	Phase B Real Pwr	Positive MVarhour				
Phasor Isg Primary	Vbc Primary	Phase C Reactive Pwr	Negative MVarhour				
Phasor In Primary	Vca Primary	Phase C Apparent Pwr	Positive MWatthour				
RMS la Primary	Vn Primary	Phase C Real Pwr	Negative MWatthour				
RMS Ib Primary	Va Primary	3 Phase Reactive Pwr	Pos MVarhour Cnt				
RMS Ic Primary	Vb Primary	3 Phase Apparent Pwr	Neg MVarhour Cnt				
RMS Ig Primary	Vc Primary	3 Phase Real Pwr	Pos MWatthour Cnt				
RMS Isg Primary	VBB Primary	Phase A Power Factor	Neg MWatthour Cnt				
10 Primary	VL Primary	Phase B Power Factor					
I1 Primary	Phase A Reactive Pwr	Phase C Power Factor					
12 Primary	Phase A Apparent Pwr	3 Phase Power Factor					

# 3.2.6.3 ALL EVENTS SCREEN

This screen shows all events that have been produced in the relay. The top of the screen shows its name (All Events), and the relative and total number of events contained in the screen.

# All Events (1/479)

This legend means that there are a total of 479 events stored in the relay, and that the cursor is located on event number 1. The information shown on this screen for each event is as follows:

## "Hour:Minute:Second:Millisecond" "Event text" "Event status(ON/OFF)"

All Events (1/4	All Events (1/479).					
	-[ReadyLEDON]-					
16:11:08.035	Ready LED ON	ON				
16:11:08.017	Breaker Closed ON	ON				
16:11:08.005	Isolated Gnd3 Block OFF	OFF				
16:11:08.005	Isolated Gnd2 Block OFF	OFF				
16:11:08.005	Isolated Gnd1 Block OFF	OFF				
16:11:08.005	Sens Gnd TOC3 Block OFF	OFF				
16:11:08.005	Sens Gnd TOC2 Block OFF	OFF				
16:11:08.005	Sens Gnd TOC1 Block OFF	OFF				
16:11:08.005	Ground TOC3 Block OFF	OFF				
16:11:08.005	Ground TOC2 Block OFF	OFF				
16:11:08.005	Ground TOC1 Block OFF	OFF				
Esc: Prev.	Intro: Menu.	L-R: Scroll.				

### Figure 3–29: ALL EVENTS SCREEN

The screen legend options are:

Esc: Prev. Intro: Menu. L-R: Scroll.

# Esc: Prev.

Pressing the ESC key, the user returns to the previous screen (Metering screen)

### Intro: Menu.

Pressing the shuttle key, the user accesses the Events menu that offers the following options at the bottom of the screen:

next prev reload details At

To access the different options in the snapshot events graphic menu the user must move the cursor from left to right. The selected option will be displayed in upper case and between brackets. To access the selected option, the user must press again the shuttle key.

# <NEXT>

The user accesses the next available graphic screen (Events – New)

# <PREV>

This option returns to the general events graphic menu (All Events)

# <RELOAD>

This option updates all events stored in the relay and returns to the general events screen.

### <DETAILS>

The Details screen provides access to metering values, and date and time related with the event.

The top of the screen displays a legend with the event text, followed by the date and time, the event status (ON or OFF), and the event index number related to the complete list of events in the relay, for example (1/479). The rest of information provided by the Details screen corresponds to the relay measures in the moment of the event. Metering values provided in the events are secondary, and voltage values correspond to phase-to-ground voltage.

Date: 10/Jun/2005 Time: 16:11:08.035	Ready LED ON	St:ON (1/479)
Phasor la Primary Phasor lb Primary Phasor lc Primary Line Frequency Phasor lg Primary Phasor lsg Primary I0 Primary I1 Primary		0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000
Intro: Meters.	ESC: Prev.	L-R: Scroll.

## Figure 3–30: SNAPSHOT EVENTS DETAIL SCREEN

To navigate this screen the user must follow the legend at the bottom of the screen:

## Intro: Meters. ESC: Prev.L-R: Scroll.

### Intro: Meters.

To access the metering values in the moment of the event, the user must press the shuttle key. A new metering screen will be displayed, containing the primary metering values in the snapshot event, such as:

Phasor la Primary	I2 Primary
Phasor Ib Primary	Vab Primary
Phasor Ic Primary	Vbc Primary
Line Frequency Primary	Vca Primary
Phasor Ig Primary	V1 Primary
Phasor Isg Primary	V2 Primary
10 Primary	V0 Primary
I1 Primary	3 Phase Power Factor

Once inside the Metering screen, a new legend will be shown for each event (Intro or ESC: Prev. L-R: Scroll); this legend indicates that by pressing ESC or the shuttle key, the system will return to the Event Detail screen, and rotating the shuttle key the user will access all the metering values contained in the metering screen of the considered event.

### ESC: Prev.

If the user presses the ESC key from the event detail screen, the system will return to the all events screen.

## L-R: Scroll.

Rotating the shuttle key left (L) or right (R) moves among all the events contained in the all events screen, allowing a preview of the details for each of them.

### <AT>

When this option is selected, the system marks the event where the cursor is located. A relative time stamp is performed, in such a way that the selected event, marked with an asterisk (\*) between the time and the event name is set with a relative time of 00:00:00:000 on the top line of the event screen, together with its relative index, and the rest of events in the screen will show a date/time that relates to the marked event. This operation mode allows a quick inspection of the relative time passed between several events, which is very useful for analyzing events in the field. The corresponding legend to this relative event-marking screen is as follows:

### Esc: Out At. Intro: Tag event.

### Esc: Out At.

The relative event marking is eliminated and the system returns to the general events screen.

### Intro: Tag event.

If the user places the cursor on a different event by rotating the shuttle key left or right, pressing the shuttle key will change the relative mark to that new event.

### 3.2.6.4 NEW EVENTS SCREEN

This screen shows the new events that have been produced in the relay since the last time the New Events screen was read. The top of the screen shows a "**New Events**" legend, and the relative and total number of events contained.

Navigation through the different menus in this New Events screen is similar to the one described in the previous section for All Events. The main difference is that in the case of new events it is necessary to select the **RELOAD** submenu to update the screen with new events that have been produced, while in the All Events screen, this refreshment is automatic.

After the new events have been read, if the user selects again the **Reload** menu, the system will show a **<No new events available.>** message, indicating that there are no more new events available since the last reading.

### **3.2 HUMAN MACHINE INTERFACE (HMI)**

### 3.2.6.5 ALARMS PANEL

Alarms panel can be viewed in all F650 models using communication software EnerVista 650 Setup, however, only models with graphic display allow access to the alarms panel from the HMI.

First line shows the relative and total number of alarms existing in that screen. The relative number refers to the alarm on which the cursor is located, and the total number refers to the total amount of alarms available. The second line on this screen shows an index that indicates the number of the configured control event that corresponds to the displayed alarm, followed by the alarm text configured in the **Control Events** menu inside the **Relay Configuration** option ("**Settings>Relay Configuration>Control Events**").

#1	Alarm Panel (1/3). OPERATIONS IN LOCAL	MODE
7/11/04 16:54:16 7/11/04 16:54:16 7/11/04 16:54:16	OPERATIONS IN LO. GENERAL PICKUP GENERAL TRIP	. 8 8 8 8
Esc	: Prev. Intro: I	Venu

#### Figure 3–31: ALARMS PANEL IN HMI

The rest of the screen shows the different alarms produced in the relay with the date and time when the corresponding event was produced, followed by the alarm identification text, and its status, active (ON) or inactive (OFF).

In the previous example, the produced alarm is the change to local of the execution of operations (OPERATIONS IN LOCAL MODE), the date and time when this event has been produced, and its status (ON):

The bottom of the screen shows the legend that indicates how to navigate through the different options available in the screen.

Intro: Menu.

## ESC: Prev.

#### ESC: Prev.

Pressing the ESC key, the system returns to the previous New Events screen.

#### Intro: Menu.

Pressing the shuttle key, the user accessed the available alarms menu, which includes the following options.

next prev ack ack all

To access the different options provided by the alarms graphic menu, the user must move the shuttle key left to right. The selected option will be displayed in upper case and between brackets. To access the selected option, the shuttle key must be pressed.

# <NEXT>

This option provides access to the next available graphic screen (I/O boards)

### <PREV>

The system returns to the previous New Events screen.

# <ACK>

This option acknowledges the alarm on which the cursor is located.

# **3 HUMAN INTERFACES**

### <ACK ALL>

This option acknowledges all alarms. Alarm acknowledgement through the graphic HMI is considered as through communication port COM2, as it is considered to be Local in both cases.

When an alarm has been acknowledged, a selection mark will appear to the right of its status. Inactive alarms will disappear from the screen once they are acknowledged.

### 3.2.6.6 INPUT/OUTPUT MONITORING SCREEN

This is the last screen available in the graphic display. This screen allows viewing the status of the relay inputs and outputs, as well as emulate inputs (for verification of the logic, or related functions), and contact outputs (to verify wiring).

The format of this screen is shown on the figure below.

The first line shows the name of the screen "I/O Cards", followed by the type and description of the board where the cursor is located, which will appear between selection marks > < and blinking.



# Figure 3–32: INPUTS/OUTPUTS GENERAL SCREEN

The navigation legend on this screen is as follows:

# Esc: Prev.Intro: Menu.L-R: Chg Card

# Esc: Prev.

This option returns to the previous screen (Alarms Panel).

### Intro: Menu.

This option provides access to the selected I/O board menu:

This menu includes the following options.

#### next view test input test output

As in previous screens, to access the different options provided by the inputs/outputs graphic menu, the user must move the shuttle key left to right. The selected option will be displayed in upper case and between brackets. To access the selected option, the shuttle key must be pressed.

	IO Card F	. Туре: 2,	#IN	18, #OUT	8
	Input	( <b>O</b> N)	(ON OFF)		
	0 CC1	8 Va CO	L1	<b>0 ОЛТ1</b> ??	
	1 CC2	9 Vb CO	L1	10UT2??	
	2 CC3	10 Va CC	2L	2 OUT3 ??	
	3 CC4	11 Vb CC	XL2	3 OUT4 ??	
	4 CC5	12 Isens	e1	4 OUT5 ??	
	5 CC6	13 Isens	<b>3</b> 1	50UT6??	
	6 CC7	14 SUP2	1	6 OUT7 ??	
	7 0008	15 SUP2	2	7 0078??	
					-
nex	t	>MEW<	test inpu	ut test output	

## Figure 3–33: INPUT/OUTPUT VIEWING SCREEN

#### <NEXT>

This option brings the system back to the one-line diagram.

#### <VIEW>

This option shows the real status of all inputs and outputs in the selected board. Depending on the type of board, with or without supervision, the screen will vary to get adapted to the characteristics of each board.

The first line of this screen shows the slot where the board is located, **F**, **G**, **H** or **J**, and the type of board, **2** if it includes supervision (8 inputs, 8 outputs, and 4 supervision circuits), or **1** if it is a mixed board (without supervision) with 16 digital inputs and 8 outputs. The view menu differentiates inputs and outputs; the active status (ON) is represented by the lighting of the corresponding input or output.

The legend at the bottom of the screen indicates how to navigate:

Esc: Prev. Intro: Menu. L-R: Chg Card
---------------------------------------

Esc: Prev.

Returns to the general I/O screen

Intro: Menu.

Provides access to the I/O menu (next, view, test input, test output).

# L-R: Chg Card

Moving the shuttle key to the left or right provides access to the status of inputs/outputs for the different boards available in the relay.

# <TEST INPUT>

This option allows testing the input activation (in emulation mode). The displayed screen is similar to the viewing screen, but in this case the user can operate the different relay inputs.

This screen shows the *Input* name lit up, showing that this is an Input emulation mode.

The first relay input will appear blinking and between brackets; the user can select a different input by rotating the shuttle key. When the shuttle key is pressed, the selected input will be activated. Navigation through this screen is indicated by the following legend:

Esc: Exit Text. Intro: Chg Input.

### Esc: Exit Text.

The ESC option returns to the general I/O board menu.

### Intro: Chg Input.

Pressing the shuttle key on the blinking input, this input will be activated in emulation mode.

Note: input emulation can only be executed through the TEST INPUT tool on the graphic display.

# <TEST OUTPUT>

This option allows testing the output activation in emulation mode. The displayed screen is similar to the viewing screen, but in this case the user can operate the different relay contact outputs to test the wiring.

This screen shows the **Output** name lit up, showing that this is an output emulation mode.

The first relay output will appear blinking and between brackets; the user can select a different output by rotating the shuttle key. When the shuttle key is pressed, the selected output will be activated. Navigation through this screen is indicated by the following legend:

### Esc: Exit Text.

Intro: Chg Output.

# Esc: Exit Text.

The ESC option returns to the general I/O board menu.

### Intro: Chg Output.

Pressing the shuttle keyshuttle key on the blinking output, this output will be activated in emulation mode.

**Note**: Output emulation can be executed through the TEST OUTPUT tool on the graphic display, and also through communications using EnerVista 650 Setup software for all F650 models.

## L-R: Chg Card

Rotating the shuttle key allows to change the selected I/O board in the main I/O screen.

The web server in the F650 can be accessed running the Windows explorer, and keying <u>http://xxx.xxx.xxx</u>, being xxx.xxx.xxx the relay IP address, which must be configured in **Setpoint > Product Setup > Communication Settings > Ethernet**.

The main screen of the F650 web server shows the different monitoring possibilities for snapshot events, events, alarms, oscillography, fault reports, data logger and metering values provided by the relay through the web.

In order to access the different functions provided by the web server, the user must simply click on the list name on the left side of the screen.

The web server (for version 1.70 and higher ones) allows the user to visualize the different web server screen languages: English, French, Spanish and Russian by pressing the language button on the top right corner of the main window. Take into account that this selection only changes the language in the web server screen, all the relay texts, such as snapshot events, control events, etc. will be the in the language selected in the relay (see section 3.2.5.11 in this manual).



Figure 3–34: WEB SERVER MAIN SCREEN

The Snapshot events screen shows all Snapshot events produced in the relay. This screen is refreshed automatically every minute.

The information provided in this screen includes: first, the relative event index, the lowest index corresponding to the most recent event; next, the event text that shows the reason for the event, its status, active (ON) or inactive (OFF), and finally the date and time when the event was produced.

The bottom of the screen shows a Metering screen; clicking on one of the events, the associated metering values will be shown on that screen.



# Figure 3–35: SNAPSHOT EVENTS SCREEN

3.3.3 CONTROL EVENTS

The control events screen provides access to all events that have been configured in the Control Events screen inside the *Relay Configuration* menu of EnerVista 650 Setup.



Figure 3–36: CONTROL EVENTS SCREEN

Unlike the case of Snapshot events, in this screen the highest index corresponds to the most recent event. The information provided is the control event index, the text that has been associated to such event when configured, its status, active (ON) or inactive (OFF), and its date and time.

The alarms screen provides access to alarms configured in the relay. As in the case of snapshot events and control events, this screen allows only to view the alarms, but not to acknowledge them.



Figure 3–37: ALARMS SCREEN

The oscillography screen allows obtaining from the relay available oscillography records in that moment.

This screen includes two windows. The first window shows oscillography records available in the relay, identified by an index, being the highest index the most recent record (oscillography record No 6 in the example below).



### Figure 3–38: OSCILLOGRAPHY SCREEN

If the user clicks on the oscillo record he wants to retrieve, the window on the right will show a description of the record header, indicating its date, time, and the most relevant parameters of the record. Once a record is selected, it is required to press the **Download** button. The system will then open a window to allow saving the files in Comtrade format in the PC hard drive. Once the records have been saved, the system will ask if the user wants to open GE-OSC tool (Comtrade record viewer) to view the downloaded files.



Clicking on the Home option, the system will return to the web server main screen.

# 3.3.6 FAULT REPORT

The fault report screen provides access to the last 10 fault reports obtained by the relay. These records are stored according to an index that marks their position among all records produced in the relay, with a range from 1 to 999, returning to 1 in case of exceeding the limit of 999. As in the case of oscillography records, the highest index corresponds to the most recent record.

In the fault report, oscillography and data logger screens, the system will request acceptance of a safety-warning message.



Figure 3–40: FAULT REPORT SCREEN

The information provided in this screen includes the date and time when the fault was registered, fault calculations such as distance to the fault, type of fault, date and time, and the line parameters, as well as the recloser and breaker status during the fault.

This screen shows also prefault and fault voltage and current primary values. At the top of the screen, associated to the trigger event number there is a button labeled as INFO. This button displays at the bottom of the screen the events produced before and after the fault report trigger, so that the user has very useful information about the moment when the fault was produced.

To obtain a text file with all the fault report information, press the **Download** option and save the file in the computer.

## 3.3.7 DATA LOGGER

The data logger screen allows viewing the data logger first and last value retrieval date and allows downloading the data record files in Comtrade format, by pressing the Download option. Stored files can be viewed later using any Comtrade format viewer.



🙋 Subprograma iniciado

Figure 3–41: DATA LOGGER SCREEN

3.3.8 METERING

This screen includes the 53 primary metering values provided by the relay display.



Figure 3–42: METERING SCREEN

New users can only be added by users that have Administrator Access (or Admin Rights). The Enable Security check box located in the Security->User Management window must be enabled.

Remember: (In order to add new users and assign user rights )

- must be logged in with Administrator Permission
- and Enable Security checkbox must be enabled

4.1.1 USER RIGHTS

NOTE: Only Administrators have access to the User Management dialog box. Following is a list of all of the User Rights Options available to be granted to users, and their functions.

### Table 4–1: USER RIGHTS AND FUNCTIONS

RIGHT	FUNCTION
Delete Entry	If this box is checked when the Administrator exits the User Management dialog box, the program will ask you to confirm the delete and if the Administrator chooses "yes", then the user whose "Delete Entry" box was checked will be permanently deleted from the list.
Admin.	WARNING: When this box is checked, the user will become an EnerVista 650 Setup Administrator, therefore receiving all of the Administrative rights.
Actual Values	When this box is checked, the user will have the ability to <u>view</u> Actual Values and all records excluding event recorder.
Settings	When this box is checked, the user will have access to <u>view and modify</u> Settings (Protection, control, inputs/ outputs and calibration).
Commands	When this box is checked, the user will be able to use <b>Commands</b> .
Event Recorder	When this box is checked, the user will have access to use Event Recorder.
Force IO	When this box is checked, the user will be able to use Force IO application.
Logic Configuration	When this box is checked, the user will have the ability to <u>view and modify</u> Relay Configuration and Logic Configuration.
Upgrade	When this box is checked, the user will have the ability to <b>upgrade firmware, bootware</b> and to <b>upload</b> and <b>download info files to/from relay.</b>

Users will be prompted to change their password after the first successful log in or through clicking **Security** from the toolbar, and choose **Change Password**.

Change Password	
Enter Old Password Enter New Password Re-enter New Password	
Enter a personal question answer to. This will be us current password and wo	that only you know the ed if you ever forget your uld like to know what it is.
Correct answer	
, 	Cancel
Figure 4–1: CHA	NGE SECURITY

r password for the first time, he/she should also

When the operator enters a new password for the first time, he/she should also enter a personal question that only they could answer. There is a limit of 50 characters available to enter the personal question. One example, as in the above diagram, would be "What is my mother's maiden name?". This question will be posed to the user if the user forgets their password and would like to know what their password was.

EnerVista UR Setup Security Control is disabled by default. Users don't have to log in through user name and password after installation and are granted access as Administrator.

Security Control can be enabled through **Security** from the tool bar when logged on as an Administrator. Click on **User Management** and a dialog box will show up.

🖥 Use	r Management	:									×
	UserName	Delete Entry	Admin	Actual Values	Settings	Commands	Event Recorder	Force 10	Logic Configuration	Upgrade	
1	Administrator					V			▼		
2	F650TEST										1
3	Service					<b>V</b>			<b>V</b>		1
x											
To delete a user simply check the delete entry box. To add a user fill the empty row with user name and check applicable check boxes. The default password for new users is 'password'.											
<b>⊽</b> Er	▼ Enable Security										

# Figure 4–2: SECURITY ENABLING

Security Control is enabled by checking the **ENABLE SECURITY** check box. The first time the enable security option is selected is necessary to close and open EnerVista 650 Setup to start working under security management.

Users have to log on in order to use EnerVista 650 Setup program after Security Control has been enabled. After the start up of EnerVista 650 Setup, a dialog will pop up asking for user name and password.

🖥 Login	×
User T	estUser
Password	
-	
Forgot y	our password?
OK	Cancel

### Figure 4–3: LOGIN USER

The user name field will display the last log in user name as default, in this example, TestUser. For the first log in session of any user name, the default password will be "password". User will be prompt to change the password to something else after the first successfully log in.

Log on can also be done by clicking **Security** from the toolbar and choose **Login New User**. User will be prompted with the same log in dialog box for a different user name and password combination.

In case a user has forgotten about the log in password, the Forgot Password function can be used to retrieve the password.

Forgot your password?
User: TestUser
Enter the correct response to the following question to receive your password.
Mother's Maiden Name
Answer: Anderson
Password: 917324
OK Cancel

### Figure 4-4: FORGOT YOUR PASSWORD?

A question, which is pre-set by the user, will be asked. The password will be retrieved for entering the right answer.

This section describes the necessary steps to update the F650 operative system and firmware.

WARNING BEFORE PERFORMING THE UPDATE PROCEDURE CHECK THAT BOOT AND FIRMWARE VERSION MATCH

The operative system and firmware versions can be seen in the relay main screen: After the text "F650", appears the relay firmware version (1.20 in the example), and between parenthesis the boot program version (2.20 in the example), followed by "GENERAL ELECTRIC", the relay model and the default front RS232 port communication parameters.



Figure 5–1: MAIN SCREEN

# BOOT CODE RELEASE NOTES

It is mandatory to maintain version compatibility between firmware and boot code in the update procedure, otherwise the relay will not start after the updating procedure (if the versions are wrongly matched).

	FIRMWARE AN	D BOOT VERSIONS COMPATIBILITY
FIRMWARE VERSION	BOOT VERSION	BOOT CODE RELEASE NOTES
		Minor changes in firmware. All models excepting:
2.20	4.00	Options 4 and 5 for I/O boards
		Option 6 for IEC 61850 protocol
1.92	4.00	File system management enhancement in boot code 4.00 Measurements enhancement in 1.82 firmware version. All models excepting:
1.02	4.00	Options 4 and 5 for I/O boards
		Option 6 for IEC 61850 protocol
2.00	3.00	New hardware options supported (see ordering code). New communication protocols supported (IEC 61850)
	2.40	Minor changes in bootcode. No functionality change for user.
1.6X-1.7X-1.80	2.35	System memory tool provided. Upgrade from 2.30 required to work with 1.61 firmware version up to 1.80
1.3X-1.4X-1.5X	2.30	Enhanced internal watchdog usage. No functionality change for user. Upgrade from 2.20 not required
1.13-1.2X	2.20	Upgraded for use with version 1.13 or later firmware
1.00-1.11	2.00	Original boot code version

# NOTE

The end of this section includes a STEP LIST SUMMARY that will allow the user to control the updating process. It is necessary to read the whole document before accomplishing the F650 UPDATE PROCEDURE related in these pages.

Notice that boot program and firmware upgrades will erase all the data contained in the relay, thus it is advisable to save all the data, oscillography, events, settings and configuration files previously.

Backward compatibility of PLC projects, settings and configuration files is not assured for versions older than 1.13.

# NOTE

RELAYS WITH FIBER OPTIC ETHERNET

The update of the boot program (BOOTCODE) will be performed, obligatorily, by crossed copper cable connected to the PC. It is not necessary to change the internal switch from fiber to RJ45, because the upgrade it is made at 10Mb/s and for that reason there is not conflict between copper/fiber optic.

This does not apply to the firmware upgrade, which can be done either via Ethernet Fiber connection, or through the RJ45 cable connection.

### **5.1.1 COMMUNICATION PARAMETERS**

Before proceeding with the update process, the following points should be taken into account:

### Type of Ethernet connection:

If the relay is connected through a hub or to a switch, a direct 10/100 Base TX Ethernet cable should be used, or with its fiber optic if the relay is of 100FX Ethernet. Otherwise, a direct connection from the PC to the relay (back-to-back) requires a crossover 10/100 Base T cable.

It is highly recommended to use a crossover cable to do the update process and do a direct connection from the PC to the relay instead of being connected through a hub or switch.

Relay IP address:

It is necessary to assign a valid IP address to the relay in the Ethernet parameters via HMI in the "Product Setup > Communication > Ethernet > Ethernet 1" menu or via EnerVista 650 Setup in "Setpoint > Product Setup>Communication Settings > Network (Ethernet) 1" as shown in Table 5–1:.

### Table 5–1: ETHERNET PARAMETERS

PRODUCT SETUP>COM	MUNICATION SE	TTINGS >NETWO	ORK (ETHERNET) 1	
Name	Value	Units	Range	
IP Address Oct1	192		[0 : 255]	
IP Address Oct2	168		[0 : 255]	
IP Address Oct3	37		[0 : 255]	
IP Address Oct4	240		[0 : 255]	
Netmask Oct1	255		[0 : 255]	
Netmask Oct2	255		[0 : 255]	
Netmask Oct3	255		[0 : 255]	
Netmask Oct4	0		[0 : 255]	
Gateway IP Oct1	192		[0 : 255]	
Gateway IP Oct2	168		[0 : 255]	
Gateway IP Oct3	37		[0 : 255]	
Gateway IP Oct4	10		[0 : 255]	

In the case of relay that has updated previously its Bootcode (Sections 2), the IP address already has been assigned in the previous process (see Figure 5–14:).

In both cases, it is necessary to check that there is no other equipment connected with the same IP address in the same net, to avoid collision.

In case of a back-to-back connection from a PC to the relay (through a crossover Ethernet cable), the IP address of the relay needs to be compatible with the TCP/IP configuration of the computer.

For example, if the relay settings are:

IP address: 192.168.37.240,

Netmask: 255.255.255.0 and

Gateway: 192.168.37.10.

The computer settings have to follow the model:

IP address: 192.168.37.XXX

Netmask: 255.255.255.0 and

Gateway: 192.168.37.10 (if desired).

XXX is a number between 0 and 255 that is not assigned to any other device to avoid collisions.

If there are not TCP/IP settings according to this model in the computer, it should be added (in order to communicate with the relay) following these steps:

Go to the **Control Panel** of the computer and select the **Network** option (the name of this option may depend on the PC operative system).



Figure 5–2: NETWORK IN CONTROL PANEL

In Network, enter in Protocols and select TCP/IP protocol by clicking on Properties.

dens DNS WINS Addens Routing
SOUCH server. If your network domains and provide the former server, your network administrator for an address, and then type it in space below.
gen 3Con Megahetz LAN PC Cad (Ethernet) Classin an IP addess hon a DHCP server Specity an IP addess P Addess P Addess 13.111.32.54 Special Galeway 3.111.32.11

Figure 5–3: TCP/IP PROPERTIES

In **IP address** tab, select **Advanced...** (Figure 5–3: TCP/IP PROPERTIES) and add a new address in the PC that corresponds to the same LAN that the relay has (in the example bellow 192.168.37.54).



Figure 5–4: IP ADDRESS FOR COMPUTER

Windows allows Multihosting, so it permits having as many directions as desired. It is necessary to turn off and on the computer to activate the new address that has been assigned to the PC.

Operating system update is performed using EnerVista 650 Setup. For this purpose, it is required that there is no communication between the program and the relay, and that no configuration file is open.

In this case, menu option *Upgrade Operating System* will be enabled under the EnerVista 650 Setup *Communication* menu.

During the operative system updating process, all the data stored in the relay will be lost, so it is required to save all calibration, settings, oscillography, etc. from the relay before the upgrade. It is extremely important to save the relay settings and calibration before continuing with the process. In this step of the updating process if the user do not want to continue, click on the NO option and no change will be perform to the relay.

EnerVista	a F650 Setup	×
•	All RELAY INFORMATION will be LOST!. Please, be sure of having saved CALIBRATION SETTINGS, PROTECTION and CONTROL SETTINGS, and RELAY CONFIGURATION before upgrading. Do you want to proceed? Sí No	1

Figure 5–5: LOST DATA WARNING MESSAGE

For upgrading the operative system, it is required to connect an RS232 cable to the front of the relay, and an Ethernet cable to the rear port (COM3). The serial communication parameters will be the ones selected in the **Communications > Computer** menu, where the COMX port (the port to be used in the upgrade) must be selected. As regards Ethernet communication, if the upgrade is to be performed through a hub or switch, it is required to connect the relay to the hub or switch through a direct 10/100 base T cable.

If the connection is made directly from the PC to the relay it is necessary to use a 10/100 Base T crossover cable. This last connection will be obligatory for relays with Fiber Optic Ethernet, although it will not be necessary to change the internal switch. During the upgrade, the system will show the following message indicating the procedure to be followed.

WARNIN	IG 🛛 🔀
?	Please connect the Relay to the PC by BOTH: 1. A RS232 direct cable (from the front RS232 port of the relay to a PC 232 port, without a null modem) 2. An ethernet cable (straight thru if both connected to a switch or hub, or crossover if connected back-to-back without a hub)
	BOTH CONNECTIONS ARE REQUIRED TO UPGRADE THE BOOT PROGRAM! Do you want to proceed?



# NOTE

To obtain more information about the Relay network configuration, please refer to section 5.1.1 COMMUNICATION PARAMETERS

# **5 BOOTCODE AND FIRMWARE UPDATE**

After accepting to proceed, a window will open up for selecting a temporary IP Address for the boot update. It is advisable to set the IP Address that is going to be used lately in the relay for Ethernet connection.

UN
Cancel

Figure 5–7: TEMPORARY IP ADDRESS SELECTION FOR BOOT UPDATE

After entering the temporary IP address, a window will open up for selecting the appropriate file from the GE Multilin web site or Product CD.

Open File				? ×
Look jn:	🚔 Boot Program	•	۲	
Boot Prog	ram_V220.bin			
File <u>n</u> ame:	Boot Program_V220.bin			Open N
Files of type:	Binary file (* bin)		<b>.</b>	Cancel
A 100 10 10 10 10 10 10	Tenned me (rend		_	Cancel

Figure 5-8: BOOT FILE SELECTION

Once the appropriate boot program file has been selected, the program will proceed to load and update the relay's boot memory.

F650 Upgrade B	105		
	- Status	Loading update file . Please wait	



## **5.2 BOOT CODE UPDATE**

After the boot memory loading, the program shows a message requiring turning off and back on the relay while the progress bar is in course.

F650 Upgrade I	BIOS	
	Switch it OFF & ON now	

Figure 5–10: SWITCH THE RELAY OFF AND ON TO START THE BOOT PROCEDURE

It is important to turn the Relay off and on again during the time shown by the progress bar; in case this time expires, the program will offer the option to continue with the process or to postpone, verify the correct RS232 connections and try again later. Notice that the serial port used in the boot update procedure is the one selected in the "*Communication>computer*" menu.



Figure 5–11: ERROR MESSAGE FOR COMMUNICATIONS PROBLEMS

If the serial communication between EnerVista 650 Setup and the relay has been successful the program shows a message to select to update the current version to the new one.



Figure 5–12: UPDATE CURRENT VERSION?

At this moment, selecting "YES" in the "Update current version?" option will start, beginning with the relay flash memory deletion, so at this point all the information stored in the relay will be lost.

Until now, no important change has been made to the relay, the boot memory updating process has simply been prepared.

The process of flash memory erasing and boot memory file loading can take some minutes, during which a progress bar is displayed.

F650 Upgrade B	Status	
	Erasing Flash Memory	

Figure 5–13: ERASING FLASH MEMORY

Once the memory has been erased and the files updated in the relay, the parameters for the Ethernet communications parameters must be assigned (Figure 5–14:). The requested values are the IP address and the gateway

Set IP Address	
Set Relay IP Address (e.g.192.168.37.240)	192 . 168 . 37 . 240
Set Relay Gateway (e.g.192.168.37.10)	192 . 168 . 37 . 10
	ОК

Figure 5–14: ETHERNET PARAMETERS

These values should match the LAN structure in which the relay will be connected.

The gateway must be the one used in the LAN structure connecting the relay. The relay IP address should have the first three octets corresponding with the Gateway and the last octet must be a free IP address reserved to the relay to avoid possible collisions with other devices.

After assigning the Ethernet parameters, the update of the boot memory program has been completed successfully .

F650 Setup	×
ogram successfully u	pdated!
Aceptar	
	ogram successfully u

Figure 5–15: BOOT PROGRAM UPDATED

After boot memory update, the equipment firmware must also be updated (Section 5.3).

The F650 equipment includes a mechanism that allows the update of the internal program called firmware, to new versions that are periodically published in the GE Multilin web.

The relay settings and configuration will be lost, so it is advisable to save them to a file. For firmware revisions lower than 1.50, it is required to save calibration settings in a file before updating the F650 to a new firmware version. In case of versions higher than 1.50, the calibration retrieval process is automatic and it is not necessary to save them to a file (nevertheless is always advisable to do it). Take into account that if the operative system (bootcode) has been previously updated, all the data (including calibration settings) would be lost.

In case of error during the firmware updating process, the user could repeat the whole process as many times as necessary, this is possible thanks to an independent boot memory (bootcode).

The firmware updating process should be done through the EnerVista 650 Setup software, after connecting the relay by Ethernet port (COM3).

#### **5.3.1 FIRMWARE UPDATE**

Once the communication with the relay through Ethernet connection has been verified<sup>1</sup>, enter the EnerVista 650 Setup program, select **Communication** and the **Upgrade Firmware Version** option.

At this point, proceeding with the update will erase all the data stored in the equipment, including the calibration settings in firmware version previous to 1.50. Therefore, it is necessary to save all settings to a file before following with the process.

After accepting to proceed, a window will open up for the update parameter for the F650 firmware update process. In firmware version previous to 1.70 the EnerVista 650 Setup program asked for the IP address of the relay to be updated and its serial number. In versions 1.70 and higher it is also necessary to enter the ordering code for the relay. See figure below:

This change is due to the multilingual implementation in F650 devices. See ordering code section in product description chapter in this manual.



Figure 5–16: FIRMWARE SELECTION WINDOW

<sup>1.</sup> Calibration settings should be stored in a file before updating the firmware.

Go to EnerVista 650 Setup main menu "*Communication > Calibration > Get Calibration Settings*" Store the file in the PC using the relay serial number, for instance, as the name of the file.

# 5 BOOTCODE AND FIRMWARE UPDATE

Once the upgrade parameters have been entered, relay IP address, serial number and ordering code, press the "**Upgrade Firmware**" button. When communication has been established, the program will show a message requesting to turn off and back on the relay to continue with the upgrade process.

Once the relay has been turned off and on again, a new screen allows selecting the folder that contains the firmware update files ("update.txt" file must be located in this folder). This Update.txt file is located in the folder where the desired firmware upgrade files are. This firmware update files can be found in the GE Multilin web site.

If the files are downloaded from the web, they are compressed in a zip file. It should be decompressed in a temporary directory from which the update.txt file will be selected.

Once the Update.txt file is selected, the "Upgrade Firmware" button will be enabled. Press this button to initiate the relay firmware upgrade process. A voltage range selection window will appear, this voltage range is connected to the serial number of the relay. The EnerVista 650 Setup program automatically pre-selects the appropriate voltage range for the unit. If the voltage range is not selected correctly the error in voltage measurements will be 20 %.

Voltage rai	nge detected!
Changing selection ma	ay cause metering errors
V Range	
C Normal V Range (0-220 V)	Extended V Range (0-270 V)
<u> </u>	k

Figure 5–17: VOLTAGE RANGE SELECTION

During the process, the program displays the files that are being updated. When the file transfer is finished, a message appears noticing that it is necessary to wait sometime before resetting the unit, in order to start working with the new firmware version in the relay. When the whole process has finished a message will be displayed asking to reboot the F650.

At this point, the firmware upgrade procedure is finished and the relay ready to be powered down and back up to check that the firmware has been upgraded properly.

When upgrading the firmware the entire settings and relay configuration are reset to factory default value.

Once the equipment has been properly checked, the F650 is ready to be used.

Remember that calibration settings and configuration must be loaded to the relay. To recover the relay calibration:

Go to EnerVista 650 Setup main menu:

Communication > Calibration > Set calibration Settings to store in the relay the calibration settings if necessary.

File > Config file (\*.650) Converter to convert the setting and configuration file \*.650 for the relay (if is was in a previous version format) to the new version (see section 3.1.6 File MENU OVERVIEW in human interfaces in this manual)

*File > Send info to relay* to send the new settings and configuration file to the unit.

Notice that boot program and firmware upgrade will erase all the data contained in the relay, thus it is advisable to save all the data, oscillography, events, settings and configuration files previously.

# 5.4.1 BOOT MEMORY UPDATE (\*)

- 1. NSTALL THE PROPER VERSION OF THE ENERVISTA 650 Setup PROGRAM.
- 2. CONNECT AN RS-232 CABLE IN THE FRONT PORT OF THE RELAY AND ETHERNET ONE AT THE REAR ETHERNET PORT (CROSSOVER CABLE FOR BACK-TO-BACK CONNECTION AND DIRECT ETHERNET CABLE FOR HUB OR SWITCH).
- 3. GET CALIBRATION SETTINGS (AND SAVE IT TO A FILE).
- 4. SAVE ALL THE DATA FROM THE RELAY (SETTINGS, OSCILLOGRAPHY, EVENTS).
- 5. FROM THE ENERVISTA 650 Setup PROGRAM SELECT COMMUNICATION/UPGRADE OPERATING SYSTEM.
- 6. FOLLOW THE INDICATIONS OF THE PROGRAM AND SELECT THE BOOT PROGRAM BIN FILE.
- 7. WHEN REQUIRED BY THE PROGRAM SWITCH OFF AND BACK ON THE RELAY.
- 8. CONTINUE WITH THE PROCESS AND SET THE IP ADDRESS AND GATEWAY WHEN REQUIRED.

### 5.4.2 FIRMWARE UPDATE (\*)

- 1. SET THE APPROPRIATE IP ADDRESS IN THE RELAY.
- 2. SET THE APPROPRIATE IP ADDRESS IN THE PC.
- 3. FROM THE ENERVISTA 650 Setup PROGRAM SELECT "COMMUNICATION/UPGRADE SOFTWARE VERSION".
- 4. ENTER THE IP ADDRESS, SERIAL NUMBER AND ORDERING CODE OF THE RELAY TO UPDATE.
- 5. WHEN REQUIRED BY THE PROGRAM SWITCH OFF AND BACK ON THE RELAY.
- 6. LOCATE THE UPDATE.TXT FILE ACCORDING TO THE MODEL OF THE RELAY.
- 7. PRESS UPGRADE FIRMWARE AND INITIATE THE UPGRADE PROCESS.
- 8. TO COMPLETE THE PROCEDURE, SWITCH OFF AND BACK ON THE RELAY WHEN REQUIRED BY THE PROGRAM.
- 9. SET CALIBRATION SETTINGS (FROM THE PC TO THE RELAY) (for versions lower than 1.50).
- 10. THE SETTINGS AND CONFIGURATION ARE NOW SET TO FACTORY DEFAULT.
- 11. SEND THE NEW SETTINGS AND CONFIGURATION FILES TO THE RELAY IF NECESSARY.

(\*) The boot code upgrade must be performed using a crossed copper cable (RJ45) connected to the PC. It is not necessary to modify the internal fiber/cable switch, as the upgrade is carried out at 10 Mb/s, and thus there is not cable/ fiber conflict.

This fact does not apply to the firmware upgrade, which can be performed either with the Ethernet fiber connection, or with the cable connection.

Verify that the relay has not suffered any damage during transportation, and that all screws are correctly fixed, and all relay terminal boards are in good condition.

Verify that the information shown on the relay front plate corresponds to the data shown on the display, and to the requested relay model.

Display information:

	 Firmware version
F650 X.XX(K.KK)	 Kernel version
GENERAL ELECTRIC	Madal
19200N81 MODBUS:254	Model
All devices running on AC current are affected by frequency. As a non-senoidal wave is the result of a fundamental wave plus a series of harmonics from this fundamental wave, it can be deducted that devices running on AC current are influenced by the applied waveform.

For a correct testing of relays running on AC current, it is fundamental to use a current and/or voltage senoidal waveform. The pureness of a senoidal wave (lack of harmonics) cannot be expressed specifically for a specific relay. However, any relay incorporating sintonized circuits, R-L and R-C circuits, will be affected by non-senoidal waveforms, as in the case of F650.

These relays respond to the voltage waveform in a different way to the majority of AC current voltmeters. If the power supply network used for the testing contains wide harmonics, the voltmeter and relay responses will be different.

Relays have been calibrated in factory using a Network of 50 or 60 Hz with a minimum harmonic content. When the relay is tested, a power supply network with no harmonics in its waveform must be used.

The ammeters and chronometers used for testing the pickup current and relay operation time must be calibrated and their accuracy must be better than the relay's. The power supply used in the tests must remain stable, mainly in the levels near the operation thresholds.

It is important to point out that the accuracy with which the test is performed depends on the network and on the instruments used. Functional tests performed with unsuitable power supply network and instruments are useful to check that the relay operates properly and therefore its operating characteristics are verified in an approximate manner. However, if the relay would be calibrated in these conditions, its operational characteristics would be outside the tolerance range values.

The following sections detail the list of tests for verifying the complete relay functionality.

During all tests, the screw located on the rear of the relay must be grounded.

For verifying isolation, independent groups will be created, and voltage will be applied as follows:

2200 RMS volts will be applied **progressively** among all terminals in a group, short-circuited between them and the case, during one second.

2200 RMS volts will be applied progressively between groups, during one second.

WARNING: No communication circuit shall be tested for isolation.

Groups to be created will depend on the type of modules included in F650, selectable according to the model.

The following table shows the different groups depending on the module type:

SOURCE 1:	SOURCE 2:	MAGNETIC MODULE.
<b>G1</b> : H10, H18	<b>G1</b> : H1, H9	<b>G1</b> : A5A12
<b>G2</b> : H13, H14, H15	<b>G2</b> : H4, H5, H6	<b>G2</b> : B1B12
	10 FZ (SUFERVISION)	
<b>G1</b> (Inp. 1): F19	G1 (Spv 1): F14	<b>G1</b> (Inp. 1): G19
G2 (Inp. 2): F1018	<b>G2</b> (Inp. 1): F59	G2 (Inp. 2): G1018
G3 (Out.): F1936	G3 (Inp. 2): F1014	<b>G3</b> (Out.): G1936
	G4 (Spv 2): F1518	
	<b>G5</b> (Out.): F1930	
	<b>G6</b> (Out.): F31.36	

Feed the relay and verify that when commanding a LED reset operation, all LED indicators light up and they are turned off when pressing the **ESC** key for more than 3 seconds.

Feed the relay to the minimum and maximum voltage. For each voltage value, verify that the alarm relay is activated when there is voltage, and it is deactivated when there is no feed. If the power supply source incorporates AC feed, this test will be performed also for VAC.

If the relay incorporates a redundant power supply, these tests shall be performed on both power supplies.

Voltage values to be applied will be the ones indicated below according to the relay model:

SUPPLY	V MIN.	V MAX.
HI/HIR 110-250 Vdc 120-230 Vac	88 Vdc 96 Vac	300 Vdc 250 Vac
LO/LOR 24-48 Vdc	20 Vdc	57.6 Vdc

NOTE: Codes HIR and LOR correspond to a redundant power supply

Verify that available communication ports allow communication with the relay.

Ports to be checked are as follows:

Front:RS232

Rear:2 x RS485, 2 x Fiber Optic - Serial, 2 x Fiber Optic - Ethernet, 1 x RJ45 - Ethernet.

A computer with EnerVista 650 Setup software and an appropriate connector must be used.

Set the relay as follows

GENERAL SETTINGS				
NAME	VALUE	UNITS	RANGE	
PHASE CT RATIO	1.0	0.1	1.0-6000.0	
GROUND CT RATIO	1.0	0.1	1.0-6000.0	
STV GROUND CT RATIO	1.0	0.1	1.0-6000.0	
PHASE VT RATIO	1.0	0.1	1.0-6000.0	
PHASE VT CONNECTION	WYE	N/A	WYE – DELTA	
NOMINAL VOLTAGE	100 V	0.1	1-250 V	
NOMINAL FREQUENCY	50 Hz	1 Hz	50-60 Hz	
PHASE ROTATION	ABC	N/A	ABC – ACB	
FREQUENCY REFERENCE	VI	N/A	VI-VII-VIII	
AUXILIARY VOLTAGE	VX	N/A	VX – VN	

## NOTE:

## ALL ANGLES INDICATED ARE DELAY ANGLES

## ALL VALUES OBTAINED IN THIS TEST MUST BE THE ONES CORRESPONDING TO THE DFT

## 6.7.1 VOLTAGES

Apply the following current and frequency values to the relay:

CHANNEL ANGLE		FREQUENCY					
		50 Hz	60 Hz	50 Hz	60 Hz	50 Hz	60 Hz
VI	0°	0	5	50	100	150	275
VII	120º	0	5	50	100	150	275
VIII	240°	0	5	50	100	150	275
VX	0°	0	5	50	100	150	275

Verify that the relay measures the values with an error of +/-1 % of the applied value plus 0,1% of full scale (275V).

## 6.7.2 PHASE CURRENTS

Apply the following voltage and frequency values to the relay:

CHANNEL ANGLE		FREQU	FREQUENCY				
		50 Hz	60 Hz	50 Hz	60 Hz	50 Hz	60 Hz
la (A)	45°	0	15	10	5	1	0.1
lb (A)	165°	0	15	10	5	1	0.1
Ic (A)	285°	0	15	10	5	1	0.1
IG(A)	0°	0	15	10	5	1	0.1
ISG(A)	0°	0	5	1	0.1	0.01	0.005

Verify that the relay measures the values with an error lower than +/-0.5% of the test value or+/- 10 mA, whichever is greater, for phases and ground.

Verify that the relay measures the values with an error lower than +/-1.5% of the test value or+/- 1 mA, whichever is greater, for sensitive ground (SG).

## 6.7.3 ACTIVE, REACTIVE POWER, AND COS9 METERING

Equations to be applied for powers in a wye connection are as follows:

POWER PER PHASE	THREE-PHASE POWER
P=V*I*Cosφ	P=Pa+Pb+Pc
Q=V*I*Senφ	Q=Qa+Qb+Qc

Apply the following current and voltage values:

APPLIED VOLTAGE AND CURRENT VALUES PER PHASE			
PHASE A	PHASE B	PHASE C	V-I ANGLES
VI = 50 V, 0°	VII = 50 V , 120º	VIII = 50V, 240°	φ <b>=</b> 45°
la = 10∠45º	lb= 10∠165º	lc = 10∠285°	Cosφ= 0.707

With the indicated voltage and current values, verify that the power measure corresponds to theoretical values indicated in the following table:

THEORETICAL POWER VALUES				
PHASE A	PHASE B	PHASE C	THREE-PHASE	
Pa = 353.55 MW	Pb = 353.55 MW	Pc = 353.55 MW	P = 1060.66 MW	
Qa = 353.55 MVAr	Qb = 353.55 MVAr	Qc = 353.55 MVAr	Q = 1060.66 MVAr	

Maximum admissible error is +/-1% of the test value for P and Q, and 0.02 for  $\cos\varphi$ .

6.7.4 FREQUENCY

Frequency measure on channel VII (terminals A7-A8):

Apply 50 Vac at 50 Hz on channel VII. Maximum admissible error:+/- 10 mHz.

Apply 50 Vac at 60 Hz on channel VII. Maximum admissible error: +/- 12 mHz.

Frequency measure on channel Vx (terminals A11-A12):

Apply 50 Vac at 50 Hz on channel Vx. Maximum admissible error:+/- 10 mHz.

Apply 50 Vac at 60 Hz on channel Vx. Maximum admissible error: +/- 12 mHz.

Results:

CHANNEL	VOLTAGE (V)	SET FREQUENCY (HZ)	MEASURED FREQUENCY (HZ)
VII	50	50 Hz	
		60 Hz	
VX	50	50 Hz	
		60 Hz	

During all tests, the screw on the rear of the relay must be grounded.

#### **6.8.1 DIGITAL INPUTS**

During this test, the user will determine the activation/deactivation points for every input in the relay for the set voltage value of 30 Volts.

Verify that the error does not exceed +/- 10% (+10% on activation, -10% on deactivation)

Default board settings for the input test can be modified in EnerVista 650 Setup software in:

## Settings>Inputs/Outputs>Contact I/O>Board X

## X, will be substituted by the corresponding board:

F for board in first slot

G for board in second slot

H for board in first slot of CIO module

J for board in second slot of CIO module

Test settings for mixed board (type 1:16 inputs and 8 outputs) :

I/O BOARD TYPE 1 (MIXED)	
Voltage Threshold A_X	30 V
Voltage Threshold B_X	40 V
Debounce Time A_X	5 ms
Debounce Time B_X	5 ms
Input Type_X_CC1 (CC1)	POSITIVE
Input Type_X_CC16 (CC16)	POSITIVE

The inputs test is completed by groups of 8 inputs, as this type of board has 2 groups of 8 inputs with the same common. For the first 8 inputs, the voltage threshold setting is determined by Voltage Threshold A. For the next 8 inputs, the setting is Voltage Threshold B. Inputs (or contact converters, CC1 - CC16) must also be set to POSITIVE.

Test settings for mixed board (type 2: 8 digital inputs, 4 blocks for supervision and 8 outputs) :

I/O BOARD TYPE 2 (SUPERVISION)			
Voltage Threshold A_X	30 V		
Voltage Threshold B_X	40 V		
Debounce Time A_X	5 ms		
Debounce Time B_X	5 ms		
Input Type_X_CC1 (CC1)	POSITIVE		
Input Type_X_CC8 (CC8)	POSITIVE		

The inputs test is completed by groups of 4 inputs, as this type of board has 2 groups of 4 inputs with the same common. For the first 4 inputs, the voltage threshold setting is determined by Voltage Threshold A. For the next 4 inputs, the setting is Voltage Threshold B. Inputs (or contact converters, CC1 - CC8) must also be set to POSITIVE.

If the relay incorporates more input modules, this test must also be applied to them.

The correct activation of every output will be verified.

For every output, activation command of a single contact must be given, and then verify that only that contact is activated. Go to EnerVista 650 Setup Software (*Settings>Inputs/Outputs>Force Outputs*).

For switched contacts, the change of state of both contacts shall be verified.

#### 6.8.3 CIRCUIT CONTINUITY SUPERVISION INPUTS

Supervision inputs will be tested as normal inputs, revising the voltage level that will be 19 Volts.

Coil 1:

Apply 19 Vdc to both 52/a (terminals F1-F2) and 52/b (terminals F3-F4)"Coil 1" circuit supervision inputs and verify that they are activated.

Apply -19 Vdc to both 52/a (terminals F1-F2) and 52/b (terminals F3-F4)"Coil 1" circuit supervision inputs and verify that they are activated.

Remove voltage from both inputs and verify that it takes them 500 ms to change state (deactivate).

## Coil 2:

Apply 19 Vdc to both 52/a (terminals F15-F16) and 52/b (terminals F17-F18)"Coil 2" circuit supervision inputs and verify that they are activated.

Apply -19 Vdc to both 52/a (terminals F15-F16) and 52/b (terminals F17-F18)"Coil 2" circuit supervision inputs and verify that they are activated.

Remove voltage from both inputs and verify that it takes them 500 ms to change state (deactivate).

**6.8.4 LATCHING CIRCUITS** 

Send a closing command to the latched contact (F31-F33).

Make circulate a current of 200 mA through the contact in series with the sensing terminal.

Send an opening command and verify that the contact does not open.

Interrupt current and check than the contact is released.



Repeat the test for the other latched contact (F34-F36).

Connect current sources to the relay according to the wiring diagram. Current and voltage input terminals are as follows:

PHASE	CONNECTIONS
Current	
IA	B1-B2
IB	B3-B4
IC	B5-B6
IG	B9-B10
ISG	B11-B12
Voltage	
VI	A5-A6
VII	A7-A8
VIII	A9-A10
VX	A11-A12

Set the relay to trip for the protection element being tested. Configure any of the outputs to be activated only by the protection element being tested.

Apply 0.9 times the Pickup current and check that the relay does not trip.

Gradually increase the current value and verify that the relay operates between 1 and 1.1 times the set pickup current. The relay must trip by instantaneous in a time frame of 10 to 55 ms. All the relay trip contacts must operate, as well as the contact set as 50.

Remove current and apply it again suddenly to a value of 4 times the pickup current. The relay should trip instantaneously in a time frame of 10 to 45 ms.

Test one point for each phase and group of the protection element.

50 ELEMENTS TEST PARAMETERS								
Element Settings (50PH, 50PL, 50G y 50SG)								
Setting	Value	Units						
Function	Enabled							
Input	RMS	NA						
Pickup Level	3	A						
Delay time	0	Seconds						
Test Execution								
Configure one output for 50 Trip								
Apply times I pickup	Element Tri	ρ	Tripping times (ms)					
0.9 x Pickup	NO		NA					
1.1 x Pickup	YES		10-55					
4 x Pickup	YES		10-45					
Elements	Phase		Group					
50PH and 50PL	IA		0					
	IB		0					
	IC		0					
50G	IG		0					
50SG	ISG		0					

Set the relay to trip for the protection element being tested. Configure any of the outputs to be activated only by the protection element being tested.

Apply 0.9 times the Pickup current and check that the relay does not trip.

Apply 1.5 times the Pickup current. The relay should trip according to the time corresponding to its set curve.

Apply 5 times the Pickup current. The relay should trip according to the time corresponding to its set curve.

PROTECTION	ELEMENT	SETTINGS (51PH	H, 51PL, 51N,	51G AND 46)		
SETTING			VALUE		UNIT	
FUNCTION		ENABLED				
INPUT			PHASOR (D	OFT)		
PICKUP LEVE	L		1		Α	
CURVE			MODIFY FC	R EACH TEST		
TD MULTIPLIE	ER		MODIFY FC	R EACH TEST		
VOLTAGE RES	STRAINT		DISABLED			
ELEMENT	PHASE	CURVE TYPE	DIAL	TIMES	TRIPPING TIM	ES (SEC)
				IPICKUP	THEORETICA L	ADMISSIBLE
51PH	IA	IEEE Ext Inv	0.5	0.9	NA	
				1.5	11.34	[11.00 – 11.60]
				5	0.648	[0.600 - 0.710]
IB	IEC Curve A	0.05	0.9	NA		
				1.5	0.860	[0.750 – 0.950]
				5	0.214	[0.200 - 0.300]
51PL	IC	IEEE Ext Inv	0.5	0.9	NA	
				1.5	11.34	[11.00 – 11.60]
				5	0.648	[0.600 – 0.710]
	IB	IEC Curve A	0.05	0.9	NA	
				1.5	0.860	[0.750 – 0.950]
				5	0.214	[0.200 – 0.300]
51N	IC	IEEE Ext Inv	0.5	0.9	NA	
				1.5	11.34	[11.00 – 11.60]
				5	0.648	[0.600 - 0.710]
51G	IG	Definite Time	2	0.9	NA	
				5	2.000	[1.900 – 2.100]
46	12	IEC Curve A	0.05	0.9	NA	
				1.5	0.860	[0.750 - 0.950]
				5	0.214	[0.200 - 0.300]

In order to test directional units in the relay, instantaneous trips will be commanded.

Two points will be tested, per phase, test element.

The factory default configuration of the relay makes the overcurrent elements be supervised by directional units. This way, if the directional element is enabled and detects the fault in the block direction, then the overcurrent unit will not operate. If the directional element is not enabled or if it is enabled and it detects a fault in a trip direction, then the overcurrent unit will operate if the set current level is exceeded.

## 6.12.1 67P ELEMENT

Activate only protection elements 50PH and 67P and set the relay as follows:

67P Settings		50PH Settings			
Function	ENABLED	Function	ENABLED		
MTA	45 Deg	Input	PHASOR (DFT)		
Direction	FORWARD	Pickup Level	0.50 A		
Block Logic	PERMISSION	Trip Delay	0.30		
Pol V Threshold	30 V	Reset Delay	0.00		

Configure one of the outputs to be activated only by unit 50PH.

Apply the following tests:

ELEMENTS	PHASE UNDER TEST			POLARIZATION PHASE			ELEMENT TRIP
	CHANNE	MAGNITUDE		CHANNEL	MAGNITUDE		
	L	MOD	ARG		MOD	ARG	
50PH/67P	IA	IA 2 A 0 <sup>0</sup>	0°	VIII	60 V	0°	NO
					60 V	180°	YES
	IB 2 A	2 A	0°	VI	60 V	0°	NO
					60 V	180º	YES
	IC 2 A 0°	0°	VII	60 V	0°	NO	
					60 V	180º	YES

#### 6.12.2 67N ELEMENT

Activate only protection elements 50N and 67N and set the relay as follows:

67N Settings		50N Settings			
Function	ENABLED	Function	ENABLED		
MTA	-45 Deg	Input	PHASOR (DFT)		
Direction	FORWARD	Pickup Level	0.50 A		
Polarization	VO	Trip Delay	0.30		
Block Logic	PERMISSION	Reset Delay	0.00		
Pol V Threshold	10 V		·		

Configure one of the outputs to be activated only by unit 50G.

Apply the following tests:

ELEMENTS	PHASE UN	PHASE UNDER TEST			ON PHAS	ELEMENT TRIP	
	CHANNE	MAGNITUDE		CHANNEL	MAGN	ITUDE	
	L	MOD	ARG		MOD	ARG	
50N/67N	IA	2 A	0°	VI	60 V	0°	NO
					60 V	180°	YES
	ΙB	0 A	0°	VII	0 V	0°	
	IC	0 A	0°	VIII	0 V	0°	

## 6.12.3 67G ELEMENT

Activate only protection elements 50G and 67G and set the relay as follows:

67G SETTINGS		50G SETTINGS	50G SETTINGS			
Function	ENABLED	Function	ENABLED			
MTA	-45 Deg	Input	PHASOR (DFT)			
Direction	FORWARD	Pickup Level	0.50 A			
Polarization	VO	Trip Delay	0.30			
Block Logic	PERMISSION	Reset Delay	0.00			
Pol V Threshold	10 V		·			

Configure one of the outputs to be activated only by unit 50G.

Apply the following tests:

ELEMENTS	PHASE UNDER TEST			POLARIZATION PHASE			ELEMENT TRIP
	CHANNE	MAGNITUDE		CHANNEL	MAGN	ITUDE	
	L	MOD	ARG		MOD	ARG	
50G/67G	IG	2 A	0°	VI	60 V	0°	NO
					60 V	180°	YES
				VII	0 V	0°	
				VIII	0 V	0°	

Activate only protection elements 50SG and 67SG and set the relay as follows:

67SG SETTINGS		50SG SETTINGS	50SG SETTINGS			
Function	ENABLED	Function	ENABLED			
MTA	-45 Deg	Input	PHASOR (DFT)			
Direction	FORWARD	Pickup Level	0.50 A			
Polarization	VO	Trip Delay	0.30			
Block Logic	PERMISSION	Reset Delay	0.00			
Pol V Threshold	10 V		·			

Configure one of the outputs to be activated only by unit 50SG.

Apply the following tests:

ELEMENTS	PHASE UNDER TEST			POLARIZATION PHASE			ELEMENT TRIP		
	CHANNE L	MAGNITUDE		CHANNEL	MAGN	ITUDE			
		MOD	ARG		MOD	ARG			
50SG/67SG	ISG	2 A	0°	VI	60 V	0°	NO		
					60 V	180º	YES		
						VII	0 V	0°	
				VIII	0 V	0°			

Set the relay to trip for the protection element being tested. Configure any of the outputs to be activated only by the protection element being tested.

Set the relay as follows:

PHASE UV (27P)				
Function	ENABLED			
Mode	PHASE-GROUND			
Pickup Level	50 V			
Curve	DEFINITE TIME			
Delay	2.00 sec			
Minimum Voltage	30 V			
Logic	ANY PHASE			
Supervised by 52	DISABLED			

Apply voltage as indicated on the table over the undervoltage setting level and verify that the relay does not trip. Decrease voltage level gradually and verify that the relay trips for the set voltage (with an admissible error of 5%).

ELEMENT	PHASE	CURVE	PICKUP	DELAY	APPLIED	TRIPPING TIMES (S)	
		VOLTAGE	THEORETICA L	ADMISSIBLE			
27P	VI	DEFINITE 50 V	50 V	2	55 V	NO TRIP	NA
	TIME			45 V	2.000 sec	[2.000 – 2.100]	

## 6.13.2 27X ELEMENT

AUXILIARY UV (27X	)
Function	ENABLED
Pickup Level	50 V
Curve	DEFINITE TIME
Delay	2.00 sec

Apply voltage as indicated on the table over the undervoltage setting level and verify that the relay does not trip. Decrease voltage level gradually and verify that the relay trips for the set voltage (with an admissible error of 5%).

ELEMENT	INPUT	CURVE	PICKUP	DELAY	APPLIED	TRIPPING TIM	E (S)
			LEVEL		VOLTAGE	THEORETICA L	ADMISSIBLE
27X	VX DEFINITE 50 V	50 V	2	55 V	NO TRIP	NA	
					45 V	2.000 sec	[2.000 – 2.100]

#### 6.14.1 59P ELEMENT

Set the relay to trip for the protection element being tested. Configure any of the outputs to be activated only by the protection element being tested.

Set the relay as follows:

PHSE OV (59P)				
Function	ENABLED			
Pickup Level	120 V			
Trip Delay	2.00			
Reset Delay	0.00			
Logic	ANY PHASE			

Apply voltage as indicated on the table under the overvoltage setting level and verify that the relay does not trip. Verify that the relay trips for the set voltage (with an admissible error of 5%).

ELEMENT	NT PHASE PICKUP LEVEL TRIP DELAY APPLIED (VOLTS) (SECONDS) VOLTAGE (V)		TRIPPING TIME (S)			
		(VOLIS)	(SECONDS)	VOLTAGE (V)	THEORETICA L	ADMISSIBLE
59P	VII	120	2	114	NO TRIP	NA
				132	2	[1.9–2.1 ]
		132	2	[1.9 – 2.1]		

## 6.14.2 59X ELEMENT

Set the relay as follows:

GENERAL SETTINGS	
Auxiliary Voltage	VX

AUXILIARY OV (59P)				
Function	ENABLED			
Pickup Level	120 V			
Trip Delay	2.00			
Reset Delay	0.00			
Logic	ANY PHASE			

Apply voltage as indicated on the table under the overvoltage setting level and verify that the relay does not trip. Verify that the relay trips for the set voltage (with an admissible error of 5%).

ELEMENT	INPUT	PICKUP LEVEL	TRIP DELAY	APPLIED	TRIPPING TIME (S)	
		(VOLIS)	(SECONDS)	VOLTAGE (V)	THEORETICA L	ADMISSIBLE
59X	VX	120	120 2 114	114	NO TRIP	NA
				132	2	[1.9–2.1 ]
				132	2	[1.9 – 2.1]

## 6.14.3 59NH AND 59NL ELEMENTS

Set the relay as follows

GENERAL SETTINGS	
Auxiliary Voltage	VN

NEUTRAL OV HIGH/LOW (59NH/59NL)				
Function	ENABLED			
Pickup Level	120 V			
Trip Delay	2.00			
Reset Delay	0.00			

Apply voltage as indicated on the table under the overvoltage setting level and verify that the relay does not trip. Verify that the relay trips for the set voltage (with an admissible error of 5%).

ELEMENTS	INPUT	PICKUP LEVEL (VOLTS)	TRIP DELAY (SECONDS)		TRIPPING TIME (S)	
				VOLTAGE (V)	THEORETICA L	ADMISSIBLE
59NH/59NL	IH/59NL VX 120 2	2	114	NO TRIP	NA	
				132	2	[1.9–2.1]
				132	2	[1.9 – 2.1]

This element can also be tested by applying only phase voltages. For this purpose, it is necessary to set Auxiliary Voltage = VX. In this condition, Vn voltage is calculated as a sum of the phase voltages.

## 6.14.4 47 ELEMENT - NEG SEQ OV

Set the relay as follows:

NEG SEQ OV (47)			
Function	ENABLED		
Pickup Level	50 V		
Trip Delay	2.00		
Reset Delay	0.00		

Apply voltage as indicated on the table under the overvoltage setting level and verify that the relay does not trip. Verify that the relay trips for the set voltage (with an admissible error of 5%).

CHANNEL	APPLIED VOLTAGE (V)	ANGLE	TRIPPING TIME (S	6)
			THEORETICAL	ADMISSIBLE
VI	65	0°	NO TRIP	NA
VII	65	120°		
VIII	65	240°		
VI	55	0°	2	[1.9–2.1 ]
VII	55	240°		
VIII	55	120°		
VI	45	0°	NO TRIP	NA
VII	45	240°		
VIII	45	120°	1	

NOTE: All angles mentioned on the tables are delay angles, where a balanced ABC system would be composed by:

CHANNEL	APPLIED VOLTAGE (V)	ANGLE
VI	65	0°
VII	65	120°
VIII	65	240°

6

Set the relay to trip for the protection element being tested. Configure any of the outputs to be activated only by the protection element being tested.

Set the relay as follows:

GENERAL SETTINGS	
Nominal Frequency	50 Hz

ELEMENT SETTINGS	ELEMENT SETTINGS		
FREQUENCY (81)	81U	810	
Function	ENABLED	ENABLED	
Pickup Level	47.50 Hz	52.50 Hz	
Trip Delay	2.00 sec	2.00 sec	
Reset Delay	0.00 sec	0.00 sec	
Minimum Voltage	30 V	30 V	

Apply voltage as indicated on the table, modifying frequency from the maximum threshold (48 Hz) to the minimum (46 Hz) for 81U, and from the minimum (52 Hz) to the maximum (54 Hz) for 81O, in steps of 10 mHz.

Verify that the relay trips at the set frequency in the corresponding element with an error of 3% ó +/-50 mHz.

Apply a voltage that is lower than the "Minimum Voltage" setting, with a frequency under (81U) or over (81O) the setting, and verify that the relay does not trip.

ELEMENTS	PHASE		TRIP DELAY	APPLIED	FREQUENCY	TRIPPING TIM	E (S)
		(HZ)	(SECONDS)	VOLTAGE (V)	THRESHOLDS	THEORETICA L	ADMISSIBLE
81U	VII	47.5	2	80	48 Hz	No trip	NA
					46 Hz	2	[1.9 –2.2]
				25	46 Hz	No trip	NA
81 O	VII	52.5	2	80	52 Hz	No trip	NA
					54 Hz	2	[1.9 –2.2]
				25	54 Hz	No trip	NA

6

## Set protection element 79 as follows:

RECLOSER	
Function	ENABLED
Max Number Shots	4
Dead Time 1	2.10 sec
Dead Time 2	4.10 sec
Dead Time 3	6.10 sec
Dead Time 4	8.10 sec
Reclaim Time	3.00 sec
Cond. Permission	ENABLED
Hold Time	7.00 sec
Reset Time	5.00 sec

## Set the relay to trip by 50PH

50PH SETTINGS	
Function	ENABLED
Input	RMS
Pickup Level	3 A
Trip Delay	0.00 s
Reset Delay	0.00 s

## 6.16.1 RECLOSING CYCLE

Connect a latching relay simulating the breaker managed by the F650 unit.

Once the relay is set, close the breaker and wait for 5 seconds.

After this time, the recloser is ready to initiate the reclosing cycle.

Command a 50PH trip and verify that the breaker opens and the relay recloses in 2.1 seconds.

Command a 50PH trip and verify that the breaker opens and the relay recloses in 4.1 seconds.

Command a 50PH trip and verify that the breaker opens and the relay recloses in 6.1 seconds.

Command a 50PH trip and verify that the breaker opens and the relay recloses in 8.1 seconds.

Command a 50PH trip and verify that the breaker opens and the recloser passes to Lockout.

Verify the correct operation of programmed outputs

Tripping times must be within the following values:

Reclosing Cycle	e	
N⁰ shot	Theoretical time	Admissible time
1	2.1 sec	[1.8 – 2.3]
2	4.1 sec	[3.8 – 4.3]
3	6.1 sec	[5.8 – 6.3]
4	8.1 sec	[7.8 – 8.3]

## 6.16.2 RECLOSER STATUSES

## **BLOCK**

Activate the block input and verify that the recloser is in BLOCK status.

Close the breaker and wait for 5 seconds.

Command a trip and verify that the breaker opens but there is no reclose.

## INHIBITION BY RECLOSING CONDITIONS

Close the breaker and wait for 5 seconds.

Command a trip, verify that the breaker opens and wait for the first shot.

Activate the inhibition input and command a new trip.

Verify that the breaker opens, wait for 8 seconds and verify that the relay does not reclose.

## 6.16.3 EXTERNAL RECLOSE INITIATION

Close the breaker and wait for 5 seconds.

Activate the reclose initiation input and open the breaker, verify that the relay executes the first shot

Disable all protection elements except for Thermal Model (49).

Set the pickup level to 2 A.

Set the time constant  $\tau 1$  to 3 minutes and  $\tau 2$  t0 one time  $\tau 1$ .

Apply currents of 2, 5, and 10 times the tap and ensure that the operation times are within the range described on the following table:

RATED CURRENT (A)	APPLIED CURRENT (A)	TIMES DE SET TAP	OPERATION TIME (S)
	4.0	2	48.5 - 53.6
5	10.0	5	7.06 - 7.80
	20.0	10	1.77 - 1.95

After each measure, the thermal element must be reset to zero in order to start the next test at a zero thermal status condition.

Repeat the test selecting a time constant  $\tau$ 1 of 60 minutes. Verify that the operation time is within the range described on the following table:

RATED CURRENT (A)	APPLIED CURRENT (A)	TIMES DE SET TAP	OPERATION TIME (S)
	4.0	2	960 - 1072
5	10.0	5	141 - 156
	20.0	10	35.4 - 39

After each measure, the thermal element must be reset to zero in order to start the next test at a zero thermal status condition.

# 7

## Q1 Does the F650 support DNP and ModBus over the Ethernet port?

A1 F650 units support both protocols over both the asynchronous serial ports and the Ethernet LAN synchronous port using TCP/IP and UDP/IP layers over the Ethernet.

## Q2 Does this equipment support dual IP access?

A1 Yes, it supports two independent IP addresses in aliasing mode. Those address go in the communications settings Network0 and Network1.

## Q3 Is the protocol IEC 870-103 supported by the F650?

A3 At this moment it is not supported.

## Q4 Can the F650 be used as a DNP master station?

A4 Not at this moment. It works as a slave IED station for all protocols.

## Q5 How many communication ports are included in the F650?

A5 The equipment has 2 different boards, one for asynchronous serial ports and another for a high-speed synchronous Ethernet port. The first board has 2 comm ports, COM1 and COM2. COM2 is multiplexed with the front serial RS232 port, whereas the COM1 port is completely independent from COM2.

The synchronous LAN port is COM3.

## Q6 Are there one or two Ethernet ports?

A6 The equipment has only 1 Ethernet port. For redundant fiber optic versions, redundancy is done at the physical level (fiber optic) but there is just one port.

## Q7 How many different communication Ethernet sessions can be opened through the LAN port?

A7 ModBus TCP/IP:4 sockets

DNP TCP/IP:3 sessions (from version 1.72 on)

## Q8 Does it support peer-to-peer horizontal communications? Is this going to interface with UR relays?

A8 It is not included in the present release.

## Q9 May I use the cooper 10/100 BaseTX connection included in the basic model with all protocols?

A9 Yes, it may be used with all protocols. In noisy substation environments and/or long distances, it is recommended to use fiber optic options due to much better EMC performance and immunity. For fiber optic models, it is necessary to adjust an internal jumper to use the copper port.

## Q10 Remote I/O CAN bus. Does it support DeviceNet protocol?

A10 No it does not support DeviceNet.

## Q11: Which functions are available in the relay web server?

A11 Currently, it includes several functions for viewing measures and retrieving information.

#### Q12: What is the web site user password and name?

A12: The password is: 7169 and user name is: GE

A13 Only oscillography records may be viewed with URPC once downloaded to a file using the ENERVISTA 650 Setup software.

#### Q14: May I connect URs and F650s to the same Ethernet?

A14: Yes, either in cable as in fiber, or even mix them.

## Q15: How do I connect with fiber 10-BASE-FL UR relays with 100-BASE-FX F650 relays?

A15: Take into account that an UR is never connected directly to a F650 (neither two UR nor two F650 with each other) but they are always connected through a hub or switch. The hub or switch where the URs are connected must be 10-BASE-FL and the hub or switch for the F650 must be 100-BASE-FX.

## Q16: How do I connect with cable 10\_BASE-T UR relays with 10/100-BASE-TX F650 relays?

A16: The answer to this question is as described before but also in this case there is an advantage added, because the hub 10-BASE-TX port is able to understand a 10-BASE-T port. This means that a hub 10-BASE-T port may be connected to an UR or a F650, and a hub 10/100-BASE-TX port may be connected either to an UR or F650.

## Q17: What happens with fiber optic connectors compatibility, because the hub that I have has a different connector to the one of the F650, although both are 100-BASE-FX?

A17: Just buy fiber cables with the appropriate male connectors. For the UR and F650 side we need the same connectors, ST type, for the hub side, the correspondent ones. And in what concerns to the fiber type, it is used the same for 10 as for 100, it is the 50/125 or 62.5/125 multimode, this last one allows longer distances.

#### Q18: What is the difference between a hub and a switch?

A18: In a repeater type hub (shared hub), one unit talks and the rest listen. If all the units are talking at the same time there may be collisions in the messages, what may produce certain communication delays.

The switch (switched hub) has very powerful processors and a lot of memory and it is much more expensive than the hub. It directs messages to the proper destination avoiding collisions and allowing a much more efficient communication.

#### Q19: Why do we have 10/100 compatibility for cable but not for fiber?

A19: The cable has some advantages that the fiber does not have, and it is that the signal attenuation in short and medium distances, is worthless and this is truth for low and high frequency signals. By the contrary, the light in one fiber optic is highly attenuated, being much worse in case of high frequencies than in the low ones. The 10-BASE-FL fiber transmission is performed in a wavelength of 850nm, what allows a less expensive electronic than the 1300 nm used in 100-BASE-FX fiber transmission. Using, in both cases, the same glass multimode fiber type, the attenuation to 1300 nm is lower than the 850 nm ones, this way the greater attenuation of the 100 Mbits is compensated. There is another fiber standard, the 100-BASE-SX, which uses 850 nm to 100 Mbits, being compatible with the 10-BASE-FL one, although it sacrifices the maximum distance to 300 m. Nowadays, this standard has not had success among Ethernet equipment manufacturers and suppliers.

7

## Q1 Does the F650 support IRIG-B signals? Which type and accuracy? How many units may be connected to the same source?

A1 Yes, the F650 includes an IRIG-B input for all models, including the basic ones.

It uses DC level format B. Formats used are B0000, B0002 and B0003.

Actual accuracy is 1 millisecond. Internal sampling rate allows true 1 ms accuracy time tagging.

The input burden is very low. The maximum number of units that may be connected to a generator depends on its output driving capability. Up to 60 units have been successfully connected with equipments commonly used in the market.

## Q2 Does the equipment work with dry inputs in both AC and DC?

A2 The equipment works only with DC inputs.

Inputs should be driven with externally generated DC current. No special 48 Vdc or other outputs are included in the equipment to drive these inputs; therefore, contacts connected to the equipment should be connected to a DC source.

## Q3 Is this equipment valid for Petersen coil grounded systems and ungrounded systems?

A3 The 5<sup>th</sup> current input is a very sensitive unit that measures from 5 mA up to 1.5 A, that is used for these systems. The present release includes 67SG (sensitive ground) as well as 67IG (isolated ground for ungrounded systems). Petersen Coil 67PC unit will be included in future releases that will only need firmware update.

## Q4 Is oscillography programmable?

A4 Yes, the sampling rate is programmable (4, 8, 16, 32 or 64 samples per input). The depth will depend on the sampling rate.

## Q5 Do I have to select a different model for 1 or 5 A?

A5 No. The same model is able to work with either /1 A or /5 A rated secondary currents. There are high accuracy sensing transformers that allow the use of any current input through the same terminals to reduce the spares and simplify wiring.

## Q6 In my installation, several digital inputs become active when I energize the transformer. How can I reduce sensitivity?

A6 By selecting debounce time and/or voltage threshold, the relay may adapt its sensitivity to different applications. Please select the maximum voltage threshold and debounce time (recommended 15 ms) to minimize AC coupling effects.

- Q1 What is the difference between Get/Send info from/to relay and Upload/Download info files to/from relay?
- A1 Get/Send are used for settings and configuration storage that although both are in a unique file, are sent separately in two times. Upload/Download are used for project or PLC files group storage. These files are the setting\_configuration file source. To operate, the F650 does not need the source files; the Upload/Download tool is destined to serve as historic file.

#### Q2 Could I program interlocks?

A2 Yes, via ENERVISTA 650 Setup interlocks may be programmed from very simple to advanced schemes.

## Q3 Can we rotate the display 90 degrees to show feeders vertically?

A3 No. The product has been designed to view it in horizontal mode (landscape) due to the following reasons:
 It is easier to read the LCD display because it has been designed for horizontal positions.
 Compatibility between text display (4x20 characters) and LCD display (16x40 characters or 128x240 pixels).
 Refresh speed is better in horizontal than vertical format.

#### Q4 Do I need a laptop or handheld to program the unit?

A4 No, all main operations can easily be performed with just the incorporated HMI. Handheld or laptops may be required to download large quantities of information (such as oscillograms, etc.) but they are not mandatory for a conventional user that just needs to change settings, view measurements, states, etc.

#### Q5 Is there password security for protection and control?

- A5 Yes, there are two passwords. An independent password for protection changes and control operations is available since version 1.44.
- Q6 Is it possible to have a remote HMI installed in the front of the panel with the rest of the relay in the rear side?
- A6 Not in the present version.

## Q7 Is it possible to program a default screen for the HMI?

A7 In graphic display versions the user may program a custom screen with the single-line diagram, measurements, etc. In text display models, there is a choice of logo, measurements, or scrolling both screens.

## Q8 May I force inputs and outputs to ease commissioning and testing?

A8 Yes.

#### Q9 How can I disable the rotary knob buzzer?

A9 Press ESC key during more than 3 seconds and then press the knob during a short pulse.

#### Q10 Why do appear strange texts on the display when switching on the relay?

A10 You will have pressed any button and the HMI has entered in a test mode.The display messages are updated after a few minutes, once the relay has completed the starting sequence.

- Q1 Does the "Service" contact on the Power Supply board cover all possible failures or do I have to create an output on the I/O board that includes all the internal errors I can access in the logic?
- A1 The power supply ready contact only monitor hardware failures in the power supply, to monitor the internal error of the unit it is necessary to configure a virtual output to and the assign it to the device desired (contact output, LED, etc.).
- Q2 I set an output contact as "Latched". If I do not set a "reset" condition, will it reset from the "ESC" key?
- A2 No, you have to configure the contact output reset signal (in *Settings>Relay Configuration>Outputs*). The ESC key only reset the LED indicators.

F650 units have been designed and verified using the most advanced and reliable equipment. Mounting and testing automation ensure a high consistency of the final product. Before sending a unit back to the factory, we strongly recommend you follow the recommendations below. Even if it will not always solve the problem, at least they will help define it better for a quicker repair.

If you need to send a unit back to the factory for repair, please use the appropriate RETURN MATERIAL AUTHORISATION process, and follow the shipping instructions provided by our Service Department, especially in the case of international shipments. This will lead to a faster and efficient solution of your problem.

CATEGORY	SYMPTOM	POSSIBLE CAUSE	RECOMMENDED ACTION
Protection	The relay does not trip	-Function not permitted	- Set the function permission to ENABLED
		- Function blocked	- Check Protection units block screen
		- Output not assigned	- Program the output to the desired function using ENERVISTA 650 Setup logic configuration
General	When feeding the unit, no indicator is lit up	-Insufficient power supply	-Verify the voltage level using a multimeter in the power supply terminals, and check that it is within the model range
		- Wrong versions	- Check relay and ENERVISTA 650 Setup versions are the same
		-Fused fuse	-Remove power supply, dismount the power supply module and replace the fuse
			- Same as above with same fuse
		- Loose fuse	-Make sure that terminals labeled + and – are connected to the 9-pin connector corresponding to the power
		-Incorrect wiring	source
Communication	The relay does not communicate via the	-Incorrect cable	-Make sure you are using a straight cable
	1011 R5232 por	-Damaged cable	-Replace the cable
		-Relay or PC not grounded	-Ensure ground connection
		-Incorrect baudrate, port, address, etc.	-Test other ports, other baudrates, etc. Make sure that the communication parameters in the computer match the ones in the relay.
General	After Updating the firmware the relay does not start up and always shows the message "Os	Check that the bootware version match with the firmware version	If there is an incompatibility between boot and firmware version, update to the corresponding boot and after that update the firmware version
	Loading".		If the boot and firmware versions are correct, perform the firmware update procedure again.
Communications	Cannot see properly the web server in F650 with Windows XP.	Disabled Java options in Advanced Internet Explorer properties or high level of security	1 Go to Advanced in Internet options for Internet explorer and select the three selections in Microsoft VM (Java Virtual Machine) and deselect any
	Some windows are in grey with a red cross mark.		other virtual machine not Microsoft, for example SUN. In case Microsoft VM is not installed in the computer, the user must install it using the Microsoft VM installation program <b>msjavx86.exe</b> For internet explorer 6.0 or higher it is not included by default. 2 Try to set a lower level of security in internet explorer options. 3Delete temporary internet files in "General" screen in internet explorer options.

## 8 TROUBLESHOOTING GUIDE

Communication	Enervista 650 Setup does not retrieve osc, fault reports and Data Logger files	Bad communication in TFTP using Windows 2000	Disable and Enable the Ethernet connection on Control Panel inside Windows 2000. Try again to retrieve files from relay

## A.1.1 FACTORY DEFAULT SETTINGS



	Jement	F050_F2G	51_1_V180.a	ul (IVIAIN)	Enervista Fobu Se
	101				· · · · · · · · · · · · · · · · · · ·
			. 1		43
	102				VO_049_51G_PKP
		INURT		OUTORI	
	GROUND TOUZ PKP	inOR2	<del>.</del>		
	103		<u>.</u>		
	GROUND TOC3 PKP	inOR3	· · · · · · · · · · · ·		
	98				40
	GROUND IOC1 PKP		0		42
	99	inOP1		outOP1	_VO_048_50G_PKP
	GROUND IOC2 PKP	mont		outorti	
	100	inOR2	<u>-</u>		
			<u>·      </u>		
	226	linOR3	225		
		<u></u>		227	· · · · · · · · · · · · · · · · · · ·
	228			VO_00	9_GROUND_OVERCURRENT_PKP
	VO_048_50G_PKP		<u></u>		
	197				201
	SENS GND TOC1 PKP		193		
	198	inOR1	OR3	outOR1	_VO_003_513G_FRF
	SENS GND TOC2 PKP		:11 11		
	100	inOR2	- II		
		1000			
	SENS GND TOUS PKP	nors			
	194				200
	SENS GND IOC1 PKP	· · · · · · · · · · · · ·	192		
	195 • • • • • • • • • • • •	inOR1	OR3	outOR1	_00_002_3036_FKF
	SENS GND IOC2 PKP	<u> </u>	:		
	196	inOR2	<u> </u>		
	SENS GND IOC3 PKP	-002	<u>-</u>		
	179				
					178
			1//		VO 043 501G PKP
OVERCURRENT	180	inOR1	OR3   [	outOR1	
PICKUPS	ISOLATED GND2 PKP	i=002	-1 11		
	.181	IIIURZ	:11 11		
	ISOLATED GND3 PKP	inOR3			
	229				
	VO 002 50SG PKP				233
			232		
	230	inOP1	232 	oi#OP1	_VO_010_SENSITIVE_GROUND_PKP
	230	inOR1	232	outOR1	VO_010_SENSITIVE_GROUND_PKP
	230 VO_003_51SG_PKP 231	inOR1 inOR2	232 OR3	outOR1	VO_010_SENSITIVE_GROUND_PKP
	230 VO_003_51SG_PKP 231	inOR1	232 OR3	outOR1	<u>VO_010_SENSITIVE_GROUND_PKP</u>
	230 VO 003 51 SG PKP 231 VO 043 50 IG PKP	inOR1 inOR2	232 OR3	outOR1	<u>VO_010_SENSITIVE_GROUND_PKP</u>
	230 VO 003 51SG PKP 231 VO 043 50IG PKP 212	inOR1 inOR2	232 OR3	outOR1	VO_010_SENSITIVE_GROUND_PKP
	230 VO 003 51SG PKP 231 VO 043 50IG PKP 212 NEG SEQ TOC1 PKP	inOR1 inOR2	232 OR3 211	outOR1	
	230 VO 003 51SG PKP 231 VO_043 50IG PKP 212 NEG SEQ TOC1 PKP 213	inOR1 inOR2 inOR3	232 OR3 211 OR3	outOR1	_VO_010_SENSITIVE_GROUND_PKP 215 VO_006_12_TOC_PKP
	230 VO 003 51SG PKP 231 VO 043 50IG PKP 212 NEG SEQ TOC1 PKP 213 NEG SEQ TOC2 PKP	inOR1 inOR2 inOR3 inOR1	232 OR3 211 OR3	outOR1	VO_010_SENSITIVE_GROUND_PKP 215 _VO_006_12_TOC_PKP
	230 VO_003_51SG_PKP 231 VO_043_50IG_PKP 212 NEG SEQ TOC1 PKP 213 NEG SEQ TOC2 PKP 214	inOR1 inOR2 inOR3 inOR1 inOR1	232 OR3 211 OR3	outOR1	VO_010_SENSITIVE_GROUND_PKP 215 VO_006_12_TOC_PKP
	230 VO_003_51SG_PKP 231 VO_043_50IG_PKP 212 NEG SEQ TOC1 PKP 213 NEG SEQ TOC2 PKP 214 VEC SEQ TOC3 PKP	inOR1 inOR2 inOR3 inOR1 inOR1	232 OR3 211 OR3	outOR1	_VO_010_SENSITIVE_GROUND_PKP 215 _VO_006_12_TOC_PKP
	230 VO_003_51SG_PKP 231 VO_043_50IG_PKP 212 NEG SEQ TOC1 PKP 213 NEG SEQ TOC2 PKP 214 NEG SEQ TOC2 PKP 214 NEG SEQ TOC3 PKP 225	inOR1 inOR2 inOR3 inOR1 inOR1 inOR2 inOR2	232 OR3 211 OR3	outOR1	VO_010_SENSITIVE_GROUND_PKP 215 VO_006_12_TOC_PKP
	230 VO_003_51SG_PKP 231 VO_043_50IG_PKP 212 NEG SEQ TOC1 PKP 213 NEG SEQ TOC2 PKP 214 NEG SEQ TOC3 PKP 235	inOR1 inOR2 inOR3 inOR1 inOR1 inOR2 j inOR3	232 OR3 211 OR3	outOR1	VO_010_SENSITIVE_GROUND_PKP 215 VO_006_12_TOC_PKP
	230 VO_003_51SG_PKP 231 VO_043_50IG_PKP 212 NEG SEQ TOC1 PKP 213 NEG SEQ TOC2 PKP 214 NEG SEQ TOC3 PKP 235 VO_007_PHASE_OVERC	inOR1 inOR2 inOR3 inOR1 inOR2 inOR2 inOR2 JinOR3	232 OR3 211 OR3	outOR1	_VO_010_SENSITIVE_GROUND_PKP 215 
	230 VO 003 51SG PKP 231 VO_043 50IG PKP 212 NEG SEQ TOC1 PKP 213 NEG SEQ TOC2 PKP 214 NEG SEQ TOC3 PKP 235 VO_007_PHASE_OVERC 236	inOR1 inOR2 inOR3 inOR1 inOR2 inOR3 URRENT PKP	232 OR3  OR3	outOR1	VO_010_SENSITIVE_GROUND_PKP 215 VO_006_12_TOC_PKP
	230 VO_003_51SG_PKP 231 VO_043_50IG_PKP 212 NEG SEQ TOC1 PKP 213 NEG SEQ TOC2 PKP 214 NEG SEQ TOC3 PKP 235 VO_007_PHASE_OVERC 236 VO_008_NEUTRAL_OVE	inOR1 inOR2 inOR3 inOR1 inOR1 inOR2 inOR3 URRENT_PKP RCURRENT_PKP	232 211 0R3 211 0R3 (OR3 (OR3) (O) (O) (O) (O) (O) (O) (O) (O	outOR1	
	230 VO_003_51SG_PKP 231 VO_043_50IG_PKP 212 NEG SEQ TOC1 PKP 213 NEG SEQ TOC2 PKP 214 NEG SEQ TOC3 PKP 235 VO_007_PHASE_OVERC 236 VO_008_NEUTRAL_OVE 237	inOR1 inOR2 inOR3 inOR1 inOR1 inOR2 inOR3 URRENT_PKP RCURRENT_P	232 211 211 0R3 0R3 0R3 (NP) 0R3 (NP)	outOR1	
	230 VO_003_51SG_PKP 231 VO_043_50IG_PKP 212 NEG SEQ TOC1 PKP 213 NEG SEQ TOC2 PKP 214 NEG SEQ TOC3 PKP 235 VO_007_PHASE_OVERC 236 VO_008_NEUTRAL_OVE 237 VO_009_GROUND_OVE	inOR1 inOR2 inOR3 inOR1 inOR1 inOR2 inOR3 URRENT_PKP RCURRENT_P	232 211 211 0R3 (OR3 (NR3) (NR3	outOR1	VO_010_SENSITIVE_GROUND_PKP           215           VO_006_I2_TOC_PKP           outOR1
	230 VO_003_51SG_PKP 231 VO_043_50IG_PKP 212 NEG SEQ TOC1 PKP 213 NEG SEQ TOC2 PKP 214 NEG SEQ TOC3 PKP 235 VO_007_PHASE_OVERC 236 VO_008_NEUTRAL_OVE 237 VO_009_GROUND_OVE 238	inOR1 inOR2 inOR3 inOR1 inOR1 inOR2 J inOR3 URRENT_PKP RCURRENT_P RCURRENT_P	232 232 232 232 211 0R3 (OR3	outOR1	VO_010_SENSITIVE_GROUND_PKP           215           VO_006_12_TOC_PKP           outOR1           234
	230 VO_003_51SG_PKP 231 VO_043_50IG_PKP 212 NEG SEQ TOC1 PKP 213 NEG SEQ TOC2 PKP 214 NEG SEQ TOC3 PKP 235 VO_007_PHASE_OVERC 236 VO_008_NEUTRAL_OVE 237 VO_009_GROUND_OVE 238	inOR1 inOR2 inOR3 inOR1 inOR1 inOR2 inOR3 URRENT_PKP RCURRENT_P	232 211 0R3 211 0R3 KPnOR1 inOR2 inOR3	outOR1	
	230 VO_003_51SG_PKP 231 VO_043_50IG_PKP 212 NEG SEQ TOC1 PKP 213 NEG SEQ TOC2 PKP 214 NEG SEQ TOC2 PKP 235 VO_007_PHASE_OVERC 236 VO_008_NEUTRAL_OVE 237 VO_009_GROUND_OVE 238 VO_010_SENSITIVE_GR	inOR1 inOR2 inOR3 inOR1 inOR2 inOR3 URRENT_PKP RCURRENT_P RCURRENT_P	232 232 232 211 0R3 (OR3 (NR3) (NOR1) (NOR2) (NOR3) (NOR4)	outOR1	VO_010_SENSITIVE_GROUND_PKP           215           VO_006_12_TOC_PKP           outOR1           234           VO_011_ALL_OVERCURRENT_PKP
	230 VO_003 51SG PKP 231 VO_043 50IG PKP 212 NEG SEQ TOC1 PKP 213 NEG SEQ TOC2 PKP 214 NEG SEQ TOC3 PKP 235 VO_007_PHASE_OVERC 236 VO_007_PHASE_OVERC 236 VO_008_NEUTRAL_OVE 237 VO_009_GROUND_OVE 238 VO_010_SENSITIVE_GR 239	inOR1 inOR2 inOR3 inOR1 inOR1 inOR2 inOR3 URRENT_PKP RCURRENT_P RCURRENT_P	232 211 0R3 211 0R3 (NP2) InOR1 InOR2 InOR4 InOP5	outOR1	
	230 VO_003_51SG_PKP 231 VO_043_50IG_PKP 212 NEG SEQ TOC1 PKP 213 NEG SEQ TOC2 PKP 214 NEG SEQ TOC3 PKP 235 VO_007_PHASE_OVERC 236 VO_008_NEUTRAL_OVE 237 VO_009_GROUND_OVE 238 VO_010_SENSITIVE_GRV 239 VO_006_12_TOC_PKP	inOR1 inOR2 inOR3 inOR1 inOR2 inOR2 inOR3 URRENT_PKP RCURRENT_P RCURRENT_P OUND_PKP	232 211 211 OR3 IOR3 INOR1 INOR2 INOR3 INOR4 INOR5	outOR1	
	230 VO_003_51SG_PKP 231 VO_043_50IG_PKP 212 NEG SEQ TOC1 PKP 213 NEG SEQ TOC2 PKP 214 NEG SEQ TOC3 PKP 235 VO_007_PHASE_OVERC 236 VO_008_NEUTRAL_OVE 237 VO_009_GROUND_OVE 238 VO_010_SENSITIVE_GR 239 VO_006_12_TOC_PKP 315	inOR1 inOR2 inOR3 inOR1 inOR1 inOR2 inOR3 URRENT_PKP RCURRENT_P RCURRENT_P OUND_PKP	232 232 232 232 241 0R3 211 0R3 inOR1 inOR2 inOR4 inOR5 inOR6	outOR1	
	230 VO_003_51SG_PKP 231 VO_043_50IG_PKP 212 NEG SEQ TOC1 PKP 213 NEG SEQ TOC2 PKP 214 NEG SEQ TOC3 PKP 235 VO_007_PHASE_OVERC 236 VO_008_NEUTRAL_OVE 237 VO_008_NEUTRAL_OVE 237 VO_009_GROUND_OVE 238 VO_010_SENSITIVE_GRV 239 VO_001_ILERNAL_ALAI	inOR1 inOR2 inOR3 inOR1 inOR1 inOR3 URRENT_PKP RCURRENT_P OUND_PKP	232 211 0R3 0R3 0R3 KPnOR1 inOR2 inOR4 inOR4 inOR5 inOR6	outOR1	
	230 VO_003_51SG_PKP 231 VO_043_50IG_PKP 212 NEG SEQ TOC1 PKP 213 NEG SEQ TOC2 PKP 214 NEG SEQ TOC2 PKP 235 VO_007_PHASE_OVERC 236 VO_008_NEUTRAL_OVE 237 VO_009_GROUND_OVE 238 VO_006_I2_TOC_PKP 315 VO_001_THERMAL_ALAL	inOR1 inOR2 inOR3 inOR1 inOR2 inOR3 iNURRENT_PKP RCURRENT_P RCURRENT_P OUND_PKP	232 211 0R3 211 0R3 (NR3 (NR3 (NR4 (NR5) (NR6)	outOR1	
	230 VO_003_51SG_PKP 231 VO_043_50IG_PKP 212 NEG SEQ TOC1 PKP 213 NEG SEQ TOC2 PKP 214 NEG SEQ TOC3 PKP 235 VO_007_PHASE_OVERC 236 VO_007_PHASE_OVERC 236 VO_009_GROUND_OVER 237 VO_009_GROUND_OVER 238 VO_001_SENSITIVE_GR 239 VO_006_12_TOC_PKP 315 VO_001_THERMAL_ALAI	inOR1 inOR2 inOR3 inOR1 inOR1 inOR2 inOR3 CURRENT_PKP RCURRENT_P RCURRENT_P RCURRENT_P	232 211 211 0R3 (OR3 (OR3 (OR3) (IOR3) (IOR2) (IOR2) (IOR2) (IOR3) (IOR5) (IOR6)	outOR1	

F650 Digital Bay Controller

GE Power Management	F650_F2G1_1_V180.aut (MAIN	) EnerVista F650 Setup
92 PHASE UV1 PKP 93 PHASE UV2 PKP 94 PHASE UV3 PKP 95 PHASE OV1 PKP 96 PHASE OV2 PKP 97 PHASE OV3 PKP	2 inOR1 OR3 out( inOR2 OR3 out( inOR3 out( inOR1 OR3 out( inOR1 out( inOR2 out(	40 VO_045_27P_PKP DR1 41 VO_046_59P_PKP DR1
241 NEUTRAL OV1 HIGH PKP 242 NEUTRAL OV2 HIGH PKP 243 NEUTRAL OV3 HIGH PKP 244 NEUTRAL OV1 LOW PKP	240 inOR1 OR3 out! inOR2 DR3 out!	260 VO_012_59NH_PKP
245 NEUTRAL OV2 LOW PKP 246 NEUTRAL OV3 LOW PKP 247 AUXILIARY UV1 PKP 248	INOR1 OR3 OUT	262 VO_014_27X_PKP
VOLTAGE PICKUPS AUXILIARY UV2 PKP 249 AUXILIARY UV3 PKP 250 AUXILIARY OV1 PKP	inOR3 257	263
251 [ AUXILIARY OV2 PKP] 252 [AUXILIARY OV3 PKP] 253	inOR1 OR3 out	DR1
NEG SEQ OV1 PKP           254           NEG SEQ OV2 PKP           255           NEG SEQ OV3 PKP	259 inOR1 OR3 out inOR2 inOR3	264 VO_016_V2_OV_PKP DR1
271 VO_045_27P_PKP 268 VO_014_27X_PKP 272	273 InOR1 OR7 Out	265 VO_017_ALL_VOLTAGE_PKP
VO 046 59P_PKP 266 VO 012 59NH_PKP 267	In OR2 In OR3 In OR4	
VO         013_59NL         PKP            269         VO         015_59X         PKP            270         VO         016_V2         OV         PKP	In OR5	

Power Mana	agement	F650_F2G1_1_V180.a	aut (MAIN)	EnerVista F650 Se
FREQUENCY PICKUPS	113 OVERFREQ1 PKP 114 OVERFREQ2 PKP 115 OVERFREQ3 PKP 116 UNDERFREQ1 PKP 117 UNDERFREQ2 PKP 118	25 inOR1 OR3 inOR2 InOR3 26 inOR1 OR3 inOR1 OR3 inOR1 OR3	47 VO_054 outOR1 48 VO_055 outOR1	<u>810_PKP</u> <u>81U_PKP</u>
	UNDERFREQ3 PKP 49 VO 054_810_PKP 50 VO 055_81U_PKP 276 BROKEN CONDUCT1	27 27 OR PKP 275	51 VO_056 279	ALL_FREQUENCY_PKP
BROKEN CONDUCTOR	277 BROKEN CONDUCT2 278 BROKEN CONDUCT3 349	inOR1 OR3 OR3 INTERNAL OR3 INTE	VO_018_BRC outOR1	KEN_CONDUCTOR_PKP
FORWARD POWER	FWD PWR1 STG1 PKI           350           FWD PWR1 STG2 PKI           351           FWD PWR2 STG1 PKI           352           FWD PWR2 STG2 PKI           353           FWD PWR3 STG1 PKI           354           FWD PWR3 STG2 PKI	348 inOR1 inOR2 inOR3 inOR4 inOR5 inOR6	355 VO_023 outOR1	FORWARD_POWER_PKP
IRECTIONAL POWER	394 DIR PWR1 STG PKP 373 DIR PWR2 STG PKP 374 DIR PWR3 STG PKP	375 inOR1 OR3 inOR2 inOR3	372 VO_025_C outOR1	DIRECTIONAL_POWER_PKP
POWER	376 VO_023_FORWARD_I 377 VO_025_DIRECTIONA	378 •OWER_PKPOR .L_POWER_PKP	380 VO_026_F	POWER_PKP
LOCKED ROTOR	397 LOCKED ROTOR1 PH 399 LOCKED ROTOR2 PH 399 LOCKED ROTOR3 PH	Image: CP         396           Image: CP         OR3           inOR2         Image: CP           inOR3         Image: CP	400 VO_029_	OCKED_ROTOR_PKP
GENERAL PICKUP	200           VO         011         ALL         OVERCI           VO         011         ALL         OVERCI           VO         011         ALL         OVERCI           VO         056         ALL         FREQU           VO         018         BROKEN_CC         381           VO         026         POWER_PKF         410           VO         029         LOCKED         RC	JRRENT_PKP         4           inOR1         inOR2           inOR2         inOR3           INDUCTOR_PKP         inOR4           inOR5         inOR5           ITOR_PKP         inOR6	109 91 109 109 100 100 100 100 100 100 1	0_085_GENERAL_PKP


GE Multilin

A-6

```
F650_F2G1_1_V180.aut (MAIN)
                                                                                          EnerVista F650 Setup
GE Power Management
                152
                                                                             72
                PHASE UV1 OP
                                                   5
                                                                             VO 073 27P TRIP
                153
                                                      OR3
                                       inOR1
                                                                   outOR1
                PHASE UV2 OP
                                       inOR2
                 154
                PHASE UV3 OP
                                       nOR3
                155
                                                                             73
                PHASE OV1 OP
                                                   6
                                                                            VO_074_59P_TRIP
                156
                                       inOR1
                                                      OR3
                                                                   outOR1
                PHASE OV2 OP
                                       inOR2
                157
                PHASE OV3 OP
                                       ihOR3
                158
                                                                             74
                NEUTRAL OV1 HIGH OP
                                                   19
                                                                             VO_075_59NH_TRIP
                159
                                                      OR3
                                       inOR1
                                                                   outOR1
                NEUTRAL OV2 HIGH OP
                                       inOR2
                160
                NEUTRAL OV3 HIGH OP
                                       ihOR3
                161
                                                                             75
                NEUTRAL OV1 LOW OP
                                                   20
                                                                             VO_076_59NL_TRIP
                162
                                       inOR1
                                                      OR3
                                                                   outOR1
                NEUTRAL OV2 LOW OP
                                       inOR2
                163
                NEUTRAL OV3 LOW OP
                                       nOR3
                164
                                                                             76
                AUXILIARY OV1 OP
                                                   21
                                                                             VO_077_59X_TRIP
                165
                                                      OR3
                                                                   outOR1
                                       inOR1
                AUXILIARY OV2 OP
                                       inOR2
                166
    VOLTAGE
                AUXILIARY OV3 OP
     TRIPS
                                       hOR3
                167
                                                                             77
                AUXILIARY UV1 OP
                                                   22
                                                                             VO 078 27X TRIP
                                                      OR3
                168
                                       inOR1
                                                                   outOR1
                AUXILIARY UV2 OP
                                       inOR2
                169
                AUXILIARY UV3 OP
                                       nOR3
                296
                                                                             299
                NEG SEQ OV1 OP
                                                   295
                                                                             VO_021_V2_OV_TRIP
                297
                                                     OR3
                                       inOR1
                                                                   outOR1
                NEG SEQ OV2 OP
                                       inOR2
                298
                NEG SEQ OV3 OP
                                       nOR3
                79
                VO_073_27P_TRIF
                                                        301
                84
                VO_078_27X_TRIP
                                            InOR1
                                                           OR7
                                                                        OutOR1
                80
                                             In OR2
                VO_074_59P_TRIP
                                             In OR3
                81
                VO_075_59NH_TRIF
                                             In OR4
                82
                                                                          78
                                             In OR5
                VO
                    076_59NL_TRI
                                                                          VO_079_ALL_VOLTAGE_TRIP
                83
                                             Ín ÖR6
                VO 077 59X TRIP
                                             In OR7
                300
                VO_021_V2_OV_TRIF
```

E Power Management	F650_F2G1_1_V180.aut (MAIN)	EnerVista F650 Set
170 OVERFREQ	1 OP 34 5	35
171 OVERFREQ 172	inOR1 OR3 outOR1	<u>vo_080_810_1RIP</u>
	<u>3 OP</u> OR3	36 V/O 081 8111 TRIP
TRIPS	Q2 OP inOR2 OR3 outOR1	
UNDERFRE 88 VO_080_810	<u>Q3 OP idOR3</u> 38 <u>D TRIP</u> OR	87
89 VO_081_81L	J_TRIP	VO_082_ALL_FREQUENCY_TRIP
	307	
BROKEN CO	<u>303</u> <u>100R1</u> OR3 OutOR1	022_BROKEN_CONDUCTOR_TRIP
CONDUCTOR BROKEN CC 306		
359		
FWD PWR1 360	<u>STG1 OP</u> 3 358	65 /O 024 FORWARD POWER TRIP
FWD PWR1 361	STG2 OP inOR1 OR6 outOR1	· · · · · · · · · · · · · · · · · · ·
FORWARD 362	<u>STG1 OP</u> inOR3	
FWD PWR2	STG2 OPinOR4	
FWD PWR3	STG1 OP	
FWD PWR3	STG2 OP	
383 DIR PWR1	STG OP 386 36	
DIRECTIONAL POWER	inOR1 OR3 outOR1	
385 DIR PWR3 (	STG OP jinOR3	
389		
POWER 390		392 VO_028_POWER_TRIP
403		
	OR3 outOR1	
LOCKED R	OTOR3 OP	
308	407	
<u>ΨΩ 020 AL</u> <u>ΨΩ 079 AL</u>	L_VOLTAGE_TRIP OR6	utOR1
GENERAL	inOR2	
and the second	in OB3	
TRIP	INOR3	
TRIP VO 022_BR 393 VO 028_PO 408		

F650 Digital Bay Controller

#### **B.1.1 FACTORY DEFAULT SETTINGS**

PRODUCT SETUP>COMMUNICATION SETTINGS >SERIAL PORTS							
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE		
Baud rate for COM 1	COM1 Baud Rate	19200	N/A	[300 : 115200]			
Baud rate for COM 2	COM2 Baud Rate	19200	N/A	[300 : 115200]			
Parity for serial COM ports	Parity	NONE	N/A	[NONE:ODD:EVEN]			

# PRODUCT SETUP>COMMUNICATION SETTINGS >NETWORK (ETHERNET) NETWORK (ETHERNET)1 > NETWORK (ETHERNET)2

SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE
1st octec of IP address	IP Address Oct1	0	N/A	[0 : 255]	
2nd octec of IP address	IP Address Oct2	0	N/A	[0 : 255]	
3rd octec of IP address	IP Address Oct3	0	N/A	[0 : 255]	
4th octec of IP address	IP Address Oct4	0	N/A	[0 : 255]	
1st octec of Netmask	Netmask Oct1	0	N/A	[0 : 255]	
2nd octec of Netmask	Netmask Oct2	0	N/A	[0 : 255]	
3rd octec of Netmask	Netmask Oct3	0	N/A	[0 : 255]	
4th octec of Netmask	Netmask Oct4	0	N/A	[0 : 255]	
1st octec of Gateway	Gateway IP Oct1	0	N/A	[0 : 255]	
2nd octec of Gateway	Gateway IP Oct2	0	N/A	[0 : 255]	
3rd octec of Gateway	Gateway IP Oct3	0	N/A	[0 : 255]	
4th octec of Gateway	Gateway IP Oct4	0	N/A	[0 : 255]	

PRODUCT SETUP>COMMUNICATION SETTINGS >MODBUS PROTOCOL							
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE		
Slave address for COM1	Modbus Address COM1	254	N/A	[1 : 255]			
Slave address for COM2	Modbus Address COM2	254	N/A	[1 : 255]			
Modbus port number for Modbus TCP/ IP	Modbus Port Number	502	N/A	[0 : 65535]			

# PRODUCT SETUP>COMMUNICATION SETTINGS >DNP3 SLAVE

DNP3 SLAVE 1 > DNP3 SLAVE 2 > D	DNP3 SLAVE 1 > DNP3 SLAVE 2 > DNP3 SLAVE 3						
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE		
Communications port assigned to the DNP protocol	Physical Port	NONE	N/A	[COM1:COM2:NETWORK]			
DNP slave address	Address	255	N/A	[0 : 65534]			
1st Octect of IP address of DNP master 1	IP Addr Client1 Oct1	0	N/A	[0 : 255]			
2nd Octect of IP address of DNP master 1	IP Addr Client1 Oct2	0	N/A	[0 : 255]			
3nd Octect of IP address of DNP master 1	IP Addr Client1 Oct3	0	N/A	[0 : 255]			
4th Octect of IP address of DNP master 1	IP Addr Client1 Oct4	0	N/A	[0 : 255]			
1st Octect of IP address of DNP master 2	IP Addr Client2 Oct1	0	N/A	[0 : 255]			
2nd Octect of IP address of DNP master 2	IP Addr Client2 Oct2	0	N/A	[0 : 255]			
3nd Octect of IP address of DNP master 2	IP Addr Client2 Oct3	0	N/A	[0 : 255]			
4th Octect of IP address of DNP master 2	IP Addr Client2 Oct4	0	N/A	[0 : 255]			
1st Octect of IP address of DNP master 3	IP Addr Client3 Oct1	0	N/A	[0 : 255]			
2nd Octect of IP address of DNP master 3	IP Addr Client3 Oct2	0	N/A	[0 : 255]			
3nd Octect of IP address of DNP master 3	IP Addr Client3 Oct3	0	N/A	[0 : 255]			
4th Octect of IP address of DNP master 3	IP Addr Client3 Oct4	0	N/A	[0 : 255]			
1st Octect of IP address of DNP master 4	IP Addr Client4 Oct1	0	N/A	[0 : 255]			
2nd Octect of IP address of DNP master 4	IP Addr Client4 Oct2	0	N/A	[0 : 255]			
3nd Octect of IP address of DNP master 4	IP Addr Client4 Oct3	0	N/A	[0 : 255]			
4th Octect of IP address of DNP master 4	IP Addr Client4 Oct4	0	N/A	[0 : 255]			
1st Octect of IP address of DNP master 4	IP Addr Client5 Oct1	0	N/A	[0 : 255]			
2nd Octect of IP address of DNP master 4	IP Addr Client5 Oct2	0	N/A	[0 : 255]			
3nd Octect of IP address of DNP master 4	IP Addr Client5 Oct3	0	N/A	[0 : 255]			
4th Octect of IP address of DNP master 4	IP Addr Client5 Oct4	0	N/A	[0 : 255]			
TCP/UDP port number for DNP over Ethernet	TCP/UDP Port	20000	N/A	[0 : 65535]			
Unsolicited responses permission	Unsol Resp Function	DISABLED	N/A	[DISABLED – ENABLED]			
Time out to confirm an unsolicited response	Unsol Resp TimeOut	5	1 s	[0 : 60]			
Number of retransmition of an unsol resp w/o confirmation	Unsol Resp Max Ret	10	N/A	[0 : 255]			
Address to which all unsolicited responses are sent	Unsol Resp Dest Adr	200	N/A	[0 : 65519]			
Scale for currents	Current Scale Factor	1	N/A	[0.00001-0.0001-0.001- 0.01-0.1-1-10-100-1000]			
Scale for voltages	Voltage Scale Factor	1	N/A	[0.00001-0.0001-0.001- 0.01-0.1-1-10-100-1000]			

PRODUCT SETUP>COMMUNICATION SETTINGS >DNP3 SLAVE (CONT.)							
DNP3 SLAVE 1 > DNP3 SLAVE 2 > DNP3 SLAVE 3							
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE		
Scale for power	Power Scale Factor	1	N/A	[0.00001-0.0001-0.001- 0.01-0.1-1-10-100-1000]			
Scale for energy	Energy Scale Factor	1	N/A	[0.00001-0.0001-0.001- 0.01-0.1-1-10-100-1000]			
Other Scale factor	Other Scale Factor	1	N/A	[0.00001-0.0001-0.001- 0.01-0.1-1-10-100-1000]			
Default deadband for Current Analog Input points to trigger unsolicited responses	Current Deadband	30000	N/A	[0 : 65535]			
Default deadband for Voltage Analog Input points to trigger unsolicited responses	Voltage Deadband	30000	N/A	[0 : 65535]			
Default deadband for Power Analog Input points to trigger unsolicited responses	Power Deadband	30000	N/A	[0 : 65535]			
Default deadband for Energy Analog Input points to trigger unsolicited responses	Energy Deadband	30000	N/A	[0 : 65535]			
Default deadband for Other Analog Input points to trigger unsolicited responses	Other Deadband	30000	N/A	[0 : 65535]			
Size (in bytes) for message fragmentation	Msg Fragment Size	240	1 byte	[30 : 2048]			
Size customization and change of DNP Binary Inputs point list	Binary Input Block 1	CTL EVENTS 1-16	N/A	[See DNP note2]			
Size customization and change of DNP Binary Inputs point list	Binary Input Block 2	CTL EVENTS 17-32	N/A	[See DNP note2]			
Size customization and change of DNP Binary Inputs point list	Binary Input Block 3	CTL EVENTS 33-48	N/A	[See DNP note2]			
Size customization and change of DNP Binary Inputs point list	Binary Input Block 4	CTL EVENTS 49-64	N/A	[See DNP note2]			
Size customization and change of DNP Binary Inputs point list	Binary Input Block 5	CTL EVENTS 65-80	N/A	[See DNP note2]			
Size customization and change of DNP Binary Inputs point list	Binary Input Block 6	CTL EVENTS 81-96	N/A	[See DNP note2]			
Size customization and change of DNP Binary Inputs point list	Binary Input Block 7	CTL EVENTS 97- 112	N/A	[See DNP note2]			
Size customization and change of DNP Binary Inputs point list	Binary Input Block 8	CTL EVENTS 113- 128	N/A	[See DNP note2]			
Size customization and change of DNP Binary Inputs point list	Binary Input Block 9	SWITCHGEAR 1-8	N/A	[See DNP note2]			
Size customization and change of DNP Binary Inputs point list	Binary Input Block 10	SWITCHGEAR 9- 16	N/A	[See DNP note2]			

DNP NOTES	
Note 1: Scale Factor	Note that a scale factor of 0.1 is equivalent to a multiplier of 10 (i.e. the value will be 10 times
Note 2: Binary Input Block Selection:	[NOT USED, CTL EVENTS 1-16, CTL EVENTS 17-32, CTL EVENTS 33-48,CTL EVENTS 49- 64, CTL EVENTS 65-80, CTL EVENTS 81-96, CTL EVENTS 97-112, CTL EVENTS 113-128, SWITCHGEAR 1-8, SWITCHGEAR 9-16]

### PRODUCT SETUP>COMMUNICATION SETTINGS >IEC 870-5-104

SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE
Enable or disable the protocol operation	Function	DISABLED	N/A	[DISABLED – ENABLED]	
Listening TCP port in the relay	TCP Port	2404	N/A	[0 : 65535]	
Address in the ASDU header	Common Addr of ASDU	255	N/A	[0 : 65535]	
Number of seconds for instantaneous meterings	Cyclic Meter Period	0	1 s	[0 : 3600]	
Not implemented	Synchronization Event	0	N/A	[0 : 3600]	

# IEC 870-5-104 NOTES

Note 1: Cyclic Meter Period

0 value means no spontaneous meterings

# SETPOINT > PRODUCT SETUP > FAULT REPORT

SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]	
Positive sequence impedance module	Pos Seq Module	3.00	0.01 Ohm	[0.01 : 250.00]	
Positive sequence impedance angle	Pos Seq Angle	75	1 Deg	[25 : 90]	
Zero sequence impedance module	Zero Seq Module	9.00	0.01 Ohm	[0.01 : 750.00]	
Zero sequence impedance angle	Zero Seq Angle	75	1 Deg	[25 : 90]	
Line length	Line Length	100.0	0.1	[0.0 : 2000.0]	
Display fault on HMI	Show Fault On HMI	DISABLED	N/A	[DISABLED – ENABLED]	
Snapshot Event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]	

# PRODUCT SETUP > MODBUS USER MAP

SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE
Address 00 for Modbus user map	Address 00	0	N/A	[0000 : FFFF]	
Address 01 for Modbus user map	Address 01	0	N/A	[0000 : FFFF]	
Address 254 for Modbus user map	Address 254	0	N/A	[0000 : FFFF]	
Address 255 for Modbus user map	Address 255	0	N/A	[0000 : FFFF]	

# SETPOINT > PRODUCT SETUP > OSCILLOGRAPHY

SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE
Function Permission	Function	ENABLED	N/A	[DISABLED – ENABLED]	
Prefault	Trigger Position	30	1%	[5 : 95]	
Samples per cycle	Samples/Cycle	64	N/A	[4 - 8 - 16 -32 - 64]	
Maximum number of oscillos	Max. Number Osc.	4	1 oscillo	[1 : 20]	
Automatic oscillography overwrite	Automatic Overwrite	DISABLED	N/A	[DISABLED – ENABLED]	
Snapshot Event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]	

SETPOINT > PRODUCT SETUP > DATA LOGGER							
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE		
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]			
Data logger Rate	Data Logger Rate	1 s	N/A	[1 s, 5 min, 10 min, 15 min, 20 min, 30 min, 60 min.]			
Data Logger analog channels X	Data Logger Chnl X	None	N/A				

SETPOINT > PRODUCT SETUP > DEMAND									
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE				
Function permission	Demand Function	DISABLED	N/A	[DISABLED – ENABLED]					
				[BLOCK INTERVAL -					
Demand method for current values	CRNT Demand	THERMAL	N/A	ROLLING DEMAND -					
	Method	EAFONENTIAL	L N/A ROLLING DEMAND - THERMAL EXPONENTIAL] [BLOCK INTERVAL - ROLLING DEMAND -						
				[BLOCK INTERVAL -					
Demand method for Power values	POWER Demand	THERMAL	N/A	ROLLING DEMAND -					
	Method	EXPONENTIAL		THERMAL EXPONENTIAL]					
Demand interval	Demand Interval	5 Minutes	N/A	[5 – 10 – 15 – 20– 30–60]					
Trigger Enabled	Trigger Enabled	DISABLED	N/A	[DISABLED – ENABLED]					
Snapshot Event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]					

### SETPOINT > SYSTEM SETUP > GENERAL SETTINGS

SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE
Phase CT ratio	Phase CT Ratio	1.0	0.1	[1.0 : 6000.0]	
Ground CT ratio	Ground CT Ratio	1.0	0.1	[1.0 : 6000.0]	
Sensitive ground CT ratio	Stv Ground CT Ratio	1.0	0.1	[1.0 : 6000.0]	
Phase VT ratio	Phase VT Ratio	1.0	0.1	[1.0 : 6000.0]	
Phase VT connection	Phase VT Connection	WYE	N/A	[WYE – DELTA]	
Rated voltage	Nominal Voltage	100.0	0.1	[1.0 : 250.0]	
Rated Frequency	Nominal Frequency	50 Hz	Hz	[50-60]	
Phase rotation	Phase Rotation	ABC	N/A	[ABC – ACB]	
Frequency reference	Frequency Reference	VI	N/A	[VI-VII-VIII]	
Auxiliary Voltage	Auxiliary Voltage	VX	N/A	[VX – VN]	
Snapshot Event generation	Snapshot Events	DISABLED	N/A	[DISABLED – ENABLED]	

SETPOINT > SYSTEM SETUP > FLEX CURVES									
FLEX CURVES A > FLEX CURVES B> FLEX CURVES C > FLEX CURVES D									
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE				
Values for reset points 0.00 pkp	Time 0.00xPKP [RST]	0.000	0.001 s	[0.000 : 65.535]					
Values for reset points 0.05 pkp	Time 0.05xPKP [RST]	0.000	0.001 s	[0.000 : 65.535]					
			0.001 s	[0.000 : 65.535]					
Values for reset points 0.97 pkp	Time 0.97xPKP [RST]	0.000	0.001 s	[0.000 : 65.535]					
Values for reset points 0.98 pkp	Time 0.98xPKP [RST]	0.000	0.001 s	[0.000 : 65.535]					
Values for operation points 1.03 pkp	Time 1.03xPKP [OP]	0.000	0.001 s	[0.000 : 65.535]					
Values for operation points 1.05 pkp	Time 1.05xPKP [OP]	0.000	0.001 s	[0.000 : 65.535]					
			0.001 s	[0.000 : 65.535]					
Values for operation points 19.50 pkp	Time 19.50xPKP [OP]	0.000	0.001 s	[0.000 : 65.535]					
Values for operation points 20.00 pkp	Time 20.00xPKP [OP]	0.000	0.001 s	[0.000 : 65.535]					

# SETPOINT > SYSTEM SETUP > BREAKER > BREAKER SETTINGS

SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE
Number of Switchgear selected as breaker	Number of Switchgear	1	1	[1 : 16]	
Maximum value of KI2t	Maximum KI2t	9999.99	0.01(KA)2 s	[0.00 : 9999.99]	
KI2t integration time	KI2t Integ. Time	0.03	0.01s	[0.03 : 0.25]	
Maximum number of openings	Maximum Openings	9999	1	[0 : 9999]	
Maximum Openings in one hour	Max.Openings 1 hour	40	1	[1 : 60]	
Snapshot Event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]	

SETPOINT > SYSTEM SETUP > BREAKER > BREAKER MAINTENANCE									
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE				
KI2t Counter Phase A	KI2t BKR Ph A Cnt	0.00	0.01 (KA)2 s	[0.00 : 9999.99]					
KI2t Counter Phase B	KI2t BKR Ph B Cnt	0.00	0.01 (KA)2 s	[0.00 : 9999.99]					
KI2t Counter Phase C	KI2t BKR Ph C Cnt	0.00	0.01 (KA)2 s	[0.00 : 9999.99]					
Openings counter	BKR Openings Cnt	0	1	[0 : 9999]					
Closings counter	BKR Closings Cnt	0	1	[0 : 9999]					

SETPOINT > SYSTEM SETUP > SWITCHGEAR								
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE			
Snapshot Event generation for switchgear #1	Snapshot Events SWGR 1	DISABLED	N/A	[DISABLED – ENABLED]				
Snapshot Event generation for switchgear #2	Snapshot Events SWGR 2	DISABLED	N/A	[DISABLED – ENABLED]				
Snapshot Event generation for switchgear #3	Snapshot Events SWGR 3	DISABLED	N/A	[DISABLED – ENABLED]				
Snapshot Event generation for switchgear #4	Snapshot Events SWGR 4	DISABLED	N/A	[DISABLED – ENABLED]				
Snapshot Event generation for switchgear #5	Snapshot Events SWGR 5	DISABLED	N/A	[DISABLED – ENABLED]				
Snapshot Event generation for switchgear #6	Snapshot Events SWGR 6	DISABLED	N/A	[DISABLED – ENABLED]				
Snapshot Event generation for switchgear #7	Snapshot Events SWGR 7	DISABLED	N/A	[DISABLED – ENABLED]				
Snapshot Event generation for switchgear #8	Snapshot Events SWGR 8	DISABLED	N/A	[DISABLED – ENABLED]				
Snapshot Event generation for switchgear #9	Snapshot Events SWGR 9	DISABLED	N/A	[DISABLED – ENABLED]				
Snapshot Event generation for switchgear #10	Snapshot Events SWGR 10	DISABLED	N/A	[DISABLED – ENABLED]				
Snapshot Event generation for switchgear #11	Snapshot Events SWGR 11	DISABLED	N/A	[DISABLED – ENABLED]				
Snapshot Event generation for switchgear #12	Snapshot Events SWGR 12	DISABLED	N/A	[DISABLED – ENABLED]				
Snapshot Event generation for switchgear #13	Snapshot Events SWGR 13	DISABLED	N/A	[DISABLED – ENABLED]				
Snapshot Event generation for switchgear #14	Snapshot Events SWGR 14	DISABLED	N/A	[DISABLED – ENABLED]				
Snapshot Event generation for switchgear #15	Snapshot Events SWGR 15	DISABLED	N/A	[DISABLED – ENABLED]				
Snapshot Event generation for switchgear #16	Snapshot Events SWGR 16	DISABLED	N/A	[DISABLED – ENABLED]				

#### SETPOINT > PROTECTION ELEMENTS > PHASE CURRENT >

> PHASE TOC HIGH > PHASE TOC HIGH 1> PHASE TOC HIGH 2 > PHASE TOC HIGH 3									
> PHASE TOC LOW > PHASE TOC LOW 1 > PHASE TOC LOW 2 > PHASE TOC LOW 3									
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE				
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]					
Input type	Input	PHASOR(DFT)	N/A	[PHASOR – RMS]					
Pickup level	Pickup Level	1.00	0.01 A	[0.05 : 160.00]					
Curve shape	Curve	IEEE Ext Inv	N/A	[See list of curves]					
Time Dial	TD Multiplier	1.00	0.01 s	[0.00 : 900.00]					
Reset type	Reset	INSTANTANEOUS	N/A	[INSTANTANEOUS – LINEAR]					
Voltage Restraint	Voltage Restraint	DISABLED	N/A	[DISABLED – ENABLED]					
Snapshot Event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]					

SETPOINT > PROTECTION ELEMENTS > PHASE CURRENT >										
> PHASE IOC HIGH > PHASE IOC HIGH 1> PHASE IOC HIGH 2 > PHASE IOC HIGH 3										
> PHASE IOC LOW > PHASE IOC LO	W 1 > PHASE IOC LOV	V 2 > PHASE IOC LC	OW 3							
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE					
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]						
Input type	Input	PHASOR(DFT)	N/A	[Phasor – RMS]						
Pickup level	Pickup Level	30.00	0.01 A	[0.05 : 160.00]						
Trip time	Trip Delay	0.00	0.01 s	[0.00 : 900.00]						
Reset time	Reset Delay	0.00	0.01 s	[0.00 : 900.00]						
Snapshot event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]						

# SETPOINT > PROTECTION ELEMENTS > PHASE CURRENT > PHASE DIRECTIONAL >

PHASE DIRECTIONAL 1> PHASE DIRECTIONAL 2 > PHASE DIRECTIONAL 3								
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE			
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]				
Maximum Torque Angle	MTA	45	1 Deg	[-90 : +90]				
Operation Direction	Direction	FORWARD	N/A	[FORWARD – REVERSE]				
Block logic	Block Logic	PERMISSION	N/A	[BLOCK – PERMISSION]				
Polarization voltage threshold	Pol V Threshold	40	1 V	[0:300]				
Snapshot event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]				

Β

# SETPOINT > PROTECTION ELEMENTS > PHASE CURRENT > THERMAL MODEL >

THERMAL MODEL 1> THERMAL MODEL 2 > THERMAL MODEL 3									
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE				
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]					
Heating constant	Heat Time Constant	6.0	0.1 min	[3.0 : 600.0]					
Cooling constant	Cool Time Constant	2.00	0.01 times Heat Time Ct.	[1.00 : 6.00]					
Pickup level	Pickup Level	1.00	0.01 A	[0.05 : 160.00]					
Alarm level	Alarm Level	80.0	0.10%	[1.0 : 110.0]					
Snapshot event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]					

#### SETPOINT > PROTECTION ELEMENTS > NEUTRAL CURRENT > NEUTRAL TOC

NEUTRAL TOC 1> NEUTRAL TOC 2 > NEUTRAL TOC 3									
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE				
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]					
Pickup level	Pickup Level	1.00	0.01 A	[0.05 : 160.00]					
Curve shape	Curve	IEEE Ext Inv	N/A	[See list of curves]					
Time Dial	TD Multiplier	1.00	0.01 s	[0.00 : 900.00]					
Reset type	Reset	INSTANTANEOUS	N/A	[INSTANTANEOUS – LINEAR]					
Snapshot Event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]					

#### SETPOINT > PROTECTION ELEMENTS > NEUTRAL CURRENT > NEUTRAL IOC

NEUTRAL IOC 1> NEUTRAL IOC 2 > NEUTRAL IOC 3									
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE				
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]					
Pickup level	Pickup Level	30.00	0.01 A	[0.05 : 160.00]					
Trip time	Trip Delay	0.00	0.01 s	[0.00 : 900.00]					
Reset time	Reset Delay	0.00	0.01 s	[0.00 : 900.00]					
Snapshot event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]					

SETPOINT > PROTECTION ELEMENTS > NEUTRAL CURRENT > NEUTRAL DIRECTIONAL > NEUTRAL DIRECTIONAL 1> NEUTRAL DIRECTIONAL 2 > NEUTRAL DIRECTIONAL 3

SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]	
Maximum Torque Angle	MTA	-45	1 Deg	[-90 : +90]	
Operation Direction	Direction	FORWARD	N/A	[FORWARD – REVERSE]	
Polarization type	Polarization	VO	N/A	$[V_0 - I_P - V_0 + I_P - V_0^* I_P]$	
Block logic type	Block Logic	PERMISSION	N/A	[BLOCK – PERMISSION]	
Polarization voltage threshold	Pol V Threshold	10	1 V	[0:300]	
Snapshot event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]	

#### SETPOINT > PROTECTION ELEMENTS > GROUND CURRENT > GROUND TOC

GROUND TOC 1> GROUND TOC 2 > GROUND TOC 3								
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE			
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]				
Input type	Input	PHASOR(DFT)	N/A	[PHASOR – RMS]				
Pickup level	Pickup Level	1.00	0.01 A	[0.05 : 160.00]				
Curve shape	Curve	IEEE Ext Inv	N/A	[See list of curves]				
Time Dial	TD Multiplier	1.00	0.01 s	[0.00 : 900.00]				
Reset type	Reset	INSTANTANEOUS	N/A	[INSTANTANEOUS – LINEAR]				
Snapshot Event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]				

### SETPOINT > PROTECTION ELEMENTS > GROUND CURRENT > GROUND IOC

GROUND IOC 1> GROUND IOC 2 > GROUND IOC 3									
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE				
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]					
Input type	Input	PHASOR(DFT)	N/A	[PHASOR – RMS]					
Pickup level	Pickup Level	30.00	0.01 A	[0.05 : 160.00]					
Trip time	Trip Delay	0.00	0.01 s	[0.00 : 900.00]					
Reset time	Reset Delay	0.00	0.01 s	[0.00 : 900.00]					
Snapshot event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]					

# SETPOINT > PROTECTION ELEMENTS > GROUND CURRENT > GROUND DIRECTIONAL >

SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE			
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]				
Maximum Torque Angle	MTA	-45	1 Deg	[-90 : +90]				
Operation Direction	Direction	FORWARD	N/A	[FORWARD – REVERSE]				
Polarization type	Polarization	VO	N/A	$[V_0 - I_P - V_0 + I_P - V_0^* I_P]$				
Block logic type	Block Logic	PERMISSION	N/A	[BLOCK – PERMISSION]				
Polarization voltage threshold	Pol V Threshold	10	1 V	[0:300]				
Snapshot event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]				

#### SETPOINT > PROTECTION ELEMENTS > SENSITIVE GROUND CURRENT > SENSITIVE GROUND TOC SENSITIVE GROUND TOC 1> SENSITIVE GROUND TOC 2 > SENSITIVE GROUND TOC 3

SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]	
Input type	Input	PHASOR(DFT)	N/A	[PHASOR – RMS]	
Pickup level	Pickup Level	0.050	0.001 A	[0.005 : 16.000]	
Curve shape	Curve	IEEE Ext Inv	N/A	[See list of curves]	
Time Dial	TD Multiplier	1.00	0.01 s	[0.00 : 900.00]	
Reset type	Reset	INSTANTANEOUS	N/A	[INSTANTANEOUS – LINEAR]	
Snapshot Event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]	

# SETPOINT > PROTECTION ELEMENTS > SENSITIVE GROUND CURRENT > SENSITIVE GROUND IOC

SENSITIVE GROUND IOC 1> SENSITIVE GROUND IOC 2 > SENSITIVE GROUND IOC 3								
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE			
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]				
Input type	Input	PHASOR(DFT)	N/A	[PHASOR – RMS]				
Pickup level	Pickup Level	0.100	0.001 A	[0.005 : 16.000]				
Trip time	Trip Delay	0.00	0.01 s	[0.00 : 900.00]				
Reset time	Reset Delay	0.00	0.01 s	[0.00 : 900.00]				
Snapshot event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]				

# SETPOINT > PROTECTION ELEMENTS > SENSITIVE GROUND CURRENT > ISOLATED GROUND IOC ISOLATED GROUND IOC 1 > ISOLATED GROUND IOC 2 > ISOLATED GROUND IOC 3

SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE
Function Permission	Function	DISABLED	N/A	[DISABLED – ENABLED]	
High Voltage level	Vh Level	20	1 V	[2 : 70]	
Low Current level	II LEVEL	0.005	0.001 A	[0.005 : 0.400]	
Low Voltage level	VI LEVEL	2	1 V	[2 : 70]	
High Current level	Ih LEVEL	0.025	0.001 A	[0.005 : 0.400]	
Operation time	Delay	0.00	0.01 s	[0.00 : 900.00]	
Deviation time to instantaneous	Time to inst	0.00	0.01 s	[0.00 : 900.00]	
Snapshot event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]	

# SETPOINT > PROTECTION ELEMENTS > SENSITIVE GROUND CURRENT > SENSITIVE GROUND DIRECTIONAL >

SENSITIVE GROUND DIRECTIONAL 1> SENSITIVE GROUND DIRECTIONAL 2 > SENSITIVE GROUND DIRECTIONAL 3									
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE				
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]					
Maximum Torque Angle	MTA	-45	1 Deg	[-90 : +90]					
Operation Direction	Direction	FORWARD	N/A	[FORWARD – REVERSE]					
Block logic type	Block Logic	PERMISSION	N/A	[BLOCK – PERMISSION]					
Polarization voltage threshold	Pol V Threshold	10	1 V	[0:300]					
Snapshot event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]					

### SETPOINT > PROTECTION ELEMENTS > NEGATIVE SEQUENCE CURRENT > NEGATIVE SEQUENCE TOC >

NEGATIVE SEQUENCE TOC 1> NEGATIVE SEQUENCE TOC 2 > NEGATIVE SEQUENCE TOC 3

SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]	
Pickup level	Pickup Level	1.00	0.01 A	[0.05 : 160.00]	
Curve shape	Curve	IEEE Ext Inv	N/A	[See list of curves]	
Time Dial	TD Multiplier	1.00	0.01 s	[0.00 : 900.00]	
Reset type	Reset	INSTANTANEOUS	N/A	[INSTANTANEOUS – LINEAR]	
Snapshot Event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]	

### SETPOINT > PROTECTION ELEMENTS > VOLTAGE ELEMENTS > PHASE UV >

PHASE UV 1> PHASE UV 2 > PHASE UV 3								
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE			
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]				
Input mode	Mode	PHASE-PHASE	N/A	[PHASE-PHASE, PHASE- GROUND]				
Pickup Level	Pickup Level	10	1 V	[3 : 300]				
Curve shape	Curve	DEFINITE TIME	N/A	[DEFINITE TIME – INVERSE TIME]				
Time Dial	Delay	10.00	0.01 s	[0.00 : 900.00]				
Minimum Voltage Threshold	Minimum Voltage	5	1 V	[0 : 300]				
Operation logic	Logic	ANY PHASE	N/A	[ANY PHASE – TWO PHASES – ALL PHASES]				
Supervision by breaker status	Supervised by 52	DISABLED	N/A	[DISABLED – ENABLED]				
Snapshot Event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]				

# SETPOINT > PROTECTION ELEMENTS > VOLTAGE ELEMENTS > PHASE OV >

PHASE OV 1> PHASE OV 2 > PHASE OV 3							
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE		
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]			
Pickup Level	Pickup Level	10	1 V	[3 : 300]			
Trip time	Trip Delay	10.00	0.01 s	[0.00 : 900.00]			
Reset time	Reset Delay	0.00	0.01 s	[0.00 : 900.00]			
Operation logic	Logic	ANY PHASE	N/A	[ANY PHASE – TWO PHASES – ALL PHASES]			
Snapshot Event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]			

SETPOINT > PROTECTION ELEMENTS > VOLTAGE ELEMENTS >									
>NEUTRAL OV HIGH > NEUTRAL OV HIGH 1> NEUTRAL OV HIGH 2 > NEUTRAL OV HIGH 3									
>NEUTRAL OV LOW > NEUTRAL OV	LOW 1> NEUTRAL OV	V LOW 2 > NEUTRAL	OV LOW 3						
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE				
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]					
Pickup Level	Pickup Level	10	1 V	[3 : 300]					
Trip time	Trip Delay	10.00	0.01 s	[0.00 : 900.00]					
Reset time	Reset Delay	0.00	0.01 s	[0.00 : 900.00]					
Snapshot Event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]					

#### SETPOINT > PROTECTION ELEMENTS > NEGATIVE SEQUENCE OV >

#### NEGATIVE SEQUENCE OV 1> NEGATIVE SEQUENCE OV 2 > NEGATIVE SEQUENCE OV 3

SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE		
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]			
Pickup Level	Pickup Level	10	1 V	[3 : 300]			
Trip time	Trip Delay	10.00	0.01 s	[0.00 : 900.00]			
Reset time	Reset Delay	0.00	0.01 s	[0.00 : 900.00]			
Snapshot Event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]			

# SETPOINT > PROTECTION ELEMENTS > AUXILIARY UV >

SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE			
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]				
Pickup Level	Pickup Level	10	1 V	[3 : 300]				
Curve shape	Curve	DEFINITE TIME	N/A	[DEFINITE TIME – INVERSE TIME]				
Time Dial	Delay	10.00	0.01 s	[0.00 : 900.00]				
Snapshot Event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]				

#### SETPOINT > PROTECTION ELEMENTS > POWER > FORWARD POWER FORWARD POWER 1> FORWARD POWER 2 > FORWARD POWER 3 USER SETTING DESCRIPTION NAME DEFAULT VALUE STEP RANGE VALUE Function permission Function DISABLED N/A [DISABLED - ENABLED] Block from off-line Blk Time After Close 0.01 s [0.00 : 900.00] 0.00 Pickup level for stage 1 Stage 1 Tap 10.00 0.01MW [0.00:10000.00] Trip time for stage 1 Stage 1 Time 60.00 0.01 s [0.00 : 900.00] Pickup level for stage 2 Stage 2 Tap 20.00 0.01MW [0.00:10000.00] Trip time for stage 2 Stage 2 Time 60.00 [0.00 : 900.00] 0.01 s Snapshot Event generation Snapshot Events ENABLED N/A [DISABLED – ENABLED]

#### SETPOINT > PROTECTION ELEMENTS > POWER > DIRECTIONAL POWER> DIRECTIONAL POWER 1> DIRECTIONAL POWER 2 > DIRECTIONAL POWER 3 USER SETTING DESCRIPTION NAME DEFAULT VALUE STEP RANGE VALUE DISABLED Function permission Function N/A [DISABLED - ENABLED] Block from off-line Blk Time After Close 0.00 0.01 s [0.00 : 900.00] Dir Power Angle 1 Directional Angle for stage 1 0.00 1 Deg [0.00:359.99] Pickup level for stage 1 Stage 1 Tap 10.00 0.01MW [-10000.00 : 10000.00] Trip time for stage 1 Stage 1 Time 60.00 0.01 s [0.00 : 900.00] Directional Angle for stage 2 Dir Power Angle 2 0.00 1 Deg [0.00 : 359.99] Pickup level for stage 2 [-10000.00 : 10000.00] Stage 2 Tap 20.00 0.01MW Trip time for stage 2 Stage 2 Time 60.00 0.01 s [0.00 : 900.00] Snapshot Event generation Snapshot Events ENABLED N/A [DISABLED - ENABLED]

# SETPOINT > CONTROL ELEMENTS > SETTING GROUP

SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE
Setting Grouping Permission	Function	DISABLED	N/A	[DISABLED – ENABLED]	
Active Group	Active Group	GROUP 1	N/A [GROUP 1 – GROUP 2 - GROUP 3]		
Snapshot Event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]	

# SETPOINT > CONTROL ELEMENTS > UNDERFREQUENCY

UNDERFREQUENCY 1 > UNDERFREQUENCY 2 > UNDERFREQUENCY 3								
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE			
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]				
Pickup level	Pickup Level	49.50	0.01 Hz	[20.00 : 65.00]				
Trip time	Trip Delay	0.00	0.01 s	[0.00 : 900.00]				
Reset time	Reset Delay	0.00	0.01 s	[0.00 : 900.00]				
Minimum voltage threshold	Minimum Voltage	30	1 V	[30 : 300]				
Snapshot event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]				

# SETPOINT > CONTROL ELEMENTS > OVERFREQUENCY OVERFREQUENCY 1 > OVERFREQUENCY 2 > OVERFREQUENCY 3

SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]	
Pickup level	Pickup Level	50.50	0.01 Hz	[20.00 : 65.00]	
Trip time	Trip Delay	0.00	0.01 s	[0.00 : 900.00]	
Reset time	Reset Delay	0.00	0.01 s	[0.00 : 900.00]	
Minimum voltage threshold	Minimum Voltage	30	1 V	[30 : 300]	
Snapshot event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]	

# SETPOINT > CONTROL ELEMENTS > SYNCHROCHECK

SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]	
Dead bus voltage level	Dead Bus Level	10.00	0.01 V	[0.00 : 300.00]	
Live bus voltage level	Live Bus Level	50.00	0.01 V	[0.00 : 300.00]	
Dead line voltage level	Dead Line Level	10.00	0.01 V	[0.00 : 300.00]	
Live line voltage level	Live Line Level	50.00	0.01 V	[0.00 : 300.00]	
Voltage Difference	Max Volt Difference	10.00	0.01 V	[2.00 : 300.00]	
Angle Difference	Max Angle Difference	10.0	0.1 Deg	[2.0 : 80.0]	
Frequency Slip	Max Freq Difference	20	10 mHz	[10 : 5000]	
Breaker Closing time	Time	0.50	0.01 s	[0.01 : 600.00]	
Dead Line – Dead Bus Function permission	DL-DB Function	DISABLED	N/A	[DISABLED – ENABLED]	
Live Line – Dead Bus Function permission	LL-DB Function	DISABLED	N/A	[DISABLED – ENABLED]	
Dead Line – Live Bus Function permission	DL-LB Function	DISABLED	N/A	[DISABLED – ENABLED]	
Snapshot event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]	

SETPOINT > CONTROL ELEMENTS > AUTORECLOSE								
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE			
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]				
Maximum Number of shots	Max Number Shots	1	N/A	[1:4]				
Dead time 1	Dead Time 1	0.00	0.01 s	[0.00 : 900.00]				
Dead time 2	Dead Time 2	0.00	0.01 s	[0.00 : 900.00]				
Dead time 3	Dead Time 3	0.00	0.01 s	[0.00 : 900.00]				
Dead time 4	Dead Time 4	0.00	0.01 s	[0.00 : 900.00]				
Reclaim time or reset lockout delay	Reclaim Time	0.00	0.01 s	[0.00 : 900.00]				
Reclose conditions permission	Cond. Permission	DISABLED	N/A	[DISABLED – ENABLED]				
Hold time	Hold Time	0.00	0.01 s	[0.00 : 900.00]				
Reset time	Reset Time	0.00	0.01 s	[0.00 : 900.00]				
Snapshot event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]				

SETPOINT > CONTROL ELEMENTS > VT FUSE FAILURE							
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE		
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]			
Snapshot event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]			

SETPOINT > CONTROL ELEMENTS > LOCKED ROTOR								
BROKEN CONDUCTOR 1 >BROKE	N CONDUCTOR 2 >BRO	OKEN CONDUCTOR	3					
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE			
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]				
Tap Level in percentage of I2/I1	Тар	20	0.10%	[20.0 : 100.0]				
Trip Time	Trip Delay	60	0.01 s	[0.00 : 900.00]				
Snapshot event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]				
Current Inhibition Level setting	Operation Threshold	0.005	0.001 A	[0.000 : 1.000]				

# SETPOINT > CONTROL ELEMENTS > LOCKED ROTOR

LOCKED ROTOR 1 SLOCKED ROTOR 2 SLOCKED ROTOR 3								
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE			
Function permission	Function	DISABLED	N/A	[DISABLED – ENABLED]				
Input type	Input	PHASOR(DFT)	N/A	[PHASOR – RMS]				
Full load current	Full Load Current	0.5	KA	[0.10 : 10.00]				
Pickup level	Pickup Level	1.01	N/A	[1.01 : 109.00]				
Trip time	Trip Delay	0	S	[0.00 : 900.00]				
Reset time	Reset Delay	0	S	[0.00 : 900.00]				
Snapshot event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]				

SETPOINT > INPUTS/OUTPUTS > CONTACT I/O >								
BOARD F > BOARD G > BOARD H > BOARD J								
SETTING DESCRIPTION	NAME	DEFAULT VALUE	STEP	RANGE	USER VALUE			
				[NONE,				
I/O board type (available only for CIO	I/O Board Type_H	NONE	N/A	16 INP + 8OUT,				
				8 INP + 8OUT + SUPV]				
Input activation voltage threshold Group A	Voltage Threshold A_X	80	1 V	[0 : 255]				
Input activation voltage threshold Group B	Voltage Threshold B_X	80	1 V	[0 : 255]				
Debounce time for Group A	Debounce Time A_X	15	1 ms	[1 : 50]				
Debounce time for Group B	Debounce Time B_X	15	1 ms	[1 : 50]				
	Input Type_X_CCY (CCY)	POSITIVE	N/A	[POSITIVE-EDGE,				
loout two				NEGATIVE-EDGE,				
input type				POSITIVE,				
				NEGATIVE]				
Input signal time delay	Delay Input Time_X_CCY (CCY)	0	1 ms	[0 : 60000]				
			N1/A	[POSITIVE,				
		POSITIVE	N/A	NEGATIVE]				
				[NORMAL,				
Output type	Output Type_X_0Z	NORMAL	N/A	PULSE,				
				LATCH]				
Output pulse length	Pulse Output Time_ <b>X</b> _0 <b>Z</b>	10000	1 ms	[0 : 60000]				
Snapshot event generation	Snapshot Events	ENABLED	N/A	[DISABLED – ENABLED]				

# NOTE 2: DESCRIPTION OF X, Y AND Z IN INPUT/OUTPUT BOARDS

x	F, G, H or J, the I/O board name, depending on the Relay model.					
	F and G are internal Relay boards, and H and J are additional boards available in CIO modules (remote Bus CAN I/O module).					
For the I/O board selection in the relay model:	I/O BOARD TYPE					
	ASSOCIATED DIGIT	ENERVISTA 650 SETUP BOARD SETTINGS	BOARD TYPE			
	0	NONE	None			
	1	16 INP+ 80UT	Mixed			
	2	8 INP +8 OUT +SUPV	Supervisio n			

	Is the name used for inputs in I/O boards	
CCY	Mixed, 16 digital inputs: CC1CC16	
	Supervision: 8 digital inputs: CC1,, CC8	
0 <b>Z</b>	Is the name used for the different outputs in I/O boards, 8 outputs available for any of the two types of board (01,, 08)	

LIST OF TIME OVERCURRENT CURVES AVAILABLE IN F650
IEEE extremely/very/moderately inverse
IEC Curve A/B/C/Long-Time Inverse/ Short-Time Inverse
IAC extremely/very/normally/moderately inverse
ANSI extremely/very/normally/moderately inverse
l2t
Definite time
Rectifier curve
User Curve - FlexCurve™ A/B/C/D

# NOTE:

#### SOURCE COLUMN:

This columns allow selecting the simple or complex (OR signal or Virtual output) operand that actives the selected elements on relay configuration

If more than one operands are selected, the relay performs an OR gate with them to activate the selected element.

# SIGNAL LOGIC COLUMN:

Refers to each individual signal selected on its left. NOT legend means that the refered signal is inverted

#### SOURCE LOGIC COLUMN:

Refers to the whole SOURCE signal selected on its left. NOT legend means that SOURCE signal is inverted If more than one operand were selected, the OR gate output is inverted

#### SETPOINT>RELAY CONFIGURATION>OUTPUTS

OUTPUT ID	OUTPUT NAME	SOURCE	SIGNAL LOGIC	SOURCE LOGIC
CONT OP OPER_F_01	79 BLOCKED	AR BLOCK BY LEVEL		
		VO_046_59P_PKP		
CONT OP OPER_F_02	27/59 PKP	VO_045_27P_PKP		
CONT OP OPER_F_03	50/67G PKP	VO_048_50G_PKP		
CONT OP OPER_F_04	51/67G PKP	VO_049_51G_PKP		
		VO_051_50PH_PKP		
CONT OP OPER_F_05	DU/67P PKP	VO_050_50PL_PKP		
CONT OP OPER_F_06	51/67P PKP	VO_053_51P_PKP		
		OPERATION BIT 1		
CONT OF OPER_F_07	RECLOSE	AR CLOSE BREAKER		
		OPERATION BIT 2		
CONT OF OPER_F_08	IRIP	VO_083_GENERAL_TRIP		
CONT OP OPER_G_01	81U/81O TRIP	VO_082_ALL_FREQUENCY_TRIP		
CONT OP OPER_G_02	27/59 TRIP	VO_079_ALL_OVERVOLTAGE_TRIP		
CONT OP OPER_G_03	50/67G TRIP	VO_068_50G_TRIP		
CONT OP OPER_G_04	51/67G TRIP	VO_067_51G_TRIP		
	50/67P TRIP	VO_059_50PL_TRIP		
CONT OF OPER_G_05		VO_058_50PH_TRIP		
CONT OP OPER_G_06	51/67P TRIP	VO_057_51P_TRIP		
CONT OP OPER_G_07	RCLS IN PROG	AR RCL IN PROGRESS		
CONT OP OPER_G_08	RCLS LOCKOUT	AR LOCKOUT		
CONT OP RESET_F_01	Not Configured			
CONT OP RESET_F_02	Not Configured			
CONT OP RESET_F_03	Not Configured			
CONT OP RESET_F_04	Not Configured			
CONT OP RESET_F_05	Not Configured			
CONT OP RESET_F_06	Not Configured			
CONT OP RESET_F_07	Not Configured			
CONT OP RESET_F_08	Not Configured			
CONT OP RESET_G_01	Not Configured			
CONT OP RESET_G_02	Not Configured			
CONT OP RESET_G_03	Not Configured			
CONT OP RESET_G_04	Not Configured			

CONT OP RESET_G_05	Not Configured		
CONT OP RESET_G_06	Not Configured		
CONT OP RESET_G_07	Not Configured		
CONT OP RESET_G_08	Not Configured		

SETPOINT>RELAY CON	IFIGURATION>LEDS			
LED ID	LED NAME	SOURCE	SIGNAL LOGIC	SOURCE LOGIC
LED01	TRIP	VO_083_GENERAL_TRIP		
LED02	50/51P TRIP	VO_019_PHASE_OVERCURRENT_TRIP		
LED03	50/51G TRIP	VO_069_GROUND_OVERCURRENT_TRIP		
LED04	27 TRIP	VO_073_27P_TRIP		
LED05	59 TRIP	VO_074_59P_TRIP		
LED06	PICKUP	VO_085_GENERAL_PKP		
LED07	50/51P PICKUP	VO_007_PHASE_OVERCURRENT_PKP		
LED08	50/51G PICKUP	VO_009_GROUND_OVERCURRENT_PKP		
LED09	27 PICKUP	VO_045_27P_PKP		
LED10	59 PICKUP	VO_046_59P_PKP		
LED11	79 READY	AR READY		
LED12	79 IN-PROG	AR RCL IN PROGRESS		
LED13	79 BLOCK	AR BLOCK BY LEVEL		
LED14	79 INHIBIT	AR CONDS INPUT		NOT
LED15	79 LOCKOUT	AR LOCKOUT		

SETPOINT>RELAY CONF	FIGURATION>PROTECTION ELEMENTS		
PROTECTION ELEMENT	SOURCE	SIGNAL LOGIC	SOURCE LOGIC
LED RESET INPUT	OPERATION BIT 3		
	GROUP 1 BLOCKED		
	CONT IP_F_CC2 (50P BLOCK)(CC2)		
	PHASE DIR1 A OP	NOT	
	LATCHED VIRT IP 1		
	GROUP 1 BLOCKED		
	CONT IP_F_CC2 (50P BLOCK)(CC2)		
	PHASE DIR1 B OP	NOT	
	LATCHED VIRT IP 1		
	GROUP 1 BLOCKED		
	CONT IP_F_CC2 (50P BLOCK)(CC2)		
	PHASE DIR1 C OP	NOT	
	LATCHED VIRT IP 1		
	GROUP 2 BLOCKED		
	CONT IP_F_CC2 (50P BLOCK)(CC2)		
	PHASE DIR2 A OP	NOT	
	LATCHED VIRT IP 1		
	GROUP 2 BLOCKED		
	CONT IP_F_CC2 (50P BLOCK)(CC2)		
	PHASE DIR2 B OP	NOT	
	LATCHED VIRT IP 1		
	l		

B.1 FACTORY DEFAULT CONFIGURATION		
	_	

PH IOC2 HIGH C BLK	GROUP 2 BLOCKED	
	CONT IP_F_CC2 (50P BLOCK)(CC2)	
	PHASE DIR2 C OP	NOT
	LATCHED VIRT IP 1	
	GROUP 3 BLOCKED	
	CONT IP_F_CC2 (50P BLOCK)(CC2)	
THOUS HIGH A BER	PHASE DIR3 A OP	NOT
	LATCHED VIRT IP 1	
	GROUP 3 BLOCKED	
	CONT IP_F_CC2 (50P BLOCK)(CC2)	
THOUS HIGH B BER	PHASE DIR3 B OP	NOT
	LATCHED VIRT IP 1	
	GROUP 3 BLOCKED	
	CONT IP_F_CC2 (50P BLOCK)(CC2)	
	PHASE DIR3 C OP	NOT
	LATCHED VIRT IP 1	
	GROUP 1 BLOCKED	
	CONT IP_F_CC2 (50P BLOCK)(CC2)	
PHIOCI LOW A BLK	PHASE DIR1 A OP	NOT
	LATCHED VIRT IP 2	
	GROUP 1 BLOCKED	
	CONT IP_F_CC2 (50P BLOCK)(CC2)	
PHIOCI LOW B BLK	PHASE DIR1 B OP	NOT
	LATCHED VIRT IP 2	
	GROUP 1 BLOCKED	
	CONT IP_F_CC2 (50P BLOCK)(CC2)	
	PHASE DIR1 C OP	NOT
	LATCHED VIRT IP 2	
	GROUP 2 BLOCKED	
	CONT IP_F_CC2 (50P BLOCK)(CC2)	
PH IOC2 LOW A BLK	PHASE DIR2 A OP	NOT
	LATCHED VIRT IP 2	
	GROUP 2 BLOCKED	
	CONT IP_F_CC2 (50P BLOCK)(CC2)	
PH IOC2 LOW B BLK	PHASE DIR2 B OP	NOT
	LATCHED VIRT IP 2	
	GROUP 2 BLOCKED	
	CONT IP_F_CC2 (50P BLOCK)(CC2)	
PH IOC2 LOW C BLK	PHASE DIR2 C OP	NOT
	LATCHED VIRT IP 2	
	GROUP 3 BLOCKED	
	CONT IP_F_CC2 (50P BLOCK)(CC2)	
PH IOC3 LOW A BLK	PHASE DIR3 A OP	NOT
	LATCHED VIRT IP 2	
	GROUP 3 BLOCKED	
	CONT IP_F_CC2 (50P BLOCK)(CC2)	
PH IOC3 LOW B BLK	PHASE DIR3 B OP	NOT
	LATCHED VIRT IP 2	

	GROUP 3 BLOCKED		
PH IOC3 LOW C BLK	CONT IP_F_CC2 (50P BLOCK)(CC2)		
	PHASE DIR3 C OP	NOT	
	LATCHED VIRT IP 2		
	GROUP 1 BLOCKED		
NEUTRAL IUCT BLUCK	NEUTRAL DIR1 OP	NOT	
	GROUP 2 BLOCKED		
NEUTRAL IUCZ BLUCK	NEUTRAL DIR2 OP	NOT	
	GROUP 3 BLOCKED		
NEUTRAL IOUS BLOCK	NEUTRAL DIR3 OP	NOT	
	GROUP 1 BLOCKED		
	CONT IP_F_CC5 (50G BLOCK)(CC5)		
	GROUND DIR1 OP	NOT	
	LATCHED VIRT IP 3		
	GROUP 2 BLOCKED		
	CONT IP_F_CC5 (50G BLOCK)(CC5)		
GROUND IOCZ BLOCK	GROUND DIR2 OP	NOT	
	LATCHED VIRT IP 3		
	GROUP 3 BLOCKED		
	CONT IP_F_CC5 (50G BLOCK)(CC5)		
GROUND IOC3 BLOCK	GROUND DIR3 OP	NOT	
	LATCHED VIRT IP 3		
	GROUP 1 BLOCKED		
SENS GND IOC1 BLK	SENS GND DIR1 OP	NOT	
	LATCHED VIRT IP 4		
	GROUP 2 BLOCKED		
SENS GND IOC2 BLK	SENS GND DIR2 OP	NOT	
	LATCHED VIRT IP 4		
	GROUP 3 BLOCKED		
SENS GND IOC3 BLK	SENS GND DIR3 OP	NOT	
	LATCHED VIRT IP 4		
	GROUP 1 BLOCKED		
	CONT IP_F_CC3 (51P BLOCK)(CC3)		
	PHASE DIR1 A OP	NOT	
	LATCHED VIRT IP 5		
	GROUP 1 BLOCKED		
	CONT IP_F_CC3 (51P BLOCK)(CC3)		
	PHASE DIR1 B OP	NOT	
	LATCHED VIRT IP 5		
	GROUP 1 BLOCKED		
	CONT IP_F_CC3 (51P BLOCK)(CC3)		
	PHASE DIR1 C OP	NOT	
	LATCHED VIRT IP 5		
	GROUP 2 BLOCKED		
	CONT IP_F_CC3 (51P BLOCK)(CC3)		
PH TOC2 HIGH A BLK	PHASE DIR2 A OP	NOT	
	LATCHED VIRT IP 5		

	GROUP 2 BLOCKED		
PH TOC2 HIGH B BLK	CONT IP_F_CC3 (51P BLOCK)(CC3)		
	PHASE DIR2 B OP	NOT	
	LATCHED VIRT IP 5		
	GROUP 2 BLOCKED		
	CONT IP_F_CC3 (51P BLOCK)(CC3)		
PH TOUZ HIGH C BLK	PHASE DIR2 C OP	NOT	
	LATCHED VIRT IP 5		
	GROUP 3 BLOCKED		
	CONT IP_F_CC3 (51P BLOCK)(CC3)		
PH TOC3 HIGH A BLK	PHASE DIR3 A OP	NOT	
	LATCHED VIRT IP 5		
	GROUP 3 BLOCKED		
	CONT IP_F_CC3 (51P BLOCK)(CC3)		
PH TOC3 HIGH B BLK	PHASE DIR3 B OP	NOT	
	LATCHED VIRT IP 5		
	GROUP 3 BLOCKED		
	CONT IP_F_CC3 (51P BLOCK)(CC3)		
PH TOC3 HIGH C BLK	PHASE DIR3 C OP	NOT	
	LATCHED VIRT IP 5		
	GROUP 1 BLOCKED		
NEUTRAL TOC1 BLOCK	NEUTRAL DIR1 OP	NOT	
	GROUP 2 BLOCKED		
NEUTRAL TOC2 BLOCK	NEUTRAL DIR2 OP	NOT	
	GROUP 3 BLOCKED		
NEUTRAL TOC3 BLOCK	NEUTRAL DIR3 OP	NOT	
	GROUP 1 BLOCKED		
	CONT IP_F_CC6 (51G BLOCK)(CC6)		
GROUND TOC1 BLOCK	GROUND DIR1 OP	NOT	
	LATCHED VIRT IP 7		
	GROUP 2 BLOCKED		
	CONT IP_F_CC6 (51G BLOCK)(CC6)		
GROUND TOC2 BLOCK	GROUND DIR2 OP	NOT	
	LATCHED VIRT IP 7		
	GROUP 3 BLOCKED		
	CONT IP_F_CC6 (51G BLOCK)(CC6)		
GROUND TOC3 BLOCK	GROUND DIR3 OP	NOT	
	LATCHED VIRT IP 7		
	GROUP 1 BLOCKED		
SENS GND TOC1 BLOCK	SENS GND DIR1 OP	NOT	
	LATCHED VIRT IP 8		
	GROUP 2 BLOCKED		
SENS GND TOC2 BLOCK	SENS GND DIR2 OP	NOT	
	LATCHED VIRT IP 8		
	GROUP 3 BLOCKED		
SENS GND TOC3 BLOCK	SENS GND DIR3 OP	NOT	
	LATCHED VIRT IP 8		
PHASE UV1 BLOCK	GROUP 1 BLOCKED		
PHASE UV2 BLOCK	GROUP 2 BLOCKED		
PHASE UV3 BLOCK	GROUP 3 BLOCKED		
		1	

NEG SEQ OV1 BLOCK	GROUP 1 BLOCKED		
NEG SEQ OV2 BLOCK	GROUP 2 BLOCKED		
NEG SEQ OV3 BLOCK	GROUP 3 BLOCKED		
THERMAL1 BLOCK	GROUP 1 BLOCKED		
THERMAL2 BLOCK	GROUP 2 BLOCKED		
THERMAL3 BLOCK	GROUP 3 BLOCKED		
	GROUP 1 BLOCKED		
PHASE DIR1 BLK INP	CONT IP_F_CC4 (67P BLOCK)(CC4)		
	LATCHED VIRT IP 9		
	GROUP 2 BLOCKED		
PHASE DIR2 BLK INP	CONT IP_F_CC4 (67P BLOCK)(CC4)		
	LATCHED VIRT IP 9		
	GROUP 3 BLOCKED		
PHASE DIR3 BLK INP	CONT IP_F_CC4 (67P BLOCK)(CC4)		
	LATCHED VIRT IP 9		
NEUTRAL DIR1 BLK INP	GROUP 1 BLOCKED		
NEUTRAL DIR2 BLK INP	GROUP 2 BLOCKED		
NEUTRAL DIR3 BLK INP	GROUP 3 BLOCKED		
	GROUP 1 BLOCKED		
GROUND DIR1 BLK INP	LATCHED VIRT IP 10		
	GROUP 2 BLOCKED		
GROUND DIR2 BLK INP	LATCHED VIRT IP 10		
	GROUP 3 BLOCKED		
GROUND DIR3 BLK INP	LATCHED VIRT IP 10		
	GROUP 1 BLOCKED		
NEUTRAL OV1 HIGH BLK	LATCHED VIRT IP 12		
	GROUP 2 BLOCKED		
NEUTRAL OV2 HIGH BLK	LATCHED VIRT IP 12		
	GROUP 3 BLOCKED		
NEUTRAL OV3 HIGH BLK	LATCHED VIRT IP 12		
NEUTRAL OV1 LOW BLK	GROUP 1 BLOCKED		
NEUTRAL OV2 LOW BLK	GROUP 2 BLOCKED		
NEUTRAL OV3 LOW BLK	GROUP 3 BLOCKED		
AUXILIARY UV1 BLOCK	GROUP 1 BLOCKED		
AUXILIARY UV2 BLOCK	GROUP 2 BLOCKED		
AUXILIARY UV3 BLOCK	GROUP 3 BLOCKED		
	GROUP 1 BLOCKED		
PHASE OV1 BLOCK	LATCHED VIRT IP 11		
	GROUP 2 BLOCKED		
PHASE OV2 BLOCK	LATCHED VIRT IP 11		
	GROUP 3 BLOCKED		
PHASE OV3 BLOCK	LATCHED VIRT IP 11		
AUXILIARY OV1 BLOCK	GROUP 1 BLOCKED		
AUXILIARY OV2 BLOCK	GROUP 2 BLOCKED		
AUXILIARY OV3 BLOCK	GROUP 3 BLOCKED		
NEG SEQ TOC1 BLOCK	GROUP 1 BLOCKED		
NEG SEQ TOC2 BLOCK	GROUP 2 BLOCKED		
NEG SEQ TOC3 BLOCK	GROUP 3 BLOCKED		
OVERFREQ1 BLOCK	GROUP 1 BLOCKED		
OVERFREQ2 BLOCK	GROUP 2 BLOCKED		<u> </u>

OVERFREQ3 BLOCK	GROUP 3 BLOCKED		
UNDERFREQ1 BLOCK	GROUP 1 BLOCKED		
UNDERFREQ2 BLOCK	GROUP 2 BLOCKED		
UNDERFREQ3 BLOCK	GROUP 3 BLOCKED		
SETT GROUPS BLOCK	Not Configured		
BROKEN CONDUCT1 BLK	GROUP 1 BLOCKED		
BROKEN CONDUCT2 BLK	GROUP 2 BLOCKED		
BROKEN CONDUCT3 BLK	GROUP 3 BLOCKED		
ISOLATED GND1 BLK	GROUP 1 BLOCKED		
	SENS GND DIR1 OP	NOT	
	GROUP 2 BLOCKED		
OOLATED ONDE DER	SENS GND DIR2 OP	NOT	
	GROUP 3 BLOCKED		
ISOLATED GINDS BER	SENS GND DIR3 OP	NOT	
SENS GND DIR1 BLK IP	GROUP 1 BLOCKED		
SENS GND DIR2 BLK IP	GROUP 2 BLOCKED		
SENS GND DIR3 BLK IP	GROUP 3 BLOCKED		
FWD PWR1 BLOCK	GROUP 1 BLOCKED		
FWD PWR2 BLOCK	GROUP 2 BLOCKED		
FWD PWR3 BLOCK	GROUP 3 BLOCKED		
	GROUP 1 BLOCKED		
	CONT IP_F_CC3 (51P BLOCK)(CC3)		
PH TOC1 LOW A BLK	PHASE DIR1 A OP	NOT	
	LATCHED VIRT IP 6		
	GROUP 1 BLOCKED		
	CONT IP_F_CC3 (51P BLOCK)(CC3)		
PH TOC1 LOW B BLK	PHASE DIR1 B OP	NOT	
	LATCHED VIRT IP 6		
	GROUP 1 BLOCKED		
	CONT IP F CC3 (51P BLOCK)(CC3)		
PH TOC1 LOW C BLK	PHASE DIR1 C OP	NOT	
	LATCHED VIRT IP 6		
	GROUP 2 BLOCKED		
	CONT IP F CC3 (51P BLOCK)(CC3)		
PH TOC2 LOW A BLK	PHASE DIR2 A OP	NOT	
	LATCHED VIRT IP 6	-	
	GROUP 2 BLOCKED		
	CONT IP_F_CC3 (51P BLOCK)(CC3)		
PH TOC2 LOW B BLK	PHASE DIR2 B OP	NOT	
	LATCHED VIRT IP 6		
	GROUP 2 BLOCKED		
	CONT IP E CC3 (51P BLOCK)(CC3)		
PH TOC2 LOW C BLK	PHASE DIR2 C OP	NOT	
PH TOC3 LOW A BLK		ΝΟΤ	

	GROUP 3 BLOCKED			
	CONT IP_F_CC3 (51P BLOCK)(CC3)			
	PHASE DIR3 B OP	NOT		
	LATCHED VIRT IP 6			
	GROUP 3 BLOCKED			
	CONT IP_F_CC3 (51P BLOCK)(CC3)			
PH TOUS LOW C BLK	PHASE DIR3 C OP	NOT		
	LATCHED VIRT IP 6			
DIR PWR1 BLOCK	GROUP 1 BLOCKED			
DIR PWR2 BLOCK	GROUP 2 BLOCKED			
DIR PWR3 BLOCK	GROUP 3 BLOCKED			
LOCKED ROTOR1 BLK	GROUP 1 BLOCKED			
LOCKED ROTOR2 BLK	GROUP 2 BLOCKED			
LOCKED ROTOR3 BLK	GROUP 3 BLOCKED			
THERMAL1 A RST	OPERATION BIT 4			
THERMAL1 B RST	OPERATION BIT 4			
THERMAL1 C RST	OPERATION BIT 4			
THERMAL2 A RST	OPERATION BIT 4			
THERMAL2 B RST	OPERATION BIT 4			
THERMAL2 C RST	OPERATION BIT 4			
THERMAL3 A RST	OPERATION BIT 4			
THERMAL3 B RST	OPERATION BIT 4			
THERMAL3 C RST	OPERATION BIT 4			
SYNCROCHECK BLK	Not Configured			
	CONT IP_F_CC8 (79 BLOCK)(CC8)			
	LATCHED VIRT IP 14			
AR PULSE BLOCK	Not Configured			
AR PULSE UNBLOCK	Not Configured			
	VO_083_GENERAL_TRIP			
AR INITIATE	CONT IP_F_CC7 (79 INITIATE)(CC7)			
	LATCHED VIRT IP 13			
	SYNCHK CLOSE PERM	NOT	NOT	
AR CONDS INFOT	LATCHED VIRT IP 15		NO1	
BKR FAIL INITIATE	Not Configured			
RESET KI2t COUNTERS	OPERATION BIT 5			
RESET BKR COUNTERS	OPERATION BIT 5			
GROUP 1 ACT ON	Not Configured			
GROUP 2 ACT ON	Not Configured			
GROUP 3 ACT ON	Not Configured			
FAULT REPORT TRIGG	VO_083_GENERAL_TRIP			
CLEAR FAULT REPORTS	Not Configured			
DEMAND TRIGGER INP	Not Configured			
DEMAND RESET INP	OPERATION BIT 7			
FREEZE ENERGY CNT	Not Configured			
UNFREEZE ENERGY CNT	Not Configured			
RESET ENERGY CNT	OPERATION BIT 6			

SETPOINT>RELAY CONFIGURATION>OSCILLOGRAPHY				
DIGITAL CHANNELS	NAME	SOURCE	SIGNAL LOGIC	SOURCE LOGIC

DIG_CHANNEL#1	TRIP	VO_083_GENERAL_TRIP		
DIG_CHANNEL#2	50/51P TRIP	VO_019_PHASE_OVERCURRENT_TRIP		
DIG_CHANNEL#3	50/51G TRIP	VO_069_GROUND_OVERCURRENT_TRIP		
DIG_CHANNEL#4	27 TRIP	VO_073_27P_TRIP		
DIG_CHANNEL#5	59 TRIP	VO_074_59P_TRIP		
DIG_CHANNEL#6	PICKUP	VO_085_GENERAL_PKP		
DIG_CHANNEL#7	50/51P PICKUP	VO_007_PHASE_OVERCURRENT_PKP		
DIG_CHANNEL#8	50/51G PICKUP	VO_009_GROUND_OVERCURRENT_PKP		
DIG_CHANNEL#9	27 PICKUP	VO_045_27P_PKP		
DIG_CHANNEL#10	59 PICKUP	VO_046_59P_PKP		
DIG_CHANNEL#11	79 READY	AR READY		
DIG_CHANNEL#12	79 IN-PROG	AR RCL IN PROGRESS		
DIG_CHANNEL#13	79 BLOCK	AR BLOCK BY LEVEL		
DIG_CHANNEL#14	79 INHIBIT	AR CONDS INPUT	NOT	
DIG_CHANNEL#15	79 LOCKOUT	AR LOCKOUT		
DIG_CHANNEL#16	Not Configured			
		OPERATION BIT 8		
OGGILLO TRIGGER	USULLO IRIGGER	VO_083_GENERAL_TRIP		

OPERATION	OPERATION TEXT	SETTINGS	VALUE/SOURCE
		INTERLOCK(LOGIC)	SYNCHK CLOSE PERM
		FINAL STATES AND(LOGIC)	BREAKER CLOSED
		FRONT KEY	I Кеу
Operation1	CLOSE BREAKER	INPUT	Not configured
		VIRTUAL OUTPUT	Not configured
		TIMEOUT	1000
		CHANNELS	ALL
		INTERLOCK(LOGIC)	Not configured
		FINAL STATES AND(LOGIC)	BREAKER OPEN
		FRONT KEY	О Кеу
Operation2	OPEN BREAKER	INPUT	Not configured
		VIRTUAL OUTPUT	Not configured
		TIMEOUT	1000
		CHANNELS	ALL
		INTERLOCK(LOGIC)	Not configured
		FINAL STATES AND(LOGIC)	Not configured
		FRONT KEY	Not configured
Operation3	LEDS RESET	INPUT	Not configured
		VIRTUAL OUTPUT	Not configured
		TIMEOUT	500
		CHANNELS	ALL
		INTERLOCK(LOGIC)	Not configured
		FINAL STATES AND(LOGIC)	Not configured
		FRONT KEY	Not configured
Operation4	THERMAL RESET	INPUT	Not configured
		VIRTUAL OUTPUT	Not configured
		TIMEOUT	500
		CHANNELS	ALL

		INTERLOCK(LOGIC)	Not configured
		FINAL STATES AND(LOGIC)	Not configured
		FRONT KEY	Not configured
Operation5	BRK COUNTERS RESET	INPUT	Not configured
		VIRTUAL OUTPUT	Not configured
		TIMEOUT	500
		CHANNELS	ALL
		INTERLOCK(LOGIC)	Not configured
		FINAL STATES AND(LOGIC)	Not configured
		FRONT KEY	Not configured
Operation6	ENERGY RESET	INPUT	Not configured
		VIRTUAL OUTPUT	Not configured
		TIMEOUT	500
		CHANNELS	ALL
		INTERLOCK(LOGIC)	Not configured
		FINAL STATES AND(LOGIC)	Not configured
		FRONT KEY	Not configured
Operation7	DEMAND RESET	INPUT	Not configured
		VIRTUAL OUTPUT	Not configured
		TIMEOUT	500
		CHANNELS	ALL
		INTERLOCK(LOGIC)	Not configured
		FINAL STATES AND(LOGIC)	Not configured
		FRONT KEY	Not configured
Operation8	TRIGGER OSCILLO	INPUT	Not configured
		VIRTUAL OUTPUT	Not configured
		TIMEOUT	500
		CHANNELS	ALL
		INTERLOCK(LOGIC)	Not configured
		FINAL STATES AND(LOGIC)	Not configured
		FRONT KEY	Not configured
Operation9	Not configured	INPUT	Not configured
		VIRTUAL OUTPUT	Not configured
		TIMEOUT	Not configured
		CHANNELS	Not configured
		INTERLOCK(LOGIC)	Not configured
		FINAL STATES AND(LOGIC)	Not configured
		FRONT KEY	Not configured
Operation10	Not configured	INPUT	Not configured
		VIRTUAL OUTPUT	Not configured
		TIMEOUT	Not configured
		CHANNELS	Not configured
		INTERLOCK(LOGIC)	Not configured
		FINAL STATES AND(LOGIC)	Not configured
		FRONT KEY	Not configured
Operation11	Not configured	INPUT	Not configured
		VIRTUAL OUTPUT	Not configured
		TIMEOUT	Not configured
		CHANNELS	Not configured

		INTERLOCK(LOGIC)	Not configured
		FINAL STATES AND(LOGIC)	Not configured
		FRONT KEY	Not configured
Operation12	Not configured	INPUT	Not configured
		VIRTUAL OUTPUT	Not configured
		TIMEOUT	Not configured
		CHANNELS	Not configured
-		INTERLOCK(LOGIC)	Not configured
		FINAL STATES AND(LOGIC)	Not configured
		FRONT KEY	Not configured
Operation13	Not configured	INPUT	Not configured
		VIRTUAL OUTPUT	Not configured
		TIMEOUT	Not configured
		CHANNELS	Not configured
		INTERLOCK(LOGIC)	Not configured
		FINAL STATES AND(LOGIC)	Not configured
		FRONT KEY	Not configured
Operation14	Not configured	INPUT	Not configured
		VIRTUAL OUTPUT	Not configured
		TIMEOUT	Not configured
		CHANNELS	Not configured
-		INTERLOCK(LOGIC)	Not configured
		FINAL STATES AND(LOGIC)	Not configured
		FRONT KEY	Not configured
Operation15	Not configured	INPUT	Not configured
		VIRTUAL OUTPUT	Not configured
		TIMEOUT	Not configured
		CHANNELS	Not configured
		INTERLOCK(LOGIC)	Not configured
		FINAL STATES AND(LOGIC)	Not configured
		FRONT KEY	Not configured
Operation16	Not configured	INPUT	Not configured
		VIRTUAL OUTPUT	Not configured
		TIMEOUT	Not configured
		CHANNELS	Not configured
		INTERLOCK(LOGIC)	Not configured
		FINAL STATES AND(LOGIC)	Not configured
		FRONT KEY	Not configured
Operation17	Not configured	INPUT	Not configured
		VIRTUAL OUTPUT	Not configured
		TIMEOUT	Not configured
		CHANNELS	Not configured
		INTERLOCK(LOGIC)	Not configured
		FINAL STATES AND(LOGIC)	Not configured
		FRONT KEY	Not configured
Operation18	Not configured	INPUT	Not configured
		VIRTUAL OUTPUT	Not configured
		TIMEOUT	Not configured
		CHANNELS	Not configured

		INTERLOCK(LOGIC)	Not configured
		FINAL STATES AND(LOGIC)	Not configured
		FRONT KEY	Not configured
Operation19	Not configured	INPUT	Not configured
		VIRTUAL OUTPUT	Not configured
		TIMEOUT	Not configured
		CHANNELS	Not configured
		INTERLOCK(LOGIC)	Not configured
		FINAL STATES AND(LOGIC)	Not configured
		FRONT KEY	Not configured
Operation20	Not configured	INPUT	Not configured
		VIRTUAL OUTPUT	Not configured
		TIMEOUT	Not configured
		CHANNELS	Not configured
		INTERLOCK(LOGIC)	Not configured
		FINAL STATES AND(LOGIC)	Not configured
		FRONT KEY	Not configured
Operation21	Not configured	INPUT	Not configured
		VIRTUAL OUTPUT	Not configured
		TIMEOUT	Not configured
		CHANNELS	Not configured
		INTERLOCK(LOGIC)	Not configured
		FINAL STATES AND(LOGIC)	Not configured
		FRONT KEY	Not configured
Operation22	Not configured	INPUT	Not configured
		VIRTUAL OUTPUT	Not configured
		TIMEOUT	Not configured
		CHANNELS	Not configured
		INTERLOCK(LOGIC)	Not configured
		FINAL STATES AND(LOGIC)	Not configured
		FRONT KEY	Not configured
Operation23	Not configured	INPUT	Not configured
		VIRTUAL OUTPUT	Not configured
		TIMEOUT	Not configured
		CHANNELS	Not configured
		INTERLOCK(LOGIC)	Not configured
		FINAL STATES AND(LOGIC)	Not configured
		FRONT KEY	Not configured
Operation24	Not configured	INPUT	Not configured
		VIRTUAL OUTPUT	Not configured
		TIMEOUT	Not configured
		CHANNELS	Not configured

SETPOINT>RELA	AY CONFIGURATION>CO	NTROL EVENTS		
EVENT	NAME	SOURCE	SIGNAL LOGIC	SOURCE LOGIC
EV1	Not Configured			
EV2	Not Configured			
EV3	Not Configured			
EV4	Not Configured			

EV5	Not Configured		
EV6	Not Configured		
EV7	Not Configured		
EV8	Not Configured		
EV9	Not Configured		
EV10	Not Configured		
EV11	Not Configured		
EV12	Not Configured		
EV13	Not Configured		
EV14	Not Configured		
EV15	Not Configured		
EV16	Not Configured		
EV17	Not Configured		
EV18	Not Configured		
EV19	Not Configured		
EV20	Not Configured		
EV21	Not Configured		
EV22	Not Configured		
EV23	Not Configured		
EV24	Not Configured		
EV25	Not Configured		
EV26	Not Configured		
EV27	Not Configured		
EV28	Not Configured		
EV29	Not Configured		
EV30	Not Configured		
EV31	Not Configured		
EV32	Not Configured		
EV33	Not Configured		
EV34	Not Configured		
EV35	Not Configured		
EV36	Not Configured		
EV37	Not Configured		
EV38	Not Configured		
EV39	Not Configured		
EV40	Not Configured		
EV41	Not Configured		
EV42	Not Configured		
EV43	Not Configured		
EV44	Not Configured		
EV45	Not Configured		
EV46	Not Configured		
EV47	Not Configured		
EV48	Not Configured		
EV49	Not Configured		
EV50	Not Configured		
EV51	Not Configured		
EV52	Not Configured		
EV53	Not Configured		
EV54	Not Configured		

EV55	Not Configured		
EV56	Not Configured		
EV57	Not Configured		
EV58	Not Configured		
EV59	Not Configured		
EV60	Not Configured		
EV61	Not Configured		
EV62	Not Configured		
EV63	Not Configured		
EV64	Not Configured		
EV65	Not Configured		
EV66	Not Configured		
EV67	Not Configured		
EV68	Not Configured		
EV69	Not Configured		
EV70	Not Configured		
EV71	Not Configured		
EV72	Not Configured		
EV73	Not Configured		
EV74	Not Configured		
EV75	Not Configured		
EV76	Not Configured		
EV77	Not Configured		
EV78	Not Configured		
EV79	Not Configured		
EV80	Not Configured		
EV81	Not Configured		
EV82	Not Configured		
EV83	Not Configured		
EV84	Not Configured		
EV85	Not Configured		
EV86	Not Configured		
EV87	Not Configured		
EV88	Not Configured		
EV89	Not Configured		
EV90	Not Configured		
EV91	Not Configured		
EV92	Not Configured		
EV93	Not Configured		
EV94	Not Configured		
EV95	Not Configured		
EV96	Not Configured		
EV97	Not Configured		
EV98	Not Configured		
EV99	Not Configured		
EV100	Not Configured		
EV101	Not Configured		
EV102	Not Configured		
EV103	Not Configured		
EV104	Not Configured		

EV105	Not Configured		
EV106	Not Configured		
EV107	Not Configured		
EV108	Not Configured		
EV109	Not Configured		
EV110	Not Configured		
EV111	Not Configured		
EV112	Not Configured		
EV113	Not Configured		
EV114	Not Configured		
EV115	Not Configured		
EV116	Not Configured		
EV117	Not Configured		
EV118	Not Configured		
EV119	Not Configured		
EV120	Not Configured		
EV121	Not Configured		
EV122	Not Configured		
EV123	Not Configured		
EV124	Not Configured		
EV125	Not Configured		
EV126	Not Configured		
EV127	Not Configured		
EV128	Not Configured		

SETPOINT>RELAY CONFIGURATION>SWITCHGEAR				
SWITCHGEAR	SETTING	VALUE/SOURCE	SIGNAL LOGIC	SOURCE LOGIC
	CONTACTS	52b		
	OPENING TIME	1000		
	CLOSING TIME	1000		
	CONTACT A SOURCE	N/A		
	SOURCE	CONT IP_F_CC1 (52b)(CC1)		
	OPEN TEXT	52 OPEN		
	ALARM	ΝΟ		
SWITCHGEAR 1	CLOSED TEXT	52 CLOSE		
	ALARM	NO		
	ERROR 00 TEXT	52 ERROR		
	ALARM	N/A		
	ERROR 11 TEXT	52 UNDEFINED		
	ALARM	N/A		
	OPENING INIT	OPERATION BIT 2		
	CLOSING INIT	OPERATION BIT 1		

SWITCHGEAR 2	CONTACTS	Not Configured	
	OPENING TIME	Not Configured	
	CLOSING TIME	Not Configured	
	CONTACT A SOURCE	Not Configured	
	CONTACT B SOURCE	Not Configured	
	OPEN TEXT	Not Configured	
	ALARM	Not Configured	
	CLOSED TEXT	Not Configured	
	ALARM	Not Configured	
	ERROR 00 TEXT	Not Configured	
	ALARM	Not Configured	
	ERROR 11 TEXT	Not Configured	
	ALARM	Not Configured	
	OPENING INIT	Not Configured	
	CLOSING INIT	Not Configured	
SWITCHGEAR 3	CONTACTS	Not Configured	
	OPENING TIME	Not Configured	
	CLOSING TIME	Not Configured	
		Not Configured	
		Not Configured	
	OPEN TEXT	Not Configured	
	ALARM	Not Configured	
	CLOSED TEXT	Not Configured	
	ALARM	Not Configured	
	FRROR 00 TEXT	Not Configured	
	ALARM	Not Configured	
	FRROR 11 TEXT	Not Configured	
	ALARM	Not Configured	
		Not Configured	
		Not Configured	
	CONTACTS	Not Configured	
		Not Configured	
		Not Configured	
	CONTACT A	Not Configured	
	SOURCE	Not Conligured	
	SOURCE	Not Configured	
	OPEN TEXT	Not Configured	
	ALARM	Not Configured	
	CLOSED TEXT	Not Configured	
	ALARM	Not Configured	
	ERROR 00 TEXT	Not Configured	
	ALARM	Not Configured	
	ERROR 11 TEXT	Not Configured	
	ALARM	Not Configured	
	OPENING INIT	Not Configured	
	CLOSING INIT	Not Configured	
# **B.1 FACTORY DEFAULT CONFIGURATION**

	CONTACTS	Not Configured	
	OPENING TIME	Not Configured	
	CLOSING TIME	Not Configured	
	CONTACT A SOURCE	Not Configured	
	CONTACT B SOURCE	Not Configured	
	OPEN TEXT	Not Configured	
	ALARM	Not Configured	
SWITCHGEAR 5	CLOSED TEXT	Not Configured	
	ALARM	Not Configured	
	ERROR 00 TEXT	Not Configured	
	ALARM	Not Configured	
	ERROR 11 TEXT	Not Configured	
	ALARM	Not Configured	
	OPENING INIT	Not Configured	
	CLOSING INIT	Not Configured	
	CONTACTS	Not Configured	
	OPENING TIME	Not Configured	
	CLOSING TIME	Not Configured	
	SOURCE	Not Configured	
	CONTACT B SOURCE	Not Configured	
	OPEN TEXT	Not Configured	
	ALARM	Not Configured	
SWITCHGEAR 6	CLOSED TEXT	Not Configured	
	ALARM	Not Configured	
	ERROR 00 TEXT	Not Configured	
	ALARM	Not Configured	
	ERROR 11 TEXT	Not Configured	
	ALARM	Not Configured	
	OPENING INIT	Not Configured	
	CLOSING INIT	Not Configured	
	CONTACTS	Not Configured	
	OPENING TIME	Not Configured	
	CLOSING TIME	Not Configured	
	SOURCE	Not Configured	
	CONTACT B SOURCE	Not Configured	
	OPEN TEXT	Not Configured	
	ALARM	Not Configured	
SWITCHGEAR 7	CLOSED TEXT	Not Configured	
	ALARM	Not Configured	
	ERROR 00 TEXT	Not Configured	
	ALARM	Not Configured	
	ERROR 11 TEXT	Not Contigured	
		Not Configured	
		Not Configured	
	CLOSING INIT	Not Configured	

	CONTACTS	Not Configured		
	OPENING TIME	Not Configured		
	CLOSING TIME	Not Configured		
	CONTACT A SOURCE	Not Configured		
	CONTACT B SOURCE	Not Configured		
	OPEN TEXT	Not Configured		
	ALARM	Not Configured		
SWITCHGEAR 8	CLOSED TEXT	Not Configured		
	ALARM	Not Configured		
	ERROR 00 TEXT	Not Configured		
	ALARM	Not Configured		
	ERROR 11 TEXT	Not Configured		
	ALARM	Not Configured		
	OPENING INIT	Not Configured		
	CLOSING INIT	Not Configured		
	CONTACTS	Not Configured		
	OPENING TIME	Not Configured		
	CLOSING TIME	Not Configured		
	CONTACT A SOURCE	Not Configured		
	CONTACT B SOURCE	Not Configured		
	OPEN TEXT	Not Configured		
	ALARM	Not Configured		
SWITCHGEAR 9	CLOSED TEXT	Not Configured		
	ALARM	Not Configured		
	ERROR 00 TEXT	Not Configured		
	ALARM	Not Configured		
	ERROR 11 TEXT	Not Configured		
	ALARM	Not Configured		
	OPENING INIT	Not Configured		
	CLOSING INIT	Not Configured		
	CONTACTS	Not Configured		
	OPENING TIME	Not Configured		
	CLOSING TIME	Not Configured		
	CONTACT A SOURCE	Not Configured		
	CONTACT B SOURCE	Not Configured		
	OPEN TEXT	Not Configured		
	ALARM	Not Configured		
SWITCHGEAR 10	CLOSED TEXT	Not Configured		
	ALARM	Not Configured		
	ERROR 00 TEXT	Not Configured		
	ALARM	Not Configured		
	ERROR 11 TEXT	Not Configured		
	ALARM	Not Configured		1
	OPENING INIT	Not Configured		1
	CLOSING INIT	Not Configured		1
			-	-

# **B.1 FACTORY DEFAULT CONFIGURATION**

	CONTACTS	Not Configured
	OPENING TIME	Not Configured
	CLOSING TIME	Not Configured
	CONTACT A SOURCE	Not Configured
	CONTACT B SOURCE	Not Configured
	OPEN TEXT	Not Configured
	ALARM	Not Configured
SWITCHGEAR 11	CLOSED TEXT	Not Configured
	ALARM	Not Configured
	ERROR 00 TEXT	Not Configured
	ALARM	Not Configured
	ERROR 11 TEXT	Not Configured
	ALARM	Not Configured
	OPENING INIT	Not Configured
	CLOSING INIT	Not Configured
	CONTACTS	Not Configured
	OPENING TIME	Not Configured
	CLOSING TIME	Not Configured
	CONTACT A SOURCE	Not Configured
	CONTACT B SOURCE	Not Configured
	OPEN TEXT	Not Configured
	ALARM	Not Configured
SWITCHGEAR 12	CLOSED TEXT	Not Configured
	ALARM	Not Configured
	ERROR 00 TEXT	Not Configured
	ALARM	Not Configured
	ERROR 11 TEXT	Not Configured
	ALARM	Not Configured
	OPENING INIT	Not Configured
	CLOSING INIT	Not Configured
	CONTACTS	Not Configured
	OPENING TIME	Not Configured
	CLOSING TIME	Not Configured
	SOURCE	Not Configured
	SOURCE	Not Configured
	OPEN TEXT	Not Configured
	ALARM	Not Configured
SWITCHGEAR 13	CLOSED TEXT	Not Configured
		Not Configured
	ERROR 00 TEXT	Not Configured
		Not Configured
	CLOSING INIT	Not Configured

F650 Digital Bay Controller

	CONTACTS	Not Configured	
	OPENING TIME	Not Configured	
	CLOSING TIME	Not Configured	
	CONTACT A SOURCE	Not Configured	
	CONTACT B SOURCE	Not Configured	
	OPEN TEXT	Not Configured	
	ALARM	Not Configured	
SWITCHGEAR 14	CLOSED TEXT	Not Configured	
	ALARM	Not Configured	
	ERROR 00 TEXT	Not Configured	
	ALARM	Not Configured	
	ERROR 11 TEXT	Not Configured	
	ALARM	Not Configured	
	OPENING INIT	Not Configured	
	CLOSING INIT	Not Configured	
	CONTACTS	Not Configured	
	OPENING TIME	Not Configured	
	CLOSING TIME	Not Configured	
	CONTACT A SOURCE	Not Configured	
	CONTACT B SOURCE	Not Configured	
	OPEN TEXT	Not Configured	
	ALARM	Not Configured	
SWITCHGEAR 15	CLOSED TEXT	Not Configured	
	ALARM	Not Configured	
	ERROR 00 TEXT	Not Configured	
	ALARM	Not Configured	
	ERROR 11 TEXT	Not Configured	
	ALARM	Not Configured	
	OPENING INIT	Not Configured	
	CLOSING INIT	Not Configured	
	CONTACTS	Not Configured	
	OPENING TIME	Not Configured	
	CLOSING TIME	Not Configured	
	CONTACT A SOURCE	Not Configured	
	CONTACT B SOURCE	Not Configured	
	OPEN TEXT	Not Configured	
	ALARM	Not Configured	
SWITCHGEAR 16	CLOSED TEXT	Not Configured	
	ALARM	Not Configured	
	ERROR 00 TEXT	Not Configured	
	ALARM	Not Configured	
	ERROR 11 TEXT	Not Configured	1
	ALARM	Not Configured	
	OPENING INIT	Not Configured	
	CLOSING INIT	Not Configured	

### C.1.1 F650 FIRMWARE REVISION HISTORY

FIRMWARE VERSION	BOOT PROGRAM VERSION	CHANGES DESCRIPTION	MODELS	DATE
1.00	2.00	First version of the product (Basic Model F1G0) Full protection scheme	F650BABF1G0HI	June 28 <sup>th</sup> 2002
1.11	2.00	New model F2G0 (inputs and outputs board type 2)	F650BABF2G0HI	October 14 <sup>th</sup> 2002
1.13	2.20	Snapshot Events included (New and All) Oscillography up to 4 records. Maximum 70 cycles at 64 samples per cycle, trip programmable via PLC. Broken Conductor protection function included. Boot program updated through F650PC program	ALL	December 20 <sup>th</sup> 2002
1.14	2.20	DNP 3.0 Level 2 protocol included, over TCP/IP and UDP/IP IRIG_B synchronization	ALL	January 22 <sup>nd</sup> 2003
1.20	2.25	Programmable Graphical display Calibration included to improve measurement accuracy	ALL	January 28 <sup>th</sup> 2003
1.30	2.25	Sensitive ground directional unit Isolated Ground directional unit (in 5 <sup>th</sup> current transformer) Energy measurements	ALL	March 31 <sup>st</sup> 2003
1.31	2.25	Enhancements in 60 Hz measurements Extended Settings Range in Negative Sequence Overcurrent function (46)	ALL	April 9 <sup>th</sup> 2003
1.33	2.30	Forward Power function (32FP) Demand	ALL	May 9 <sup>th</sup> 2003
1.44	2.30	51PL function included (besides existing 51PH) Control Events Alarms ModBus over TCP/IP	ALL	July 24 <sup>th</sup> 2003
1.48	2.30	Changes in 67 units in reverse mode ModBus TCP/IP enhancement	ALL	September 5 <sup>th</sup> 2003
1.50	2.30	PROTECTION   The following operation curves have been added to F650 functionality:   IEC Long-Time Inverse   IEC Short-Time Inverse   ANSI Extremely Inverse   ANSI Extremely Inverse   ANSI Normally Inverse   ANSI Moderately Inverse   ANSI Moderately Inverse   Rectifier Curve   User Curve A/B/C/D - Flex Curve™   Note: User Curves allow the user to program any non-standard curve type by selecting, point by point, the Operation time.   HARDWARE   Voltage Range:Voltage Metering Range expanded from (2 to 200 Volts) to (2 to 275V)   CIO Module: For those applications requiring a high number of inputs and outputs, F650 units can be connected to a CIO module (Remote CAN Bus I/O module) for using up to 2 additional boards.   COMMUNICATIONS   ModBus Protocol:   ModBus User Map   Virtual Inputs (control over internal logic variables, which can be used in the configurable logic).   DNP 3.0 Protocol   New Metering scale factors   Switchgear bits mapped to binary points   Possibility of restricting the binary points map by setting   USER INTERFACE	ALL	October 31 <sup>st</sup> 2003
		HMI Configurable Main Screen: The main screen offers the possibility to select the initial logo, a simplified Metering screen showing primary values, or both. Snapshot Events: Possibility of viewing snapshot events from the relay display in models without graphical display.		

С

FIRMWARE VERSION	BOOT PROGRAM VERSION	CHANGES DESCRIPTION	MODELS	DATE
1.61	2.35	COMMUNICATIONS Configuration: LED Reset by communications using the configurable logic METERING Monitoring of phasor measurements in module and argument REGISTER Snapshot Events: Possibility of reading the Snapshot events in Binary and ASCII format via ModBus Oscillography: The oscillography function has been improved to offer the possibility of creating up to a maximum of 20 oscillography records, with possibility to create concatenated oscillographies. Oscillography records can be obtained via communications using serial messaging (ModBus) or Ethernet (TCP/IP or TFTP). Fault Report: This version incorporates the tool to visualize and store the information from the last ten faults produced. This report can be shown on the relay display. The fault report will be available on the relay display and via communications, either on ModBus (serial) or TCP/IP. Data Logger: It allows registering 16 channels among all the available analog measures in the relay. The information provided by the data logger can be obtained via TCP/IP. <b>USER INTERFACE</b> Fault Report screen on HMI: Fault report information on display, selectable by setting <b>WEB SERVER</b> Web server tool has been upgraded to provide visualization of: Snapshot Events Control Events Alarms Oscillography Fault report Data Logger Metering	ALL	April 30 <sup>th</sup> 2004
1.62	2.35	Internal file management enhancement. IP Address maintenance after firmware upgrading. Latched Virtual Inputs maintenance after powering off and on the relay.	ALL	June 24 <sup>th</sup> 2004
1.70	2.35	Multilingual relay (French and English available)	F650BABF1G0HIF F650MFDF2G1LOF F650MFCF1G1LOF	August 5 <sup>th</sup> 2004

FIRMWARE VERSION	BOOT PROGRAM VERSION	CHANGES DESCRIPTION	MODELS	DATE
1.72	2.35	COMMUNICATIONS Multimaster DNP (3 masters)	ALL	November 26 <sup>th</sup> 2004
		METERING Measurement enhancement		
		PROTECTION Sensitive Directional Power unit is included (32)		
		<b>REGISTER</b> Snapshot Events: Possibility to be enabled and disabled by setting. In previous versions snapshot event generation was enabled by default and fixed for all elements. Using the "config file converter" tool the snapshot event settings will be included but to their default value (disabled), user must set the snapshot event generation to the desired value. Notice that having snapshot event to disabled no internal signals will be recorded in the snapshot event buffer.		
		USER INTERFACE		
		HMI Enhanced HMI meeting EnerVista 650 Setup structure. Multilingual Option available: The relay can be ordered in languages different from English, the relay always has English as default Languages Available now: French/English (F in ordering code request) English/English (former ordering code)		
		ENERVISTA 650 Setup Multilingual unit (French and English available). WEB SERVER Multilingual visualization of snapshot events, control events, oscillography fault recorder data logger, metering		
1.80	2.35	USER INTERFACE	ALL	March 1 <sup>st</sup>
		HMI: New languages available: Russian and Spanish. Russian/English (P in ordering code, basic display only) Spanish/English (S in ordering code)		2005
		ENERVISTA 650 Setup New languages available: Russian and Spanish. Passwords included in EnerVista 650 Setup (different from the HMI ones).		
		WEB SERVER Multilingual visualization of snapshot events, control events, oscillography, fault recorder, data logger, metering. New languages available: Russian and Spanish. Visualization Enhancement.		
		COMMUNICATIONS Modbus TCP communications enhacement. External CAN interruptions management enhancement.		
		METERING Decimal point included in PT and CT ratios. Power Factor measurement enhancement.		
		PROTECTION Function 48 included. I2/11 setting to select the minimum inhibition current level of the unit .		
		TOC operation level at 1.03 times the pickup (1.05 in previous releases). Neutral units measures management enhancement. Startup Enhancement.		
		REGISTER Time Stamp for switchgear control events enhancement.		

FIRMWARE VERSION	BOOT PROGRAM VERSION	CHANGES DESCRIPTION	MODELS	DATE
2.00	3.00	HARDWARE: New options for Real Serial Comm. Board 1: C: Cable remote CAN bus I/O M: RS485 + cable remote CAN bus I/O New options for Rear Ethernet Comm. Board 2: E: Redundant 10/100 Base TX New options for I/O Boards (available for slot G and CIO modules): 4: 32 digital inputs 5: 16 digital inputs	ALL	June 30th, 2005
		COMMUNICATIONS Protocol IEC 61850 GSSE Client/server implementation. SNTP Synchronization (Clock time obtained over an Ethernet network)		
1.82	4.00	File system management enhancement in boot code 4.00 Measurements enhancement in 1.82 firmware version	All models, excepting Options 4 and 5 for I/O boards. Option 6 for IEC 61850 protocol	October 17th 2005
2.20	4.00	USER INTERFACE ENERVISTA 650 Setup. - Data Logger visualization changes. - File name available in "Config file converter" tool. COMMUNICATIONS. - DNP Scale factor correction - DNP Scale factor correction - DAte and time synchronization available. - 980 ms delay correction. INPUTS/OUTPUTS. - Inputs Activation/Deactivation correction - Voltage threshold setting range from 20 to 230 Vdc - Debounce time settings: - Timestamp before debounce time - Setting range from 1 to 50 ms. METERING. - New measurements provided when using Delta connection and VN as auxiliary voltage input: - Neutral voltage available. - Phase to ground voltages available. - Single phase power measurements available. PROTECTION. - Neutral, ground and sensitive ground directional units available with delta connection and VN as auxiliary voltage input. - Minor changes in Forward Power elements. REGISTER. - Ground current available in Fault report. - Corrected 150 ms delay in Snapshot events measurements.	All models, excepting Options 4 and 5 for I/O boards. Option 6 for IEC 61850 protocol	November 25th 2005

#### **C.1.2 GE MULTILIN WARRANTY**

### **GE MULTILIN RELAY WARRANTY**

GE Power Management, S.A. (GE Multilin) warrants each relay it manufactures to be free from defects in material and workmanship under normal use and service for a period of 24 months from date of shipment from factory.

In the event of a failure covered by warranty, GE Multilin will undertake to repair or replace the relay providing the warrantor determined that it is defective and it is returned with all transportation charges prepaid to an authorized service center or the factory. Repairs or replacement under warranty will be made without charge.

Warranty shall not apply to any relay, which has been subject to misuse, negligence, accident, incorrect installation, or use not in accordance with instructions nor any unit that has been altered outside a GE Multilin authorized factory outlet.

GE Multilin is not liable for special, indirect or consequential damages or for loss of profit or for expenses sustained as a result of a relay malfunction, incorrect application or adjustment.

For complete text of Warranty (including limitations and disclaimers), refer to GE Multilin Standard Conditions of Sale.