


<1> Bit 10 must be set in the first PZD word of the telegram received from the serial interface in order that the drive accepts the process data.

<2> PROFIdrive interconnection:
For PROFIdrive standard telegrams, the upper inputs are connected with PROFIdrive-STW1 [2420]. Only involves CDS0.

<3> When the master control is retrieved, entered from STARTER or AOP30.

<4> Cannot be enabled with jog.

<5> AOP30 only for SINAMICS GM150 and SINAMICS GL150.

<6> Also control word from commissioning software (drive control panel).

<7> With „OFF in REMOTE“ OFF1, OFF2 and OFF3 are in REMOTE mode, too.