

<1> The master system requests process data.

<2> If „Safe Brake Control" (SBC) is activated and selected, the brake is no longer controlled via this signal.

<3> These signals are only relevant if the "extended brake control" function module is active (r0108.14 = 1).