

<1> In order to maintain the PROFIdrive profile, send word 1 must be used as status word 1 (ZSW1), not as DWORD.

<2> Each PZD word can be assigned one word or double word. Only one of the 2 interconnection parameters p2051 or p2061 can have the value ≠ 0 for a PZD word.

<3> Physical word and double word values are inserted in the telegram as referenced variables. p200x apply as reference variables (telegram contents = 4000 hex or 4000 0000 hex in the case of double words if the input variable has the value p200x).
For temperatures, the following applies: 100 degrees Celsius corresponds to 100 % = 4000 hex or 4000 0000 hex, and 0 degrees Celsius corresponds to 0%.
For the electrical angle, the following applies: 90 degrees corresponds to 100 % = 4000 hex or 4000 0000 hex, and 0 degrees corresponds to 0 %.