



PRODUCT SPECIFICATION SHEET
I T C
15kV 200A Loadbreak Elbow Probe
166LRF


The **166LRF** loadbreak elbow probe is designed to be used with all the 15 kV class loadbreak elbow, such as 165/166LR, 167/168ELR, 167/168RLR and 168FLR.


DESCRIPTION
ELASTIMOLD PART NUMBER
25kV 200A Loadbreak Elbow Probe
274LRF


The **274LRF** loadbreak elbow probe is designed to be used with all the 25 kV class loadbreak elbow, such as 275/276LR, 273/274ELR, 273/274RLR and 274FLR.

DESCRIPTION

35kV 200A Loadbreak Elbow Probe

ELASTIMOLD PART NUMBER

376LRF

The **376LRF** loadbreak elbow probe is designed to be used with all the 35 kV class loadbreak elbow, such as 375/376LR.