

INSTRUCTIONS

KINATROL[®]

speed variator

EXCITER

WITH

S-4 REGULATOR

These instructions do not purport to cover all details or variations in equipment nor to provide for every possible contingency to be met in connection with installation, operation or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the General Electric Company.

DIRECT CURRENT MOTOR AND GENERATOR DEPARTMENT

GENERAL  ELECTRIC

INDEX

TITLE PAGE	
KINATROL DRIVES	GEI-95582
KINATROL INSTRUCTIONS	GEH-3255
SIGNAL AMPLIFIER	GEI-95508A
CARD DIAGRAM	36C759762DA
FUNCTION DIAGRAM	36C759856CA
LINEAR TIME	GEI-95509A
CARD DIAGRAM	36C759882DA
FUNCTION DIAGRAM	36C759857CA
TORQUE LIMIT	GEI-95510A
CARD DIAGRAM	36C759883DA
FUNCTION DIAGRAM	36C759858CA
POWER AMPLIFIER	GEI-95518D
CARD DIAGRAM	36C760031FC 36C761079BB
FUNCTION DIAGRAM	36C761080AA
MAINTENANCE KIT	36C759321

REVISED SEPT. 3, 1969