



Basic Operator Panel BOP-2



1	2	3	4	5	6	7	8
External Interfaces					2400_BOP.vsd	Function diagram	- 2400 -
Basic Operator Panel (BOP-2)					16.08.2006 V2.1	MICROMASTER 430	