




1	2	3	4	5	6	7	8
DO: SERVO					fp_1630_01_eng.vsd	Function diagram	
Overviews - Servo control, current control					30.03.07 V02.05.00	SINAMICS S	
					- 1630 -		