

Bit no.	Sequencer status word	Seq ZSW r6222
00	1 = Converter cooling ON	r6222.0
01	1 = Output isolating switch ON	r6222.1
02	1 = Power circuit excitation ON	r6222.2
03	1 = Output transformer de-magnetization ON	r6222.3
07	1 = Motor sequencer active	r6222.7
08	1 = Input-side circuit-breaker ON	r6222.8
09	1 = Output-side circuit-breaker ON	r6222.9
10	1 = Converter in operation	r6222.10
11	1 = Line-side converter displacement angle specification	r6222.11
14	1 = Stop active	r6222.14
15	1 = Quick stop active	r6222.15
16	1 = Switch off circuit breaker active	r6222.16
24	1 = New alarm detected	r6222.24
25	1 = Fault with stop reaction OFF 1 present	r6222.25
26	1 = Fault with stop reaction OFF 2 present	r6222.26
27	1 = Fault with stop reaction OFF 3 present	r6222.27