

5VKBR SPARE PARTS LIST

DESCRIPTION	PART NUMBER
Operating Mechanism (less coils and motor)	163770-T09
Trip Coil 48VDC	708393-T06
Trip Coil 125VDC	708393-T07
Trip Coil 250VDC	708393-T08
Control Device 48VDC	708392-T06
Control Device 125VDC	708392-T07
Control Device 250VDC	708392-T08
Control Device 120VAC	163747-T01
Control Device 240VAC	163747-T02
Resistor Assembly 120VAC	163747-T13
Resistor Assembly 240VAC	163747-T14
Charging Motor 48VDC	709799-T03
Charging Motor 125VDC & 120VAC	709799-T01
Charging Motor 250VDC & 240VAC	709799-T02
Motor Disconnect Switch	715668-A00
Lead Assembly 1200A	148187-T01
2000A	148187-T02
Pushrod (1200 or 2000A)	166106-K01
Manual Charging Handle	166500-T10