



INSTALLATION • OPERATION • MAINTENANCE I N S T R U C T I O N S

TYPE AR HIGH SPEED AUXILIARY RELAY FOR CLASS 1E APPLICATIONS

CAUTION: Before putting protective relays into service, remove all blocking which may have been inserted for the purpose of securing the parts during shipment. Make sure that all moving parts operate freely. Inspect the contacts to see that they are clean and can close properly. Operate the relay to check the settings and electrical connections.

APPLICATION

- These relays have been specially designed and
- tested to establish their suitability for Class 1E applications. Materials have been selected and tested to insure that the relays will perform their intended function for their design life when operated in a normal environment as defined by ANSI standard C37.90-1978 when exposed to radiation levels up to 10^4 rads, and when subjected to seismic events producing a Shock Response Spectrum of 8g ZPA as defined in IEEE Standard C37.98-1978 for multifrequency broad-band standard response spectrum shape.

"Class 1E" is the safety classification of the electric equipment and systems in nuclear power generating stations that are essential to emergency shutdown of the reactor, containment isolation, cooling of the reactor, and heat removal from the containment and reactor, or otherwise are essential in preventing significant release of radioactive material to the environment.

The AR relay is a four-pole auxiliary type relay, especially designed for ultra high speed circuit breaker tripping duty in protective relaying systems. The AR relay is well suited for bus arrangements where more than one breaker must be tripped. It can provide isolation as well as high

speed tripping. The AR relay may also be applied to provide isolation of primary and back-up relaying, and provide high speed tripping for zone one faults.

However, when the AR relay is energized by the thyristor trip circuit of the SDG, SKD, SRU, SBFU, STU-91, or STU-92 relays, a 22 ohm resistor or its equivalent must be added in parallel with the AR coil. Without this resistor, it is possible that when dc voltage is suddenly applied to the relay, sufficient current will flow through the series R-C circuit paralleling the tripping thyristor to cause the 10-watt AR relay to pickup.

CONSTRUCTION AND OPERATION


AR UNIT

The relay consists of four stationary contact screws, four leaf spring moving contacts, a moving armature and card assembly, which operates the moving contacts; a U shaped laminated core, a coil, a frame, a molded insulation block and usually a series resistor. Refer to Fig. 1 and 2.

The armature and card assembly slip over a hinge pin which is inserted in the laminations. The moving and stationary contacts are mounted on the molded insulating block. The molded block and the coil and lamination assembly are mounted to the frame. All contacts are fine silver.


When the coil and resistor are energized, the armature is attracted to the laminations. The card moves with the armature thereby operating the moving contacts. The tension of the moving contacts is the resetting force.

All possible contingencies which may arise during installation, operation, or maintenance, and all details and variations of this equipment do not purport to be covered by these instructions. If further information is desired by purchaser regarding his particular installation, operation or maintenance of his equipment, the local Westinghouse Electric Corporation representative should be contacted.



- 1 - NORMALLY CLOSED STATIONARY CONTACT SCREWS.
- 2 - NORMALLY OPEN STATIONARY CONTACT SCREWS.
- 3 - MOVING CONTACT AND LEAF SPRING ASSEMBLY
- 4 - MOVING CARD ASSEMBLY (CARD)
- 5 - RELAY COIL
- 6 - MOLDED INSULATION BLOCK
- 7 - BEFORE CHECKING THE NORMALLY CLOSED CONTACT PRESSURE, THERE SHOULD BE A GAP BETWEEN THE MOVING CONTACT SPRING AND THE CARD.
- 8 - INTERNAL SERIES RESISTOR

Fig. 1. Type AR Unit



- 1 - NORMALLY CLOSED STATIONARY CONTACT SCREWS.
- 2 - NORMALLY OPEN STATIONARY CONTACT SCREWS.
- 3 - MOVING ARMATURE.
- 4 - U-SHAPED LAMINATED CORE.
- 5 - ARMATURE GAP ADJUSTMENT SET SCREW.
- 6 - ARMATURE GAP.
- 7 - BEFORE CHECKING THE NORMALLY CLOSED CONTACT PRESSURE, THERE SHOULD BE A GAP BETWEEN THE MOVING CONTACT SPRING AND THE CARD.
- 8 - INTERNAL SERIES RESISTOR.

Fig. 2. Type AR Unit

TABLE I -- OPERATING DATA

Coil Circuit Volts	Coil Circuit DC Ohms 25°C		Typical Time (Milliseconds)			Operating Volts	
			Pickup (Operate)		Dropout* (Reset)	Must Pickup	Must Dropout
dc	Coil	Series Resistor	N.O. Contact Closes	N.C. Contact Opens	N.C. Contact Closes		
24	4	50	< 3	1.5	< 4	19	2.4
48	14	200	< 3	1.5	< 4	38	4.8
125	100	1500	< 3	1.5	< 4	100	12.5
250	170	6000	< 3	1.5	< 4	200	25.0
62.5	1080	None	5	—	—	50	—

*Without Coil Suppression

**TABLE II -- CONTACT RATING
OF THE NORMALLY OPEN CONTACTS**

Contact Circuit Volts dc	Interrupting Rating (Amperes)				Carry Rating (Amperes)
	Resistive		Inductive†		Continuous
	Single	Double	Single	Double	
48	3.750	20.	1.750	20.	3
125	0.500	1.7	0.350	1.20	3
250	0.250	0.5	0.150	0.250	3

- ✱ †L/R = .005 for I > 1 ampere
L/R = .040 for I < 1 ampere

High speed operation is obtained by the inertia of the moving parts, a sensitive electromagnet, and the low L/R ratio of the operating circuit.

CHARACTERISTIC

The AR unit used in the ultra high speed, 2 millisecond operate time relay has a sensitivity of 0.5 watts. By the proper combination of the AR unit and a large series resistor, an optimum speed of 2 milliseconds is obtained for an energy input of 10 watts.

All relays are capable of being energized continuously. All relays will pickup when 80% of rated voltage is applied to the coil circuit, and will drop out if the voltage is reduced to 10% of rated voltage.

Tables I, II, and III give the following typical and/or test values.

Table I — Operating data — coil ohms-series resistor ohms

Table II — Contact ratings

Table III — Contact bounce

**TABLE III
CONTACT BOUNCE**

Contact Loading	Typical Effective Bounce Time In Milliseconds	
	Normally Open	Normally Closed
Dry Circuit	2-4	6-8
10 Watts (one AR relay)	1.0	—
Breaker Trip Coil	0.2	—

CONTACT RATING

Each relay contact is rated 3 amps continuous and will make and carry 30 amps long enough to trip a breaker.

Material transfer will be minimized and contact life extended, if positive polarity is connected to the moving contact.

SETTINGS

AR UNIT

No settings are required.

ICS UNIT

No settings are required.

INSTALLATION

The relays should be mounted on switchboard panels or their equivalent in a location free from dirt, moisture, excessive vibration and heat. Mount the relay vertically by means of the four mounting holes on the flange for the semi-flush type FT case. The mounting screws may be utiliz-

ed for grounding the relay. External toothed washers are provided for use in the locations shown on the outline and drilling plan to facilitate making a good electrical connection between the relay case, its mounting screws and the relay panel. Ground Wires are affixed to the mounting screws as required for poorly grounded or insulating panels. Other electrical connections may be made directly to the terminals by means of screws for steel panel mounting.

For detail information on the FT case refer to I.L. 41-076 for semi-flush mounting.

ADJUSTMENTS AND MAINTENANCE

The proper adjustments to insure correct operation of this relay have been made at the factory and should not require readjustment after receipt by the customer. The routine test following is recommended for new equipment and prior to readjustment or recalibration. If the adjustments have been changed or the relay taken apart for repairs, the calibrations instructions should be followed.

ROUTINE TEST

The following checks are recommended to insure that the relay is in proper working order:

1. Armature gap

The armature gap should be approximately .009 inches measured at the narrowest part of the armature gap.

2. Visual inspection

For relays having normally closed contacts, the contact spring should not be touching the card.

3. Contact gaps and forces

All gram measurements should be made at the end of the moving contact spring per table IV.

★ **TABLE IV**

Contact arrangement	With Relay De-energized			With relay energized	
	N.O. contact gap INCHES	N.C. contact force GRAMS	Force to move the N.O. contact spring away from the card	N.C. contact gap INCHES	N.O. contact force GRAMS
4 N.O.	.018 Min.	—	4 Grams ± 1	—	15-40
3 N.O.-1N.C.	.018 Min.	15 min.	6 Grams ± 1	.013 Min.	15-40
2 N.O.-2N.C.	.018 Min.	15 min.	*8-11 Grams	.013 Min.	15-40

*For this check to be made accurately, back out the N.C. stationary contact screw. This will disturb the factory calibration and therefore it is recommended this check not be made on a relay which passes all other checks.

4. Contact operate and reset timers

Check values in Table I that have tolerances.

CALIBRATION

Use the following procedure for calibrating the relay if the relay has been taken apart for repairs or the adjustments disturbed. This procedure should not be used until it is apparent that the relay is not in proper working order. (See "Routine Test").

- Adjust the set screw at the rear of the top of the frame to obtain a 0.009-inch gap at the rear end of the armature air gap.
- Adjust each contact spring to obtain 4 grams pressure at the very end of the spring. This reading is taken when the pressure is sufficient to move the spring away from the edge of the slot of the card.

On the two normally open, two normally closed contact relay, adjust each normally open contact spring of 8 grams to just move the contact spring away from the card. Adjust the normally closed contacts for 15 grams spring pressure, to just move the contact spring away from the card (See Fig. 1 and 2). Then adjust the normal-

ly closed stationary contact to just move the contact spring away from the card.

On the three normally open, one normally closed contact relay, adjust each normally open contact spring for 6 grams to just move the contact spring away from the card. Adjust the normally closed contact for 15 grams spring pressure, to just move the contact spring away from the card (See Fig. 1 & 2). Then adjust the normally closed stationary contact to just move the contact spring away from the card.

- Adjust each normally open stationary contact screw to obtain a contact gap of 0.020 to 0.022 inches. Energize the relay and the normally open contacts should have 15 to 30 grams contact follow. The normally closed contact, if any, should have a contact gap of .015 inches.

When calibrated as outlined above, the relay should meet the characteristics of Tables I and III.

MAINTENANCE

For worst case operating conditions; 30 amps resistive, contact make duty; the contact should be inspected each year or 50 operations and replaced every two years or 100 operations.

RENEWAL PARTS

Repair work can be done most satisfactorily at the factory. However, interchangeable parts can be furnished to the customers who are equipped for doing repair work. When ordering parts, always give the complete nameplate data.




Fig. 3. Internal schematic of the Type AR Relay in front connected molded case with 4 make contacts.




Fig. 4. Internal schematic of the Type AR Relay in front connected molded case with 2 make and 2 break contacts.




Fig. 5. Internal schematic of the Type AR Relay in semi-flush FT-11 case with 4 make contacts and without internal series resistor.




Fig. 6. AR Relay, FT-11, with 2 ICS units (4M)




Fig. 7. AR Relay, FT-11 Case (2M-2B)




Fig. 8. AR Relay FT-11 (4M)




Fig. 9. Internal schematic of the Type AR Relay in semi-flush FT-22 case double unit, with 8 make contacts.




Fig. 10. Internal schematic of the type AR Relay in semi-flush FT-22 case double unit with 8 make contacts and without internal series resistor.




Fig. 11. Internal schematic of the type AR Relay in semi-flush FT-22 case, double unit, with 6 make and 2 break contacts.




Fig. 12. Internal schematic of the type AR Relay in semi-flush FT-22 case, double unit, with 5 make and 3 break contacts.




Fig. 13. Internal schematic of the type AR Relay in semi-flush FT-22 case, double unit, with 4 make and 4 break contacts.





Fig. 14. Outline and drilling plan for type AR Relay in the front connected molded case



OUTLINE AND DRILLING FOR RELAY CASE TYPE FT-11 FOR CLASS I-E APPLICATION



Sub. 1
(3519A65)

Fig. 15. Outline and drilling plan for Type AR Relay in semi-flush FT-11 case.

FOR CLASS I-E APPLICATION



Sub. 1
(3519A67)

Fig. 16. Outline and drilling plan for Type AR Relay in semi-flush FT-22 case